Design Project 3: Implementing the Simple Computer on the DEO Nano Board Validation Sheet – Page 1, Instructions

The validation sheet is provided as an example of how the GTA will test your implementation. You do not have to go the CEL to have your implementation validated in person.

No <u>GTA</u> or <u>student</u> should discuss any aspect of a student's design with another student. Among other things, this includes the manner in which a student implements specific operations.

Student Name :			
Last four digits of your student ID:			
Optional instruction implemented:	Yes	No	

Validation Instructions

For the DIP switch settings, SW[3:1] values from 000 to 101 select registers RO-R5, with SW[0] selecting between the most significant byte (SW[0]=1) and the least significant byte (SW[0]=0) being displayed on the LEDs. The PC register is displayed for SW[3:1]=110.

- 1. Program the FPGA on the DEO Nano board using the Start button on the programmer window.
- 2. When the programming has successfully completed, reset the design by pressing and holding KEYO, and while keeping KEYO pressed, pressing and releasing the KEY1 pushbutton.
- 3. Set the DIP switches to "1100" to show the program counter (PC). Press and release KEY1 two times. The LEDs should read 0x02.
- 4. Set the DIP switches SW[3:1] to "001", and then use SW[0] to record the 16-bit value for R1 in Table 1 (next page) as four digit hex.
- 5. Compare the four digits from step 4 to the last four digits of the student's ID number. If the four digits do not match the last four digits of the student's ID number, STOP THE VALIDATION. DO NOT CONTINUE.
- 6. Press and release KEY1 (PC = 0x03). Set the SW[3:1] for R4, and record the 16-bit value for R4 as four digit hex in Table 1.
- 7. Press and release KEY1 (PC = 0x04). Set the SW[3:1] for R2, and record the 16-bit value for R2 as four digit hex in Table 1.
- 8. Press and release KEY1 (PC = 0x05). Set the SW[3:1] for R3, and record the 16-bit value for R4 as four digit hex in Table 1.
- 9. Press and release KEY1 (PC = 0x06). Set the SW[3:1] for R4, and record the 16-bit value for R3 as four digit hex in Table 1.
- 10. Press and release KEY1. Set the SW[3:1] for R5, and record the 16-bit value for R4 as four digit hex in Table 1.
- 11. Press and release KEY1. Set the SW[3:1] for R5, and record the 16-bit value for R5 as four digit hex in Table 1.
- 12. If the student has implemented the optional instruction: Press and release KEY1. Set the SW[3:1] for RO and then the PC, and record the 16-bit values for RO and the PC register as four digit hex in Table 1.

Design Project 3: Implementing the Simple Computer on the DEO Nano Board Validation Sheet – Page 2, Results

Table 1: Checking the operation of the CPU.

All values of the registers should be recorded as four digit hexadecimal numbers, two digits for the most significant byte of the register and two digits for the least significant byte.

DIP switch settings SW[3:1]

- Values from 000 to 101 select Registers RO R5.
- The PC register is displayed for SW[3:1] = 110.
- SW[0] selects between the most significant byte (SW[0]=1) and the least significant byte (SW[0]=0) being displayed on the LEDs.

Step number	PC Value	Register	SW[3:1] setting	SW[0]=1	SW[0]=0
4	0x02	R1	001		
6	OxO3	R4	100		
7	OxO4	R2	010		
8	0x05	R3	100		
9	0x06	R4	011		
10	OxO7	R5	100		
11	0x08	R5	101		
12 (optional)	OxO9	RO	000		
12 (optional)	OxO9	PC	110		

Comments (only required if something is unusual or wrong):