The Batch Interface

This is an advanced feature, if you are just using Libmsr for power monitoring/limiting or performance monitoring, you probably don't need to know this.

When using Libmsr you may need to access a large custom list of MSRs. Doing this with the traditional pread/pwrite method has a lot of overhead for anything over 2 MSRs. Therefore, we have created an optimized way to access a list of MSRs.

Note: Use of this feature is subject to change (it will probably become easier).

Using a Batch

- 1. Create an array of references to the raw data using uint64_t
- 2. Allocate memory for the batch using specify_batch_size and give it the batch number and a size
- 3. Load the array of references for your batch using load_core_batch. Pass in the MSR the array will have data for, the array, and the batch number.

```
Creating a Single MSR Batch
uint64_t ** val = (uint64_t **) malloc(num_cores() * sizeof(uint64_t *)); // Each pointer in this array will reference the data from a batch
allocate_batch(USR_BATCHO, num_cores()); // This will allocate the space for a batch
load_core_batch(0x19C, val, USR_BATCHO); // This will set all the pointers in the array val to reference the data for accessing msr 0x19C
```

```
Creating a Multiple MSR Batch
uint64_t ** val1 = (uint64_t **) malloc(num_devs() * sizeof(uint64_t *));
uint64_t ** val2 = (uint64_t **) malloc(num_devs() * sizeof(uint64_t *));
uint64_t ** val3 = (uint64_t **) malloc(num_devs() * sizeof(uint64_t *));
specify_batch_size(USR_BATCH4, 3 * num_devs());
load_thread_batch(0x309, val1, USR_BATCH4); // Add MSR 0x309 to the usr batch and have the val1 array reference the data
load_thread_batch(0x30A, val2, USR_BATCH4); // Add MSR 0x30A to the usr batch and have the val2 array reference the data
load_thread_batch(0x30B, val3, USR_BATCH4); // Add MSR 0x30B to the usr batch and have the val3 array reference the data
```

```
Reading and Writing with a Batch
// To read a batch and access its data
read_batch(USR_BATCH0); // Based on USR_BATCH0 in 'Creating a Single MSR Batch'
int i;
for (i = 0; i < num_cores(); i++)
{
    fprintf(stdout, "Data for MSR %x is %lx\n", 0x19C, *val[i]);
}

// To assign data to a batch and write
for (i = 0; i < num_devs(); i++)
{
    vall[i] = 1;
    val2[i] = 2;
    val3[i] = 3;
}

write_batch(USR_BATCH4); // Based on USR_BATCH4 in 'Creating a Multiple MSR Batch'</pre>
```

Deleting a Batch



free_batch(USR_BATCH0);

Related articles



The Batch Interface
RAPL
General LIBMSR Use

