AMS00x OpenMV GPIO0/I2C_SDA GPIO1/I2C_SCL UIN **↑** GPIO2/USER_TX/SPI_SLAVE_MOSI/ADC GPIO3/USER_RTS/SPI_SLAVE_MISO/ADC GPIO4/USER_CTS/SPI_SLAVE_CLK GPIO5/USER_RX/SPI_SLAVE_CS RESET PROG_TX PROG_RX GPIO6/SPI_MASTER_MOSI/FACTORY_RST GPIO8/SPI_MASTER_MISO GPIO9/SPI_MASTER_CLK SWC SWD RESET BOOT GPIO12/SPI MASTER CS/ADC GPIO10/ADC/PWM GPIO11/ADC_PWM TXD/SCL RXD/SDA GPIO14/ADC/PWM/XOSC32_IN GPIO13/ADC/PWM/XOSC32_OUT GPIO7/RSVD GND GNDGNDGND OSHN @penMV TITLE: ble Copyright (c) 2013 Ibrahim Abd Elkader <i.abdalkader@gmail.com>
This work is licensed under the Creative Commons Attribution—ShareAlike 3.0 License.
To view a copy of this license, visit http://creativecommons.org/licenses/by-sa/3.0/ Document Number: REV: 2

Date: 10/7/15 6:20 PM

Sheet: 1/1