# 目视停靠引导系统飞行员指南 Pilot instructions for Visual Docking Guidance System

#### 20.系统崩溃

### SYSTEM BREAKDOWN

In case of a severe system failure, the display will go black, except for a red stop indicator. A manual backup procedure must be used for docking quidance.



如果遇到严重的系统故障,显示器将变黑,并显示红色的停止信息。这时必须提供人工引导。

如果遇到电力中断,显示器将完全变黑。这时必须提供人工引导。

# 21.电源失效

# **POWER FAILURE**

In case of a power failure, the display will be completely black. A manual backup procedure must be used for docking guidance.



Note: Use for the DGS of Gates 204-224.