目视停靠引导系统飞行员指南 Pilot instructions for Visual Docking Guidance System

20.系统崩溃

SYSTEM BREAKDOWN

In case of a severe system failure, the display will be completely black. A manual backup procedure must be used for docking guidance. 如果遇到严重的系统故障,显示器将完全变黑。这时必须提供人工引导。



21.电源失效

POWER FAILURE

In case of a power failure, the display will be completely black. A manual backup procedure must be used for docking guidance. 如果遇到电力中断,显示器将完全变黑。这时必须提供人工引导。



Note: Use for the DGS of Gate 112.