## A380航空器运行规则 Operational Rules for A380

- 4. 在部分滑行道有A380正在运行时, 相邻滑行道有航空器的翼展限制。
- 4. When A380 taxiing on TWYs, other contiguous TWYs have wingspan limits for aircrafts.

运行A380的滑行道	受限制的滑行道	航空器翼展限制
TWYs for A380 taxiing	Contiguous TWYs on limit	Wingspan limits for A/C
Z3 (BTN F2 & Z2)	F (BTN F2 & Z2)	65m
Z3 (BTN M4 & M5)	Z18	65m
M7	Z2 (BTN Z3 & Z8)	65m
F (BTN F2 & Z2)	Z3 (BTN F2 & Z2)	65m
Y2	Y1 (south of T1)	45m
Y1 (south of T1)	Y2	45m

- 5. A380 转弯滑行限制:
- 5.1 禁止A380由A0或A1滑行道直接转向G滑行道;
- 5.2 禁止A380由A0或A1滑行道直接转向F滑行道;
- 5.3 A380在F滑行道上南向北滑行时,禁止转向M4 5.3 When A380 taxiing from south to north on 滑行道。
- 5. Rule for A380 taxi-turning:
- 5.1 A380 turning to TWY G from TWY A0(or A1) directly is forbidden;
- 5.2 A380 turning to TWY F from TWY A0(or A1) directly is forbidden;
  - TWY F, turning to TWY M4 is forbidden.

Changes: Nil.