

Pump P201 Operation Manual

Equipment: Pump P201

Purpose: Transfers cooling water.

Pressure: 6-8 bar

Temperature: 20-45 C

Flow: 120 L/min

Startup: Verify power, open inlet valve, start motor, monitor vibration.

Safety: Wear PPE. Never run dry.