Supermodel Edition

Model:Cycles | Features and shortcut guide

This build includes the features below. For button combinations, hold the first button and then press the next button or turn the named knob. TRIG means a step key; pad means a track key; DATA means the LEVEL/DATA encoder.

Machines and sound Stock engines plus Sample Wizard, SD Vintage, Clap Vintage, SY Toy, SY Bits, Swarm LITE, MACRO, ACID, WAVE, TINY, ChpHzrd / Retrosyn and MIDI Out. Syntakt-derived engines use the supplied Syntakt OS file.	**Performance and sequencing** Arpeggiator, Octave 0 held-note mode, ChordKeys, Sequence Genie, SCRAMBLE, slide trigs, trig preview, easier trig removal, dimmed trigless trigs, latching mute and solo.
Sound shaping Synth Attack, per-track filter and envelope, filter/resonance/attack LFO destinations, second audio LFO, MACRO fine tune and Lo-Fi, Sample Wizard preview/slicing, and numeric volume/pan display.	**Routing and workflow** MIDI Out machine with sequenced notes, assignable CCs and locks; MIDI OUT/THRU toggle; six-channel or stereo USB audio; permanent quick save; Supermodel startup; long-name scrolling and multiline sample browser.

Track, step and performance controls

Feature	Controls	What it does
Step Recorder	Playback stopped: press REC twice; PLAY advances; STOP goes back; press REC again to exit	Enter step recording and play notes to write successive steps. PLAY advances one step; STOP moves back one step; press REC again to leave Step Recorder.
Latching mute	TRACK + tap FUNC	First choose Mute: Latch in Mod Setup. Then latch mute mode with this gesture; tap FUNC again to leave. Mute: Stk keeps stock behavior (default).
Solo in mute mode	In latching mute mode, hold FUNC + press T1-T6	Solo that track. Press the soloed track again to restore the previous mute state; tracks already muted remain muted.
Silent track selection	Choose Silent in Mod Setup ; tap T1-T6	Select a track without triggering its sound. TRACK + pad selects and plays. Stock pad behavior (Stk) is the default; select Silent to enable silent selection.
Trig preview	Hold TRIG + PAGE	Audition the selected step with its note and locks while stopped or paused.
Slide trig	SETTINGS + TRIG	Toggle a parameter slide on the step.
Sequence Genie	SETTINGS + PAGE	Open the generator for the selected track. Select with DATA; choose Generate or Queue and set Loop/Page timing.
SCRAMBLE	Quick tap SETTINGS + TRACK	On release, randomize supported synthesis parameters for the selected track. SCRAMBLE is able to be parameter-locked to steps in the sequencer.
Control All setup	TRACK + TRIG 1-6	Include or exclude audio tracks from Control All changes.
Audio beat repeat	Hold TRACK + RETRIG , then hold a TRIG 1-16	The held step selects a repeat division for included audio tracks. Release a modifier or division pad to stop.
Control All filter	Hold TRACK + MACHINES ; turn SWEEP / CONTOUR	Adjust cutoff/resonance across included audio tracks. Without TRACK, adjust the selected track.
Synth Attack	MACHINES + DECAY	Adjust the added attack control on supported machines.
Arpeggiator / ChordKeys settings	FUNC + RETRIG	Open the settings for the active Arpeggiator or ChordKeys feature. Arpeggiator octave 0 cycles only through held notes.
ChordKeys	Select the Chord machine, then play TRIG 1-16	Play scale-based chord voicings from the step keys. To leave a ChordKeys track you must use TRACK + Track Pad.
ChordKeys harmony locks	Grid record: hold a step TRIG and press T1-T6 . Live record: play a chord and use the harmony pads.	Record the chosen harmony on the step. Press the same harmony pad again on a held grid step to restore its base harmony. Harmony locks save with the pattern independently of LFO 2.

LFO, samples and setup

Feature and shortcut reference (continued)

LFO and MACRO controls

Feature	Controls	What it does
Second audio LFO	Press LFO twice	Open LFO 2 and edit its speed, shape, destination and depth.
LFO quick assignment	On an LFO page, hold LFO and turn a destination knob	Assign the corresponding ordinary knob destination. To select the added Attack, Filter or Resonance targets, also hold MACHINES .
Attack / Filter / Resonance LFO targets	On an LFO page, hold LFO + MACHINES while turning DECAY , SWEEP or CONTOUR	Select Attack, Filter or Resonance as supported by the machine. Release MACHINES for ordinary knob control. Sample Wizard labels its native filter controls Filter and Resonance.
MACRO fine tune	SETTINGS + turn PITCH	Adjust fine pitch. Plain PITCH retains its regular control; FUNC + PITCH is MACRO Lo-Fi.

Sample Wizard and Mod Setup

Feature	Controls	What it does
Sample Preview	FUNC + MACHINES ; highlight a sample, then press its track pad or keyboard trig	Audition the highlighted sample. Scrolling through the list remains silent.
Sample lock	Open the sample selection menu and highlight a sample; then hold a step TRIG + MACHINES	Lock the highlighted sample to that step on a Sample Wizard track. The sample browser must be open with the desired sample selected.
Playback modes	SETTINGS + MACHINES	Open Sample Wizard playback-mode controls.
Slice editor	FUNC + step key; FUNC + click DATA	Play upper slices; remove a slice marker with the DATA click. Marker knobs can snap to zero crossings.
Mod Setup	Long hold SETTINGS + TRACK	Set pad behavior (Stk/Silent), mute behavior (Stk/Latch), USB audio (2ch/6ch), and Num (Off/On). Select a row, press DATA before turning to edit; BACK exits. Defaults: Stk pads, Stk mutes, 2ch USB, Num Off.
Permanent quick save	Hold FUNC + SETTINGS	Save the project permanently using the stock quick-save action.
MIDI Out CC assignment **MIDI Out machine only**	On a track using the MIDI Out machine, hold SETTINGS and turn a parameter knob	Choose the CC number. Turn the knob normally afterward to send its assigned value. This assignment control is available only on MIDI Out machine tracks.

Startup defaults: stock track pads, stock mute behavior, stereo USB (2ch), numeric volume/pan display Off. Change these choices in Mod Setup; Stk means Stock.