FACTORIAL:

MOV CX, [0500]

MOV AX, 0001

MOV DX, 0000

MUL CX

LOOP 040A

MOV [0600], AX

MOV [0601], DX

HL