Editor

g6g.m × | smart.m × | untitled.m × | ML.m × | ML2.m × | mlll.m × | mageshco1exp1.m × | MaheshCo1ex2.m × | Maheshco1exp3.m × | MaheshCo1exp4.m × | MaheshCo1Exp5.m ×

/MATLAB Drive/MaheshCo1Exp5.m

```
1   clc;
2   clear;
3   close all;
4
5   %% IIR FILTER COEFFICIENTS
6   b = [0.0048 0.0193 0.0289 0.0193 0.0048];
7   a = [1 -2.3695 2.3140 -1.0547 0.1874];
8
9   N = 50;
10  x = [1 zeros(1,N-1)];
11  n = 0:N-1;
12
13  %% TRANSFER FUNCTION
14  H = tf(b,a,1);
15
16  disp('=======================================');
17  disp('IIR FILTER REALIZATION');
18  disp('=======================================');
19  disp('Transfer Function:');
20  disp(H);
21
22  %% 1. DIRECT FORM-I
23  y1 = filter(b,a,x);
24
25  disp('=======================================');
26  disp('DIRECT FORM-I');
27  disp('=======================================');
28  disp('Numerator coefficients:');
29  disp(b);
30  disp('Denominator coefficients:');
31  disp(a);
32
```


Figures

FIGURE | FORMAT | TOOLS | LAYOUT

Tab All | Tile All

DISPLAY

Figure 1 × | Figure 2 × | Figure 3 × | Figure 4 ×



Command Window

New to MATLAB? See resources for Getting Started.

```
"Cascade"          1.9221e-15          8.242e-13
"Parallel"         1.9811e-15         8.4949e-13
```

Editor

g6g.m × | smart.m × | untitled.m × | ML.m × | ML2.m × | mlll.m × | mageshco1exp1.m × | MaheshCo1ex2.m × | Maheshco1exp3.m × | MaheshCo1exp4.m × | MaheshCo1Exp5.m ×

/MATLAB Drive/MaheshCo1Exp5.m

```
1   clc;
2   clear;
3   close all;
4
5   %% IIR FILTER COEFFICIENTS
6   b = [0.0048 0.0193 0.0289 0.0193 0.0048];
7   a = [1 -2.3695 2.3140 -1.0547 0.1874];
8
9   N = 50;
10  x = [1 zeros(1,N-1)];
11  n = 0:N-1;
12
13  %% TRANSFER FUNCTION
14  H = tf(b,a,1);
15
16  disp('=====================================');
17  disp('IIR FILTER REALIZATION');
18  disp('=====================================');
19  disp('Transfer Function:');
20  disp(H);
21
22  %% 1. DIRECT FORM-I
23  y1 = filter(b,a,x);
24
25  disp('=====================================');
26  disp('DIRECT FORM-I');
27  disp('=====================================');
28  disp('Numerator coefficients:');
29  disp(b);
30  disp('Denominator coefficients:');
31  disp(a);
32
```


Figures

FIGURE | FORMAT | TOOLS | LAYOUT

Tab All | Tile All

DISPLAY

Figure 1 × | Figure 2 × | Figure 3 × | Figure 4 ×



Command Window

New to MATLAB? See resources for Getting Started.

```
    "Cascade"          1.9221e-15          8.242e-13
    "Parallel"         1.9811e-15         8.4949e-13
```

Editor

g6g.m × | smart.m × | untitled.m × | ML.m × | ML2.m × | mlll.m × | mageshco1exp1.m × | MaheshCo1ex2.m × | Maheshco1exp3.m × | MaheshCo1exp4.m × | MaheshCo1Exp5.m ×

/MATLAB Drive/MaheshCo1Exp5.m

```
1   clc;
2   clear;
3   close all;
4
5   %% IIR FILTER COEFFICIENTS
6   b = [0.0048 0.0193 0.0289 0.0193 0.0048];
7   a = [1 -2.3695 2.3140 -1.0547 0.1874];
8
9   N = 50;
10  x = [1 zeros(1,N-1)];
11  n = 0:N-1;
12
13  %% TRANSFER FUNCTION
14  H = tf(b,a,1);
15
16  disp('========================================');
17  disp('IIR FILTER REALIZATION');
18  disp('========================================');
19  disp('Transfer Function:');
20  disp(H);
21
22  %% 1. DIRECT FORM-I
23  y1 = filter(b,a,x);
24
25  disp('========================================');
26  disp('DIRECT FORM-I');
27  disp('========================================');
28  disp('Numerator coefficients:');
29  disp(b);
30  disp('Denominator coefficients:');
31  disp(a);
32
```


Figures

FIGURE | FORMAT | TOOLS | LAYOUT

Tab All | Tile All

DISPLAY

Figure 1 × | Figure 2 × | Figure 3 × | Figure 4 ×



Command Window

New to MATLAB? See resources for Getting Started.

```
"Cascade"          1.9221e-15          8.242e-13
```

Editor

g6g.m × | smart.m × | untitled.m × | ML.m × | ML2.m × | mlll.m × | mageshco1exp1.m × | MaheshCo1ex2.m × | Maheshco1exp3.m × | MaheshCo1exp4.m × | MaheshCo1Exp5.m ×

/MATLAB Drive/MaheshCo1Exp5.m

```
1   clc;
2   clear;
3   close all;
4
5   %% IIR FILTER COEFFICIENTS
6   b = [0.0048 0.0193 0.0289 0.0193 0.0048];
7   a = [1 -2.3695 2.3140 -1.0547 0.1874];
8
9   N = 50;
10  x = [1 zeros(1,N-1)];
11  n = 0:N-1;
12
13  %% TRANSFER FUNCTION
14  H = tf(b,a,1);
15
16  disp('=======================================');
17  disp('IIR FILTER REALIZATION');
18  disp('=======================================');
19  disp('Transfer Function:');
20  disp(H);
21
22  %% 1. DIRECT FORM-I
23  y1 = filter(b,a,x);
24
25  disp('=======================================');
26  disp('DIRECT FORM-I');
27  disp('=======================================');
28  disp('Numerator coefficients:');
29  disp(b);
30  disp('Denominator coefficients:');
31  disp(a);
32
```


Figures

FIGURE | FORMAT | TOOLS | LAYOUT

Tab All | Tile All

DISPLAY

Figure 1 × | Figure 2 × | Figure 3 × | Figure 4 ×



Command Window

New to MATLAB? See resources for Getting Started.

```
"Cascade"          1.9221e-15          8.242e-13
"Parallel"         1.9811e-15         8.4949e-13
```