

GNUSim8085 - 8085 Microprocessor Simulator

File Reset Assembler Debug Help



Registers

A	00	S	0
BC	00 00	Z	1
DE	00 00	AC	0
HL	85 00	P	1
PSW	00 00	C	0
PC	42 17		
SP	FF FF		
Int-Reg	00		

Decimal - Hex Conversion

Decimal: Hex:

I/O Ports

-

Memory

-

Load me at

```

1 LXI H, 8050H
2 MOV C, M
3 INX H
4 MOV B, M
5 DCR C
6
7 LOOP: INX H
8 MOV A, M
9 CMP B
10 JC SKIP
11 MOV B, A
12
13 SKIP: DCR C
14 JNZ LOOP
15
16 LXI H, 8500H
17 MOV M, B
18 HLT
    
```

Data Stack Keypad **Memory** I/O Ports

Start


Address (Hex)	Address	Data
2134	8500	9
2135	8501	0
2136	8502	0
2137	8503	0
2138	8504	0
2139	8505	0
213A	8506	0
213B	8507	0
213C	8508	0
213D	8509	0
213E	8510	0
213F	8511	0

Line No Assembler Message

0 Program assembled successfully

Simulator: Idle

File Reset Assembler Debug Help



Registers		Flag
A	00	S 0
BC	00 00	Z 1
DE	00 00	AC 0
HL	85 00	P 1
PSW	00 00	C 0
PC	42 17	
SP	FF FF	
Int-Reg	00	

Decimal - Hex Conversion

Decimal	Hex
0	0
→ To Hex	← To Dec

I/O Ports

0	-	+	00
Update Port Value			

Memory

0	-	+	00
Update Memory			

Load me at

```
1 LXI H, 8050H
2 MOV C, M
3 INX H
4 MOV B, M
5 DCR C
6
7 LOOP: INX H
8 MOV A, M
9 CMP B
10 JC SKIP
11 MOV B, A
12
13 SKIP: DCR C
14 JNZ LOOP
15
16 LXI H, 8500H
17 MOV M, B
18 HLT
```

Data Stack KeyPad Memory I/O Ports

Start 8050

OK

Address (Hex) Address Data

1F72	8050	0
1F73	8051	5
1F74	8052	2
1F75	8053	6
1F76	8054	8
1F77	8055	9
1F78	8056	0
1F79	8057	0
1F7A	8058	0
1F7B	8059	0
1F7C	8060	0
1F7D	8061	0

Line No Assembler Message

0 Program assembled successfully

Simulator: Idle