CHAPTER 8 / SUPPLEMENTARY MATERIAL

Cyber–Physical Security and Mission Assurance for Unmanned Aerial Vehicles

Countermeasures, Mitigation Strategies, and Defensive Architectures

Proactive Countermeasures

Preparedness starts with knowing which aircraft are expected and where the site can observe them.

Baseline the airspace


Record authorized operations and survey sensor blind spots, background RF activity, and likely sources of false alerts.

Harden the protected system

Authenticate command links where supported, restrict configuration access, and rehearse loss-of-link and navigation contingencies.

Prepare the response

Define who receives alerts, who verifies authorization, and who can approve a response under the site plan.



Illustrative layout for layered site awareness

Exercise the plan with an authorized UAV and score false alerts, track gaps, and handoff delays.

Reactive Countermeasures

A reactive workflow turns an alert into a documented decision under time pressure.

Confirm and correlate


Check track age, sensor agreement, and uncertainty. Compare the track with known traffic and request visual confirmation where feasible.

Assess and authorize

Consider route, proximity, and site exposure. Verify authority before any action that affects the aircraft or its links.

Respond and record

Notify the designated team, apply the approved site response, and preserve the timeline and decision evidence.



Decision path from alert to authorized response

If identity stays uncertain, keep tracking and follow the site escalation procedure.

Modern Countermeasures for Drone Defense Systems

A layered architecture gives the operator several ways to establish and maintain a track.

Complementary sensors


Radar can provide a track when a UAV emits no detectable control signal. RF observations and EO/IR imagery can add context.

Track fusion

Associate time-stamped observations with a common track. Retain source provenance and flag disagreements and stale data.

Separate decision authority

Use a response policy with independent authorization checks. Keep the evidence log available for review.



Reference architecture for sensor fusion and decision review

Measure performance during sensor outages and handoffs as well as during nominal operation.

RF Detection and Electronic Countermeasure Systems

Passive radio-frequency monitoring observes emissions. Electronic countermeasures act on a link.

Passive RF sensing


Log signal timing, channel activity, and bearings where available. Compare candidate emissions with the local RF baseline.

Interpretation limits

Unrelated emitters, shared spectrum, and absent RF emissions limit identification. Correlate observations with radar or imagery.

Active RF effects

Interference can affect nearby services, and a UAV's response to link loss depends on its configuration. Active use requires applicable authority.



Passive observation and active link effects

Record RF detections and authorized interventions as separate events.

Fiber-Optic-Controlled UAVs and Anti-Jamming Limits

A fiber-optic UAV can carry command and video over a physical cable.

Control path


RF interference directed at a wireless command or video link does not directly disrupt the data carried by the fiber.

Detection consequence

A detector looking for an RF control link may have little evidence. Continue surveillance with radar and EO/IR where coverage permits.

Other radio dependencies

A particular UAV may still use GNSS or auxiliary radios. Assess those functions separately from the optical command path.



Wireless and fiber-optic command paths

Evaluate detection with and without observable control-link emissions.

Radar-Based Drone Defense Systems

Radar provides range and track information from reflected energy, including for UAVs without a detectable RF control link.

Detect and track


Associate returns over time to estimate a track. Depending on the radar, the measurements can include range, bearing, and radial velocity.

Account for clutter

Birds, buildings, terrain, and a low radar cross section can complicate detection or classification.

Cue another sensor

Pass the predicted bearing, track time, and uncertainty to EO/IR for confirmation when conditions allow.



Radar surveillance and EO/IR cueing

Evaluate detection probability and false alarms across range, altitude, and clutter conditions.

Electro-Optical and Thermal Detection Systems

Visible and thermal imagery can help confirm a track and document what the sensor saw.

Visible imaging


Electro-optical (EO) cameras can resolve shape and motion when lighting, visibility, and image scale support it.

Thermal imaging

Infrared (IR) cameras use thermal contrast and can work in darkness. Weather and low contrast can still limit detection.

Cueing and review

Use radar or RF bearings to narrow the search. Store time-stamped imagery and report identification confidence.



Illustrative visible-light and thermal observations

A missed visual confirmation can reflect field of view, occlusion, or limited contrast.

Interceptor- and Capture-Based Countermeasures

Capture systems attempt physical restraint. Mission planning must account for the outcomes of both capture and failure.

Capture options


Examples include an interceptor carrying a net and a fixed or portable net launcher. Suitability depends on the site and the target.

Risk assessment

Consider bystanders, obstacles, other aircraft, and where equipment or debris could fall if capture fails or a system malfunctions.

Abort and recovery

Define when to abort, how to secure the affected area, and who can recover and document the captured equipment.



Illustrative capture, abort, and recovery decision path

Compare capture outcomes, aborts, and recovery risks when evaluating the system.

Kinetic Drone Defense and High-Power Microwaves

Physical impact and high-power microwave effects present different risks to the surrounding area.

Kinetic effects


Physical contact or impact can damage an aircraft. The risk assessment includes debris, unintended impacts, and the area beyond the engagement.

Microwave effects

High-power microwaves can disrupt electronics. Effects depend on susceptibility, and nearby electronic systems may also be exposed.

Operational assurance

Evaluate authorization, control of the affected area, independent outcome assessment, and post-event reporting.



Conceptual comparison of physical and electromagnetic effects

Compare collateral effects and verification requirements alongside the intended effect.