```
6 rs2 imm rs7
sw x5, 32 (x30)
```

Format S

plock

oplead: 0100011

funet3: 010

rs1 : 11110

rs2: 00101

in, + 00010000

imm: 0000001,00000

0000 001,0 0101,1111 0,010,0000 0,010 0011 imm [10:5] rs2 rs1 funct3 imm[4:0] option

70

0000 000,0 0001,0000 1,000 1000 1,011 0011 funct 7 rs2 rs1 rs1 funct 3 rd opkool

ophod: 0110011 > format R

funct 3: 000 > sub/odd

funct 7: 0000000 -> add

rd: 00001 > x1

rs1 : 00001 -> 1

rs2 : 00001 =>1

add x1, x1, x1