

※Please contact us when you order these parts. ※订购零件时请与我们联系

PARTS CODE 零件编号

PARTS NAME 零件名称		Type - L	Type - LL
Train wheel bridge	轮列夹板	0125 318	
Center wheel and pinion bridge	中心轮夹板	4283 042	
Center wheel and pinion	中心轮	0221 091	※
Third wheel and pinion	3# 轮	0231 059	
Fourth wheel and pinion	4# 轮	0144 002	
Fifth wheel and pinion	5# 轮	0701 015	
Step rotor	磁石轮	4146 063	
Hour wheel	时轮	0273 041	※
Minute wheel and pinion	度数轮	0261 126	
Setting wheel	小铁车	0281 452	
Clutch wheel	离合轮	0282 452	
Setting lever	设置杆 (压制)	0383 891	
Yoke	离合杆 (横担)	0384 024	
Reset lever	止秒弹弓	4455 006	
Train wheel setting lever	规正弹弓	0391 028	
Stator (A)	定子板 (A)	4239 063	
Stator (B)	定子板 (B)	4239 064	
Circuit block	回路板	4004 353	
Circuit block spacer	回路板垫片	4408 149	
Coil block (A)	线圈 (A)	4002 054	
Coil block (B)	线圈 (B)	4002 055	
Battery connection (-)	负极片 (-)	4270 336	
Seconds wheel	秒轮	0240 018	※
Seconds counter intermediate wheel and pinion	计秒中间轮	0885 003	
Seconds counting wheel	计秒轮	0888 027	※
Counter intermediate wheel and pinion	计时中间轮	0886 004	
Minute counter intermediate wheel and pinion (A)	计分中间轮和轴 (A)	0886 005	
Minute counter intermediate wheel (B)	计分中间轮和轴 (B)	0886 006	
Minute counter intermediate wheel (C)	计分中间轮和轴 (C)	0886 007	
Minute counting wheel	计分轮	0902 017	※
Positioning arbor	定位柱	0685 003	
Lower plate for chronograph bridge	计时轮列夹板	0186 002	
Chronograph bridge	计时码表夹板	0190 007	
Seconds counting wheel friction spring	秒计压片	0353 018	
Hammer	三叉锤	0585 013	
Chronograph coupling lever	计时码表连接杆	0581 007	
Hammer operating lever (A)	三叉锤操作杆 (A)	0587 004	
Hammer operating lever (B)	三叉锤操作杆 (B)	0587 006	
Switch lever (A)	按制杆 (A)	4450 017	
Switch lever (B)	按制杆 (B)	4450 018	
Train wheel stop lever	规正弹弓	0894 002	
Date indicator maintaining plate	日历定位片 (日历盘压片)	0808 052	
Date jumper	日历定位弹弓	0810 019	
Date corrector setting transmission wheel (A)	企轮 (A)	0962 032	
Date corrector setting transmission wheel (B)	企轮 (B)	0962 013	
Date corrector setting transmission wheel (C)	企轮 (C)	0962 891	
Date corrector wheel	日历修正轮	0806 002	
Small hour hand wheel	小时针轮	0157 012	※

※Please contact us when you order these parts. ※订购零件时请与我们联系

PARTS NAME 零件名称		PARTS CODE 零件编号	
		Type - L	Type - LL
Intermediate small hour hand wheel and pinion	小时针中间轮	0817 048	
Switch lever holder	按制杆压片	0837 005	
Switch spring	按制弹弓	4250 076	※
Switch spring screw	按制弹弓螺丝	0016 121	
Lower plate for chronograph bridge screw	计时轮列夹板螺丝	0016 121	
Date indicator maintaining plate screw	日曆定位片螺丝	0012 354	
Coil block screw	线圈组螺丝	0012 354	
Switch lever holder screw	按制杆压片螺丝	0012 354	
Winding Stem	巴芯	0351 177	