## Chapter 3

## **Memory Hierarchy**



Technology Trend and Memory Hierarchy

Four Questions for Cache Designers

- Memory System Performance
  - Improve Cache Performance
- Storage Systems

#### Memory

Register

Cache

Memory

Storage

- Mechanical memory
  - Acoustic wave/torque wave delay line memory
  - Magnetic Drum Memory
  - Magnetic core memory
- Electronic memory
  - SRAM
  - DRAM
    - SDRAM
  - Flash
  - ROM
    - PROM
    - EPROM
- Optical memory



#### Memory

Register

Cache

Memory

Storage

- Mechanical memory
  - Acoustic wave/torque wave delay line memory
  - Magnetic Drum Memory
  - Magnetic core memory
- Electronic memory
  - SRAM
  - DRAM
    - SDRAM
  - Flash
  - ROM
    - PROM
    - EPROM
- Optical memory



Temporal locality (locality in time): if an item is referenced, it will tend to be referenced again soon. If you recently brought a book to your desk to look at, you will probably need to look at it again soon.


**Spatial locality** (locality in space): if an item is referenced, items whose addresses are close by will tend to be referenced soon.

## Memory?

• Load R2, O(R1)

• Store R2, O(R1)





#### Data processing & temporary storage


CPU

Register

Register reference




#### **Temporary storage**






#### Faster temporary storage




#### Faster temporary storage



Size Speed


#### **Memory Hierarchy**



Memory hierarchy for a personal mobile device


\*1000 picoseconds = 1 nanosecond = 10<sup>-6</sup> millisecond

#### **Memory Hierarchy**



Memory hierarchy for a laptop or a desktop


#### **Memory Hierarchy**




Memory hierarchy for server

## Wait, but what's cache?
















## So, what's cache?




#### So, what's cache?

• Cache: a safe place for hiding or storing things.

Webster's New World Dictionary of the American Language

Second College Edition (1976)

#### Cache




- The highest or first level of the memory hierarchy encountered once the *addr* leaves the processor
- Employ buffering to reuse commonly occurring items



### **Cache Hit/Miss**

 When the processor can/cannot find a requested data item in the cache




hit rate miss rate

hit time miss penalty



### **Block/Line Run**


 A fixed-size collection of data containing the requested word, retrieved from the main memory and placed into the cache





### **Block/Line Run**


 A fixed-size collection of data containing the requested word, retrieved from the main memory and placed into the cache





### **Block/Line Run**

 A fixed-size collection of data containing the requested word, retrieved from the main memory and placed into the cache





#### **Cache Locality**

Temporal locality
 need the requested word again soon

• Spatial locality
likely need other data in the block soon



#### **Cache Miss**


• Time required for cache miss depends on:

**Latency**: the time to retrieve the first word of the block

Bandwidth: the time to retrieve the rest of this block



#### **Technology Trend**



#### § 3.2 Technology Trend and Memory Hierarchy


| Memory technology          | Typical access time    | \$ per GiB in 2012 |
|----------------------------|------------------------|--------------------|
| SRAM semiconductor memory  | 0.5–2.5 ns             | \$500-\$1000       |
| DRAM semiconductor memory  | 50-70 ns               | \$10-\$20          |
| Flash semiconductor memory | 5,000-50,000 ns        | \$0.75-\$1.00      |
| Magnetic disk              | 5,000,000-20,000,000ns | \$0.05-\$0.10      |

SRAM (static random access memory)

DRAM (dynamic random access memory)

SDRAM (Synchronous DRAM)

Double Data Rate (DDR) SDRAM




**FIGURE 5.4 Internal organization of a DRAM.** Modern DRAMs are organized in banks, typically four for DDR3. Each bank consists of a series of rows. Sending a PRE (precharge) command opens or closes a bank. A row address is sent with an Act (activate), which causes the row to transfer to a buffer. When the row is in the buffer, it can be transferred by successive column addresses at whatever the width of the DRAM is (typically 4, 8, or 16 bits in DDR3) or by specifying a block transfer and the starting address. Each command, as well as block transfers, is synchronized with a clock.

HBM (High Bandwidth Memory)


Storage

### Memory/Storage




Flash Memory: electrically erasable programmable read-only memory (EEPROM).

#### **Processor-Memory Performance Gap**



Size Speed

#### Who Cares About the Memory Hierarchy?



1980: no cache in μproc;

1995 2-level cache on chip (1989 first Intel µproc with a cache on chip)



# Three classes of computers with different concerns in memory hierarchy

#### Desktop computers:

- Are primarily running one application for single user
- Are concerned more with average latency from the memory hierarchy.

#### Server computers:

- May typically have hundreds of users running potentially dozens of applications simultaneously.
- Are concerned about memory bandwidth.



# Three classes of computers with different concerns in memory hierarchy.

- Embedded computers:
  - Real-time applications.
    - Worst-case performance vs Best case performance
  - Are concerned more about power and battery life.
    - Hardware vs software
  - Running single app & use simple OS
    - The protection role of the memory hierarchy is often diminished.
  - Main memory is very small
    - often no disk storage



#### **Enhance speed of memory**

- Component character of hardware:
  - Smaller hardware is faster and more expensive
  - Bigger memories are lower and cheaper

#### The goal:

- There are speed of smallest memory and capacity of biggest memory
- To provide cost almost as low as the cheapest level of memory and speed almost as fast as the fastest level.

#### The method enhance speed of memory

By taking advantage of the principle of locality:

- most programs do not access all code or data uniformly
- Temporal Locality (Locality in Time):
- If an item is referenced, the same item will tend to be referenced again soon
  - Keep most recently accessed data items closer to the processor
- Spatial Locality (Locality in Space):
- If an item is referenced, nearby items will tend to be referenced soon
  - Move recently accessed groups of contiguous words(block) closer to processor.



# The method enhance speed of memory

#### The method


- Hierarchies bases on memories of different speeds and size
- The more closely CPU the level is, the faster the one is.
- The more closely CPU the level is, the smaller the one is.
- The more closely CPU the level is, the more expensive one is.



# Memory Hierarchy of a Modern Computer System

By taking advantage of the principle of locality:

- Present the user with as much memory as is available in the cheapest technology.
- Provide access at the speed offered by the fastest technology.






## **36 terms of Cache**

Cache full associative write allocate Virtual memory unified cache dirty bit block offset Memory stall cycles block write back misses per instruction direct mapped Valid bit data cache locality Block address address trace hit time Write through cache miss set Instruction cache page fault miss rate index field cache hit random replacement tag field Average memory access time page no-write allocate miss penalty n-way set associative write buffer Least-recently used write stall




### What is a cache?

- Small, fast storage used to improve average access time to slow memory.
- In computer architecture, almost everything is a cache!
  - Registers "a cache" on variables software managed
  - First-level cache a cache on second-level cache
  - Second-level cache a cache on memory
  - Memory a cache on disk (virtual memory)
  - TLB a cache on page table
  - Branch-prediction a cache on prediction information?





#### § 3.2 Technology Trend and Memory Hierarchy



| X <sub>4</sub> |
|----------------|
| X <sub>1</sub> |
| $X_{n-2}$      |
|                |
| $X_{n-1}$      |
| X <sub>2</sub> |
|                |
| X <sub>3</sub> |

| $X_4$            |
|------------------|
| X <sub>1</sub>   |
| $X_{n-2}$        |
|                  |
| X <sub>n-1</sub> |
| X <sub>2</sub>   |
| $X_n$            |
| $X_3$            |

- a. Before the reference to  $X_n$
- b. After the reference to  $X_n$

How do we know if a data item is in the cache? Moreover, if it is, how do we find it?



# Four Questions for Cache Designers

**Caching** is a general concept used in processors, operating systems, file systems, and applications. There are **Four Questions** for Cache/Memory Hierarchy Designers

Q1: Where can a block be placed in the upper level/main memory?

(Block placement)

- Fully Associative, Set Associative, Direct Mapped
- Q2: How is a block found if it is in the upper level/main memory?
   (Block identification)
  - Tag/Block
- Q3: Which block should be replaced on a Cache/main memory miss? (Block replacement)
  - Random, LRU,FIFO
- Q4: What happens on a write?


(Write strategy)


Write Back or Write Through (with Write Buffer)



# Q1: Block Placement Direct mapped

(Block address) modulo (Number of blocks in the cache)






# Q1: Block Placement


# **Direct mapped**


(Block address) modulo (Number of blocks in the cache)

i: j  $\longleftarrow$  m bit  $\longrightarrow$ 




# **Fully-associative**





# 2-way Set-associative




# Q1: Block Placement

- Direct mapped
  - Block can only go in one place in the cache
- *Note that direct mapped is the same as 1-way set* • Fully associative, and fully associative is m-way set-associative (for a cache with m blocks).
- Set as
  - Block can go in one of a set of places in the cache.
  - A set is a group of blocks in the cache.
    - Block address MOD Number of sets in the cache
  - If sets have n blocks, the cache is said to be n-way set associative.



### 8-32 Block Placement





# **N-way Set-associative**

 The higher the degree of association, the higher the utilization of cache space, the lower the probability of block collision and the lower the failure rate.

|                  | n         | G         |
|------------------|-----------|-----------|
| Full-associative | M         | 1         |
| Direct mapped    | 1         | M         |
| Set-associative  | 1 < n < M | 1 < G < M |

• Most Cache: *n* ≤ *4* 

• Question: Is the greater the number n, the better?



## **Q2: Block Identification**

 Every block has an address tag that stores the main memory address of the data stored in the block.

 When checking the cache, the processor will compare the requested memory address to the cache tag -- if the two are equal, then there is a cache hit and the data is present in the cache

 Often, each cache block also has a valid bit that tells if the contents of the cache block are valid



# The Format of the Physical Address

- The Index field selects
  - The set, in case of a set-associative cache
  - The block, in case of a direct-mapped cache
  - Has as ma for direct
- The Byte Of
  - The byte



• Has as many bits as log\_\_\size or blocky

- The Tag is used to find the matching block within a set or in the cache
  - Has as many bits as Address\_size Index\_size Byte\_Offset\_Size




Byte Offset

g2(#blocks)


Index

# Direct-mapped Cache Example (1-word Blocks)



# Fully-Associative Cache example (1-word Blocks)


Assume cache has 4 blocks






# 2-Way Set-Associative Cache

- Assume cache has 4 blocks and each block is 1 word
- 2 blocks per set, hence 2 sets per cache





#### § 3.3 Four Questions for Cache Designers



- 64-bit addresses
- A direct-mapped cache
- The cache size is 2<sup>n</sup> blocks, so n bits are used for the index
- The block size is
  - $\checkmark$  2<sup>m</sup>words (2<sup>m+2</sup> bytes = 2<sup>m+5</sup> bits)
  - ✓ m bits are used for the word within the block, and two bits are used for the byte part of the address

tag 
$$64 - (n + m + 2)$$

cache 
$$2^n \times (block size + tag size + Valid size)$$
.

$$= 2^{n} \times (2^{m} \times 32 + (64 - n - m - 2) + 1)$$

$$= 2^{n} \times (2^{m} \times 32 + 63 - n - m).$$

actual size/complete cache size


| Binary address of reference | Assigned cache block (where found or placed)             |
|-----------------------------|--|
| 10110 <sub>two</sub>        | $(10110_{\text{two}} \text{ mod } 8) = 110_{\text{two}}$ |
| 11010 <sub>two</sub>        | $(11010_{\text{two}} \text{ mod } 8) = 010_{\text{two}}$ |
| 10110 <sub>two</sub>        | $(10110_{\text{two}} \text{ mod } 8) = 110_{\text{two}}$ |
| 11010 <sub>two</sub>        | $(11010_{\text{two}} \text{ mod } 8) = 010_{\text{two}}$ |
| 10000 <sub>two</sub>        | $(10000_{\text{two}} \text{ mod } 8) = 000_{\text{two}}$ |
| 00011 <sub>two</sub>        | $(00011_{two} \text{ mod } 8) = 011_{two}$               |
| 10000 <sub>two</sub>        | $(10000_{\text{two}} \text{ mod } 8) = 000_{\text{two}}$ |
| 10010 <sub>two</sub>        | $(10010_{\text{two}} \text{ mod } 8) = 010_{\text{two}}$ |
| 10000 <sub>two</sub>        | $(10000_{\text{two}} \mod 8) = 000_{\text{two}}$         |

| Index | V | Tag               | Data                           |
|-------|---|-------------------|--------------------------------|
| 000   | Υ | 10 <sub>two</sub> | Memory (10000 <sub>two</sub> ) |
| 001   | N |                   |                                |
| 010   | Y | 10 <sub>two</sub> | Memory (10010 <sub>two</sub> ) |
| 011   | Υ | 00 <sub>two</sub> | Memory (00011 <sub>two</sub> ) |
| 100   | N |                   |                                |
| 101   | N |                   |                                |
| 110   | Υ | 10 <sub>two</sub> | Memory (10110 <sub>two</sub> ) |
| 111   | N |                   |                                |



# Q3: Block Replacement

- In a direct-mapped cache, there is only one block that can be replaced
- In set-associative and fully-associative caches, there are N blocks (where N is the degree of associativity)





# **Strategy of Block Replacement**

- Several different replacement policies can be used
  - Random replacement randomly pick any block
    - Easy to implement in hardware, just requires a random number generator
    - Spreads allocation uniformly across cache
    - May evict a block that is about to be accessed
  - Least-Recently Used (LRU) pick the block in the set which was least recently accessed
    - Assumed more recently accessed blocks more likely to be referenced again
    - This requires extra bits in the cache to keep track of accesses.
  - First In, First Out(FIFO)-Choose a block from the set which was first came into the cache


# **Strategy of Block Replacement**

#### Suppose:


• Cache block size is 3, and access sequence is shown as follows.

• FIFO, LRU and OPT are used to simulate the use and replacement of cache block.


## **FIFO**



## **LRU**



### **OPT**



The hit rate is related to the replacement algorithm.

