The pads and traces in yellow represent the RF net.

They should be matched to 50 ohm impedance.

