

Access Point
SSID:
Password:

Once connected to the O.MG's access point, open your phone's browser and head over to

At the bottom of the web UI, select the "LOAD" button to choose various demo payloads from the onboard flash.

SLOT ONE: Shows the HID injection capability by opening notepad and printing a brief overview of the device, as well as some examples of various text.

SLOT TWO:

Further emulates keystrokes by opening/browsing the UC Baseline webpage via a Powershell command and selecting Hardware 101 spec sheet to display.

## Things to know!

- You'll see the signal fluctuate continuously and even drop to 0. If connectivity is a problem, you can change the AP's channel under the settings menu on the web UI.
- Due to the size of the device and radio, it can be finnicky. If a payload doesn't run the first time, click "RUN" again until you get the "running payload" dialogue.
- After a payload executes, you may lose connection to the cable's AP. Make sure to reconnect or select "connect automatically" under your phone's wireless settings.