

MCU 编译说明

直接使用 Keil 打开代码，编译时会出现编译错误。

```

*** Using Compiler 'V5.05 update 6 (build 750)', folder: 'C:\Keil_v5\ARM\ARMCC\Bin'
Rebuild target 'UART_IED'
compiling soft_timer.c...
../Core/Inc/main.h(30): error: #5: cannot open source input file "stm32f1xx_hal.h": No such file or directory
#include "stm32f1xx_hal.h"
../Core/Src/soft_timer.c: 0 warnings, 1 error
compiling stm32f1xx_hal_gpio.c...
no source: Error: #5: cannot open source input file "C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_gpio.c": No such file or directory
../Core/Inc/main.h(30): error: #5: cannot open source input file "stm32f1xx_hal.h": No such file or directory
#include "stm32f1xx_hal.h"
../Core/Src/gpio.c: 0 warnings, 1 error
compiling stm32f1xx_hal_rcc.c...
no source: Error: #5: cannot open source input file "C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_rcc_ex.c": No such file or directory
C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_rcc_ex.c: 0 warnings, 1 error
assembling startup_stm32f10xxx.s...
compiling stm32f1xx_it.c...
../Core/Inc/main.h(30): error: #5: cannot open source input file "stm32f1xx_hal.h": No such file or directory
#include "stm32f1xx_hal.h"
../Core/Src/stm32f1xx_it.c: 0 warnings, 1 error
compiling stm32f1xx_hal_uart.c...
no source: Error: #5: cannot open source input file "C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_uart.c": No such file or directory
C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_uart.c: 0 warnings, 1 error
compiling main.c...
../Core/Inc/main.h(30): error: #5: cannot open source input file "stm32f1xx_hal.h": No such file or directory
#include "stm32f1xx_hal.h"
../Core/Src/main.c: 0 warnings, 1 error
compiling stm32f1xx_hal_rcc.c...
no source: Error: #5: cannot open source input file "C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_rcc_ex.c": No such file or directory
C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_rcc_ex.c: 0 warnings, 1 error
compiling stm32f1xx_hal_rcc.c...
no source: Error: #5: cannot open source input file "C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_rcc_ex.c": No such file or directory
C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_rcc_ex.c: 0 warnings, 1 error
compiling uart.c...
../Core/Inc/main.h(30): error: #5: cannot open source input file "stm32f1xx_hal.h": No such file or directory
#include "stm32f1xx_hal.h"
../Core/Src/uart.c: 0 warnings, 1 error
compiling stm32f1xx_hal_cortex.c...
no source: Error: #5: cannot open source input file "C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_cortex.c": No such file or directory
C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_cortex.c: 0 warnings, 1 error
compiling stm32f1xx_hal_dma.c...
no source: Error: #5: cannot open source input file "C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_dma.c": No such file or directory
C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_dma.c: 0 warnings, 1 error
compiling stm32f1xx_hal_msp.c...
../Core/Inc/main.h(30): error: #5: cannot open source input file "stm32f1xx_hal.h": No such file or directory
#include "stm32f1xx_hal.h"
../Core/Src/stm32f1xx_hal_msp.c: 0 warnings, 1 error
compiling stm32f1xx_hal_pwr.c...
no source: Error: #5: cannot open source input file "C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_pwr.c": No such file or directory
C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_pwr.c: 0 warnings, 1 error
compiling stm32f1xx_hal_flash.c...
no source: Error: #5: cannot open source input file "C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_flash.c": No such file or directory
C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_flash.c: 0 warnings, 1 error
compiling stm32f1xx_hal_flash_ex.c...
no source: Error: #5: cannot open source input file "C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_flash_ex.c": No such file or directory
C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_flash_ex.c: 0 warnings, 1 error
compiling stm32f1xx_hal_exti.c...
no source: Error: #5: cannot open source input file "C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_exti.c": No such file or directory
C:/Users/Dawns/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6/Drivers/STM32F1xx_HAL_Driver/Src/stm32f1xx_hal_exti.c: 0 warnings, 1 error
compiling system_stm32f1xx.c...
../Core/Src/system_stm32f1xx.c(58): error: #5: cannot open source input file "stm32f1xx.h": No such file or directory
#include "stm32f1xx.h"
../Core/Src/system_stm32f1xx.c: 0 warnings, 1 error
compiling app_ctrl.c...
compiling app_player.c...
compiling app_dot.c...
../Core/Inc/./../Core/Inc/main.h(30): error: #5: cannot open source input file "stm32f1xx_hal.h": No such file or directory
#include "stm32f1xx_hal.h"
../src/app_dot.c: 0 warnings, 1 error
compiling app_at.c...
compiling app_modes.c...
compiling ad_port.c...
../Core/Inc/main.h(30): error: #5: cannot open source input file "stm32f1xx_hal.h": No such file or directory
#include "stm32f1xx_hal.h"
../ad/ad_port.c: 0 warnings, 1 error
compiling ad_sdk.c...
../ad/ad_sdk.c(136): warning: #177-D: function "read_i32_be" was declared but never referenced
static int32_t read_i32_be(const uint8_t *data) {
../ad/ad_sdk.c(137): warning: #177-D: function "validate_frame" was declared but never referenced
static int validate_frame(const uint8_t *data, uint16_t len, uint16_t *frame_len) {
../ad/ad_sdk.c: 2 warnings, 0 errors
"UART_LED\UART_LED.axf" - 201 Error(s), 2 Warning(s).
Target not created.

```

报错信息为路径错误。

我们需要先打开文件夹中的 CubeMX 文件。

名称	修改日期	类型	大小
.git	2025/12/24 10:33	文件夹	
Core	2025/12/8 21:26	文件夹	
MDK-ARM	2025/12/24 10:37	文件夹	
sdk	2025/12/8 21:26	文件夹	
src	2025/12/24 10:33	文件夹	
.gitignore	2025/11/24 13:32	txtfile	1 KB
.mxproject	2025/12/24 10:33	MXPROJECT 文件	9 KB
README.md	2025/11/24 13:32	MD 文件	1 KB
MX UART_LED.ioc	2025/12/24 10:33	STM32CubeMX	6 KB
软件定时器使用说明.md	2025/12/8 21:26	MD 文件	7 KB

打开文件后，直接点击右上角 **GENERATE CODE** 重新生成本地路径的代码。

STM32CubeMX UART_LED.ioc: STM32F103C8Tx

File Window Help

Home STM32F103C8Tx UART_LED.ioc - Project Manager **GENERATE CODE**

Pinout & Configuration	Clock Configuration	Project Manager	Tools
Project	Project Settings Project Name: UART_LED Project Location: D:\GitHub\ad-firmware-bk7252n-standard-ai-module-mcu-demo-1105\ Browse		
Code Generator	Application Structure: Advanced ☐ Do not generate the main() Toolchain Folder Location: D:\GitHub\ad-firmware-bk7252n-standard-ai-module-mcu-demo-1105\ Toolchain / IDE: MDK-ARM Min Version: V5.32 ☐ Generate Under Root		
Advanced Settings	Linker Settings Minimum Heap Size: 0x200 Minimum Stack Size: 0x400		
	Thread-safe Settings Cortex-M3NS ☐ Enable multi-threaded support Thread-safe Locking Strategy: Default - Mapping suitable strategy depending on RTOS selection.		
	Mcu and Firmware Package Mcu Reference: STM32F103C8Tx Firmware Package Name and Version: STM32Cube FW_F1 V1.8.6 ☒ Use latest available version ☒ Use Default Firmware Location Firmware Relative Path: C:/Users/wghot/STM32Cube/Repository/STM32Cube_FW_F1_V1.8.6 Browse		

重新生成代码后使用 **Keil** 再次打开项目代码。重新编译即可完成编译。

