REV	DATE	BY	CHANGE
A	10-March-2012	BBT	Initial release
A1	1-MAY-2012	BBT	buttons are re-arranged with diffrent GPIO's
A2	25-July-2012	BBT	stand-alone backlight circuit added. GPIO3_19 is used for User LED, GPIO1_18 is used for Backlight and GPIO0_3 is used for Enter button

beagleboardtoys.com

1380 Presidential Dr. #100
Richardson, TX 75081
www.beagleboardtoys.com

Title

BeagleBone LCD3 Cape   COVER PAGE

| Size B | Document Number BB-BONE-LCD3-01 | Rev A2 |

Date: Tuesday, September 04, 2012   Sheet   1   of   4

J1

LCD_VSYNC 3
LCD_HSYNC 3

| 1 | 2 | LCD_PCLK 3 |
| 3 | 4 | LCD_EN 3 |
LCD_DATA14 5 6 LCD_DATA15
LCD_DATA13 7 8 LCD_DATA11
LCD_DATA12 9 10 LCD_DATA10
LCD_DATA8 11 12 LCD_DATA9
LCD_DATA6 13 14 LCD_DATA7
LCD_DATA4 15 16 LCD_DATA5
LCD_DATA2 17 18 LCD_DATA3
LCD_DATA0 19 20 LCD_DATA1

LCD_DATA[0..15] 3

CONN PCB 10x2-S

VDD_3V3

C1 10uF,10V
C2 10uF,10V 4

DGND   DGND   DGND

J2

VDD_5V
DGND 1 2 DGND
VDD_3V3 3 4 VDD_3V3
5 6
SYS_5V 7 8 SYS_5V
PWR_BUT 9 10 RESET 3,4
3
11 12
13 14 EHRPWM1A 4
GPIO1_16 15 16 GPIO1_19 4
SPI_CS 3 R86 0, DNI 17 18 R87 0, DNI SPI_MOSI 4
I2C2_SCL 3 19 20 I2C2_SDA 3
GPIO0_3 3 21 22 R88 0, DNI SPI_CLK 4
GPIO1_17 3 23 24
25 26
USER_LED1 27 28
29 30 GPIO3_16 3
31 32
33 34
35 36
AIN2 4 37 38 AIN3 4
AIN0 4 39 40 AIN1 4
41 42
43 44
45 46

R90 0 2 1

MALE HEADER 2x23

DGND   DGND

J3

BL_ISET1 2 1 BL_ISET2
BL_IN 4 3 BL_OUT
BL_SINK2 6 5 BL_SINK1

R70 100K, DNI
R71 100K, DNI

DGND   DGND

HEADER 3X2, DNI

AUX_BL

SYS_5V

L3 18uH, DNI L4
BL_IN
10uH, DNI
D4 MBRX140-TP, DNI

BL_OUT BL+ 4

BL_SINK1
BL_SINK2 BL- 4

SYS_5V

FB8 MMZ1608R301A

R119 470
R63 470

LEDAA

D5 LTST-C190GKT GRN
D3 LTST-C190GKT GRN

User LED   Power LED

LEDAC

VDD_3V3

Q1B DMC56404
10k 5 3
47k R122 100K,1% 4

USER_LED1 2
10k Q1A DMC56404
6
47k
R121 100K,1% 1

DGND DGND DGND DGND

beagleboardtoys.com

Title: BeagleBone LCD3 Cape   HOST CONNECTORS

Size: B
Document Number: BB-BONE-LCD3-01
Rev: A2

Date: Tuesday, September 04, 2012   Sheet 2 of 4

BeagleBone LCD3 Cape — BUFFER Schematic (Sheet 3 of 4)

This page is a full-page electronic schematic diagram.

Key labels present on the schematic:

U1 — 74AVC32T245

VCCB1, VCCB2, VCCB3, VCCB4 / VCCA1, VCCA2, VCCA3, VCCA4

Decoupling capacitors: C5, C7, C9, C10, C6, C8, C11, C12 — all 0.1uF, to VDD_3V3 / DGND

Left side signals (with series resistors 33,402):
- LCD_EN — R1 — LCDEN — A2 — 1B1
- LCD_PCLK — R14 — LCDPCLK — A1 — 1B2
- LCD_VSYNC — R4 — LCDVSYNC — B2 — 1B3
- LCD_HSYNC — R15 — LCDHSYNC — B1 — 1B4
- LCD_DATA15 — R7 — RED4 — C2 — 1B5
- LCD_DATA14 — R8 — RED3 — C1 — 1B6
- LCD_DATA13 — R10 — RED2 — D2 — 1B7
- LCD_DATA12 — R12 — RED1 — D1 — 1B8
- LCD_DATA10 — R13 — GRN5 — E2 — 2B1
- LCD_DATA11 — R19 — RED0 — E1 — 2B2
- LCD_DATA8 — R21 — GRN3 — F2 — 2B3
- LCD_DATA9 — R23 — GRN4 — F1 — 2B4
- LCD_DATA6 — R25 — GRN1 — G2 — 2B5
- LCD_DATA7 — R27 — GRN2 — G1 — 2B6
- LCD_DATA4 — R29 — BLU4 — H2 — 2B7
- LCD_DATA5 — R31 — GRN0 — H1 — 2B8
- LCD_DATA3 — R33 — BLU3 — N1 — 4B1
- LCD_DATA1 — R35 — BLU1 — P2 — 4B2
- LCD_DATA2 — R37 — BLU2 — P1 — 4B3
- LCD_DATA0 — R39 — BLU0 — R2 — 4B4

LCD_DATA[0..15]

Right side signals (with series resistors 10,402):
- A5 — 1A1 — B_LCDEN — R2 — BEN
- A6 — 1A2 — B_PCLK — R3 — BPCLK
- B5 — 1A3 — B_VSYNC — R5 — BVSYNC
- B6 — 1A4 — B_HSYNC — R6 — BHSYNC
- C5 — 1A5 — B_D15 — R16 — BRED4
- C6 — 1A6 — B_D14 — R9 — BRED3
- D6 — 1A7 — B_D13 — R11 — BRED2
- D5 — 1A8 — B_D12 — R17 — BRED1
- E5 — 2A1 — B_D10 — R18 — BGRN5
- E6 — 2A2 — B_D11 — R20 — BRED0
- F5 — 2A3 — B_D8 — R22 — BGRN3
- F6 — 2A4 — B_D9 — R24 — BGRN4
- G5 — 2A5 — B_D6 — R26 — BGRN1
- G6 — 2A6 — B_D7 — R28 — BGRN2
- H5 — 2A7 — B_D4 — R30 — BBLU4
- H6 — 2A8 — B_D5 — R32 — BGRN0
- N6 — 4A1 — B_D3 — R34 — BBLU3
- P5 — 4A2 — B_D1 — R36 — BBLU1
- P6 — 4A3 — B_D2 — R38 — BBLU2
- R5 — 4A4 — B_D0 — R40 — BBLU0

Control pins:
- A4 — 1OE*, H4 — 2OE*, J4 — 3OE*, T4 — 4OE*
- A3 — 1DIR, H3 — 2DIR, J3 — 3DIR, T3 — 4DIR

Ground pins: GND1–GND16 (DGND)

3B1–3B8 (J2, J1, K2, K1, L2, L1, M2, M1), 4B5–4B8 (R1, T2, T1, ...), 3A1–3A8, 4A5–4A8

Push buttons (B3F-1000):
- S2 — GPIO1_16, R83 10K, VDD_3V3
- S3 — GPIO1_17, R82 10K, VDD_3V3
- S4 — GPIO1_19, R80 10K, VDD_3V3
- S5 — GPIO3_16, R81 10K, VDD_3V3
- S7 — GPIO0_3, R89 10K, VDD_3V3 — ENTER
- S6 — B3F-3100 — PWR_BUT
- S1 — B3U-1100 — RESET

Board ID memory

U4 — CAT24C256W
- Pin 6 SCL, Pin 5 SDA, Pin 8 VCC, Pin 4 VSS, Pin 7 WP
- A0 (pin 1), A1 (pin 2), A2 (pin 3)
- I2C2_SCL, I2C2_SDA
- SW1: SW1_A0, SW1_A1, SW1_A3 — SW DIP-2
- Resistors: R65, R66 (5.6K 5%), R67, R68, R69 (4.75K)
- R72 4.75K
- C41 0.1uF
- VDD_3V3, DGND
- TP1 — T POINT A
- TP2 — T POINT A

Title: BeagleBone LCD3 Cape BUFFER

Size: B

Document Number: BB-BONE-LCD3-01

Rev: A2

Date: Wednesday, July 25, 2012   Sheet 3 of 4

62684-5521N0ALF

LED-
LED+

2,3
2
2
2
RESET
SPI_CS
SPI_CLK
SPI_MOSI

3 BBLU0
3 BBLU1
3 BBLU2
3 BBLU3
3 BBLU4

3 BGRN0
3 BGRN1
3 BGRN2
3 BGRN3
3 BGRN4
3 BGRN5

3 BRED0
3 BRED1
3 BRED2
3 BRED3
3 BRED4
3 BHSYNC
3 BVSYNC
3 BPCLK

VDD_3V3   VDD_3V3

C13
10uF,10V

DGND

3   BEN

J4

2 AIN3
R74 0,DNI   Bottom
R75
0
2 AIN2
R76 0,DNI   Top
R77
0

2 AIN0
R78 0,DNI   left
R79
0
2 AIN1
R84 0,DNI   right
R85
0

right
Bottom
left
Top

DGND

BACKLIGHT SUPPLY

VDD_5V
SYS_5V   R132
2   0,DNI
2   0   1
R133

C38
4.7uF, 25V

R123 0R, DNI
2   EHRPWM1A

VDD_3V3EXP

R125
0R, DNI
R139
10K

C23 1 2 0.1uF
VDD_3V3EXP

DGND

U6
NC VCC
A   GND Y
SN74LVC1G06DCK
DGND

Q3
G   D
S
BSS138
DGND

R120
10R
R124
6.8K
C39
47nF, DNI

R129
100K, DNI
DGND

R126
0R
R127
0R

DGND

DGND

L2
BL_L   4.7uH   BL_SW
U5
L   SW
VIN
EN   OUT
SS   THERMAL
FSW FB
GND PGND
TPS61080DRC

R128
0R, DNI
DGND

B_LED+
B_LED-

R130
2R
C40
4.7uF, 25V
DGND

2   BL+   R131 10, DNI   LED+
B_LED+ R135
0   1
2   BL-   R134 10, DNI   LED-
B_LED- R136
0   1

VDD_3V3EXP   VDD_3V3

VDD_3V3EXP needs to be tied to VDD_3V3. A deadbug
wire is added on PCB assembly.

beagleboardtoys.com

1380 Presidential Dr.
#100
Richardson, TX 75081
www.beagleboardtoys.com

Title
BeagleBone LCD3 Cape   LCD&TOUCH INTERFACE

Size
B
Document Number
BB-BONE-LCD3-01
Rev
A2

Date: Tuesday, October 09, 2012   Sheet   4   of   4