Android WiFi定頻軟體



Matt Chang 2015/09/23



• 因為wifi test tool要有額外的config才能正常運作,所以需要在init.xxx.rc(跟wpa_supplicant放在一起)中加入以下的config...

```
on property:sys.wifi.on=*
start xx wifi test
```

```
service xx_wifi_test /system/bin/xx_wifi.sh
disabled
oneshot
```



xx_wifi.sh

```
#!/system/bin/sh
load=`getprop sys.wifi.on`
if [ "$load" == 1 ];then
        echo "loading ssv6051" > /dev/kmsg
        insmod Path_To_WiFi_Ko
        sleep 2;
        busybox ifconfig wlan0 up
else
        echo "unloading ssv6051" > /dev/kmsg
        busybox ifconfig wlan0 down
        sleep 1;
        rmmod WiFi_Interface_Name
fi
```



Install

- adb remount
- adb wait-for-device
- adb install iCommTool.apk
- adb push xx_wifi.sh /system/bin/xx_wifi.sh
- adb shell chmod 777 /system/bin/xx_wifi.sh
- adb shell sync



	····WiST1	VERGUON					
iCom	nmWifiTool	VERSION					
	ТХ	RX					
REF CLK (N	MHz):	TX OFF					
Channel:	1 (2412 MHz)						
Mode:	11b						
Rate:	1 Mbps						
DAC:	0 (no offset)						
IQ Phase:	IQ Amp: 0						
Freq Offset: 0							



Enable Register Table

● 右上角VERSION旁邊按一下, pw: qaz123






Reopen app





Version





Disable Register Table

· 輸入空白, 重開app即可

								c			
*** iCommWifiTool											
TX			RX			REGTABLE					
REF CLK (M	1Hz):							TX OFF			
Channel:	1 (2412 MHz)										
Mode:	11b		CANCEL		▶ ок						
Rate:	1 Mbps										
DAC:	0 (no offset)										
IQ Phase: O IQ Amp: O O											
Freq Offset: 0 0											
q	w	е	r	t	y u	i	0	р			
	a s	d	f	g	h	j	k				
· ·	z	х	С	V	b	n	m	OEL (X)			
	英文	2123						完成			

Android Service Modification

```
以A33為例:
在init.sun8i.rc中,
service p2p_supplicant /system/bin/wpa_supplicant \
  -iwlan0 -Dnl80211 -c/data/misc/wifi/wpa_supplicant.conf \
  -e/data/misc/wifi/entropy.bin \
  -O/data/misc/wifi/sockets \
  -g@android:wpa_wlan0 -N \
  -ip2p0 -Dnl80211 -c/data/misc/wifi/p2p_supplicant.conf
  class main
  socket wpa_wlan0 dgram 660 wifi wifi
  disabled
  oneshot
on property:sys.wifi.on=*
start a33 wifi test
service a33_wifi_test /system/bin/a33_wifi.sh
    disabled
```

oneshot



a33_wifi.sh

```
#!/system/bin/sh
load=`getprop sys.wifi.on`
if [ "$load" == 1 ];then
        echo "loading ssv6051" > /dev/kmsg
        insmod /system/vendor/modules/ssv6051.ko
        sleep 2;
        busybox ifconfig wlan0 up
else
        echo "unloading ssv6051" > /dev/kmsg
        busybox ifconfig wlan0 down
        sleep 1;
        rmmod ssv6051
fi
```



Install - A33

- adb remount
- adb wait-for-device
- adb install iCommTool.apk
- adb push a33_wifi.sh /system/bin/a33_wifi.sh
- adb shell chmod 777 /system/bin/a33_wifi.sh
- adb shell sync