

1.

List 5 common issues users face with USB keyboards or mice on laptops, and write one possible solution for each.

ANS:-

Common USB Keyboard or Mouse Issues

Issue	Possible Solution
1. Keyboard or mouse is not detected	Unplug the USB device and connect it to another USB port.
2. Keyboard or mouse stops responding	Restart the laptop and reconnect the device.
3. Some keys or mouse buttons do not work	Clean the device and check for physical damage; try another keyboard or mouse to confirm the problem.
4. USB device driver has a problem	Open Device Manager , find the keyboard/mouse, and update or reinstall its driver.

2.

Simulate a troubleshooting flow: Your Bluetooth headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.

ANS:-

1. Turn on the Bluetooth headphones and check that the **power indicator** is on.
2. Put the headphones into **Bluetooth pairing mode**. Usually, the Bluetooth light starts flashing.
3. On the phone, open **Settings** → **Bluetooth** and turn Bluetooth **ON**.
4. Check the list of available devices and look for the headphone name.
5. Tap the headphone name and select **Pair/Connect**.
6. If the headphones are already listed but not connecting, tap the device and choose **Forget/Unpair**.
7. Turn Bluetooth off and on again on the phone.
8. Turn the headphones off and back on, then enter pairing mode again.
9. Make sure the headphones are not already connected to another nearby phone, laptop, or tablet.
10. Check the headphone battery level and charge them if necessary.
11. Restart the phone and try pairing again.
12. If they still do not connect, reset the headphones according to their instructions and repeat the pairing process.

3.

A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem. Hint: Consider device manager, privacy settings, and app permissions.

ANS:-

- Check the USB connection: Disconnect and reconnect the webcam. Try another USB port and check whether the webcam's indicator light turns on.
- Check Device Manager: Right-click Start → Device Manager → Cameras/Imaging devices. Check whether the webcam appears. Update or reinstall its driver if necessary.
- Check Windows privacy settings: Go to Settings → Privacy → Camera and make sure Allow access to the camera on this device is enabled.
- Allow app access: In the same Camera privacy settings, enable Allow apps to access your camera and allow desktop apps to access the camera.
- Check Zoom's camera selection: Open Zoom → Settings → Video and select the external webcam from the camera drop-down list.
- Close other apps using the webcam: Close applications such as Microsoft Teams, Skype, or the Windows Camera app, then restart Zoom and test the webcam again.

4.

You are helping a friend whose printer is showing 'offline' status on their PC. Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.

ANS:-

Using Windows Troubleshooter for an Offline Printer

1. Click **Start → Settings → Devices → Printers & scanners**.
2. Select the printer that is showing **Offline**.
3. Click **Manage** and look for the Windows troubleshooting option.
4. Run the **Printer Troubleshooter**.
5. Windows checks common problems such as printer connection, printer status, driver issues, print spooler problems, and configuration errors.
6. Follow the recommended fixes provided by the troubleshooter.
7. If Windows finds a problem, it displays information about the problem and may automatically apply a fix.
8. After troubleshooting, print a **test page** to check whether the printer is working.