
实验一: 机器人运动学模型建立

1. 实验目的

本实验介绍如何使用 matlab 工具箱(RTB 工具箱 10.3)建立机器人模型, 并对其进行绘制。

2. 实验内容

以如下三轴机械臂模型为例(三轴的明白了,其他的也就会了),如下图所示该模型具有三个转动关节:



要求:利用机器人学中的相关知识,使用 DH 法建立连杆坐标系,使用机器人工具箱建立如上的机械臂模型。

D-H参数表

i	a _(i-1)	α(i-1)	d_i	Θ_i
1	0	0	a ₀	$\theta_1(0)$
2	0	-90	d	$\theta_2(0)$
3	0	90	a ₁	$\theta_3(0)$

3. 重要函数学习

1、Link 类函数

Link 类函数,基于 DH 法建模,建立其相关关系,DH 法建模分改进型和标准型,Link 类函数的一种用法是 R = Link([theta,d,a,alpha]),其中参数 theta 代表 DH 建模的关节角、参数 d 代表 DH 建模的连杆偏距、参数 a 代表 DH 建模的连杆长度、参数 alpha 代表 DH 建模的连杆转角。例如:

- L(1)=Link([1,2,3,4], 'modified'), 其中 modified 表示用改进型 DH 法建模:
 - (1) 我们在命令行窗口输入上面的例子

(2) Link 类函数中包含一些属性,我们可以用像调用 c/c++语言里面的结构体成员类似的方法去调用它,如下所示:

R.RP:可以用来获取连杆关节类型,如下所示我们可以知道我们建立的 L(1) 是转动关节 (若为 P 则为移动关节)

R. theta:可以用来获取连杆关节角:,如下所示我们可以知道我们建立的 L(1) 的关节角为 1

R. d:可以用来获取连杆偏距:,如下所示我们可以知道我们建立的 L(1)的连杆偏距为 2

R. a:可以用来获取连杆长度:,如下所示我们可以知道我们建立的 L(1)的连杆长度为 3

R.alpha:可以用来获取连杆扭转角:,如下所示我们可以知道我们建立的 L(1) 的连杆扭转角为 4

R.sigma:也可以用来查询我们建立的是转动关节还是移动关节,默认 0 是转动关节; 1 是移动关节,如下所示我们可以知道我们建立的 L(1)为转动关节

R.mdh:可以用来查询我们是按照标准 DH 法建立的还是按改进型 DH 法建

立的模型, 默认 0 为标准 D.H 法, 1 为改进 D-H 法, 如下所示我们可以知道我们是按照改进型 DH 法建立的 L(1)

```
1 L(1).mdh
```

2、Seriallink 类函数

Seriallink 类函数可以把我们使用 Link 函数建立的连杆连成一个整体,生成一个串联机械臂,比如下面这个例子,我们已经使用 Link 函数建立好了 L(1)~L(6)这六个关节模型,然后我们只需要使用:

Six Link=SerialLink([L(1),L(2),L(3),L(4),L(5),L(6)]);

就可以将其连成一个整体生成一个六周的串联机械臂,并取名为 Six_Link (名字可以任意取)

```
1 L(1)=Link([0,0,0,0],'modified');
2 L(2)=Link([1.25,pi/2,0,pi/2],'modified');
3 L(3)=Link([10.5,0,0,pi/2],'modified');
4 L(4)=Link([0,pi/2,13,-pi],'modified');
5 L(5)=Link([0,pi/2,0,-pi],'modified');
6 L(6)=Link([0,pi/2,10,-pi],'modified');
7 Six_Link=SerialLink ([L(1),L(2),L(3),L(4),L(5),L(6)]);
```

在命令行窗口输入 help Seriallink 会发现 Seriallink 类函数有很多可以设置的参数,在这里只针对一小部分进行介绍

①只读参数: 关节自由度 n、机械臂配置字符串 config、DH 约定形式布尔值 mdh 、DH 参数 theta、d、a、alpha

```
1
   Properties (read only)::
2
3
                   number of joints
                   joint configuration string, eg. 'RRRRRR'
      config
4
5
      mdh
                   kinematic convention boolean (0=DH, 1=MDH)
                   kinematic: joint angles (1xN)
6
      theta
7
                   kinematic: link offsets (1xN)
                   kinematic: link lengths (1xN)
8
                   kinematic: link twists (1xN)
9
      alpha
```

他们的使用方法很简单,比如我们已经按上面建立好了一个机械臂模型 Six_Link,要查看当前关节的自由度,只需要使用 Six_Link.n 就可以了,如下所示:

```
>> Six_Link.n
ans =
```

要查看当前各个关节的类型,只需要使用 Six_Link.config 就可以了,如下所示,可以知道我们建立的六轴机械臂各个关节均为转动关节:

```
>> Six_Link.config
ans =
   'RRRRRR'
```

②可读可写参数: 连杆对象的矢量 links 、重力方向 gravity 、机器人基座的 姿态 base 、 机器人工具坐标系转换 tool 、关节极限 qlim 、运动关节坐标偏移 offset、机器人的名称 (用于图形显示) name 、注释 manuf 和 comment、plot()方 法的选项(单元格数组)plotopt 、使用 MEX 版本的 RNE (只有当 mex 文件存在 时才能设置为 true。默认为 true)fast

```
Properties (read/write)::
 2
                  vector of Link objects (1xN)
 3
       links
 4
       gravity
                  direction of gravity [gx gy gz]
 5
       base
                  pose of robot's base (4x4 homog xform)
 6
       tool
                  robot's tool transform, T6 to tool tip (4x4 homog xform)
 7
                  joint limits, [qmin qmax] (Nx2)
       qlim
                  kinematic joint coordinate offsets (Nx1)
 8
       offset
9
                  name of robot, used for graphical display
       name
10
       manuf
                  annotation, manufacturer's name
11
       comment
                  annotation, general comment
12
                  options for plot() method (cell array)
       plotopt
       fast
                  use MEX version of RNE. Can only be set true if the mex
13
14
                  file exists. Default is true.
```

比如要查看当前各个关节连杆情况,只需要使用 Six_Link.links 就可以了,如下所示:

```
>> Six_Link. links
ans =
                            0, alpha=
                                         0, offset=
                                                          0 (R, modDH)
theta=q1, d=
               0, a=
theta=q2, d= 1.571, a=
                              0, alpha=
                                        1.571, offset=
                                                                0 (R, modDH)
              0, a=
                              0, alpha=
                                          1.571, offset=
                                                               0 (R, modDH)
theta=q3, d=
theta=q4, d= 1.571, a=
                             13, alpha=
                                           -3.142, offset=
                                                                0 (R, modDH)
             1.571, a=
theta=q5, d=
                                                                0 (R, modDH)
                              0, alpha= -3.142, offset=
                                                                0 (R, modDH)
theta=q6, d=
               1.571, a=
                             10, alpha=
                                           -3.142, offset=
```

比如要查看当前机器人基座的姿态,只需要使用 Six_Link.base 就可以了,如下所示:

③Seriallink 类函数中的一些方法或者函数,本部分不做详细介绍,有兴趣的可自行研究,比如显示机器人的图形表示的 plot、显示机器人的三维图形模型 plot3d (只能用于标准 DH 建模)、teach、关节空间轨迹 jtraj 等

```
1 | SerialLink Serial-link robot class
 2
 3
      A concrete class that represents a serial-link arm-type robot. The
 4
      mechanism is described using Denavit-Hartenberg parameters, one set
 5
      per joint.
 6
 7
      Methods::
 8
 9
                     display graphical representation of robot
      plot
10
      plot3d
                    display 3D graphical model of robot
11
       teach
                    drive the graphical robot
                    get position of graphical robot
12
       getpos
13
14
       jtraj
                     a joint space trajectory
15
16
       edit
                     display and edit kinematic and dynamic parameters
17
       isspherical test if robot has spherical wrist
18
                  test if robot at joint limit
19
       islimit
20
       isconfig
                    test robot joint configuration
21
22
       fkine
                     forward kinematics
23
                     link transforms
                    forward kinematics as a chain of elementary transforms
24
       trchain
26
       ikine6s
                     inverse kinematics for 6-axis spherical wrist revolute robot
27
       ikine
                     inverse kinematics using iterative numerical method
28
       ikunc
                     inverse kinematics using optimisation
       ikcon
                     inverse kinematics using optimisation with joint limits
30
       ikine sym
                     analytic inverse kinematics obtained symbolically
31
32
       jacob0
                     Jacobian matrix in world frame
33
       jacobn
                     Jacobian matrix in tool frame
34
       jacob_dot
                     Jacobian derivative
       maniplty
                    manipulability
36
       vellipse
                    display velocity ellipsoid
37
       fellipse
                    display force ellipsoid
38
       gmincon
                    null space motion to centre joints between limits
39
40
                     joint acceleration
41
       coriolis
                     Coriolis joint force
42
                     show dynamic properties of links
43
       friction
                    friction force
44
       gravload
                    gravity joint force
45
       inertia
                     joint inertia matrix
46
       cinertia
                    Cartesian inertia matrix
47
       nofriction
                     set friction parameters to zero
48
                    inverse dynamics
49
       fdyn
                    forward dynamics
50
51
       payload
                    add a payload in end-effector frame
52
       perturb
                    randomly perturb link dynamic parameters
53
                    gravity load and Jacobian
       gravjac
54
                    payload capacity
       paycap
55
                     payload effect
       pay
56
57
                    a symbolic version of the object
       gencoords symbolic generalized coordinates
58
```