Conservation of Angular Momentum & Turbomachinery Torque

Moment balance about strategic reduction centers x_0, elimination of unknown reactions, and Euler's fundamental turbomachinery equation.

OFFICIAL MATERIAL Notes.pdf · p. 35

1. The Master Angular Momentum Equation

In continuum mechanics, the moment of momentum (angular momentum) of a closed material fluid system $V_f(t)$ about an arbitrary fixed point in space x_0 changes at a rate equal to the resultant external moment acting on the fluid:

$$\frac{d}{dt}\left[\int_{V_f(t)} \rho[(x-x_0)\times v]\,dV\right] = \sum M_{x_0,\text{ext}}$$

[Eq. 3.37] Angular momentum principle for a material fluid volume.

Substituting intensive angular momentum $b=(x-x_0)\times v$ into the universal Reynolds Transport Theorem yields the **Master Integral Angular Momentum Equation** for any moving control volume $V_c(t)$:

$$\mathbf{\frac{d}{dt}\left[\int_{V_c(t)} \rho[(x-x_0)\times v]\,dV\right] + \int_{\Sigma_c(t)} \rho[(x-x_0)\times v][(v-v_c)\cdot n]\,d\sigma = \sum M_{x_0,\text{ext}}}$$

[Eq. 3.38] Universal Integral Angular Momentum Conservation Equation.

The external moments $\sum M_{x_0,\text{ext}}$ consist of pressure forces, viscous shear forces, body forces (e.g., gravity), and mechanical holding torques applied by shaft couplings or mounting flanges:

$$\sum M_{x_0,\text{ext}} = -\int_{\Sigma_c}(x-x_0)\times(pn)\,d\sigma + \int_{\Sigma_c}(x-x_0)\times(\bar{\bar{\tau}}'\cdot n)\,d\sigma + \int_{V_c}\rho(x-x_0)\times f_m\,dV + \mathcal{M}_{\text{shaft}}$$

Angular Momentum: Complete Derivation Chain (Notes.pdf, Eqs. 3.37-3.38)

Step 1: Angular momentum of a fluid volume (Eq. 3.37)

Let $r = x - x_0$, with x_0 a fixed point of an inertial frame. A fluid particle of mass $\rho\, dV$ has angular momentum $r \wedge \rho v\, dV$ about x_0 (Notes, p. 33), so the angular momentum of the fluid volume is $\int_{V_f} \rho\, r \wedge v\, dV$. Newton's second law for angular momentum states that its rate of change equals the moment of the external forces about x_0. The moment of the surface force $\bar{\bar{\tau}} \cdot n\, d\sigma$ on each element of the boundary and the moment of the body force $\rho f_m\, dV$ on each particle give Eq. 3.37:

$$\frac{d}{dt}\int_{V_f(t)} \rho\, r \wedge v\, dV = \int_{\Sigma_f(t)} r \wedge (\bar{\bar{\tau}} \cdot n)\, d\sigma + \int_{V_f(t)} \rho\, r \wedge f_m\, dV$$

Eq. 3.37

Step 2: Consistency with the local momentum equation (extension)

Extension, not in the Notes. For a fluid particle the mass $\rho\, dV$ is constant and $Dr/Dt = v$ because x_0 is fixed. The product rule gives

$$\frac{D}{Dt}\big[r \wedge \rho v\, dV\big] = \big[v \wedge v + r \wedge \frac{Dv}{Dt}\big]\rho\, dV = r \wedge \rho\frac{Dv}{Dt}\, dV$$

since $v \wedge v = 0$. Insert Cauchy's equation (Eq. 3.25), $\rho Dv/Dt = \nabla \cdot \bar{\bar{\tau}} + \rho f_m$, and integrate over the volume:

$$\frac{d}{dt}\int_{V_f} \rho\, r \wedge v\, dV = \int_{V_f} r \wedge (\nabla \cdot \bar{\bar{\tau}})\, dV + \int_{V_f} \rho\, r \wedge f_m\, dV$$

It remains to show that the first integral on the right equals the surface integral of Eq. 3.37. With the permutation symbol ϵ_{kij}, component k of the integrand is $\epsilon_{kij} r_i\, \partial\tau_{lj}/\partial x_l$. The product rule and $\partial r_i/\partial x_l = \delta_{il}$ give

$$\epsilon_{kij}\, r_i \frac{\partial \tau_{lj}}{\partial x_l} = \frac{\partial}{\partial x_l}\big(\epsilon_{kij} r_i \tau_{lj}\big) - \epsilon_{kij}\, \tau_{ij}$$

The last term vanishes because ϵ_{kij} is antisymmetric in (i, j) and τ_{ij} is symmetric (Eq. 3.19). Gauss' theorem on the first term, together with $\tau_{lj} n_l = \tau_{jl} n_l = (\bar{\bar{\tau}} \cdot n)_j$, gives

$$\int_V r \wedge (\nabla \cdot \bar{\bar{\tau}})\, dV = \int_\Sigma r \wedge (\bar{\bar{\tau}} \cdot n)\, d\sigma$$

which shows that linear momentum together with a symmetric stress tensor is equivalent to Eq. 3.37. The symmetry of the stress tensor is exactly the condition that makes both statements agree. Note that this is not a derivation of Eq. 3.37 from linear momentum alone: in Notes.pdf (pp. 29-30) the symmetry of $\bar{\bar{\tau}}$ (Eq. 3.19) is itself obtained from angular momentum, so the argument would be circular if read that way.

Step 3: Transfer to a moving control volume (Eq. 3.38)

Apply Eq. 3.8 with the density $\phi = \rho\, r \wedge v$, evaluate the right-hand side of Eq. 3.37 on Σ_c, V_c (coincident with Σ_f, V_f at the instant considered) and split the stress with Eq. 3.28. Since $r \wedge \left((-p\bar{\bar{I}}) \cdot n\right) = -r \wedge (pn)$:

$$\frac{d}{dt}\int_{V_c} \rho\, r \wedge v\, dV + \int_{\Sigma_c} \rho\, (r \wedge v)\big[(v - v_c) \cdot n\big]\, d\sigma = -\int_{\Sigma_c} r \wedge (pn)\, d\sigma + \int_{\Sigma_c} r \wedge (\bar{\bar{\tau}}' \cdot n)\, d\sigma + \int_{V_c} \rho\, r \wedge f_m\, dV$$

Eq. 3.38

Because x_0 is fixed, r is not differentiated in the control-volume term; the point x_0 may be placed anywhere, and the choice is a matter of convenience.

Step 4: Uniform ports and the pivot rule (extension)

Extension, not in the Notes. If a port A_k is small compared with its distance to x_0, then $r \approx r_k$ is constant over the port. With uniform ρ_k, v_k normal to the port and a fixed volume,

$$\int_{A_k} \rho\, (r \wedge v)(v \cdot n)\, d\sigma \approx r_k \wedge \Big[\int_{A_k} \rho v (v \cdot n)\, d\sigma\Big] = \dot{m}_k\, r_k \wedge v_k$$

For steady flow the equation reduces to $\sum_k \dot{m}_k\, r_k \wedge v_k = \sum M_{x_0}$, with $\dot{m}_k$ negative at inlets. An unknown reaction force R applied at the point x_R contributes the moment $(x_R - x_0) \wedge R$, which is zero if $x_0 = x_R$ (or if x_0 lies on the line of action of R). This is the pivot rule.

Step 5: Euler turbomachinery equation (every step)

Extension, not in the Notes. Take a fixed annular control volume around the rotor axis z, with an inlet cylinder $r = r_1$ (normal $-e_r$) and an outlet cylinder $r = r_2$ (normal $+e_r$), with x_0 on the axis. The flow is periodic and is treated as steady and axisymmetric on average, with ρ, v_r, v_θ uniform on each cylinder. The end walls are impermeable. The z component of the angular momentum per unit mass follows from $r = re_r + ze_z$ and $v = v_r e_r + v_\theta e_\theta + v_z e_z$:

$$(r \wedge v)_z = r\, v_\theta$$

Convective flux in the z component of Eq. 3.38. On the outlet $v \cdot n = +v_r$ and on the inlet $v \cdot n = -v_r$. The mass flow through each cylinder is the same, $\dot m = \int \rho v_r \, d\sigma$, by Eq. 3.11 in steady flow:

$$\int_{\Sigma_0} \rho\,(r v_\theta)(v \cdot n)\, d\sigma = r_2 v_{\theta 2}\, \dot m - r_1 v_{\theta 1}\, \dot m = \dot m\,(r_2 v_{\theta 2} - r_1 v_{\theta 1})$$

Moments on the right-hand side. A pressure force on a cylinder of constant r is $\mp p\, e_r \, d\sigma$, and $(r e_r + z e_z) \wedge e_r = z\, e_z \wedge e_r = z\, e_\theta$, which has no z component. On the end walls the force is along $\pm e_z$ and $r e_r \wedge e_z = -r e_\theta$, again with no z component. Viscous stresses on the ports and the moment of the body force about the axis are neglected. The only remaining moment is the moment M_z exerted by the blades (solid surfaces inside the volume) on the fluid:

$$M_z = \dot m\,(r_2 v_{\theta 2} - r_1 v_{\theta 1})$$

Here M_z is the torque exerted by the rotor on the fluid. The torque exerted by the fluid on the rotor is $-M_z$ (Newton's third law). Each blade point moves with velocity $\Omega r\, e_\theta$, so the power transmitted to the fluid is ΩM_z and the work per unit mass is

$$w_{\text{Euler}} = \frac{\Omega M_z}{\dot m} = u_2 v_{\theta 2} - u_1 v_{\theta 1}, \qquad u = \Omega r$$

Dimensional check: $[\dot m\, r\, v_\theta] = \mathrm{kg\,s^{-1}\,m\,m\,s^{-1}} = \mathrm{N\,m}$ and $[u\, v_\theta] = \mathrm{m^2/s^2} = \mathrm{J/kg}$.

2. Strategic Pivot Selection Strategy

In many exam problems (such as pipe elbows, nozzle mounts, and rotating sprinklers), several complex linear reaction forces R act at physical supports, bearings, or hinges. Solving for these linear reaction forces simultaneously with moments can be tedious and prone to algebraic errors.

> **THE STRATEGIC PIVOT RULE**
> Always place the reference reduction point x_0 **directly at the support hinge, bearing axis, or bolt circle** where unknown linear reaction forces act!

> Because the position vector from x_0 to the reaction point is zero ($r = x - x_0 = 0$), the moment arm is zero: $r \times R = 0$. The unknown linear reaction forces **completely vanish from the moment balance**, allowing direct solution for holding torque or shaft power in a single line!

1D Streams Approximation

For discrete 1D inlets and outlets with mass flow rates $\dot{m}_i$, position vectors $r_i = x_i - x_0$, and mean velocities v_i, steady angular momentum reduces to:

$$\sum_j \dot{m}_{\text{out},j}(r_{\text{out},j} \times v_{\text{out},j}) - \sum_k \dot{m}_{\text{in},k}(r_{\text{in},k} \times v_{\text{in},k}) = \sum M_{x_0,\text{ext}}$$

CANONICAL WALKTHROUGH 1 · CL3 & CL15 SETUP

Holding Torque on an Offset Pipe Bend / Mixing Elbow

Physical Setup: Consider a horizontal planar pipe bend in the xy-plane. Water enters at inlet 1 located at $r_1 = (0, -L_1, 0)$ flowing in $+y$ direction with speed v_1, area A_1, and gauge pressure p_{g1}. It is deflected through 90° and exits at $r_2 = (L_2, 0, 0)$ discharging in $+x$ direction with speed v_2, area A_2, at atmospheric pressure ($p_{g2} = 0$). Mass flow rate is $\dot{m} = \rho A_1 v_1$.

The pipe is anchored to a central mounting hub at the origin $x_0 = (0, 0, 0)$. Determine the holding torque $\mathcal{M}_0 = \mathcal{M}_z \hat{k}$ that the support must exert to prevent the elbow from spinning.

1 Angular Momentum Fluxes

Compute the convective angular momentum cross-products about $x_0 = 0$:

- **Inlet flux:** Position $r_1 = -L_1 \hat{j}$, velocity $v_1 = v_1 \hat{j}$.

$$r_1 \times v_1 = (-L_1 \hat{j}) \times (v_1 \hat{j}) = 0 \qquad \text{(parallel vectors!)}$$

- **Outlet flux:** Position $r_2 = L_2 \hat{i}$, velocity $v_2 = v_2 \hat{i}$.

$$r_2 \times v_2 = (L_2 \hat{i}) \times (v_2 \hat{i}) = 0 \qquad \text{(parallel vectors!)}$$

Thus, in this symmetric offset orientation, the convective angular momentum flux is zero! What creates the torque?

2 Moments of External Pressure Forces

Evaluate moments of surface gauge pressure forces:

- **Inlet pressure force:** Pushes inward ($+y$): $F_{p1} = p_{g1} A_1 \hat{j}$.

$$r_1 \times F_{p1} = (-L_1 \hat{j}) \times (p_{g1} A_1 \hat{j}) = 0$$

- **Outlet pressure force:** Zero because $p_{g2} = 0$ (atmospheric).

General Offset Case: Now suppose the exit is offset by a moment arm d from the x-axis, so $r_2 = L_2 \hat{i} + d\hat{j}$.

Then $r_2 \times v_2 = (L_2 \hat{i} + d\hat{j}) \times (v_2 \hat{i}) = -d v_2 \hat{k}$.

The angular momentum balance yields:

$$\dot{m}(-d v_2 \hat{k}) = \mathcal{M}_{\text{anchor}} \implies \mathcal{M}_{\text{anchor}} = \boxed{-\dot{\mathbf{m}} \mathbf{d} \mathbf{v_2} \hat{\mathbf{k}}}$$

The anchor must apply a clockwise holding torque of magnitude $\dot{m} d v_2$ to resist the jet's reaction moment!

CANONICAL WALKTHROUGH 2 · TURBOMACHINERY PRINCIPLE

Euler's Turbomachinery Equation (Rotor Shaft Power)

Problem: A centrifugal compressor or pump rotor rotates at steady angular velocity $\Omega = \Omega \hat{e}_z$. Fluid of density ρ enters at inner radius r_1 with mass flow rate $\dot{m}$ and tangential velocity component $v_{\theta 1}$, and exits at outer radius r_2 with tangential velocity component $v_{\theta 2}$. Determine the torque M_z and shaft power $\dot{W}_{\text{shaft}}$ transmitted from the impeller to the fluid.

Derivation Angular Momentum Balance about Axis of Rotation

Select a fixed cylindrical control volume enclosing the rotating impeller. In cylindrical coordinates (r, θ, z), position vectors from the axis are $r_1 = r_1 \hat{e}_r$ and $r_2 = r_2 \hat{e}_r$.

The cross product of radius with velocity $v = v_r\hat{e}_r + v_\theta\hat{e}_\theta + v_z\hat{e}_z$ isolates the tangential velocity component:

$$r \times v = (r\hat{e}_r) \times (v_r\hat{e}_r + v_\theta\hat{e}_\theta + v_z\hat{e}_z) = rv_\theta\hat{e}_z - rv_z\hat{e}_\theta$$

Projecting onto the axis of rotation z, the angular momentum per unit mass is simply rv_θ.

For steady flow, the net torque M_z exerted by the rotor blades on the fluid equals the net outflow of angular momentum:

$$\mathbf{M_z = \dot{m}(r_2 v_{\theta 2} - r_1 v_{\theta 1})}$$

Multiplying torque by rotor angular speed Ω gives the shaft mechanical power $\dot{W}_{\text{shaft}}$ delivered to the fluid:

$$\dot{W}_{\text{shaft}} = \Omega M_z = \dot{m}(\Omega r_2 v_{\theta 2} - \Omega r_1 v_{\theta 1})$$

Defining blade peripheral speeds $u_1 = \Omega r_1$ and $u_2 = \Omega r_2$, we obtain the celebrated **Euler Turbomachinery Equation**:

$$\mathbf{w_{\text{Euler}} = \frac{\dot{W}_{\text{shaft}}}{\dot{m}} = u_2 v_{\theta 2} - u_1 v_{\theta 1}}$$

PUMPS VS TURBINES SIGN INTERPRETATION

- **Pumps, Fans, and Compressors ($w_{\text{Euler}} > 0$):** The impeller increases the fluid's whirl ($u_2 v_{\theta 2} > u_1 v_{\theta 1}$). Mechanical shaft work is consumed to raise fluid pressure and stagnation enthalpy.
- **Turbines ($w_{\text{Euler}} < 0$):** The fluid enters with high swirl created by stationary guide vanes/nozzles and leaves with reduced tangential velocity ($u_2 v_{\theta 2} < u_1 v_{\theta 1}$). Fluid delivers mechanical shaft work to drive aircraft generators or compressor spools!

← 3.3 Linear Momentum

Topic 3 Hub

Next: 3.5 Total Energy →

Study notes written from the official course material (Notes.pdf · p. 35). Online version: subjects/fluid-mechanics/teoria/topic-3-4-angular-momentum.html