

TABLE C.5.1-J14.0. J14.0 to Link 11/11B Message Translation Tree (Sheet 1 of 5)

TEST NODE DIAGRAM	TEST NODE CONDITION	NOTES
<pre> graph TD 1[1] -- Y --> 2[2] 1 -- N --> 3[3] 2 -- Y --> 3 2 -- N --> 4[4] 3 -- Y --> 4 3 -- N --> 5[5] 4 -- Y --> 5 4 -- N --> 6[6] 5 -- Y --> 6 5 -- N --> 7[7] 6 -- Y --> 7 6 -- N --> 8[8] 7 -- Y --> 8 7 -- N --> 9[9] 8 -- Y --> 9 8 -- N --> 10[10] 9 -- Y --> 10 9 -- N --> 11[11] </pre>	1. FIX OR BEARING DESCRIPTOR (F/B) = 6 OR TN, REFERENCE/INDEX NUMBER INDICATOR = 1. 2. F/B = 4. 3. BEARING ORIGIN = 1. 4. F/B = 1. 5. AREA MAJOR AXIS, AREA MINOR AXIS OR SQUARE/CIRCLE SWITCH = NO STATEMENT OR UNDEFINED. 6. COURSE OR SPEED = NO STATEMENT. 7. F/B = 5. 8. F/B = 0. 9. PARAMETER SOURCE = 3 OR 4.	
	REQUIRED ACTION	
A A B C D E F G Z Z K K K K K	A. DISCARD MESSAGE. B. FWD M.6A. C. FWD M.9F(AC=0)/M.89F(AC=0). D. FWD M.9F(AC=0)/M.89F(AC=0)/M.9F(AC=1). E. FWD M.6B/M.86B(EV SW=0). F. FWD M.5/M.85. G. GO TO TEST NODE 10. K. GO TO TEST NODE 15. Z. END TRANSLATION.	3 1 2

C-239

MIL-STD-6016B
APPENDIX C

TABLE C.5.1-J14.0. J14.0 to Link 11/11B Message Translation Tree (Sheet 2 of 5)

TEST NODE DIAGRAM	TEST NODE CONDITION	NOTES
<pre> graph TD 10[10] -- N --> 12[12] 10 -- Y --> 11[11] 11 -- N --> 12 11 -- Y --> 13[13] 12 -- N --> 13 12 -- Y --> 13 13 -- N --> 14[14] 13 -- Y --> 13 14 -- N --> 15[15] 14 -- Y --> 15 15 -- N --> 15 15 -- Y --> 15 </pre>	10. J14.0C4 WORD INCLUDED. 11. POLARIZATION, PULSE WIDTH, OR ANTENNA SCAN RATE/PERIOD INDICATOR NOT EQUAL TO 0. 12. FREQUENCY DATA INCLUDED. 13. EMITTER NUMBER INDICATOR = 1. 14. F/B = 0. 15. SPECIAL PROCESSING INDICATOR HAS CHANGED, THIS IS INITIAL REPORT FROM THE DATA SOURCE, OR RESPONSE INDICATOR = 1.	
A H E E E I J J K K K K L M M Z Z Z	REQUIRED ACTION A. DISCARD MESSAGE. E. FWD M.6B/M.86B(EV SW=0). H. FWD M.6C/M.86C. I. FWD M.6C. J. FWD M.6B/M.86B (EV SW=1). K. GO TO TEST NODE 15. L. FWD APPROPRIATE INITIAL SEQUENCE. M. GO TO TEST NODE 12. Z. END TRANSLATION.	3

C-240

APPENDIX C

MIL-STD-6016B

APPENDIX C

TABLE C.5.1-J14.0. J14.0 to Link 11/11B Message Translation Tree (Sheet 3 of 5)

NOTES

1. If both the Frequency, 1 value in the J14.0E0 and the Elevation Angle value in the J14.0C2 are not No Statement, then consecutive M.6A messages shall be forwarded with Switch = 0 and Switch = 1, respectively.
2. The Switch value is set to 0 when Course and Speed are reported as No Statement. The Switch value is set to 1 if Minute and Hour or Altitude, 25 Ft are other than No Statement. If both Switch = 0 and 1 are required, the M.5/M.85(SW=0) shall be immediately followed by an identical M.5, followed by an M.85(SW=1).
3. If an M.6C or an M.6C/M.86C message results with no M.6B being transmitted, the received J14.0 message is discarded and not forwarded.

APPENDIX C

TABLE C.5.1-J14.0. J14.0 to Link 11/11B Message Translation Tree (Sheet 4 of 5)

RELATED MESSAGES

RECEIVED LINK 16
MESSAGE

J14.0

ALL POSSIBLE LINK 11/11B MESSAGES
THAT MAY BE REQUIRED

M.5
M.85
M.6A
M.6B
M.86B
M.6C
M.86C
M.9A
M.9F(0)
M.89F(0)
M.9F(1)

APPENDIX C

TABLE C.5.1-J14.0. J14.0 to Link 11/11B Message Translation Tree (Sheet 5 of 5)

FORWARDING TRANSMIT REQUIREMENTS

1. The M.5 initial sequence shall be transmitted by the FJU once in each of two successive transmission opportunities on Link 11. The M.5 initial sequence shall be transmitted by the FJU at the first transmission opportunity and every transmission opportunity thereafter until the M.9A(AC=0) message is acknowledged on Link 11B.
2. The FJU shall transmit the M.6A, M.6B, or M.6C initial sequence on Link 11B immediately preceded by an M.9A(AC=0) message at the first transmission opportunity and every opportunity thereafter until the M.9A(AC=0) message is acknowledged.
3. The M.5/M.85, M.6A, M.6B/M.86B, M.6C, or the M.6C/M.86C shall be transmitted once in each of two consecutive transmission opportunities on Link 11 and once on Link 11B except as required by rules 1 and 2 above.
4. The FJU shall transmit the M.9F(AC=0)/M.89F(AC=0) or M.9F(AC=0)/M.89F(AC=0)/M.9F(AC=1) initial sequence on Link 11B immediately preceded by an M.9A(AC=0) message at the first transmission opportunity and every transmission opportunity thereafter until the M.9A(AC=0) is acknowledged.
5. The M.9F(AC=0)/M.89F(AC=0) and M.9F(AC=0)/M.89F(AC=0)/M.9F(AC=1) shall be transmitted once in each of two consecutive transmission opportunities, except as required by rule 4 above.

DATA RETENTION RULES

There are no Data Retention Rules associated with this message translation.