

TABLE C.5.1-J5.4. J5.4 to Link 11 Message Translation Tree (Sheet 1 of 5)

TEST NODE DIAGRAM	TEST NODE CONDITION	NOTES
<pre>graph TD 1[1] -- N --> 2[2] 1 -- Y --> 3a[3] 2 -- Y --> 3b[3] 2 -- N --> 3c[3] 3a -- Y --> 3d[3] 3a -- N --> 3e[3] 3b -- Y --> 3f[3] 3b -- N --> 3g[3] 3c -- Y --> 3h[3] 3c -- N --> 3i[3]</pre>	1. THIS IS INITIAL REPORT FROM THE DATA SOURCE. 2. SPECIAL PROCESSING INDICATOR HAS CHANGED. 3. MINUTE OR HOUR OTHER THAN NO STATEMENT.	1
	REQUIRED ACTION	
B A B A C E E E E D E	A. FWD M.4D/M.84D INITIAL SEQUENCE. B. FWD M.4D/M.84D/M.4B INITIAL SEQUENCE. C. FWD M.4D/M.84D SEQUENCE. D. FWD M.4D/M.84D/M.4B SEQUENCE. E. GO TO TEST NODE 4.	

C-160

APPENDIX C

APPENDIX C

TABLE C.5.1-J5.4. J5.4 to Link 11 Message Translation Tree (Sheet 3 of 5)

NOTES

1. The J5.4 message is not forwarded on to Link 11B.
2. If both Emergency and Force Tell Indicators have been set to "on," only the Emergency alert is transmitted on Link 11. Transmission of an initial message sequence is not required if the Force Tell Indicator is changed to "on" and the Emergency alert is already being reported.

APPENDIX C

TABLE C.5.1-J5.4. J5.4 to Link 11 Message Translation Tree (Sheet 4 of 5)

RELATED MESSAGES

RECEIVED LINK 16
MESSAGE

J5.4

ALL POSSIBLE LINK 11 MESSAGES
THAT MAY BE REQUIRED

M.4B

M.4D

M.84D

M.9A(AC=0, 5 OR 7)

APPENDIX C

TABLE C.5.1-J5.4. J5.4 to Link 11 Message Translation Tree (Sheet 5 of 5)

FORWARDING TRANSMIT REQUIREMENTS

1. The FJU shall forward the M.4D/M.84D initial message sequence and if appropriate, the M.4B, on Link 11 once in each of two successive transmission opportunities.
2. The M.4D/M.84D message sequence, and M.4B message if appropriate, shall be forwarded for each subsequent J5.4 message received.
3. If appropriate, the M.9A(AC=0, SI=1) message shall be forwarded once preceding every transmission of a simulated track on Link 11.
4. The M.9A(AC=5) message, if appropriate, shall be forwarded at the same frequency as, and immediately preceding the M.4D message to which it applies. The M.9A(AC=5) shall be transmitted prior to the M.9A(AC=0) if both are appropriate.
5. The M.9A(AC=7) message shall be forwarded once in each of three successive transmission opportunities.

DATA RETENTION RULES

The FJU shall retain the latest reported status of the Emergency and Force Tell Indicators for all J5.4 TNs being forwarded.