

TABLE C.5.1-J7.0. J7.0 to Link 11/11B Message Translation Tree (Sheet 1 of 4)

TEST NODE DIAGRAM		TEST NODE CONDITION	NOTES
<pre> graph TD 1[1] -- Y --> 2[2] 1 -- N --> 5[5] 2 -- Y --> 3[3] 2 -- N --> 5 3 -- Y --> 4[4] 3 -- N --> 5 4 -- Y --> 5 5 -- Y --> 6[6] 5 -- N --> 7[7] 6 -- Y --> 7 6 -- N --> 9[9] 7 -- Y --> 8[8] 7 -- N --> 9 8 -- Y --> 9 9 -- Y --> 10[10] 9 -- N --> 10 10 -- Y --> 10 10 -- N --> 10 </pre>		1. ACTION, TRACK MANAGEMENT = 5, 6, OR 7. 2. ACTION, TRACK MANAGEMENT = 0. 3. IS TN, REFERENCE AN ACTIVE UNIT. 4. IS TN, SOURCE THE CURRENT R2 FOR THE TN, REFERENCE. 5. ACTION, TRACK MANAGEMENT = 1. 6. ACTION, TRACK MANAGEMENT = 2. 7. ENVIRONMENT/CATEGORY = 2 OR 3. 8. CONTROLLING UNIT INDICATOR = 1. 9. ACTION, TRACK MANAGEMENT = 3. 10. ALERT STATUS CHANGE = 1.	1 1 3 2
		REQUIRED ACTION	
A B B A A A C C D E F G F H I J K L Z Z Z Z L Z Z Z Z Z Z Z Z		A. DISCARD MESSAGE. B. FWD M.9A(AC=4). C. DECLARE UNIT INACTIVE IN FJU DATABASE. D. FWD M.9A(AC=1). E. FWD M.9A(AC=2). F. FWD M.9A(AC=5). G. SET EMERGENCY INDICATOR IN DATABASE. H. FWD M.9A(AC=7). I. CLEAR EMERGENCY INDICATOR IN DATABASE. J. SET FORCE TELL INDICATOR IN DATABASE. K. CLEAR FORCE TELL INDICATOR IN DATABASE. L. FWD M.9A(AC=6). Z. END TRANSLATION.	

C-169

APPENDIX C

MIL-STD-6016B

APPENDIX C

TABLE C.5.1-J7.0. J7.0 to Link 11/11B Message Translation Tree (Sheet 2 of 4)

NOTES

1. If the FJU holds local data for the track, the FJU shall assume R^2 for the track rather than forwarding a Drop Track message. If the reference track is a C^2 IU being forwarded on Link 11B, link protocol demands that a Drop Track message be sent to signify inactive status of an interface unit. The latter is true even in those cases where the FJU assumes R^2 for the C^2 IU.
2. Environment/Category of 2 (Air) or 3 (Surface) are the only legal values on Link 11/11B for Information Difference or Change Data Order messages.
3. If the FJU is retaining ID data received in a previous M.9A(AC=1, CI=0) or J7.0 (ACT = 1) message for the same TN, disregard this message.

APPENDIX C

TABLE C.5.1-J7.0. J7.0 to Link 11/11B Message Translation Tree (Sheet 3 of 4)

RELATED MESSAGES

RECEIVED LINK 16
MESSAGE

J7.0

ALL POSSIBLE LINK 11/11B MESSAGES
THAT MAY BE REQUIRED

M.9A(AC=1, 2 OR 4-7)

APPENDIX C

TABLE C.5.1-J7.0. J7.0 to Link 11/11B Message Translation Tree (Sheet 4 of 4)

FORWARDING TRANSMIT REQUIREMENTS

1. A single M.9A(AC=1, 2, or 6) message shall be forwarded for each J7.0 (ACT = 1 or 2) message received.
2. Upon receipt of the J7.0 (ACT = 3 or 4), the M.9A(AC=5 or 7) shall be transmitted in three consecutive transmit opportunities.
3. The M.9A(AC=4) message is transmitted in two consecutive transmit opportunities after receipt of a J7.0 (ACT = 0) message. If the track becomes active, including an R² shift, prior to either of the M.9A(AC=4) messages being transmitted, the M.9A(AC=4) message(s) that would have followed will not be transmitted.

DATA RETENTION RULES

The FJU shall retain ID data received in a J7.0 (ACT = 1) message until the conflict has been resolved by the R² unit or an R² shift occurs.