### Computer Arithmetic

What is the difference between (signed) int and unsigned int?

Pat Hanrahan

cs 107e

### Addition


### Adding 2 1-bit numbers: sum = a + b

- a b sum
- 0 0 00
- 0 1 01
- 1 0 01
- 1 1 10

#### Adding 2 1-bit numbers (Half Adder)

```
a b sum
0 0 00
0 1 01
1 0 01
1 1 10
```

lsb bit 0 of sum: S = a^b
msb 1 of sum: C = a&b



Have reduced addition to logical operations!

```
Carry
00000111 A
+00001011 B
```

Sum

```
1 Carry
00000111 A
+00001011 B
```

0 Sum

```
11 Carry
00000111 A
+00001011 B
-----
10 Sum
```


```
00001111 Carry 00000111 A +00001011 B ----- 00010010 Sum
```

```
abc=cs
00000
0 1 0 0 1
100
      0 1
1 1 0 1 0
0 0 1
      0 1
0 1 1
      1 0
1 0 1 1 0
1 1 1
      1 1
```

### Adding 3 1-bit numbers (Full Adder)

```
a b ci = co s
000 00
0 1 0 0 1
100
1 1 0
001 01
0 1 1 0
                 CIN'
1 0 1 1 0
1 1 1
s = a^b^c
co = (a\&b)|(b\&c)|(c\&a)
```

#### 8-bit Ripple Adder



Note Cin (carry in) and Cout (carry out)


```
// Multiple precision addition
// https://gcc.godbolt.org/z/6TRmY8
uint64 t add64(uint64_t a, uint64_t b)
 return a + b;
add64:
 adds r0, r0, r2
  adc r1, r1, r3
  bx lr
```

#### Binary Addition - Modular Arithmetic

```
1111111 Carry
11111111 A
+00000001 B
-----
100000000 Sum
```

To represent the result of adding two n-bit numbers to full precision requires n+1 bits

```
But we only have 8-bits!
sum = (A+B)%256 = 0b00000000
```



### Gangnam Style overflows INT\_MAX, forces YouTube to go 64-bit

Psy's hit song has been watched an awful lot of times.

PETER BRIGHT - 12/3/2014, 2:32 PM



### Subtraction

BIG IDEA: Define subtraction using addition


A clever way of defining subtraction by 1 is to find a number to add that yields the same result as the subtract by 1.

This number is the *negative* of the number.

More precisely, this number is the number that when added to 1, results in 0 (mod 16)

0x1 - 0x1 = 0x1 + 0xf = 0x10 % 16 = 0x0

Oxf can be interpreted as -1



```
Signed 4-bit numbers,
```

```
0x0 = 0
0xf = -1
0xe = -2
0x8 = -8 (could be interpreted as 8)
0x7 = 7
0x1 = 1
0x0 = 0
```

if we choose to *interpret* 0x8 as -8, then the most-significant bit of the number indicates that it is negative (n)

signed int **vs as** unsigned int

### Are just different interpretations of the bits comprising the number

0xff **vs** -1

### Negation

How do we negate an 8-bit number?

Find a number -x, s.t. (x + (-x)) % 256 = 0

Subtract it from 256 = 2^8 = 100000000

-x = 100000000 - x

Since then (x + (-x)) % 256 = 0

1111111 Borrow 10000000 Carry 100000000 0000001 +1111111 ------

1111111 00000000

Thus the term two's complement

```
Another way to negate
Rewrite 100000000 = (111111111 + 1)
-x = (111111111+1)-x
   = (11111111-x)+1
   = \sim x + 1
Bitwise invert: ~x = 11111111-x (one's complement)
For example, -1
~0000001 = 11111111
           -00000001
            11111110
 11111110 + 00000001 = 11111111
```

Subtraction is converted negation + addition

-B is implemented using ∼B+1

$$A - B = A + \sim B + 1$$

$$01 - 00 = 01 + ff + 01 = 01 + c$$

$$01 - 01 = 01 + fe + 01 = 00 + c$$

$$01 - 02 = 01 + fd + 01 = ff$$


Note the carry out bit c

The +1 can be done by setting Cin to 1!

```
unsigned int timer_get_ticks(void)
  return *SYSTIMERCLO;
void timer_delay_us(unsigned int usecs)
  unsigned int start=timer_get_ticks();
 while (timer_get_ticks()-start) < usecs);</pre>
// The timer continuously ticks.
// Does this code work if the timer overflows?
```


## Addition and Subtraction of signed and unsigned numbers are the same!


### CPSR: Current Program Status Register





Arithmetic instructions set N, Z, C, V Logic instructions just set N, Z


What is V?











### Comparison (cmp)

## Subtract and through away result Always set the Flags

Code	Suffix	Flags	Meaning
0000	EQ	Z set	equal
0001	NE	Z clear	not equal
0010	CS	C set	unsigned higher or same
0011	CC	C clear	unsigned lower
0100	MI	N set	negative
0101	PL	N clear	positive or zero
0110	VS	V set	overflow
0111	VC	V clear	no overflow
1000	Н	C set and Z clear	unsigned higher
1001	LS	C clear or Z set	unsigned lower or same
1010	GE	N equals V	greater or equal
1011	LT	N not equal to V	less than
1100	GT	Z clear AND (N equals V)	greater than
1101	LE	Z set OR (N not equal to V)	less than or equal
1110	AL	(ignored)	always

## Methods used to compare signed and unsigned numbers are NOT the same!

# Types and Type Conversion

#### Unsigned Type Hierarchy

```
uint32 {0,...,4294967295(0xffffffff)}
uint16 {0,...,65535(0xffff)}
uint8 {0,...,255(xff)}
```

Types are *sets* of allowed values
Arrow indicate *subsets*: uint16 ⊂ uint32


### **Type Conversion**

Type conversion is a way of converting data from one type to another type

Explicit type conversion means that the programmer must specify type conversions. Often called *casting*.

Implicit type conversions means that the language has rules for automatically performing type conversion. Often called *coercion* 

Casting usually refers to a reinterpretation of the same bits as a different type (int\* a = void\* b)



Type *Promotion* is Safe (values preserved)

```
#include <stdint.h>
uint16_t x = 0xffff;
uint32_t y = x;

// x = 0xffff
// y = ?
```

```
#include <stdint.h>
uint16_t x = 0xffff;
uint32_t y = x;

// x = 0xffff
// y = 0x0000ffff
```

#### Signed Type Hierarchy

```
int32 {-2,147,483,648,...,2,147,483,647}
int16 {-32768,...,32767}
int8 {-128,...,127}
```

Arrow indicate *subsets*: int16 ⊂ int32

```
int16_t x = -1;
int32_t y = x;

// x = -1
// y = ?
```

```
int16_t x = -1;
int32_t y = x;

// x = -1
// y = -1
```

```
// positive
int16 t x = 1;
int32_t y = x;
// x = 1 = 0x0001
// y = 1 = 0x00000001
// negative
int16 t x = -1;
int32 t y = x;
// x = -1 = 0xffff
// y = -1 = 0xffffffff
```

```
// To preserve signed values need sign extension
int8 t 0xfe -> int32 t 0xfffffffe
int8_t 0x7e -> int32 t 0x0000007e
// Sign extend instructions:
//
// sxtb - sign extend byte to word
// sxth - sign extend half word to word
//
```


```
int32_t x = 0x80000;
int16_t y = x;

// x = 0x80000
// y = ?
```

```
int32_t x = 0x80000;
int16_t y = x;
// x = 0x80000
// y = 0x0000
```



value has changed



Defined (remove most significant bits)

Dangerous (doesn't preserve all values)

```
int32_t x = -1;
uint32_t y = x;

// x = -1
// y = ?
```

```
int32_t x = -1;
uint32 t y = x;
// x = -1
// y = 0xffffffff = 4294967295
/!\ value has changed
x is negative, but y is positive!
// draw pixel(-1, -1, color);
// !!
```

uint32 — int32

uint16 — int16

uint8 — int8

Defined (copies bits)

uint32 — int32

uint16 — int16

uint8 — int8

Dangerous! (neg maps to pos)

uint32 int32

uint16—int16

uint8 — int8

Technically Not Defined (arm: copies bits)

uint32 — int32

uint16—int16

uint8 — int8

Dangerous!
(large positive numbers change)

"Whenever you mix signed and unsigned numbers you get in trouble."

Bjarne Stroustrup

#### Implicit Type Promotion

in


**Binary Operators** 

#### Type promotions for binary operations


## Note that the type of the result can be different than the type of the operands!

_								
	u8	u16	u32	u64	i8	i16	i32	i64
u8	i32	i32	u32	u64	i32	i32	i32	i64
u16	i32	i32	u32	u64	i32	i32	i32	i64
u32	u32	u32	u32	u64	u32	u32	u32	i64
u64								
i8	i32	i32	u32	u64	i32	i32	i32	i64
i16	i32	i32	u32	u64	i32	i32	i32	i64
i32	i32	i32	u32	u64	i32	i32	i32	i64
i64	i64	i64	i64	u64	i64	i64	i64	i64


#### arm-none-eabi-gcc type promotions




Safe?



Safe?



## Bugs, Bugs, Bugs



```
#include <stdio.h>
int main(void)
    int a = -20;
    unsigned int b = 6;
    if( a < b )
        printf("-20<6 - all is well\n");</pre>
    else
        printf("-20>=6 - omg \n");
```

#### Be Wary of Implicit Type Conversion

## Modern languages like rust and go do not perform implicit type conversion

### Summary

Signed numbers are represented in two's complement

■ Negation:  $-x = 2^n-x = -x+1$ 

In 2's complement,

- Arithmetic between signed and unsigned numbers is identical
- Comparison between signed and unsigned numbers is different

Know the rules for type conversion, watch out for implicit type conversions and promotions!!

# C Type Conversion and Promotion Rules

The semantics of numeric casts are:

Casting from a larger integer to a smaller integer (e.g. u32 -> u8) will truncate

Casting from a smaller integer to a larger integer (e.g. u8 -> u32) will zero-extend if the source is unsigned sign-extend if the source is signed

Casting between two integers of the same size (e.g. i32 -> u32) is a no-op

- 6.3.1.3 Signed and unsigned integers conversions
- 1 When a value with integer type is converted to another integer type, if the value can be represented by the new type, it is unchanged.
- 2 Otherwise, if the new type is unsigned, the value is converted by repeatedly adding or subtracting one more than the maximum value that can be represented in the new type until the value is in the range of the new type.
- 3 Otherwise, if the new type is signed and the value cannot be represented in it; either the result is implementation-defined or an implementation-defined signal is raised.

#### 6.3.1.8 Usual arithmetic conversions

1 If both operands have the same type, then no further conversion is needed.

2 Otherwise, if both operands have signed integer types or both have unsigned integer types, the operand with the type of lesser integer conversion rank is converted to the type of the operand with greater rank.

3 Otherwise, if the operand that has unsigned integer type has rank greater or equal to the rank of the type of the other operand, then the operand with signed integer type is converted to the type of the operand with unsigned integer type.

4 Otherwise, if the type of the operand with signed integer type can represent all of the values of the type of the operand with unsigned integer type, then the operand with unsigned integer type is converted to the type of the operand with signed integer type.

5 Otherwise, both operands are converted to the unsigned integer type corresponding to the type of the operand with signed integer type.