

















Port SARJ Mot plugs directly into HDMI bres board SARJ_Motor Motor_Wiring Port TRRJ Servo Motor_Wiring SSARJ connector does not connect to anything on Port side	Akout PSARJ SARJ_Connector Motor- Mo	Port HDMI Breakout 1 M1/3i HDMI_Cable_Out 2 5v 3 M1/3o x4 N/C 5 3.3V x6 N/C 7 Neopixel x8 N/C 11 Encoder_A1 x12 N/C 13 Encoder_A2 x14 N/C 15 Encoder_B2 x14 N/C 15 Encoder_B2 x15 N/C 17 M2/4o 18 TRRJ_Data M2/4i Shie 8nd Internal routing of signals on board	□Port HDMI Cable
PSARJ connector does not connect to anything on Port side Stbd TRRJ Servo Motor_Wiring Stbd SARJ_Motor Stbd SARJ Motor Plugs directly into HDMI brei board		Stbd HDMI Breakout 1 M1/3i HDMI_Cable_Out 2 5v 3 M1/3o	The only connections between this part of the model and the base are via two HDMI cables