


# **RISAT Input Data File**



## **Description:**

This program sets and configures the main characteristics of the Input Data Files in order to convert polarimetric data sets encoded using the RISAT specific data format to PolSARpro compatible binary data.

### **Comments:**

Parameters written in Red can be modified directly by the user from the keyboard.

## **Input/Output Arguments:**

**Input Directory** Indicates the location of the considered **Main Directory** (**MD**)

containing the RISAT data file to be converted.

**Output Directory** 

Indicates the location of the converted data output directory

Band-Meta File Correspond to the RISAT Band-Meta File (product file) which is

automatically detected

## **Read Header:**

**Read Header** Input RISAT Band-Meta file contains information describing the

polarimetric data acquisition characteristics

The auxiliary files are thus detected

• Incidence angle grid file

Leader file

3

If Google Earth application is installed on the machine, users have the possibility to visualize the footprint of the measured scene

Input Data Files Correspond to the input polarimetric channel data files, encoded

using the RISAT format, to be processed.

### **Initial Number of Rows/Columns:**

Users have to provide the considered image **Initial Number of Rows and Columns.**