

### **Physical layer**







- Physical layer is responsible for transmission of a stream of bits
  - Put bits from a machine to a medium
  - Pick bits from the medium give to receiver
- Some issues
  - Medium
  - Line Encoding: representing the digital logic levels using the physical attributes associated with the media.
  - Multiplexing

#### From signal to packet

Analog Signal

"Digital" Signal

Bit Stream 0 0 1 0 1 1 1 0 0 0 1


Packets

Header/Body

Header/Body


Header/Body

Packet Transmission




# Model of data transmission system





(a) General block diagram



(b) Example










Figure 1.3 Simplified Network Models

# Direct Data transmission system






#### Media


- Wired
  - Twisted Pair
  - Coaxial Cable
  - Fiber Optics
- Wireless
  - Radio
  - Infra red
  - Light
  - ...





### **Twisted pair**












- (a) Category 3 UTP.
- (b) Category 5 UTP.




- Cheap, simple
- Widely used
- Weak resistance to noice
- Short Transmission distance

- Need amplification after each 5km in analog transmission
- In digital transmission
  - Need repeater after each 2 km
- Limited speed (100MHz)
- Noice








Category	<b>Impedance</b>	Use
RG-59	75 Ω	Cable TV
RG-58	50 Ω	Thin Ethernet
RG-11	50 Ω	Thick Ethernet







- Using in TV transmission
- For transmission of telephone signal
  - 10,000 calls in the same time
  - Is being replaced by fiber optics
- Linking the computers of the short distance
- LAN 10BaseT, 100BaseT,


. . .

- For digital transmission
  - Repeater should be used after each 1km
  - More repeater is needed for high speed transmission











- (a) Single core
- (b) Cable with 3 cores

# Optical fiber transmission mode



















- Used for long distance transmission
- Used for communication in metropolitan networks
- Used for connecting routers of ISP
- Used in backbone part of a LAN

- Advantage in comparison with other cables
  - Large data rate
  - Small and light cable
  - Low attenuation
  - Better isolation from electromagnetic environment
  - Large distance between repeaters (10km)







- Terrestrial microwave
  - Used for metropolitan connection, for cellular network
- Microwave satellite
  - Used in TV, Long distance telephone communication
- Radio broadcast
- Infrared
  - Small scope, low data rate, unable to travel through the wall



- Microwave: 1GHz đến 40GHz
- Radio: 30MHz đến 1GHz
- Infrared: 300GHz đến 200 THz
- Antenna: wireless transceiver

## Frequency range of transmission chanels











- Use different discrete signal, different voltage level for representing bit 0 and 1.
- Data transmission should be synchronized between sender and receiver: clock synchronization
- Encoding could be performed by bit or by a group of bit e.g., 4 or 8 bits.
- There are many way to represent 0 and 1 → See data transmission technique.


### **Topology**


- Point-to-point
  - Star
  - Ring
  - Mesh
- Point-to-multipoint
  - Bus
  - Ring
  - Star







#### **Point -to-Point**



















- Simplex: Data is trasmitted in one direction
- Full Duplex: Data can be transmitted in both directions in the same time
- Half duplex: Data can be transmitted in both directions but one direction at a time.









- Sequent transmission: Transmit 1 bit at a moment (over a signal line)
- Parallel transmission: Trasmit multiple bits in the same time (over multiple signal lines)











- Data terminal equipment (DTE)
  - Have data to transmit but has no feature for transmission
  - Need an additional device for accessing the media
- Data circuit terminating equipment (DCE)
  - Transmit bits on the media
  - Transmit data and control information with DCE through connection the media
- Need a clear interface standard between DTE, DCE



#### **DTE-DCE**



(a) Generic interface to transmission medium



(b) Typical configuration






- Mechanism
  - Define the form of the interface, number of pins for assuring the interfaces match together
- Electrics
  - Define the level of voltage to be used
  - Define the length of pulse (frequency)
  - Define enconding method
- Functionalities
  - Functionality of each pins
  - There are 4 groups of pins: data, control, synchronization, ground
- Procedure
  - Lists of events to perform for transmitting data





- Define for serial communication
- Mechanism: ISO 2110
- Electrics: V. 28
- Functionality: V. 24
- Procedure: V. 24





- Mechanic:
  - 25 or 15 pins
  - Transmission distance 15m
- Electrics
  - Digital data
  - 1=-3v, 0=+3v (NRZ-L)
  - Data rate 20kbps
  - Transmission distance15m




Figure 6.5 Pin Assignments for V.24/EIA-232 (DTE Connector Face)

## **Data Encoding**

Introduction

Encoding digital data to digital signal Encoding digital data to analogical signal Encoding analogical data to digital signal Encoding analogical data to digital signal





#### **Fundamental concepts**

- Objective
  - Transform the data into some signals that is suitable for transmission media

4 forms of encoding digital data to digital signal digital data to analogical signal analogical data to digital signal analogical data to digital signal



- Data unit: 1 bit
- Digital data is a digital signal
  - Each pulse is considered as a signal unit.
  - A signal unit can be considered as 1 bit
- Data encoding: mapping data to signal
- Set of mapping is called Encoding scheme
- Mark:1, Space:0

### Line encoding method




- NRZ
  - NRZ-L,NRZI
- Bipolar
  - Bipolar alternate mark inversion
  - Pseudoternary


- Phase encoding
  - Manchester
  - Manchester vi sai



#### NRZ-L Non Return to Zero Level


- During bit time, signal does not go back to 0 level
- Signal level is not changed during bit time.
- NRZ-L Non return to zero level
  - Bit 1 signal is in low/high level
  - Bit 0 signal is in high/low level





#### NRZ-I Non return to zero invert

- Bit 0: signal level is not changed at the begining of bit time
- Bit 1: signal level is changed at the begining of bit time
- A differential encoding method :
  - 0 and 1 represent by the signal level change, not by the level itself.
  - Reliable/ simple.







- Two aspects should be consider in any encoding methods:
  - Clock recovery on receiver side: If the clock recovery is not ideal, then the signal to be decoded will not be sampled at the optimal times. This will increase the probability of error in the received data.
  - DC-component: Directed Current vontage component.
    - DC-component makes recepter mistakenly detect level of signal
    - Encoding should avoid DC-component by having signal mean altitude to be around 0.

### NRZ

- NRZ Advantage
  - Simple, utilise the maximum capacity of the line
- NRZ Weakness
  - NRZ does not contain element supporting clock synchorization
    - Example: when sending a suit of 1 or 0
  - Contain DC-component when sending a suit of 1.
- Application
  - Encoding data on magnetic storage
  - Not popular in data transmission


### Bipolar AMI



- Use more than 2 signal level for 1 bit
- Bipolar alternate mark inversion
  - 0 : No signal
  - 1: Presence of signal. Two consequent 1 have two different signal levels
- pseudoternary
  - 1 : No signal
  - 0 : Presence of signal. Two consequent 0 have two different signal levels







### **Bipolar AMI**



- DC component =0
- Good synchronization when there are many bit 1(0), lost of synchronization when there are many bit 0(1)
- 3 possible signal levels for 1 bit:
  - Not optimal in using transmission line.
  - Receipter needs to distingush 3 levels of signal







- Manchester: Always change signal level in the middle of bit time
  - Bit 1: Signal change from low level to high level
  - Bit 0: Signal change from high level to low level
  - Level change provide synchonisation mechanism.
- Differential Manchester:
  - 0: signal level change at the begining of bit
  - 1: no signal level change at the begining of bit
  - Always change signal level in the middle of bit time for synchronization purpose

## Manchester encoding









### **Manchester encoding**


#### Manchester Encoding



#### Differential Manchester Encoding



# Units in transmitting digital data in digital transmission



Term	Units	Definition	
Data unit	bit	A single bit, Value 0 or 1	
Data rate	bit/s	Rate transmitting bit	
Signal unit	Pulse a sinus	Part of the signal correspond to the smallest duration of a symbol	
Symbol rate/ Rate of modulation	Number of symbol/s (baud)	Number of symbols generated in a unit of time	




### **Encoding rate: Baud rate**

- Number of symbol changes, waveform changes, or signaling events across the transmission medium per unit of time
- Unit: Baud/s = symbol/s

	Minimum	101010	Maximum
NRZ-L	0 (all 0's or 1's)	1.0	1.0
NRZI	0 (all 0's)	0.5	1.0 (all 1's)
Binary-AMI	0 (all 0's)	1.0	1.0
Pseudoternary	0 (all 1's)	1.0	1.0
Manchester	1.0 (1010)	1.0	2.0 (all 0's or 1's)
Diff Manchester	1.0 (all 1's)	1.5	2.0 (all 0's)

### Line encoding









- Ví dụ: truyền số liệu thông qua hệ thống điện thoại
  - Hệ thống điện thoại truyền, chuyển tiếp tín hiệu điện có tần số 300Hz đến 3400Hz
  - Tại nguồn và đích, dữ liệu số cần được điều chế thành tín hiệu liên tục để truyền trên đường điện thoại
- Căn cứ vào tính chất của tín hiệu, chúng ta có 3 kỹ thuật điều chế
  - Điều chế khóa dịch biên độ
  - Điều chế khóa dịch pha
  - Điều chế khóa dịch tần số






- 0 và 1 tương ứng với hai biên độ tín hiệu, thông thường một trong hai biên độ=0
- Dễ bị ảnh hưởng bởi nhiễu (1200bps cho đường thoại)
- Khó đồng bộ
- Thường được dùng trong cáp quang (LED hoặc laser

$$s(t) = \begin{cases} A\cos(2\pi ft) \ cho \ 1\\ 0 \ cho \ 0 \end{cases}$$




### Điều chế khóa dịch tần số (FSK)



$$s(t) = \begin{cases} A \cos(2\pi f_1 t) \\ A \cos(2\pi f_2 t) \end{cases}$$

- Hai giá trị nhị phân được biểu diễn bởi hai tín hiệu tần số khác nhau
- Ví dụ về điều tần song công
- Tỷ suất lỗi thấp hơn
- Dùng trong truyền số liệu qua đường điện thoại (tần số thấp), hoặc trong mạng không dây (tần số cao)



3/23/21

Figure 5.8 Full-Duplex FSK Transmission on a Voice-Grade Line


# Điều chế khóa dịch pha (PSK)

- 0,1 tương ứng với hai độ lệch pha khác nhau
- 0,1 tương ứng với chuyến pha (vi sai)
- Có thể sử dụng giải thông một cách hiệu quả hơn khi mã hóa cùng lúc nhiều bít
- Có thể kết hợp với điều biên
- Nếu tốc độ dữ liệu là 9600 bps, tốc độ điều chế là ?



$$s(t) = \begin{cases} A\cos(2\pi f_c t + \pi) & \text{binary 1} \\ A\cos(2\pi f_c t) & \text{binary 0} \end{cases}$$


$$s(t) = \begin{cases} A\cos(2\pi f_c t + 45^\circ) & 11 \\ A\cos(2\pi f_c t + 135^\circ) & 10 \\ A\cos(2\pi f_c t + 225^\circ) & 00 \\ A\cos(2\pi f_c t + 315^\circ) & 01 \end{cases}$$




## Kết hợp với điều biên



9,600 bps modem (2,400 baud x 4)



### Điều chế số/liên tục



## 3. Điều chế dữ liệu liên tục- số




- Điều chế dữ liệu liên tục thành dữ liệu số, sau đó
  - Điều chế thành tín hiệu số
    - Mã hóa trực tiếp bằng NRZ-L
    - Sử dụng phương pháp mã hóa tín hiệu số khác
  - Điều chế thành tín hiệu liên tục
    - Sử dụng các biện pháp điều chế số-liên tục đã học
- Có hai phương pháp chính điều chế dữ liệu liên tục thành dữ liệu số
  - Điều chế mã xung
  - Điều chế Delta


# Điều chế mã xung (PCM)



- Pulse Code Modulation
- Lấy mẫu tín hiệu dựa trên định luật lấy mẫu của Shannon
  - Nếu tần số lấy mẫu >= 2 lần tần số (có ý nghĩa) cao nhất của tín hiệu, phép lấy mẫu bảo toàn thông tin của tín hiệu
  - Vd: Tiếng nói tần số tối đa 4300Hz, cần lấy mẫu với tần số min 8600Hz
- Tiến hành theo hai bước
  - Lấy mẫu (PAM)
  - Lượng tử hóa








# Điều chế delta (Delta Modulation)




- Sử dụng hàm bậc thang
  - Khi hàm số tăng, xung=1
  - Khi hàm số giảm, xung=0
- Tổng quát
  - Biểu diễn giá trị của đạo hàm theo bít
- Tham số
  - Bậc thang
  - Tốc độ lấy mẫu
- Sai số
  - Khi tín hiệu thay đổi chậm: nhiễu lượng tử
  - Khi tín hiệu thay đổi nhanh: nhiễu tràn



### Dữ liệu liên tục tín hiệu liên tục


- Kết hợp tín hiệu m(t) và sóng mang có tần số Fc thành một tín hiệu tập trung xung quanh Fc
- Cho phép chuyển tín hiệu trên một tần số khác phù hợp với kênh truyền
- Cho phép dồn kênh bằng các tần số sóng mang khác nhau
- 3 phương pháp chính dựa vào đặc điểm của tín hiệu
  - Điều biên
  - Điều tần
  - Điều chế góc pha




# $s(t) = [1 + m(t)] cos2 f_C t$


### Điều biên


- Biến đổi biên độ sóng mang theo đầu vào
- Nếu đầu vào cũng là hình sin
  - Tín hiệu đầu ra sẽ có hai thành phần lệch với tần số sóng mang một khoảng bằng tần số đầu vào
  - Na<1 điều biên hợp lệ</li>
  - Na>1 mất thông tin
- Giải thông=2 lần giải thông đầu vào
- Điều biên một chiều: 1 lần giải thông




(a) Sinusoidal modulating wave













- Biểu diễn các tín hiệu mã hóa chuỗi dữ liệu sau đây bằng các phương pháp mã hóa đã học
  - 11000000 00000010 11001101 01010101





- Dữ liệu mã hóa bằng mã manchester (không vi sai) cho tín hiệu
  - Xác định thời gian của từng bít
  - Xác định dữ liệu ban đầu





### Bài tập-04

- Biểu diễn phương pháp điều chế pha-biên độ sau bằng công thức
- Tốc độ ký hiệu là 2400 baud. Tốc độ dữ liệu là bao nhiêu?

