ECE 351

Verilog and FPGA Design

Week 2_1: Literals, nets, and vars Simulating digital systems

Roy Kravitz Electrical and Computer Engineering Department Maseeh College of Engineering and Computer Science



1

Literals, nets, and vars

Source material drawn from:

- · Alex P., Mark F. and Roy K. ECE 571 lecture slides
- Roy K. ECE 351 and Verilog Workshop lecture slides
- Logic Design and Verification Using SystemVerilog (Revised) by Donald Thomas
- RTL Modeling with SystemVerilog for simulation and Synthesis by Stuart Sutherland

3 Literals sized or unsized: <size>'[s]<radix><number> ■ **Sized** example: 3′b010 = 3-bit wide binary number ☐ The prefix (3) indicates the size of number ■ **Unsized** example: 123 = 32-bit wide decimal number by default ■ **Signed** example: -8'sd39 = 8-bit wide signed number Defaults ■ No specified <base format> defaults to **decimal** No specified <size> defaults to 32-bit number ■ No "s" defaults to unsigned Radix: Decimal ('d or 'D) 16'd255 = 16-bit wide decimal number Hexadecimal ('h or 'H) 8'h9a = 8-bit wide hexadecimal number ■ Binary ('b or 'B) "b1010 = 32-bit wide binary number Octal ('o or 'O) 'o21 = 32-bit wide octal number Portland State ECE 351 Verilog and FPGA Design

3

Literals (cont'd)

\[
\text{ '_' (underscore): used for readability (ignored)} \]
\[
\text{ Example: } \frac{32'h21_65_bc_fe} = 32-bit hexadecimal number \]
\[
\text{ 'x' or 'X' (unknown value)} \]
\[
\text{ Example: } \frac{12'hxxx} = 12-bit hexadecimal number, unknown state \]
\[
\text{ 'z' or 'Z' (high impedance value)} \]
\[
\text{ Example: } \frac{1'bz} = 1-bit high impedance number \]
\[
\text{ '?' can used in place of 'z' or 'Z' to represent hi-impedance and don't care }
\]
\[
\text{ Fortland State } \]


5 Mismatched size and values ☐ Legal to specify a literal integer with a bit-width != number of bits required: ■ 4'hFACE // 4-bit width, 16-bit unsigned value // 16-bit size, 4 bit signed value, MSB set ■ 32′bz // 32-bit width, 1-bit unsigned valued ☐ SystemVerilog will adjust to match according to these rules: ■ When size < #bits than value, left-most bits truncated ■ When size > #bits than value, value is left-extended ☐ if left-most bit of value is 0 or 1, additional bits filled w/ 0 ☐ If left-most bit of value is Z, upper bits are filled w/ Z ☐ If left-most bit of value is X, upper bits are filled w/ X • e.g. Value is not sign extended even is literal integer is specified as signed. Sign extension occurs when signed literal value is used in operations and assignment statements Portland State ECE 351 Verilog and FPGA Design

5

```
6
Mismatched size and values
 Your turn:
□4'hFACE
             //
□16'sh8
             //
□32′bz
             //
□4'hFACE
             // truncates to 4'hE
□16'sh8
             // extends to 16'hsh0008
□32′bz
             // extends to 32'hZZZZZZZZ
                                              Portland State
ECE 351 Verilog and FPGA Design
```

Vector fill and floating-point literal values

- SystemVerilog provides a special form of unsized literals:
 - Sets all bits of vector of any size to 0, 1, X, or Z
 - Vector size is automatically determined based on context
 - □ '0 fills all bits on the LHS w/ 0
 - $\ \square$ '1 fills all bits on the LHS w/ 1
 - □ 'z or 'Z fills all bits on the LHS w/ z
 - □ 'x or 'X fills all bits on the LHS w/ x
 - Important construct for modeling scalable designs (i.e. different vector widths for different design configurations)
- ☐ Floating-point literal values (real numbers):
 - Represented using 64-bit double precision floating point values
 - □ Examples: 3.1567, 5.0, 0.5
 - Real numbers not typically supported by synthesis tools



ECE 351 Verilog and FPGA Design

7

Vectors and part select

8

7

- Verilog net and variable data types more than one bit wide are called vectors
 - Examples:

```
wire [255:0] bus;  // 256-bit wide bus
tri [0:127] backward_bus; // bit 0 is MSB
logic[31:24] whatever;  // don't need bit 0
```

- Select part of a vector
 - Examples:



Vector part select

Part select can include expressions of variables

my_byte = word[n*8+7:n*8]; //selects nth byte of word

□ Part select increment and decrement function [<starting_bit>+:<width>] increments from starting_bit [<starting_bit>-:<width>] decrements from starting_bit

□ Examples:

```
logic [127:0] vector_le;
logic [0:127] vector_be;
my_byte = vector_le[31-:8];    //selects vector_le[31:24]
my_byte = vector_le[24+:8];    //selects vector_le[31:24]
my_byte = vector_be[31-:8];    //selects vector_be[24:31]
my_byte = vector_be[24+:8];    //selects vector_be[24:31]
my_byte = vector_le[n*8+:8];    //selects nth byte of vector_le
my_byte = vector_be[n*8+:8];    //selects nth byte of vector_be
```

Source: Verilog 2001 A guide to the New Features of the Verilog Hardware Description Language by Stuart Sutherland

ECE 351 Verilog and FPGA Design

Portland State

9

Types and data types

10

9

- SystemVerilog introduces notion of type and data type
 - type indicates whether identifier is a net or a variable
 - data type indicates the value system (0/1 for two-state logic, 0/1/X/Z for four-state logic)
- Data types are used in RTL modeling to indicate desired silicon behavior
 - ex: should an adder performed signed or unsigned arithmetic
- ☐ Type:
 - Nets are used to connect design blocks together
 - ☐ Transfers data values from a source (driver) to a destination (receiver)
 - □ SystemVerilog supports several net types
 - □ Net types are always 4-state data types
 - Variables provide temporary storage for simulation
 - Required on LHS of procedural block assignments
 - ☐ Can be either 2-state or 4-state data types



Types and data types (cont'd) type - wire, wand, ... (net) or var keyword for general purpose variable is var When type is omitted from declaration var is implied data type - logic (4-state), bit (2-state), reg (4-state), ... When data type is omitted logic is implied reg maintains compatibility w/ Verilog but use logic for your designs

Portland State

ECE 351 Verilog and FPGA Design

11

Types and data types (cont'd)

type

var logic [63:0] addr;

data type

var implied

logic [63:0] data;

data type

var implied

logic [63:0] data; // a 64-bit wide variable

logic [0:7] array [0:255]; // an array of 8-bit variables

ECE 351 Verilog and FPGA Design

Synthesizable variable data types

13

Туре	Representation
reg	An obsolete general purpose 4-state variable of a user-defined vector size; equivalent to var logic
logic	Usually infers a general purpose var logic 4-state variable of a user-defined vector size, except on module input/inout ports, where wire logic is inferred
integer	A 32-bit 4-state variable; equivalent to var logic [31:0]
bit	A general purpose 2-state var variable with a user-defined vector size; defaults to a 1-bit size if no size is specified
int	A 32-bit 2-state variable; equivalent to var bit [31:0]; synthesis compilers treat int as the 4-state integer type
byte	An 8-bit 2-state variable; equivalent to var bit [7:0]
shortint	A 16-bit 2-state variable; equivalent to var bit [15:0]
longint	A 64-bit 2-state variable; equivalent to var bit [63:0]

ECE 351 Verilog and FPGA Design

Source: Sutherland, Table 3-1



13

SystemVerilog 2-State variables

14

- ☐ Useful for modeling at higher levels of abstraction than RTL (e.g. system, transaction)
 - Higher level models seldom require z, x which take up more memory and are slower to simulate
- Most of the 2-state types are signed by default
 - Can override w/ the unsigned keyword

```
int s_int; // signed 32-bit variable
int unsigned u_int; // unsigned 32-bit variable
```

- Common uses:
 - Bus functional models
 - Interfacing Verilog models to C/C++ models using SystemVerilog Direct Programming I/F
 - Loop variables (aren't synthesized, don't require z, x states)



SystemVerilog 2-State variables (cont'd)

15

□ 2-state types:

bit 1-bit 2-state integer

shortint 8-bit 2-state integer (similar to C char)
shortint 16-bit 2-state integer (similar to C short)
int 32-bit 2-state integer (similar to C int)
longint 64-bit 2-state integer (similar to C longlong)

- Synthesis treats 4-state and 2-state variables the same way
- 2-state data types are initialized to 0 in simulation but not in synthesized hardware
- 4-state variables can be assigned to 2-value data types but be careful...

ECE 351 Verilog and FPGA Design



15

SystemVerilog 2-State variables (cont'd)

16

4-state variables can be assigned to 2-value data types but use care when connecting 2-state variables in testbench to design under test, especially outputs.

- □ 4-state variables driving x or z to a 2-state variable will be (silently) converted to 2-state value (0) and your testbench will never know
- □ Use \$isunknown() which returns 1 if any bit of the expression is x or z.

☐ Use \$countbits() to count number of bits having a specified set of values (0, 1, x, z)

```
assert (!$isunknown(data)
else $error ("data has %0d bits with x or z", $countbits (data, 'x, 'z));


ECE 351 Verilog and FPGA Design

Portland State
UNIVERSITY
```

Variable assignment rules

- ☐ A variable can receive a value from any one of these ways:
 - Assigned a value from single always_comb, always_ff, or always_latch procedural block
 - Assigned a value from single continuous assignment statement
 - As the result of an assignment operator such as ++
 - As an input to a module, task or function
 - As a connection to an output port of a module instance, task or function instance or primitive (gate level) instance
- A variable can only be assigned by a single source, however multiple assignments to a variable in the same procedural block is treated as a single driver

```
logic [15:0] q; //16-bit 4-state unsigned variable
always_ff @(posedge clk)
  if (!rstN)
    q <= '0;
  else
    q <= d</pre>
```



17

ECE 351 Verilog and FPGA Design

ECE 351 Verilog and FPGA Design

Variable assignment rules (cont'd)

18

var(iables) cannot be driven by multiple sources but nets can

```
module add_and_increment (output logic [63:0] sum,
                         output logic
                         input logic [63:0] a, b );
  always @(a, b)
    sum = a + b;
                        // procedural assignment to sum
  assign sum = sum + 1; // ERROR! sum is already being
                         // assigned a value
  look ahead il (carry, a, b); // module instance drives carry
 overflow_check i2 (carry, a, b); // ERROR! 2nd driver of carry
endmodule
module look_ahead (output wire
                  input logic [63:0] a, b);
endmodule
module overflow_check (output wire
                                          carry,
                       input logic [63:0] a, b);
endmodule
```

Portland State


Non-synthesizable variable data types

19

Туре	Representation
real	A double precision floating-point variable
shortreal	A single precision floating-point variable
time	A 64-bit unsigned 4-state variable with timeunit and timeprecision attributes
realtime	A double precision floating-point variable, identical to real
string	A dynamically sized array of byte types that can store a string of 8-bit ASCII characters
event	A pointer variable that stores a handle to a simulation synchronization object
class handle	A pointer variable that stores a handle to a class object (the declaration type is the name of a class, not the keyword class)
chandle	A pointer variable that stores pointers passed into simulation from the SystemVerilog Direct Programming Interface
virtual interface	A pointer variable that stores a handle to an interface port (the interface keyword is optional)

ECE 351 Verilog and FPGA Design

Source: Sutherland, Table 3-2



19

Net types

20

- Used to connect design elements together
 - ex: connecting the output port of one module to the input port of another module
- Nets differ from variables in these significant ways:
 - Nets reflect the current value of the driver(s) on the net (i.e. no temporary storage)
 - Nets can resolve the results of multiple drivers
 - Nets reflect both a driver value (0, 1, Z, or X) and a driver strength
 - □ Strength is represented in steps from 0 (weak, low drive) to 7 (strong, high drive)
 - □ Default drive strength is 6 (strong)
 - Strengths are NOT used in RTL modeling (dependent on target technology)



Synthesizable net types

21

Туре	Representation
real	A double precision floating-point variable
shortreal	A single precision floating-point variable
time	A 64-bit unsigned 4-state variable with timeunit and timeprecision attributes
realtime	A double precision floating-point variable, identical to real
string	A dynamically sized array of byte types that can store a string of 8-bit ASCII characters
event	A pointer variable that stores a handle to a simulation synchronization object
class handle	A pointer variable that stores a handle to a class object (the declaration type is the name of a class, not the keyword class)
chandle	A pointer variable that stores pointers passed into simulation from the SystemVerilog Direct Programming Interface
virtual interface	A pointer variable that stores a handle to an interface port (the interface keyword is optional)

ECE 351 Verilog and FPGA Design

Source: Sutherland, Table 3-3



21

(Generally) non-synthesizable net types

22

Туре	Representation
uwire	An interconnecting net that does not permit or resolve multiple drivers
pull0	An interconnecting net that has the behavior of having a pull-down resistor tied to the net
pull1	An interconnecting net that has the behavior of having a pull-up resistor tied to the net
wand	An interconnecting net that resolves multiple drivers by ANDing the driven values
triand	A synonym for wand, and identical in all ways; can be used to emphasize nets that are expected to have tri-state values
wor	An interconnecting net that resolves multiple drivers by ORing the driven values
trior	A synonym for wor, and identical in all ways; can be used to emphasize nets that are expected to have tri-state values
trireg	An interconnecting net with capacitance; if all drivers are at high-impedance, the capacitance reflects the last resolved driven value

ECE 351 Verilog and FPGA Design

Source: Sutherland, Table 3-4



Net assignment and connection rules

23

- Nets can receive a value from two types of sources:
 - As a connection to an output or inout port
 - As the LHS of a continuous assignment (and assign statement)
- ☐ Any changes on the RHS of an assignment cause the LHS to be reevaluated and LHS updated
 - LHS can be a variable or a net

```
wire [15:0] sum;
assign sum = a + b;
```

 An implicit continuous assignment combines the declaration of a net and the assignment

```
wire [15:0] sum = a + b;
```

- □ Rules for resolving port/connection mismatches:
 - port size < net or variable size leftmost bits truncated</p>
 - Port size > net or variable size value of net is left-extended
 - $\hfill \square$ If either port or net/variable is unsized zero-extended
 - ☐ If both port and net/variable are sighed sign-extended

ECE 351 Verilog and FPGA Design



23

Simulating Digital Systems

Source material drawn from:


- · SystemVerilog for Design: Overview by Donald Thomas
- RTL Modeling with SystemVerilog for Simulation and Stimulus by Stuart Sutherland

Some basic terms


25

- □ System (or model) state
 - Includes variables and things intended to become nets and registers
 - Every variable deep in instantiated modules is uniquely named (hierarchical naming)
 - Statically defined
- Events and their flavors
 - Events are tuples:
 - □ something to do, and
 - □ a time to do it
 - Update Event a value-change scheduled to occur at a given time
 - □ e.g., b is set to 1 at time 15
 - Evaluation Event (sometimes "execution event") a model (always, initial...) to resume executing at a given time

ECE 351 Verilog and FPGA Design



25




Event regions

- Events in a begin-end statement group are scheduled into an event region and executed in the order in which the statements are listed
- □ Events from concurrent processes are scheduled into the event region in an arbitrary order chosen by the simulator
- Simulators will execute all scheduled events in a region before transitioning to the next region
- As events are processed, they are permanently removed from the event list
- ☐ Each region will be empty before simulation proceeds to the next region
- As events are processed in a later region, they can possibly schedule new events in a previous region
- □ The transition from one event region to the next is referred to as a delta. Each iteration through all event regions is referred to as a delta cycle


ECE 351 Verilog and FPGA Design


Sutherland Section 1.5.3.5.



27

28 Pseudo Code: Event-Driven Simulation put all initial and always blocks in the event list while something in time-ordered event list { One traversal of the while loop is a *simulation cycl*e. advance simulation time to first event's time retrieve all events e for this time update state from all update-event values For each event e in arbitrary order { If it's an update event { follow fanout, evaluate gates there If an output changes schedule update event for it } else // it's an evaluation event evaluate the model 🦀 Portland State ECE 351 Verilog and FPGA Design






Sutherland Example 1-7

31

ECE 351 Verilog and FPGA Design




31

Sutherland Example 1-7 (cont'd)

32

```
// Top module with clk oscillator
//`begin_keywords "1800-2012"
module top;
 timeunit 1ns; timeprecision 1ns;
            clk;
 logic
 logic [7:0]
            d;
 logic [7:0]
            q; test i1 (.*); // connect top module to test module
 d_reg i2 (.*); // connect top module to d_reg module
 initial begin
   // clk oscillator
  clk <= 0;
            // initialize clk at time 0
  forever #5 clk = ~clk; // toggle clk every 5ns
endendmodule: top//`end_keywords
```




```
Sutherland Example 1-7 (cont'd)
```

```
// Test module with stimulus generator
//`begin_keywords "1800-2012"
module test (
 input logic
                clk,
 output logic [7:0] d,
 input logic [7:0] q
 timeunit 1ns; timeprecision 1ns;
 initial begin
   d = 1;
   #7 d = 2;
   #10 d = 3;
   #10 $display("\n%m: No output-- checking that example compiles\n");
   #10 $finish;
endendmodule: test
//`end_keywords
ECE 351 Verilog and FPGA Design
```

Portland State

33



Next Time

- □ Topics:
 - Simulation w/ QuestaSim
 - Graded In-class exercise (implementing and simulating a RCA)
- ☐ You should:
 - Read Sutherland Ch 3
 - Prepare to write and simulate code
- ☐ Homework, projects and quizzes
 - Homework #1 will be assigned Tue, 13-Apr

ECE 351 Verilog and FPGA Design

