

USRP Receiver Debugging Diagram

(Top View)



HP Logic Analyzer 100k Termination Adapter USRP Basic RX Daughterboard



1. Connect Termination Adapter to J15 with Pin1 connected to bottom-right side.