Francis Rukab N00961805

To subtracting is the same as adding negative numbers. So, in binary to subtract two bit-string, all that is required is inverting the second string and adding one. To add one using the adder chips in Multisim, just replace ground going into COUT with VCC to give you a high. This is equivalent to adding one to the final answer. Following this method will give you the answer for subtracting two bit-strings.