


VIRTUATILT – Xbox SETUP GUIDE

Following some basic instructions to set up your new VirtuaTilt for Xbox systems.


IMPORTANT NOTE: You need a proper USB dongle (not provided and not supported) to make VirtuaTilt compatible with above devices. If you connect directly, it won't be recognized as a controller.

Load Profile

Load **VTConfig-Xbox_v1.X.json** profile in **Pinscape Pico Config Tool**:



Click on “Program Pico” to save new configuration:



That's it, enjoy!

Default Buttons Mapping

This is the default buttons mapping for Xbox profile. You can of course change assignments in Pinscape Pico Config Tool.

