3Laws

Release latest

Thomas Gurriet (tgurriet@3laws.io)

Mar 07, 2024

Table of Contents

1 Introduction **3**
1.1 Architecture . . . 3
1.2 Supervisor interfaces . . . 4
1.3 RunTime Assurance Module (RAM) . . . 4
1.4 Robot Diagnostic Module (RDM) . . . 5
1.5 Configuration . . . 5

2 Getting Started **7**
2.1 1. Installation . . . 7
2.2 2. Configuration . . . 7
2.3 3. Launch . . . 8
2.4 4. Monitor . . . 8

3 Installation and Update **9**
3.1 Quick Installation . . . 9
3.2 Non Interactive Installation . . . 9
3.3 Update . . . 10

4 Control Panel **11**
4.1 Launch the Control Panel . . . 11
4.2 Use the Control Panel . . . 11

5 Visualization **15**
5.1 Dashboards . . . 15
5.2 Navigation Tools . . . 16
5.3 Incident Management . . . 16

Table of Contents:

Chapter 1

Introduction

The 3Laws Robotics supervisor is a software package that provides a control filter to insure safety without compromising performance. In addition, the supervisor contains a diagnostic module to monitor relevant metrics for safety and performance.

In order to make the configuration and the usage of the supervisor easier, we provide a control panel, that will guide you through the configuration of the supervisor and help you visualize the supervisor's safety filter in action.

1.1 Architecture

The supervisor is composed of 3 main modules:

- The RAM: The RunTime Assurance Module is the core of the supervisor. It is a filter at the control level that ensures that the robot's control commands are safe and do not violate any safety constraints.
- The RDM: The Robot Diagnostic Module is a diagnostic tool that monitors and compute metrics about the robot health and safety.
- The Control Panel: The control panel is a web application that will guide you through the configuration of the supervisor. It will ask you for the robot's model, the safety constraints and the control commands topics. Also, the control panel will help you visualize the supervisor's safety filter in action.



1.2 Supervisor interfaces

The 3Laws Robotics supervisor is designed to work with ROS. The supervisor is a ROS node that subscribes to the robot's state, perception and control commands, and publishes the filtered control commands to the robot's actuators. Also the supervisor can subscribes to the robot's sensors and planning topics and publishes the diagnostic information.

Multiple ROS version are supported. Here is a list of the tested versions:

Ubuntu Distribution	ROS1 version	ROS2 version
22.04	N/A	Humble/Iron
20.04	Noetic	Galactic/Foxy
18.04	Melodic	N/A

1.3 RunTime Assurance Module (RAM)

The RunTime Assurance Module (RAM) is a filter at the control level. It is designed to ensure that

the robot's control commands are safe and do not violate any safety constraints. Based on formal mathematical proven methods, the RAM is able to guarantee that the robot will not violate any safety constraints, while still allowing the robot to perform at its best.

This ability can be used to safely develop your robot's control and planning algorithms without the need to worry about safety. With the supervisor, focus on your core value and let the supervisor take care of the safety.

The RAM needs a basics kinematic and dynamic model of the robot and safety constraints on state in order to perform the right filtering. 3LawsRobotics knows that it is not always easy to describe a model of the robot which is why the supervisor is designed to be easily configurable and adaptable to the robot's model.

1.4 Robot Diagnostic Module (RDM)

The Robot Diagnostic Module (RDM) is a diagnostic tool that monitors and compute metrics about the robot health and safety. The computed metrics are published on ROS topics and can be used to monitor the robot's health and safety in real-time but can also be send to a data base for further analysis. 3LawsRobotics has developed a set of Dashboards to help developers quickly diagnose issues the robot might have. These Dashboards are made using Grafana.

1.5 Configuration

The Supervisor require a bit of configuration to work properly. Knowing that this process can be a bit complex, 3LawsRobotics created a control panel to help you configure the supervisor.

The control panel is a web application that will guide you through the configuration of the supervisor. It will ask you for the robot's model, the safety constraints and the control commands topics. Also, the control panel will help you visualize the supervisor's safety filter in action.

In order to successfully identify the user, the configuration requires a token that 3LawsRobotics will provide you with.

Chapter 2

Getting Started

This guide will help you to install and configure the Supervisor on your robot.

Table of Contents

2.1 1. Installation 7
2.2 2. Configuration 7
2.3 3. Launch 8
2.4 4. Monitor 8

2.1 1. Installation

The first step is to install the Supervisor on your robot.

On your robot computer, open a terminal and run the following command:

```
bash <(curl
https://raw.githubusercontent.com/3LawsRobotics/3laws/master/rdm/install.sh)
```

Some questions may be asked if the script is unable to find the ROS distribution or architecture of your computer.

Restart your terminal to complete the installation. If ROS is not sourced, run the following command:

```
source /opt/ros/<DISTRO>/setup.sh
```

The Supervisor is now installed on your robot.

2.2 2. Configuration

After a successful installation, you will need to configure the Supervisor to match your robot. For this use the Control Panel that started automatically after the installation or open a terminal and run the following command:

```
sudo systemctl start lll_control_panel
```

By default the control panel is accessible to the following address: *http://localhost:8000*

Optionally, you can start a rosbridge server to connect the Control Panel to your robot:

```
ros2 run rosbridge_server rosbridge_websocket
```

This will provide a websocket server at *ws://localhost:9090* that the control panel can connect to to get topics and services information.

Finally, open a web browser and go to the Control Panel address. Follow the instructions to configure

the Supervisor. You will need to provide the following information:

- **Robot ID**: The name of your robot
- **Credentials**: The 3Laws Robotics Inc. key provided to you on the purchase of the Supervisor.
- **Model**: The dynamic model of your robot.
- **Supervisor configuration**: The configuration of the Supervisor and control input interfaces.
- **State**: The state interface of your robot and safety constraints.
- **Perception**: The perception interface of your robot.

2.3 3. Launch

Before starting the supervisor be sure to have your ROS environment correctly set up and sourced.

```
source /opt/ros/<DISTRO>/setup.sh
```

To launch the Supervisor you can use the following command:

```
ros2 launch lll_rdm rdm.launch.py
```

2.4 4. Monitor

Thanks to the websocket server, you can monitor the Supervisor using the Control Panel. Go to the Operations tab verify that the Supervisor is running and that the state and perception interfaces are correctly connected.

Chapter 3

Installation and Update

Table of Contents

3.1 Quick Installation 9
3.2 Non Interactive Installation 9
3.3 Update 10

The Supervisor is distributed as a debian package. A package is available for each of the following configuration

Ubuntu Distribution	ROS1 version	ROS2 version	Architecture
22.04	N/A	Humble/Iron	amd64/arm64v8
20.04	Noetic	Galactic/Foxy	amd64/arm64v8
18.04	Melodic	N/A	amd64/arm64v8

3.1 Quick Installation

Copy and paste the following command in a terminal to install the Supervisor:

```
bash <(curl
https://raw.githubusercontent.com/3LawsRobotics/3laws/master/rdm/install.sh)
```

This will install the Supervisor for the current distribution and architecture and the control panel.

At the end of the installation, the control panel will be started and you will be able to start the configuration of the supervisor. To do so open a web browser and go to the following address: http://localhost:8000

3.2 Non Interactive Installation

If you want to install a specific package in a non interactive mode, here is the process:

- Download the script:

```
wget https://raw.githubusercontent.com/3LawsRobotics/3laws/master/rdm/install.sh
```

- Make it executable

```
chmod +x install.sh
```

- Run it with your arguments

```
sudo ./install.sh [-hyf] [-r <ROS_DISTRO>] [-a <ARCH>] [-v <UBUNTU_VERSION>]
```

if `-yf -r <ROS_DISTRO> -a <ARCH> -v <UBUNTU_VERSION>` specified, the script is non interactive

3.3 Update

To update the Supervisor, you can use the same command as for the installation.

The supervisor will be updated to the latest version available for your distribution, **All your configuration will be kept**.

```
bash <(curl
https://raw.githubusercontent.com/3LawsRobotics/3laws/master/rdm/install.sh)
```

Chapter 4

Control Panel

Table of Contents

4.1 Launch the Control Panel 11
4.2 Use the Control Panel 11

The **Control Panel of 3LawsRobotics** is a helper tool to help the configuration of the 3Laws Robotics supervisor. It provides a web interface to configure the 3Laws Robotics supervisor and visualize the robot's state. Currently in alpha version, it runs on your local network and can be accessed from any device with a web browser. The backend is written in Python and uses the CGI protocol (Common Gateway Interface) to communicate with the web interface.

In order to get your account setup and use freely this RDM, please contact support@3lawsrobotics.com

This product is still at a alpha development stage. New features are developed every month and some breaking changes can still happened. The 3LawsRobotics Team is available to answer your question.

For now only a ROS1, ROS2 interfaces are configurable via this control panel.

4.1 Launch the Control Panel

The control panel is installed as a systemd service. To start the control panel, use the following command:

```
sudo systemctl start lll_control_panel
```

and to stop it:

```
sudo systemctl stop lll_control_panel
```

Also you can start it manually with the following command:

```
python3 /opt/3lawsRoboticsInc/control_panel/server.py
```

You can add the following command line options:

- **-p or –port**: <number, default: 8000> Specify the port to use

You can specify the emplacement of the configuration file by setting the environment variable *LLL_CONFIG_FOLDER*

4.2 Use the Control Panel

The control panel is meant to be user friendly and safe explanatory. However some detail might be

useful to know.

Here is a picture of the control panel:



The control panel is divided in 3 parts:

- The Navigation bar, where you can find the main pages, a Ros Bridge WebSocket status indicator and a WebSocket parameter button.
- The main page, where you can find the configuration form and the control buttons.
- The footer, where you can find the version number and the 3LawsRobotics website link and a link to the update pages.

In order to use this control panel at its best, you need to configure the Ros Bridge WebSocket parameters. To do so, click on the WebSocket parameter button in the navigation bar and fill the form with the correct parameters.

By default, the control panel is configured to connect to a Ros Bridge WebSocket running on the same machine, on the port 9090. More information on the Ros Bridge WebSocket can be found following this link: Ros Bridge WebSocket.



A successful connection to the Ros Bridge WebSocket will be indicated by a green status indicator in the navigation bar.

Chapter 5

Visualization

Visualization is a key part of the monitoring system. The following sections will guide you through the visualization tools that are available to you.

Table of Contents

5.1 Dashboards 15
5.2 Navigation Tools 16
5.3 Incident Management 16

5.1 Dashboards

In order to visualize your monitoring data. 3LawsRobotics provides a Grafana dashboard. You can access it by opening your web browser and navigating to https://3laws.app. Your credentials will be given to you by your 3LawsRobotics representative.

This dashboards are tailored to quick diagnostic. This means that the workflow will help you dive into the data that is relevant to your current problems. The dashboards are organized in the following way:

- **General**: This dashboard displays your robots that are currently monitored and their current state. It will also gives you a list of the latest events that have been recorded by the monitoring system.
- **Behavior**: This dashboard gives you insights into the behavior of your robot, like his computed safety score, your distance to obstacle, etc.
- **Hardware**: This dashboard expose the hardware health of the robot. It let you quickly see if the current physical behavior of the robot is coherent with your model or if some degradation is happening.
- **Systems**: This is the most important dashboard. It gives information about the system of the robot like signals delay, computer usage and Node status.
- **Perception**: This dashboard make it easy to diagnose a sensors issue like obstructed sensor or noisy sensor.
- **Control**: Finally this dashboard allows you to observe the good tracking and feasibility of the control commands or the planning algorithms

Each dashboard is composed of several panels with always an overview that helps you to quickly see if everything is fine and then more detailed panels that will help you to precisely diagnose the problem.

5.2 Navigation Tools

The dashboards are composed of several navigation tools that will help you to quickly diagnose a problem. Here is a screenshot of a dashboard with the navigation tools highlighted:



- **Time Range**: This tool allows you to select the time range of the data that you want to visualize. You can select a predefined range or a custom range.
- **Refresh**: This tool allows you to refresh the data displayed in the dashboard. You can select the refresh interval or manually refresh the data.

5.3 Incident Management

The Dashboards display a list of incident, you can use it to navigate directly to the right detailed dashboard. The timestamp of the incident is clickable and will bring to the right detailed dashboard at

the time of the incident.