



## Quick Guide



## Battery Doorbell Dual-lens



x1




x1



x1



x1




x1




x1



x1



x1



x1





x1



x1













Scan for video,  
user guide,  
support...





| Status                               | Meaning                            |
|--------------------------------------|------------------------------------|
| Flashing green                       | Device is connecting to network    |
| Steady green                         | Device is online                   |
| Flashing red<br>(1 time per second)  | Device is not connected to network |
| Flashing red<br>(3 times per second) | Device failed to connect to server |


# APP



OR



## Option 1



## Option 2

