


3COM


Quick Guide





WiredCam PT
Indoor Dual-lens



Scan for video,
user guide,
support...







Pan&Tilt Wi-Fi Camera

1. Device Introduction
To reset the device, press and hold the RST button for more than 3 seconds within 10 minutes of powering it on.

2. Cable Connection

- Network connection: Supports both wireless and wired connections. If using wireless mode, please do not connect
- The network cable.

Power connection: Connect the device to the power supply

Device Status	Indicator Status
Starting up	Steady red
Waiting for network connection	Blinking blue
Normal operation	Steady blue
Wi-Fi connection failed	Blinking red
Resetting	Blinking red

3. Web Login

- Default IP address: 192.168.1.13
- Default username: admin / password: 123456



