

RAMPSTART

1.	CLOSE CANOPY	8.	POWER AVIONIC SWITCHES	15.	RF / CHAFF / FLARE / JAMMER = ON	22.	CNI SWITCH TO UFC
2.	PARKING BRAKE ON	9.	POWER LIGHTS SWITCHES	16.	RHAW POWER / ACTIVATION	23.	SELECT COMM1
3.	SET AIR SOURCE	10.	INS TO NORM	17.	WAIT UNTIL INS READY (FLASH)	24.	USE AEKRAN TO SET FREQ.
4.	FUEL / FEED PUMP ON	11.	RALT TO STBY	18.	INS TO NAV	25.	CALL CHOCK REMOVE
5.	BATTERY / MAIN POWER	12.	MFD ON	19.	RALT TO ON	26.	CALL TAXI CLEARANCE
6.	JFSTART (WAIT 20%)	13.	HUD BRIGHT	20.	TAXI LIGHTS ON	27.	ACTIVATE NWS
7.	DETENT (MIL/IDLE)	14.	AUX COMM VOLUMES	21.	RADIO CHANNEL SET TO BOTH	28.	UNLOCK PARKING BRAKE





