

UEFI Self-Certification Test Case Writer's Guide

Version 0.91 July1, 2009 THIS DOCUMENT IS PROVIDED "AS IS" WITH NO WARRANTIES WHATSOEVER, INCLUDING ANY WARRANTY OF MERCHANTABILITY, NONINFRINGEMENT, FITNESS FOR ANY PARTICULAR PURPOSE, OR ANY WARRANTY OTHERWISE ARISING OUT OF ANY PROPOSAL, SPECIFICATION OR SAMPLE. Except for a limited copyright license to copy this specification for internal use only, no license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted herein.

Intel disclaims all liability, including liability for infringement of any proprietary rights, relating to implementation of information in this specification. Intel does not warrant or represent that such implementation(s) will not infringe such rights.

Designers must not rely on the absence or characteristics of any features or instructions marked "reserved" or "undefined." Intel reserves these for future definition and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them.

This document is an intermediate draft for comment only and is subject to change without notice. Readers should not design products based on this document.

Intel, the Intel logo, and Itanium are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

* Other names and brands may be claimed as the property of others.

Copyright © 2009, Intel Corporation.

Revision History

Revision Number	Description	Revision Date
<0.9>	Internal draft.	June, 2009
0.91	Formatting and general editing; Contribution to UEFI	July, 2009

Contents

I	mtroc	auction				
	1.1	Overvie	w	1		
	1.2	Organiz	ation	1		
	1.3	Convent	tions Used in This Document	1		
	1.4	Referen	ces	2		
2	The U	The UEFI SCT Source Package				
	2.1		w			
	2.2		Package Layout			
	2.3		Requirements			
	2.4	•	equired Source for SCT Build			
	2.4	2.4.1	Required Source:			
	2.5		·			
	2.5		OCESS			
		2.5.1	Build UEFI SCT			
		2.5.2	Build IHV SCT			
		2.5.3	Build Step	c		
3	Test (Test Case Quick Started7				
	3.1	3.1 Ove	rview	7		
	3.2	The Con	nponents of Test Case	7		
	3.3	Test Cas	se Description File	7		
	3.4	Header	Files	9		
		3.4.1	ProtocolNameBBTestMain.h	9		
		3.4.2	ProtocolName.h	14		
		3.4.3	Guid.h	15		
	3.5	Source	Files	16		
		3.5.1	ProtocolNameBBTestMain.c	16		
		3.5.2	<protocolname>Protocol.c</protocolname>	18		
		3.5.3	ProtocolNameBBTestFunction.c	19		
		3.5.4	ProtocolNameBBTestConformance.c	21		
		3.5.5	Guid.c	21		
	3.6	IHV Tes	t Case	22		
		3.6.1	ProtocolNameBBTestMain.h	22		
		3.6.2	ProtocolName.c	22		
		3.6.3	ProtocolNameBBTestMain.c	22		
4	Work Items for Build and Execution23					
	4.1	Preparation for Build23				
	4.2	2 Preparation for Execution				
		4.2.1	SctPkg\Config\Category.ini			

	4.2.2	SctPkg\Config\Data\GuidFile.txt	24
	4.2.3	SctPkg\CommonGenFramework.bat	25
4.3	Required	d Work Items after Execution - Case Spec update	25
4.4	EFI_CON	MPONENT_NAME2_PROTOCOL Test	25
	4.4.1	GetDriverName()	25
4.5	Other Re	equired Work Items	26
Appendix A Test Supp	port Serv	ices	27
A.1	Standar	d Test Services	27
A.2	Test Red	covery Services	29
A.3	Test Log	ging Services	33
A.4	Test Pro	file Services	37

1 Introduction

1.1 Overview

This document defines the guidelines for writing the test cases under UEFI Self-Certification Test (SCT) and introduces the UEFI SCT source tree. This document is intended for anyone interested in developing or porting tests for the UEFI SCT. The main objective is to provide test case writers a standard for writing *UEFI 2.3 Specification* compliant test cases, with shared output, reporting and logging features. These features allow test case writers to concentrate their efforts on test functionality.

1.2 Organization

This UEFI SCT Case Writer's Guide is organized as listed below:

Table 1 Organization of the EFI SCT Case Writer's Guide

Chapter/Appendix	Description	
1. Introduction	Introduces the UEFI SCT Writer's Guide and topics related to using the document.	
2. Downloading and Building	Describes the downloading and building procedures of the UEFI SCT source tree.	
3. Test Case Quick Started	Describes the detail procedures to create a test case which can be executed in the UEFI SCT Harness.	
4. Preparations for Build and Execution	Describes the detail procedures before build and execution.	
Appendix A. Test Support Services	Defines the test support protocols, and introduce the usage model.	

1.3 Conventions Used in This Document

Term

Definition

UEFI

Unified Extensible Firmware Interface

UEFI Driver

Modular chunk of firmware code that supports chipset or platform features. Reusable in multiple system contexts. Code relating to a device or function that is run in the DXE phase of execution.

SCT

Self Certification Test

Shell

UEFI Shell is a simple, interactive "command interpreter" hat allows UEFI device drivers to be loaded, UEFI applications to be launched, and operating systems to be booted.

1.4 References

- Unified Extensible Firmware Interface Specification, Version 2.3
- UEFI SCT Case Spec, Version 2.1
- UEFI SCT Getting Started, Version 2.1
- UEFI SCT User Guide, Version 2.1
- UEFI SCT Glossary

The UEFI SCT Source Package

2.1 Overview

The chapter discusses the folder organization of UEFI SCT source package, how to prepare build environment and how to build it.

2.2 Source Package Layout

Besides the test cases, UEFI SCT source package all provides SCT test services, SCT core, SCRT and other applications and tools, shown in the figure below.

```
|--Include
          |--Application
          |--Config
          |--Include
          |--Library
                                            //test services
          |--Protocol
                                            //test services
|--SctPkg--|--SCRT
                    --RIVL
        --IHV
                                          // IHV Test Case
        |--TestInfrastructure
                                         // SCT core
        |--Tools
        --UEFI
```

2.3 System Requirements

Several Microsoft tools are used to build the UEFI SCT source package. The following tools must be installed on the development system.

- Microsoft Windows XP operation system
- Microsoft Visual Studio. NET 2003 Professional (7.1)
- Microsoft Windows Server 2003 Driver Development Kit (DDK), build 3790.1830
- SubVersion, an open source version control system, http://subversion.tigris.org/

Note: Refer to https://edk2.tianocore.org/subversion_setup.html for the usage of subversion.

2.4 Other Required Source for SCT Build

As mentioned in overview part, besides test case, SCT source package only includes SCT core, some APIs of test service. To build UEFI SCT source package, some other packages are needed to provide more libraries, or others.

2.4.1 Required Source:

A stable version of BaseTools binary

Download BaseTools binary stable version - BaseTools(Binaries).zip from https://edk2.tianocore.org/servlets/ProjectDocumentList?folderID=103&expandFolder=103&folderID=102

A stable version of EdkCompatibilityPkg

Check out one EdkCompatibilityPkg stable version 8621 from

https://svn.tianocore.org/svn/edk2/trunk/edk2/EdkCompatibilityPkg

A stable version of Shellpkg

Check out one Shellpkg stable version 33 from

https://efi-shell.tianocore.org/svn/efi-shell/trunk/Shell

2.5 Build Process

According to the selected build target, two build processes are provided here.

2.5.1 Build UEFI SCT

2.5.1.1 Prepare the build directory

- Extract UefiSctEdkII-Dev.zip to the UEFI SCT directory, for example, extract to
 C:\UefiSct, then two folders named as SctPkg and Include will be located in
 C:\ UefiSct
- 2. Extract BaseTools(Binaries).zip to C:\UefiSct, then two folders named as BaseTools and Conf, one batch file named as edksetup.bat will be located in C:\UefiSct
- 3. Check out one EdkCompatibilityPkg stable version 8621 to C:\UefiSct\EdkCompatibilityPkg
- 4. Check out one Shell stable version 33 toC:\UefiSct\EdkCompatibilityPkg\Other\Maintained\Application\Shell

Note: Since the build tools of EFKII are friendly and flexible to support more compilers, we only need modify the C:\UefiSct\BaseTools\Conf\tools_def.template and make it support UEFI SCT. Before the first build process of UEFI SCT, please replace the section between line 819 and line 927 with the content of SctPkg\DDK3790.txt.

2.5.1.2 **Build Step**

- 1. Run Visual Studio .NET 2003 Command Prompt to go to the command line environment. Let's make UEFI SCT X64 tip as an example.
- 2. Execute follow commands in turn.

```
cd C:\UefiSct
edksetup.bat
set efi_source=C:\UefiSct
set edk_source= C:\UefiSct\EdkCompatibilityPkg
copy SctPkg\Tools\Bin\GenBin.exe BaseTools\Bin\Win32\
build -p SctPkg\UEFI\UEFI_SCT.dsc -t DDK3790 -a X64
cd Build\UefiSct\DEBUG_DDK3790
```

- ..\..\SctPkg\CommonGenFramework.bat uefi_sct X64 InstallX64.efi
- 3. The target subdirectory named as SctPackageX64 which includes test cases and UEFI SCT applications will be generated and located at C:\UefiSct\Build\UefiSct\DEBUG_DDK3790

Note: The example shows the build process of X64 only. For other architecture, please change the keyword, X64, which is highlighted in build step to IA32 or IPF.

2.5.2 Build IHV SCT

Compared with the build process of UEFI SCT, to support IHV SCT, only several mini-changes need be updated for IHV SCT build.

2.5.3 Build Step

- Run Visual Studio .NET 2003 Command Prompt to go to the command line environment. Let's make IHV SCT X64 tip as an example.
- 2. Execute follow commands in turn.
 - a. cd C:\UefiSct
 - b. edksetup.bat
 - c. set efi_source=C:\UefiSct
 - d. set edk_source= C:\UefiSct\EdkCompatibilityPkg
 - e. copy SctPkg\Tools\Bin\GenBin.exe BaseTools\Bin\Win32\
 - f. build -p SctPkg\UEFI\IHV_SCT.dsc -t DDK3790 -a X64
 - g. cd Build\IHVSct\DEBUG_DDK3790
 - h. ..\..\SctPkg\CommonGenFramework.bat ihv_sct X64 InstallX64.efi
- 3. The target subdirectory named as SctPackageX64 which includes test cases and UEFI SCT applications will be generated and located at C:\UefiSct\Build\IHVSct\DEBUG_DDK3790

Test Case Quick Started

3.1 Overview

This section describes how to create a simple test case to work within SCT infrastructure quickly. We will make Blocklo protocol test case as an example in this chapter. Generally, according to the execution mode, UEFI SCT test cases are divided into 2 types, native mode test case and passive mode test case. In this chapter, native mode test case will be introduced only. In native mode, test case can be divided into EFI/IHV for IBV/IHV too. The difference between them is very little, and will be introduced in the last section of this chapter.

3.2 The Components of Test Case

A SCT test case is generally composed of three types of files:

- INF: Test Case description file
- H: C source header file.
- C: C source code file

3.3 Test Case Description File

The INF file is the description file of test case. It is mainly used to generate the makefile of each component.

The following is the INF file for Blocklo protocol test case, BlockloBBTest.inf

```
[defines]
BASE_NAME
                   = BlockIoBBTest
FILE_GUID
                   = A7DF1948-4CD3-4d24-B373-8B701C8AB9A4
COMPONENT_TYPE
                  = BS_DRIVER
[sources.common]
 BlockIoBBTestMain.c
 BlockIoBBTestMain.h
 BlockIoBBTestConformance.c
 BlockIoBBTestFunction.c
 BlockIoBBTestStress.c
 BlockIoProtocol.c
 Guid.c
[includes.common]
 $(EDK_SOURCE)\Foundation
  $(EDK_SOURCE)\Foundation\Efi
  $(EDK_SOURCE)\Foundation\Include
  $(EDK_SOURCE)\Foundation\Efi\Include
  $(EDK_SOURCE)\Foundation\Framework\Include
  $(EDK_SOURCE)\Foundation\Include\IndustryStandard
  $(EDK_SOURCE)\Foundation\Library\Dxe\Include
  $(EFI_SOURCE)\
  $(EFI_SOURCE)\Include
  $(EFI_SOURCE)\SctPkg\Include
  $(EFI_SOURCE)\SctPkg\Library\EfiTestLib
  $(EFI_SOURCE)\SctPkg\Library\EfiTestUtilityLib
[libraries.common]
 EfiProtocolLib
 TestProtocolLib
 EfiCommonLib
 EfiTestLib
 EfiTestUtilityLib
[nmake.common]
  IMAGE_ENTRY_POINT = InitializeBBTestBlockIo
```

3.4 Header Files

Header files are used to store the global definitions, GUIDs, Function prototypes, header file inclusions and macros/definitions. Generally, there are 3 header files in the source code of test case.

- ProtocolNameBBTestMain.h, BlockIoBBTestMain.h here.
- ProtocolName.h, BlockIoProtocol.h here.
- Guid.h

3.4.1 ProtocolNameBBTestMain.h

It contains GUIDs for each test entry, and also specifies the set of UEFI SCT include files that the test case is dependent on.

```
#ifndef _BLOCK_IO_BBTEST_H_
#define _BLOCK_IO_BBTEST_H_
11
// Includes
11
#include "Efi.h"
#include "BlockIoProtocol.h"
#include "Guid.h"
#include "EfiTestUtilityLib.h"
#include "EfiTestLib.h"
//
// Definitions
                                             0x00010000
#define BLOCK_IO_PROTOCOL_TEST_REVISION
                                             20
#define MAX_NUMBER_OF_READ_BLOCK_BUFFER
#define MAX_DIFFERENT_BUFFERSIZE_FOR_TEST
#define MAX_DIFFERENT_LBA_FOR_TEST
#define MAX_DIFFERENT_IOALIGN_FOR_TEST
                                             4
#define MAX_REPEAT_OF_STRESS_TEST
                                             20
```

```
#define MAXIMUM(a,b)
                                             ((a)>(b)?(a):(b))
#define MINIMUM(a,b)
                                             ((a)<(b)?(a):(b))
11
// Entry GUIDs
// Conformance
#define BLOCK_IO_PROTOCOL_READBLOCKS_CONFORMANCE_AUTO_GUID \
  { 0x826159d3, 0x4a5, 0x4cce, \
  { 0x84, 0x31, 0x34, 0x47, 0x7, 0xa8, 0xb5, 0x7a } }
#define BLOCK_IO_PROTOCOL_READBLOCKS_CONFORMANCE_MANUAL_GUID \
  { 0xd743e08, 0xe3fd, 0x401b, \
  { 0x95, 0xc4, 0x98, 0x61, 0x1f, 0x65, 0xf2, 0xee } }
#define BLOCK_IO_PROTOCOL_WRITEBLOCKS_CONFORMANCE_AUTO_GUID \
  { 0x75961463, 0x882b, 0x4afd, \
  { 0x87, 0xcc, 0x7a, 0xfb, 0xd4, 0xd8, 0xff, 0x32 } }
#define BLOCK_IO_PROTOCOL_WRITEBLOCKS_CONFORMANCE_MANUAL_GUID \
  { 0x8b983f70, 0x7478, 0x4f59, \
  \{ 0xbe, 0xad, 0x16, 0xd1, 0x89, 0x0, 0xa3, 0xd9 \} \}
#define BLOCK_IO_PROTOCOL_FLUSHBLOCKS_CONFORMANCE_AUTO_GUID \
  { 0x759c5229, 0x272a, 0x45aa, \
  { 0xa6, 0x16, 0xb5, 0x62, 0x26, 0x19, 0xeb, 0x6 } }
#define BLOCK_IO_PROTOCOL_FLUSHBLOCKS_CONFORMANCE_MANUAL_GUID \
  { 0x5c484ad1, 0xa3bc, 0x495a, \
  { 0xa8, 0x82, 0xd6, 0xd8, 0x9d, 0x76, 0xf2, 0xa } }
11
// Function
#define BLOCK_IO_PROTOCOL_RESET_FUNCTION_AUTO_GUID \
  { 0xb0501c52, 0x1564, 0x4945, \
  { 0xb5, 0x7b, 0x1f, 0xd2, 0xc8, 0x82, 0xff, 0x91 } }
#define BLOCK IO PROTOCOL READBLOCKS FUNCTION AUTO GUID \
  { 0xa4284ae9, 0xc988, 0x4230, \
  \{ 0x97, 0x3a, 0x5c, 0x19, 0x39, 0x8c, 0x82, 0x54 \} \}
```

```
#define BLOCK_IO_PROTOCOL_WRITEBLOCKS_FUNCTION_AUTO_GUID \
  { 0xb7e32978, 0x4a8, 0x414d, \
  { 0x99, 0x7b, 0x59, 0x62, 0x8d, 0x73, 0xbf, 0x0 } }
#define BLOCK_IO_PROTOCOL_MEDIA_INTEGRITY_MANUAL_GUID \
  { 0x616fdaf9, 0x413f, 0x4a8c, \
  { 0xac, 0xd5, 0xa5, 0xac, 0x72, 0x71, 0x2c, 0xf2 } }
#define BLOCK_IO_PROTOCOL_FLUSHBLOCKS_FUNCTION_AUTO_GUID \
  { 0x7c947313, 0xc8a3, 0x4abd, \
  { 0xa1, 0xf2, 0x86, 0x70, 0xee, 0x57, 0x4b, 0xe5 } }
11
// Combination
#define BLOCK_IO_PROTOCOL_RESET_STRESS_AUTO_GUID \
  { 0xc29d4482, 0x3341, 0x4bbb, \
  { 0x8c, 0xa3, 0x82, 0xf2, 0x77, 0x2d, 0x98, 0x80 } }
#define BLOCK_IO_PROTOCOL_READBLOCKS_STRESS_AUTO_GUID \
  { 0x4fdealda, 0x643d, 0x4e71, \
  { 0x82, 0xd7, 0xad, 0xd1, 0xc6, 0x4d, 0x70, 0x9c } }
#define BLOCK_IO_PROTOCOL_WRITEBLOCKS_STRESS_AUTO_GUID \
  { 0x8619522b, 0xc0bb, 0x48ea, \
  { 0xb9, 0xa2, 0x23, 0x0, 0x69, 0xfd, 0x4, 0xa9 } }
// Global variables
extern EFI EVENT
                                 TimerEvent:
11
// Prototypes
11
EFI_STATUS
InitializeBBTestBlockIo (
 IN EFI_HANDLE
                                ImageHandle,
 IN EFI SYSTEM TABLE
                               *SystemTable
  );
```

```
EFI_STATUS
BBTestBlockIoProtocolUnload (
 IN EFI_HANDLE
                                ImageHandle
 );
// Conformance test case prototypes
11
EFI STATUS
BBTestReadBlocksConformanceAutoTest (
 IN EFI_BB_TEST_PROTOCOL
                                *This,
 IN VOID
                                *ClientInterface,
 IN EFI_TEST_LEVEL
                                TestLevel,
  IN EFI_HANDLE
                               SupportHandle
  );
EFI_STATUS
BBTestReadBlocksConformanceManualTest (
  IN EFI_BB_TEST_PROTOCOL
                                *This,
 IN VOID
                                *ClientInterface,
  IN EFI_TEST_LEVEL
                                TestLevel,
  IN EFI_HANDLE
                                SupportHandle
  );
EFI STATUS
BBTestWriteBlocksConformanceAutoTest (
 IN EFI_BB_TEST_PROTOCOL
                                *This,
 IN VOID
                                *ClientInterface,
 IN EFI_TEST_LEVEL
                                TestLevel,
  IN EFI HANDLE
                                SupportHandle
  );
EFI_STATUS
BBTestWriteBlocksConformanceManualTest (
  IN EFI_BB_TEST_PROTOCOL
                                *This,
 IN VOID
                                *ClientInterface,
  IN EFI_TEST_LEVEL
                                TestLevel,
  IN EFI_HANDLE
                                SupportHandle
  );
EFI STATUS
BBTestFlushBlocksConformanceAutoTest (
  IN EFI_BB_TEST_PROTOCOL
                                *This,
```

```
IN VOID
                                *ClientInterface,
  IN EFI_TEST_LEVEL
                                TestLevel,
  IN EFI_HANDLE
                                SupportHandle
  );
EFI_STATUS
BBTestFlushBlocksConformanceManualTest (
 IN EFI_BB_TEST_PROTOCOL
                                *This,
 IN VOID
                                *ClientInterface,
  IN EFI_TEST_LEVEL
                                TestLevel,
 IN EFI_HANDLE
                                SupportHandle
 );
11
// Function test case prototypes
11
EFI_STATUS
BBTestResetFunctionAutoTest (
 IN EFI_BB_TEST_PROTOCOL
                                *This,
 IN VOID
                                *ClientInterface,
 IN EFI_TEST_LEVEL
                               TestLevel,
  IN EFI_HANDLE
                                SupportHandle
  );
EFI_STATUS
BBTestReadBlocksFunctionAutoTest (
 IN EFI_BB_TEST_PROTOCOL
                                *This,
                                *ClientInterface,
 IN VOID
 IN EFI_TEST_LEVEL
                               TestLevel,
 IN EFI_HANDLE
                                SupportHandle
  );
EFI_STATUS
BBTestWriteBlocksFunctionAutoTest (
 IN EFI_BB_TEST_PROTOCOL
                                *This,
  IN VOID
                                *ClientInterface,
 IN EFI_TEST_LEVEL
                               TestLevel,
  IN EFI HANDLE
                                SupportHandle
  );
EFI_STATUS
BBTestFlushBlocksFunctionAutoTest (
```

13

3.4.2 ProtocolName.h

The second one is ProtocolName.h, BlockIoProtocol.h here, which provides the prototype definitions for the specified protocol. Generally, these definitions can be found in UEFI Spec, and all UEFI compatible implementation should to follow these definitions.

```
#ifndef _EFI_BLOCK_IO_FOR_TEST_H_
#define _EFI_BLOCK_IO_FOR_TEST_H_
#define EFI_BLOCK_IO_PROTOCOL_GUID \
  { 0x964e5b21, 0x6459, 0x11d2, \
 0x8e, 0x39, 0x0, 0xa0, 0xc9, 0x69, 0x72, 0x3b }
EFI_FORWARD_DECLARATION(EFI_BLOCK_IO);
typedef struct {
 UINT32
                      MediaId;
 BOOLEAN
                      RemovableMedia;
 BOOLEAN
                      MediaPresent;
 BOOLEAN
                      LogicalPartition;
 BOOLEAN
                      ReadOnly;
 BOOLEAN
                      WriteCaching;
 UINT32
                      BlockSize;
 UINT32
                      IoAlign;
 EFI_LBA
                      LastBlock;
} EFI_BLOCK_IO_MEDIA;
typedef UINT64
                      EFI_LBA;
typedef
EFI_STATUS
(EFIAPI *EFI_BLOCK_RESET) (
 IN EFI_BLOCK_IO
                   *This,
 IN BOOLEAN
                   ExtendedVerification
  );
```

```
typedef
EFI_STATUS
(EFIAPI *EFI_BLOCK_READ) (
  IN EFI_BLOCK_IO *This,
 IN UINT32
                     MediaId,
  IN EFI_LBA
                     LBA,
 IN UINTN
                     BufferSize,
 OUT VOID
                     *Buffer
  );
typedef
EFI_STATUS
(EFIAPI *EFI_BLOCK_WRITE) (
 IN EFI_BLOCK_IO
                    *This,
  IN UINT32
                     MediaId,
 IN EFI_LBA
                     LBA,
 IN UINTN
                     BufferSize,
  IN VOID
                     *Buffer
  );
typedef
EFI_STATUS
(EFIAPI *EFI_BLOCK_FLUSH) (
  IN EFI BLOCK IO
                     *This
  );
typedef struct _EFI_BLOCK_IO {
 UINT64
                         Revision;
 EFI_BLOCK_IO_MEDIA
                         *Media;
 EFI_BLOCK_RESET
                         Reset;
 EFI_BLOCK_READ
                        ReadBlocks;
 EFI_BLOCK_WRITE
                         WriteBlocks;
  EFI_BLOCK_FLUSH
                         FlushBlocks;
} EFI_BLOCK_IO_PROTOCOL;
extern EFI_GUID
                                          gEfiBlockIoProtocolGuid;
#endif
```

3.4.3 Guid.h

The third one is Guid.h, which defines the globally unique identifiers(GUID) value for all test assertions. The GUID value is generated by Microsoft Visual Studio.

3.5 Source Files

Source files contain the code for a test case. Generally, there are five source files at least.

- ProtocolNameBBTestMain.c, BlockIoBBTestMain.c here.
- ProtocolName.c, BlockIoProtocol.c here.
- ProtocolNameBBTestConformance.c, BlockIoBBTestConformance.c here.
- ProtocolNameBBTestFunction.c, BlockIoBBTestFunction.c here
- Guid.c

There are several important pieces in a source file for a test case.

3.5.1 ProtocolNameBBTestMain.c

In this file, an individual protocol test is defined by the UEFI Black-Box Test Protocol structure. This structure contains meta-data regarding the test, including revision, category, and human readable test descriptions. Each test is required to have a protocol field.

```
EFI_BB_TEST_PROTOCOL_FIELD gBBTestProtocolField = {
   BLOCK_IO_PROTOCOL_TEST_REVISION,
   EFI_BLOCK_IO_PROTOCOL_GUID,
   L"Block I/O Protocol Test",
   L"UEFI 2.0 Block I/O Protocol Test"
};
```

Each test is required to have a GUID, which is included in the test protocol field as a structure of this form:

```
EFI_GUID gSupportProtocolGuid1[2] = {
   EFI_STANDARD_TEST_LIBRARY_GUID,
   EFI_NULL_GUID
};
```

An individual protocol test may be composed of several test cases, which are specified by the Test Entry Field.

```
EFI_BB_TEST_ENTRY_FIELD gBBTestEntryField[] = {
  // Conformance test section
    BLOCK_IO_PROTOCOL_READBLOCKS_CONFORMANCE_AUTO_GUID,
    L"ReadBlocks_Conf",
    L"Perform auto consistency checkes on the ReadBlocks interface",
    EFI_TEST_LEVEL_MINIMAL,
    gSupportProtocolGuid1,
    EFI_TEST_CASE_AUTO,
    BBTestReadBlocksConformanceAutoTest
  },
  // Function test section
  11
  {
    BLOCK_IO_PROTOCOL_RESET_FUNCTION_AUTO_GUID,
    L"Reset_Func",
    L"Invoke Reset and verify interface correctness within test case",
    EFI_TEST_LEVEL_DEFAULT,
    gSupportProtocolGuid1,
    EFI_TEST_CASE_AUTO,
    BBTestResetFunctionAutoTest
 },
}
```

The entry and exit point of an individual protocol test are also defined in this file.

```
EFI_DRIVER_ENTRY_POINT(InitializeBBTestBlockIo)
EFI_STATUS
InitializeBBTestBlockIo (
 IN EFI_HANDLE
                         ImageHandle,
 IN EFI_SYSTEM_TABLE
                        *SystemTable
{
 EfiInitializeTestLib (ImageHandle, SystemTable);
  InitializeLib (ImageHandle, SystemTable);
  gtBS->CreateEvent (EFI_EVENT_TIMER, 0, NULL, NULL, &TimerEvent);
 return EfiInitAndInstallBBTestInterface (
             &ImageHandle,
             &gBBTestProtocolField,
             gBBTestEntryField,
             BBTestBlockIoProtocolUnload,
             &gBBTestProtocolInterface
             );
}
EFI_STATUS
BBTestBlockIoProtocolUnload (
 IN EFI_HANDLE
                      ImageHandle
  )
 EFI_STATUS
                      Status;
  gtBS->CloseEvent (TimerEvent);
 Status = EfiUninstallAndFreeBBTestInterface (
               ImageHandle,
               gBBTestProtocolInterface
               );
 return Status;
}
```

3.5.2 < ProtocolName > Protocol.c

Only gProtocolNameGuid is defined in this file.

```
#include "Efi.h"

#include "BlockIoProtocol.h"

EFI_GUID gEfiBlockIoProtocolGuid = EFI_BLOCK_IO_PROTOCOL_GUID;

EFI_GUID_STRING(&gEfiBlockIoProtocolGuid, "BlockIo Protocol", "EFI 1.0 Block IO protocol");
```

3.5.3 ProtocolNameBBTestFunction.c

In this file, all test cases are designed to call the API of Protocol with correct arguments or available resource. The API should return EFI_SUCCESS in most cases.

```
EFI_STATUS
BBTestResetFunctionAutoTest (
 IN EFI_BB_TEST_PROTOCOL
                                       *This,
                                       *ClientInterface,
 IN VOID
 IN EFI_TEST_LEVEL
                                       TestLevel,
 IN EFI_HANDLE
                                       SupportHandle
 EFI_STANDARD_TEST_LIBRARY_PROTOCOL *StandardLib;
 EFI_STATUS
                                       Status;
 EFI_BLOCK_IO_PROTOCOL
                                       *BlockIo;
  EFI_TEST_ASSERTION
                                       AssertionType;
  11
  // Get the Standard Library Interface
  Status = gtBS->HandleProtocol (
                      SupportHandle,
                      &gEfiStandardTestLibraryGuid,
                      &StandardLib
                      );
```

```
if (EFI_ERROR(Status)) {
    StandardLib->RecordAssertion (
                      StandardLib,
                      EFI_TEST_ASSERTION_FAILED,
                      gTestGenericFailureGuid,
                      L"BS.HandleProtocol - Handle standard test library",
                      L"%a:%d:Status - %r",
                      __FILE__,
                      (UINTN)__LINE__,
                      Status
                      );
   return Status;
  //The protocol want to be tested is found by SCT infrastructure and transferred
as a parameter.
 BlockIo = (EFI_BLOCK_IO_PROTOCOL *)ClientInterface;
 //
  // Reset must succeed to reset the block device with extended verification
 Status = BlockIo->Reset (BlockIo, TRUE);
 if (EFI_ERROR(Status)) {
 AssertionType = EFI_TEST_ASSERTION_FAILED;
 } else {
   AssertionType = EFI_TEST_ASSERTION_PASSED;
 Print (L"Wait 5 seconds for the block device resetting...");
 gtBS->Stall (5000000);
  StandardLib->RecordAssertion (
                    StandardLib,
                    AssertionType,
                    gBlockIoFunctionTestAssertionGuid001,
                    L"EFI_BLOCK_IO_PROTOCOL.Reset - Reset the block device with
extended verification",
                    L"%a:%d:Status=%r",
                    __FILE__,
                    (UINTN)__LINE__,
                    Status
                    );
// Reset must succeed to reset the block device without extended verification
```

```
11
  Status = BlockIo->Reset (BlockIo, FALSE);
 if (EFI_ERROR(Status)) {
 AssertionType = EFI_TEST_ASSERTION_FAILED;
 } else {
 AssertionType = EFI_TEST_ASSERTION_PASSED;
 Print (L"Wait 5 seconds for the block device resetting...");
 gtBS->Stall (5000000);
 StandardLib->RecordAssertion (
                    StandardLib,
                    AssertionType,
                    gBlockIoFunctionTestAssertionGuid002,
                    L"EFI_BLOCK_IO_PROTOCOL.Reset - Reset the block device
without extended verification",
                    L"%a:%d:Status=%r",
                    __FILE__,
                   (UINTN)__LINE__,
                    Status
                    );
 return EFI_SUCCESS;
}
```

For gTestGenericFailureGuid, it is not test case/test assertion fail, and just means test environment is not ready for test case. For one test case, it may be composed of several test assertion points at most case (2 assertion points are tested in this example). You can implement all test assertions in one function as this instance, or you can implement one test assertion as one sub function and test case call all sub functions in turn.

3.5.4 ProtocolNameBBTestConformance.c

In this file, all test cases are designed to use the API of Protocol with various combinations of invalid arguments or unavailable resource. The API should fail and should not return EFI_SUCCESS. Each invalid parameter combination, all but one of its parameters is set to an inadmissible value, need be verified.

3.5.5 Guid.c

This file defines the globally unique identifiers (GUID) for all test assertions.

3.6 IHV Test Case

IHV test cases are designed for IHV, and user not only can specify the device from the device list, but also can specify the test case thru menu. This design gives IHV more convenience and freedom. For some

In essence, IHV test cases are similar with EFI test cases, and only 3 points need be updated.

3.6.1 ProtocolNameBBTestMain.h

- IHV_COMPONENT_NAME2_PROTOCOL_GUID need to be defined.
- IHV_COMPONENT_NAME2_TEST_REVISION need to be defined.

3.6.2 ProtocolName.c

The definition of gEfiComponentName2ProtocolGuid need to be removed.

3.6.3 ProtocolNameBBTestMain.c

- The member of structure gBBTestProtocolField need to be updated with IHV_COMPONENT_NAME2_PROTOCOL_GUID and IHV_COMPONENT_NAME2_TEST_REVISION
- The entry point need be updated with **EfiInitAndInstallIHVBBTestInterface**
- The exit point need be updated with **EfiUninstallAndFreeIHVBBTestInterface**

4

Work I tems for Build and Execution

After the new test case has been developed, some Meta files need be modified to include new test case into build system and let UEFI SCT infrastructure detect new test case while executing.

4.1 Preparation for Build

In order to add the new test case into build system, the content in "\SctPkg\UEFI\UEFI_SCT.dsc" or "\SctPkg\UEFI\IHV_SCT.dsc" need be updated. The example below shows a new highlighted test case is inserted in the DSC file.

Example

SctPkg\TestCase\UEFI\EFI\Protocol\DriverSupportedEfiVersion\BlackBoxTest\DriverSupportedEfiVersionBBTest.inf

SctPkg\TestCase\UEFI\EFI\Protocol\AbsolutePointer\BlackBoxTest\AbsolutePoint
erBBTest.inf

SctPkg\TestCase\UEFI\EFI\Protocol\PlatformToDriverConfiguration\BlackBoxTest \PlatformToDriverConfigurationBBTest.inf

SctPkg\TestCase\UEFI\EFI\Protocol\SpecifiedFolderforSpecifiedProtocol\BlackBoxTest\SpecifiedProtocolBBTest.inf

#

Dependency files for UEFI\EFI Compliant Test

#

4.2 Preparation for Execution

After build successfully, several file need be updated which make the new test case be detected by UEFI SCT infrastructure while running.

4.2.1 SctPkg\Config\Category.ini

The new test case information need be inserted in this INI file which constructs the relationship between the catalogs in UI execution mode with actual test case. The example below shows a new test case for EFI Component Name2 Protocol is inserted in the INI file. Here, CategoryGuid/InterfaceGuid is 6a7a5cff-e8d9-4f70-bada-75ab3025ce14, which is specified in UEFI Spec and defined

SctPkg\TestCase\UEFI\EFI\Protocol\ComponentName2\BlackBoxTest\ComponentName2BB
TestMain.h in EFI_COMPONENT_NAME2_PROTOCOL_GUID. The value of Name is 'Driver Model
Test\ Component Name2 Protocol Test', since EFI Component Name2 Protocol is classified to
UEFI Driver Model by UEFI Spec. The value of Description is blank here.

Note: For new IHV test case, corresponding content need be updated in this file too. The difference is CategoryGuid value, **764165ed-a8ae-4dff-a3f2-6e99c5565690**, which is defined in

SctPkg\TestCase\UEFI\IHV\Protocol\ComponentName2\BlackBoxTest\ComponentName 2BBTestMain.h with IHV_COMPONENT_NAME2_PROTOCOL_GUID. Besides this, Name need be updated with IHV\Driver Model Test\Component Name2 Protocol Test too.

Example

[Category Data]

Revision = 0×00010000

CategoryGuid = 6a7a5cff-e8d9-4f70-bada-75ab3025ce14 InterfaceGuid = 6a7a5cff-e8d9-4f70-bada-75ab3025ce14

Name = Driver Model Test\Component Name2 Protocol Test

Description =

[Category Data]

Revision = 0×00010000

CategoryGuid = 764165ed-a8ae-4dff-a3f2-6e99c5565690 InterfaceGuid = 6a7a5cff-e8d9-4f70-bada-75ab3025ce14

Name = IHV\Driver Model Test\Component Name2 Protocol Test

Description = Component Name2 Protocol Test on IHV Drivers

4.2.2 SctPkg\Config\Data\GuidFile.txt

All assertions information is stored in this TXT file. Thru this file, UEFI SCT provides the 'report generation' feature which retrieves all log files, matches them with this file by Guid, and generate one Excel compatible report file. Report file gives an overall result and user can find the failure rapidly. Moreover, user can find the test description in the *UEFI SCT Case Specification*'by searching the index.

Note: Developers need to update this TXT file carefully and the information should be consistent with the implementation of the corresponding test case. In the example, 31518904-1307-4BEF-84E6-66FF76A78FF4 is one assertion Guid of assertion point in the test case, COMPONENT_NAME2_PROTOCOL.GetDriverName - GetDriverName() returns EFI_INVALID_PARAMETER with NULL Language is the assertion description of the assertion point, 5.5.8.1.1 is the index which should be exclusive in this file.

Example

```
#
31518904-1307-4BEF-84E6-66FF76A78FF4

COMPONENT_NAME2_PROTOCOL.GetDriverName - GetDriverName() returns

EFI_INVALID_PARAMETER with NULL Language

5.5.8.1.1

#
7B478492-53C0-4748-A244-60F3F2D0EE5A

COMPONENT_NAME2_PROTOCOL.GetDriverName - GetDriverName() returns

EFI_INVALID_PARAMETER with NULL DriverName

5.5.8.1.2

#
36E0A7E5-BFC8-4AB9-B41A-9D6925436AD2

COMPONENT_NAME2_PROTOCOL.GetDriverName - GetDriverName() returns

EFI_UNSUPPORTED with unsupported language

5.5.8.1.3
```

4.2.3 SctPkg\CommonGenFramework.bat

After a successful build, this batch file must be updated with an inserted line to ensure the binary of new test case will be integrated into the binary package.

Example

copy %ProcessorType%\ComponentName2BbTest.efi %Framework%\Test\ > NUL

4.3 Required Work I tems after Execution - Case Spec update

After the new test case is validated, some work items need be completed as the integrality criteria for a new test case. Besides the works mentioned in this chapter above, test case developer need update 'UEFI SCT Case Spec' with the test case implementation, and ensure it is consistent with GuidFile.txt. This work is very important and will help SCT user to locate failure reason rapidly with 'UEFI SCT Case Spec'. The table below is abstracted from 'UEFI SCT Case Spec' as a template.

Example

4.4 EFI_COMPONENT_NAME2_PROTOCOL Test

4.4.1 GetDriverName()

No.	GUID	Assertion	Test Description
5.5.8.1.1	0x31518904, 0x1307, 0x4bef, 0x84, 0xe6, 0x66, 0xff, 0x76, 0xa7, 0x8f, 0xf4	COMPONENT_NAME2_PROTOCOL. GetDriverName - GetDriverName() returns EFI_INVALID_PARAMETER with NULL Language	Call GetDriverName() with Language being NULL. The returned status should be EFI_INVALID_PARAMETER
5.5.8.1.2	0x7b478492, 0x53c0, 0x4748, 0xa2, 0x44, 0x60, 0xf3, 0xf2, 0xd0, 0xee, 0x5a	COMPONENT_NAME2_PROTOCOL. GetDriverName - GetDriverName() returns EFI_INVALID_PARAMETER with NULL DriverName	Call GetDriverName() with DriverName being NULL. The returned status should be EFI_INVALID_PARAMETER
5.5.8.1.3	0x36e0a7e5, 0xbfc8, 0x4ab9, 0xb4, 0x1a, 0x9d, 0x69, 0x25, 0x43, 0x6a, 0xd2	COMPONENT_NAME2_PROTOCOL. GetDriverName - GetDriverName() returns EFI_UNSUPPORTED with unsupported language	Call GetDriverName() with unsupported Language. The returned status should be EFI_UNSUPPORTED
5.5.8.1.4	0x327aa49d, 0x4a8b, 0x4101, 0x8b, 0x0d, 0x92, 0x32, 0x33, 0xfc, 0x09, 0xe5	COMPONENT_NAME2_PROTOCOL. GetDriverName - GetDriverName() returns EFI_SUCCESS with supported languange	Call GetDriverName() with supported Language. The returned status should be EFI_SUCCESS

Note: Developer need filled in one table which will be integrated into the UEFI SCT Case Specification and the test case information in the table should be consistent with both the implementation of corresponding test case and the related content in GuidFile.txt.

4.5 Other Required Work Items

Currently, as one separated application, SCRT is included in SCT official release package, so *UEFI SCT Getting Started* and *UEFI SCT User Guide* are updated to add corresponding description, such as build process and usage model, which give the user a good experience. So, if SCT developer wants to add some applications or makes some changes about usage model, please update these two documents too.

Appendix A Test Support Services

Besides the test case, the UEFI SCT Package also provides some test service Protocols that test writers can use to develop test case that work within the UEFI SCT Harness.

A.1 Standard Test Services

The standard test services are provided by an EFI Standard Test Library Protocol. This protocol is responsible for recording/reporting test results and test messages, and tracking the number of test results of each type.

Protocol Interface Structure

```
typedef struct _EFI_STANDARD_TEST_LIBRARY_PROTOCOL {
  UINT64
                                               LibraryRevision;
  CHAR16
                                               *Name;
  CHAR16
                                               *Description;
  EFI_RECORD_ASSERTION
                                               RecordAssertion;
                                               RecordMessage;
  EFI_RECORD_MESSAGE
 EFI_GET_RESULT_COUNT
                                               GetResultCount;
} EFI_STANDARD_TEST_LIBRARY_PROTOCOL;
typedef
EFI_STATUS
(EFIAPI *EFI_RECORD_ASSERTION) (
  IN EFI_STANDARD_TEST_LIBRARY_PROTOCOL
                                                 *This,
  IN EFI_TEST_ASSERTION
                                                 Type,
  IN EFI GUID
                                                 EventId,
  IN CHAR16
                                                 *Description,
  IN CHAR16
                                                 *Detail,
  )
```

```
typedef
            EFI_STATUS
            (EFIAPI *EFI_RECORD_MESSAGE) (
              IN EFI_STANDARD_TEST_LIBRARY_PROTOCOL
                                                              *This,
              IN EFI_VERBOSE_LEVEL
                                                              VerboseLevel,
              IN CHAR16
                                                              *Message,
              . . .
              )
            typedef
            EFI_STATUS
            (EFIAPI *EFI_GET_RESULT_COUNT) (
              IN EFI_STANDARD_TEST_LIBRARY_PROTOCOL
                                                               *This,
              IN EFI_TEST_ASSERTION
                                                               Type,
              OUT UINT32
                                                               *Count
              )
Usage Model
            {
              EFI_STATUS
                                                           Status;
              EFI_STANDARD_TEST_LIBRARY_PROTOCOL
                                                           *StandardLib;
              UINT32
                                                           PassedCount;
            11
            // Locate the test support libraries
            Status = BS->LocateProtocol (
                              &gEfiStandardTestLibraryGuid,
                              NULL,
                              &StandardLib
                                );
              If (EFI_ERROR (Status)) {
              return EFI_UNSUPPORTED;
            }
            11
            // Record assertion
            StandardLib->RecordAssertion (
            StandardLib,
            EFI_TEST_ASSERTION_PASSED,
            gSampleAppTestAssertionGuid001,
            L"Sample Assertion 001",
            L"%a:%d:put the detail information at here",
            __FILE__,
```

```
__LINE__
);
  11
// Record message
11
StandardLib->RecordMessage (
StandardLib,
EFI_VERBOSE_LEVEL_DEFAULT,
L" %a:%d:put the detail information at here",
__FILE__,
__LINE__
);
  11
// Get result count
StandardLib->GetResultCount (
StandardLib,
EFI_TEST_ASSERTION_PASSED,
&PassedCount
Print (L"Passed Count: %d\n", PassedCount);
return EFI_SUCCESS;
}
```

A.2 Test Recovery Services

The test recovery services are provided by an EFI Test Recovery Library Protocol. The protocol is responsible for handling the system reset in the test execution. All test cases that are required to reset the test system in the test execution could use the test recovery services to set and get the recovery data.

Protocol Interface Structure

```
typedef struct _EFI_TEST_RECOVERY_LIBRARY_PROTOCOL {
 UINT64
                                                  LibraryRevision;
  CHAR16
                                                  *Name;
  CHAR16
                                                  *Description;
 EFI TRL READ RESET RECORD
                                                  ReadResetRecord:
 EFI_TRL_WRITE_RESET_RECORD
                                                  WriteResetRecord;
} EFI_TEST_RECOVERY_LIBRARY_PROTOCOL;
typedef
EFI_STATUS
(EFIAPI *EFI_TRL_READ_RESET_RECORD) (
  IN EFI TEST RECOVERY LIBRARY PROTOCOL
                                                   *This,
 OUT UINTN
                                                   *Size,
 OUT VOID
                                                   *Buffer
typedef
EFI_STATUS
(EFIAPI *EFI TRL WRITE RESET RECORD) (
  IN EFI_TEST_RECOVERY_LIBRARY_PROTOCOL
                                                   *This,
  IN UINTN
                                                   Size,
  IN VOID
                                                   *Buffer
```

Usage Model

The function below uses the test recovery service to verify the variable still exists across a power cycle.

```
11
// Locate the test support libraries
Status = BS->LocateProtocol (
             &gEfiTestRecoveryLibraryGuid,
             NULL,
             &RecoveryLib
              );
 If (EFI_ERROR (Status)) {
 return EFI_UNSUPPORTED;
}
11
// Read the recovery record
11
Status = RecoveryLib->ReadResetRecord (
RecoveryLib,
&BufferSize,
Buffer
);
 If (EFI_ERROR (Status)) {
 return EFI_UNSUPPORTED;
If (BufferSize == 0) || (Buffer[0] == 0)) {
 //
// Set a variable
 Attribute = EFI_VARIABLE_NON_VOLATILE
                EFI_VARIABLE_BOOTSERVICE_ACCESS |
                EFI_VARIABLE_RUNTIME_ACCESS;
 DataSize = 10;
  Status = RT->SetVariable (
                    L"Test Variable",
                    &gEfiTestVariableGuid,
                    Attributes,
                    DataSize,
                    Data
);
    If (EFI_ERROR (Status)) {
   return EFI_UNSUPPORTED;
}
  //
```

```
// Write the recovery record
11
 Buffer[0] = 1;
 Status = RecoveryLib->WriteResetRecord (
RecoveryLib,
Buffer
);
   If (EFI_ERROR (Status)) {
   return EFI_UNSUPPORTED;
}
 // Reset the system
 RT->ResetSystem (EfiResetCold, 0, 0, NULL);
} else {
 //
 // Clear the recovery record
 Status = RecoveryLib->WriteResetRecord (
                               RecoveryLib,
                               Ο,
                               Buffer
);
    If (EFI_ERROR (Status)) {
   return EFI_UNSUPPORTED;
}
11
// Get the variable
 //
 DataSize = 10;
 Status = RT->GetVariable (
                    L"Test Variable",
                    &gEfiTestVariableGuid,
                    &Attributes,
                    &DataSize,
                    Data
) ;
// Here ship the validation code
 11
```

```
}
return EFI_SUCCESS;
}
```

A.3 Test Logging Services

The test logging services are provided by an EFI Test Logging Library Protocol. This protocol is responsible for reporting test messages. It provide more control over output than the service RecordMessage() in the Standard Test Library Protocol..

Protocol Interface Structure

```
typedef struct _EFI_TEST_LOGGING_LIBRARY_PROTOCOL {
  UINT64
                                               LibraryRevision;
  CHAR16
                                               *Name;
                                               *Description;
  CHAR16
  EFI_TLL_LINE
                                               Line;
  EFI_TLL_ENTER_FUNCTION
                                               EnterFunction:
  EFI_TLL_EXIT_FUNCTION
                                               ExitFunction;
  EFI_TLL_DUMP_MASK
                                               DumpMask;
  EFI_TLL_DUMP_BUF
                                               DumpBuf;
} EFI_TEST_LOGGING_LIBRARY_PROTOCOL;
typedef
EFI_STATUS
(EFIAPI *EFI_TLL_LINE) (
  IN EFI_TEST_LOGGING_LIBRARY_PROTOCOL
                                                *This,
  IN EFI_VERBOSE_LEVEL
                                                VerboseLevel,
  IN UINT32
                                                Length
  )
```

```
typedef
EFI_STATUS
(EFIAPI *EFI_TLL_ENTER_FUNCTION) (
 IN EFI_TEST_LOGGING_LIBRARY_PROTOCOL
                                                *This,
 IN CHAR16
                                                *FunctionName,
 IN CHAR16
                                                 *Format,
  )
typedef
EFI_STATUS
(EFIAPI *EFI_TLL_EXIT_FUNCTION) (
 IN EFI_TEST_LOGGING_LIBRARY_PROTOCOL
                                                *This,
 IN CHAR16
                                                *FunctionName,
 IN CHAR16
                                                 *Format,
  )
typedef
EFI_STATUS
(EFIAPI *EFI_TLL_DUMP_MASK) (
 IN EFI_TEST_LOGGING_LIBRARY_PROTOCOL
                                                *This,
 IN EFI_VERBOSE_LEVEL
                                                VerboseLevel,
 IN UINT32
                                                BitMask,
 IN UINT32
                                                 Length
  )
typedef
EFI_STATUS
(EFIAPI *EFI_TLL_DUMP_BUF) (
 IN EFI_TEST_LOGGING_LIBRARY_PROTOCOL
                                                  *This,
 IN EFI_VERBOSE_LEVEL
                                                  VerboseLevel,
 IN CHAR16
                                                  *Buffer,
 IN UINT32
                                                  Length,
 IN UINT32
                                                  Flags
  )
```

Usage Model

The function below invokes the five test logging services. But in SCT, a filter is created for all recorded messages. It is set to **EFI_VERBOSE_LEVEL_DEFAULT**. So the output of two special services EnterFunction() and ExitFunction() will not be recorded.

```
//
// Insert a line "---" into a log file
11
LoggingLib->Line (
                 LoggingLib,
                 EFI_VERBOSE_LEVEL_DEFAULT,
                 80
);
 11
// Enter a function. It is put at the entry point of a function.
LoggingLib->EnterFunction (
                 LoggingLib,
                 L"Function Name",
L"%a:%d:put the detail information here",
__FILE__,
__LINE__
);
 11
// Exit a function. It is put at the exit point of a function.
LoggingLib->ExitFunction (
                 LoggingLib,
                 L"Function Name",
L"%a:%d:put the detail information here",
__FILE__,
__LINE__
);
11
// Dump a bitmap buffer
//
LoggingLib->DumpMask (
                 LoggingLib,
                 EFI_VERBOSE_LEVEL_DEFAULT,
                 0x00F0FF00,
                 32
);
// Dump a buffer
//
LoggingLib->DumpMask (
                 LoggingLib,
                 EFI_VERBOSE_LEVEL_DEFAULT,
```

A.4 Test Profile Services

The test profile services are provided by an EFI Test Profile Library Protocol. This protocol is responsible for handling the file in INI format.

Protocol Interface Structure

```
typedef struct _EFI_TEST_PROFILE_LIBRARY_PROTOCOL {
  UINT64
                                           LibraryRevision;
  CHAR16
                                           *Name;
  CHAR16
                                           *Description;
  EFI TPL INI OPEN
                                           EfiIniOpen;
  EFI_TPL_INI_CREATE
                                           EfiIniCreate;
  EFI_TPL_INI_CLOSE
                                           EfiIniClose;
 EFI_TPL_GET_SYSTEM_DEVICE_PATH
                                           EfiGetSystemDevicePath;
 EFI_TPL_SET_SYSTEM_DEVICE_PATH
                                           EfiSetSystemDevicePath;
} EFI_TEST_PROFILE_LIBRARY_PROTOCOL;
typedef
EFI_STATUS
(EFIAPI *EFI_TPL_INI_OPEN) (
  IN EFI_TEST_PROFILE_LIBRARY_PROTOCOL
                                            *This,
  IN EFI_DEVICE_PATH_PROTOCOL
                                            *DevicePath,
  IN CHAR16
                                            *FileName,
 OUT EFI_INI_FILE
                                            **FileHandle
typedef
EFI_STATUS
(EFIAPI *EFI_TPL_INI_CREATE) (
  IN EFI_TEST_PROFILE_LIBRARY_PROTOCOL
                                            *This,
 IN EFI_DEVICE_PATH_PROTOCOL
                                            *DevicePath,
  IN CHAR16
                                            *FileName,
 OUT EFI_INI_FILE
                                            **FileHandle
typedef
EFI_STATUS
(EFIAPI *EFI_TPL_INI_CLOSE) (
  IN EFI_TEST_PROFILE_LIBRARY_PROTOCOL
                                            *This,
 IN EFI_INI_FILE
                                            *FileHandle
typedef
EFI_STATUS
(EFIAPI *EFI_TPL_GET_SYSTEM_DEVICE_PATH) (
  IN EFI_TEST_PROFILE_LIBRARY_PROTOCOL
                                             *This,
 OUT EFI_DEVICE_PATH_PROTOCOL
                                             **DevicePath,
  OUT CHAR16
                                             **FilePath
  )
```

```
typedef
EFI_STATUS
(EFIAPI *EFI_TPL_SET_SYSTEM_DEVICE_PATH) (
  IN EFI_TEST_PROFILE_LIBRARY_PROTOCOL
                                           *This,
  IN EFI_DEVICE_PATH_PROTOCOL
                                           *DevicePath,
  IN CHAR16
                                           *FilePath
  )
typedef struct _EFI_INI_FILE {
 UINT64
                                           Revision;
 EFI_INI_GETSTRING
                                           GetString;
 EFI_INI_SETSTRING
                                           SetString;
 EFI_INI_RMSECTION
                                           RmSection;
 EFI_INI_GETSTRING_BYORDER
                                           GetStringByOrder;
 EFI_INI_SETSTRING_BYORDER
                                           SetStringByOrder;
 EFI_INI_RMSECTION_BYORDER
                                           RmSectionByOrder;
 EFI_INI_GETORDERNUM
                                           GetOrderNum;
 EFI_INI_FLUSH
                                           Flush;
} EFI_INI_FILE, *EFI_INI_FILE_HANDLE;
typedef
EFI_STATUS
(EFIAPI *EFI_INI_FLUSH) (
 IN EFI_INI_FILE
                                           *This
  )
typedef
EFI_STATUS
(EFIAPI *EFI_INI_GETSTRING) (
        EFI_INI_FILE
                                          *This,
  IN
         CHAR16
                                          *Section,
         CHAR16
                                          *Entry,
    OUT CHAR16
                                          *String,
  IN OUT UINT32
                                          *MaxLength
typedef
EFI_STATUS
(EFIAPI *EFI_INI_SETSTRING) (
 IN EFI_INI_FILE
                                          *This,
 IN CHAR16
                                          *Section,
  IN CHAR16
                                          *Entry,
  IN CHAR16
                                          *String
```

```
)
typedef
EFI_STATUS
(EFIAPI *EFI_INI_RMSECTION) (
 IN EFI_INI_FILE
                                           *This,
 IN CHAR16
                                           *Section
typedef
EFI_STATUS
(EFIAPI *EFI_INI_GETSTRING_BYORDER) (
        EFI_INI_FILE
                                           *This,
 IN
        UINT32
                                           Order,
  IN
         CHAR16
                                           *Section,
         CHAR16
                                           *Entry,
 IN
    OUT CHAR16
                                           *String,
 IN OUT UINT32
                                           *MaxLength
typedef
EFI_STATUS
(EFIAPI *EFI_INI_SETSTRING_BYORDER) (
 IN EFI_INI_FILE
                                           *This,
 IN UINT32
                                           Order,
 IN CHAR16
                                           *Section,
  IN CHAR16
                                           *Entry,
  IN CHAR16
                                           *String
typedef
EFI_STATUS
(EFIAPI *EFI_INI_RMSECTION_BYORDER) (
 IN EFI_INI_FILE
                                           *This,
 IN UINT32
                                           Order,
  IN CHAR16
                                           *Section
  )
typedef
EFI_STATUS
(EFIAPI *EFI_INI_GETORDERNUM) (
 IN EFI_INI_FILE
                                          *This,
 IN CHAR16
                                          *Section,
 OUT UINT32
                                          *OrderNum
```

)

Usage Model

Assume an INI file, named as test.ini, is put in the root directory of UEFI SCT folder

```
[Test Data1]
Key1 = Value1
Key2 = Value2

[Test Data2]
Key1 = Value3
Key2 = Value4
```

The function below reads the data in the INI file.

```
{
 EFI_STATUS
                                            Status;
 EFI_TEST_PROFILE_LIBRARY_PROTOCOL
                                            *ProfileLib;
 EFI_DEVICE_PATH
                                            *SystemDevicePath;
 CHAR16
                                            *SystemFilePath;
  CHAR16
                                            *FileName;
 EFI_INI_FILE_HANDLE
                                            IniFileHandle;
 UINT32
                                            OrderNum;
 UINT32
                                            ValueSize;
  CHAR16
                                            Value[20];
  11
  // Locate the test support libraries
  Status = BS->LocateProtocol (
&gEfiTestProfileLibraryGuid,
NULL,
&ProfileLib
);
 if (EFI_ERROR (Status)) {
   return EFI_UNSUPPORTED;
}
// Get the system device path and file path
11
Status = ProfileLib->EfiGetSystemDevicePath (
                            ProfileLib,
                            &SystemDevicePath,
                            &SystemFilePath
);
 if (EFI_ERROR (Status)) {
   return EFI_UNSUPPORTED;
}
 11
// Create the path of the INI file
 FileName = PoolPrint (L"%s\\%s", SystemFilePath, L"test.ini");
 If (FileName == NULL) {
 BS->FreePool (SystemDevicePath);
 BS->FreePool (SystemFilePath);
 return EFI_UNSUPPORTED;
}
```

```
BS->FreePool (SystemFilePath);
11
// Open the INI file
Status = ProfileLib->EfiIniOpen (
                            ProfileLib,
                            SystemDevicePath,
                            FileName,
                            &IniFileHandle
);
  If (EFI_ERROR (Status)) {
  BS->FreePool (SystemDevicePath);
  BS->FreePool (FileName);
  return EFI_UNSUPPORTED;
}
BS->FreePool (SystemDevicePath);
BS->FreePool (FileName);
// Get the number of required sections
Status = IniFileHandle->GetOrderNum (
                               IniFileHandle,
                               L"Test Data",
                                &OrderNum
);
  if (EFI_ERROR (Status) || (OrderNum < 2)) {</pre>
ProfileLib->EfiIniClose (ProfileLib, IniFileHandle);
return EFI_UNSUPPORTED;
}
// Read the Keyl's value in the second section (start from 0)
ValueSize = 20;
Status = IniFileHandle->GetStringByOrder (
                               IniFileHandle,
                                (UINT32)1,
                               L"Test Data",
                               L"Key1",
                               Value,
```

&ValueSize

```
if (EFI_ERROR (Status)) {
ProfileLib->EfiIniClose (ProfileLib, IniFileHandle);
Return EFI_UNSUPPORTED;
}
Print (L"Key1's value in the second section: %s", Value);

//
// Close the INI file
//
ProfileLib->EfiIniClose (ProfileLib, IniFileHandle);

return EFI_SUCCESS;
}
```