

The Ten Soldering Commandments

- I. Thou shalt wear eye protection whenever thou solderest, lest they get molten solder in thine eye.
- II. Thou shalt not touch the heated end of thy soldering iron, lest they burn thyself.
- III. Thou shalt not fashion molten solder into false globs.
- IV. Thou shalt wash thy hands after thou solderest, to remove vile contamination from upon thy hands before thou eatest.
- V. Thou shalt provide bright illumination upon thine objects which thou solderest, that might see clearly the way unto which the solder may be applied.
- VI. Thou shalt not spill they excess solder upon thy neighbour's pad lest they create unintended pathways through which current may flow.
- VII. Thou shalt not leave thine hot soldering iron unattended.
- VIII. Thou shalt not covet they neighbours professional-grade temperature-controlled soldering station.
- IX. Thou shalt not apply solder directly upon thine solder iron, but shall instead apply solder to the objects which thou solderest that their heat may melteth they solder.
- X. Thou shalt always place thine hot soldering iron in a suitable holder.

(D Lowe and D Ross, 2014, Electronics for Dummies – Getting Started with Electronics,)

Soldering Safety

1. Always wear safety glasses
2. Do not touch the hot end of the soldering iron
3. Do not play with solder
4. Wash your hands after soldering and before eating
5. Make sure you have even light to see what you are doing
6. Use the minimum solder you need to complete the task
7. NEVER leave a hot soldering iron unattended
8. Use your own tools - do not 'borrow' your neighbours'
9. Apply solder to the object not to the soldering iron
10. Always use a stand for your soldering iron