

Technos Ird

88E1111 Datasheet

Integrated 10/100/1000 Ultra Gigabit Ethernet Transceiver

Doc. No. MV-S100649-00, Rev. G February 10, 2006

MOVING FORWARD

FASTER®





Document S	Document Status						
Advance Information	is document contains design specifications for initial product development. Specifications may change hout notice. Contact Marvell Field Application Engineers for more information.						
Preliminary Information	This document contains preliminary data, and a revision of this document will be published at a later date. Specifications may change without notice. Contact Marvell Field Application Engineers for more information.						
Final Information	This document contains specifications on a product that is in final release. Specifications may change without notice. Contact Marvell Field Application Engineers for more information.						
Revision Code:	Rev. G						
Preliminary	Technical Publications: 2.70						

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose, without the express written permission of Marvell. Marvell retains the right to make changes to this document at any time, without notice. Marvell makes no warranty of any kind, expressed or implied, with regard to any information contained in this document, including, but not limited to, the implied warranties of merchantability or fitness for any particular purpose. Further, Marvell does not warrant the accuracy or completeness of the information, text, graphics, or other items contained within this document.

Marvell products are not designed for use in life-support equipment or applications that would cause a life-threatening situation if any such products failed. Do not use Marvell products in these

types of equipment or applications.

With respect to the products described herein, the user or recipient, in the absence of appropriate U.S. government authorization, agrees:

the U.S. Munitions List (USML).

At all times hereunder, the recipient of any such information agrees that they shall be deemed to have manually signed this document in connection with their receipt of any such information. Copyright © 2006. Marvell International Ltd. All rights reserved. Marvell, the Marvell logo, Moving Forward Faster, Alaska, Fastwriter, Datacom Systems on Silicon, Libertas, Link Street, NetGX, PHYAdvantage, Prestera, Raising The Technology Bar, The Technology Within, Virtual Cable Tester, and Yukon are registered trademarks of Marvell. Ants, AnyVoltage, Discovery, DSP Switcher, Feroceon, GalNet, GalTis, Horizon, Marvell Makes It All Possible, RADLAN, UniMAC, and VCT are trademarks of Marvell. All other trademarks are the property of their respective

Doc. No. MV-S100649-00 Rev. G

¹⁾ Not to re-export or release any such information consisting of technology, software or source code controlled for national security reasons by the U.S. Export Control Regulations ("EAR"), to a national of EAR Country Groups D:1 or E:2;
2) Not to export the direct product of such technology or such software, to EAR Country Groups D:1 or E:2, if such technology or software and direct products thereof are controlled for national

security reasons by the EAR; and,
3) In the case of technology controlled for national security reasons under the EAR where the direct product of the technology is a complete plant or component of a plant, not to export to EAR Country Groups D:1 or E:2 the direct product of the plant or major component thereof, if such direct product is controlled for national security reasons by the EAR, or is subject to controls under the U.S. Munitions List ("USML").



OVERVIEW

MARVELL CONFIDENTIA

The Alaska[®] Ultra 88E1111 Gigabit Ethernet Transceiver is a physical layer device for Ethernet 1000BASE-T, 100BASE-TX, and 10BASE-T applications. It is manufactured using standard digital CMOS process and contains all the active circuitry required to implement the physical layer functions to transmit and receive data on standard CAT 5 unshielded twisted pair.

The 88E1111 device incorporates the Marvell Virtual Cable Tester™ (VCT™) feature, which uses Time Domain Reflectometry (TDR) technology for the remote identification of potential cable malfunctions, thus reducing equipment returns and service calls. Using VCT, the Alaska 88E1111 device detects and reports potential cabling issues such as pair swaps, pair polarity and excessive pair skew. The device will also detect cable opens, shorts or any impedance mismatch in the cable and report accurately within one meter the distance to the fault.

The 88E1111 device supports the Gigabit Media Independent Interface (GMII), Reduced GMII (RGMII), Serial Gigabit Media Independent Interface (SGMII), the Ten-Bit Interface (TBI), and Reduced TBI (RTBI) for direct connection to a MAC/Switch port.

The 88E1111 device incorporates an optional 1.25 GHz SERDES (Serializer/Deserializer). The serial interface may be connected directly to a fiber-optic transceiver for 1000BASE-T/1000BASE-X media conversion applications. Additionally, the 88E1111 device may be used to implement 1000BASE-T Gigabit Interface Converter (GBIC) or Small Form Factor Pluggable (SFP) modules.


The 88E1111 device uses advanced mixed-signal processing to perform equalization, echo and crosstalk cancellation, data recovery, and error correction at a gigabit per second data rate. The device achieves robust performance in noisy environments with very low power dissipation.

The 88E1111 device is offered in three different package options including a 117-Pin TFBGA, a 96-pin BCC featuring a body size of only 9 x 9 mm, and a 128 PQFP package.


FEATURES

- 10/100/1000BASE-T IEEE 802.3 compliant
- Supports GMII, TBI, reduced pin count GMII (RGMII), reduced pin count TBI (RTBI), and serial GMII (SGMII) interfaces
- Integrated 1.25 GHz SERDES for 1000BASE-X fiber applications
- Four RGMII timing modes
- Energy Detect and Energy Detect+ low power modes
- Three loopback modes for diagnostics
- "Downshift" mode for two-pair cable installations
- Fully integrated digital adaptive equalizers, echo cancellers, and crosstalk cancellers
- Advanced digital baseline wander correction
- Automatic MDI/MDIX crossover at all speeds of operation
- Automatic polarity correction
- IEEE 802.3u compliant Auto-Negotiation
- Software programmable LED modes including LED testing
- Automatic detection of fiber or copper operation
- Supports IEEE 1149.1 JTAG
- Two-Wire Serial Interface (TWSI) and MDC/MDIO
- CRC checker, packet counter
- Packet generation
- Virtual Cable Tester (VCT)
- Auto-Calibration for MAC Interface outputs
- Requires only two supplies: 2.5V and 1.0V (with 1.2V option for the 1.0V supply)
- I/Os are 3.3V tolerant
- Low power dissipation Pave = 0.75W
- 0.13 μm digital CMOS process
- 117-Pin TFBGA, 96-Pin BCC, and 128 PQFP package options
- 117-Pin TFBGA and 96-Pin BCC packages available in Commercial or Industrial grade
- Lead-free packages available






88E1111 Device used in Copper Application



88E1111 Device used in Fiber Application



88E1111 RGMII/GMII MAC to SGMII MAC Conversion

Doc. No. MV-S100649-00, Rev. G

Table of Contents

SEC		SIGNAL DESCRIPTION	
1.1	117-Pin	TFBGA Package	10
1.2	96-Pin E	BCC Package	11
1.3	128-Pin	PQFP Package	12
1.4		criptionin Type Definitions	
1.5	I/O State	e at Various Test or Reset Modes	37
1.6	117-Pin	TFBGA Pin Assignment List - Alphabetical by Signal Name	38
1.7	96-Pin B	BCC Pin Assignment List - Alphabetical by Signal Name	40
1.8	128-Pin	PQFP Pin Assignment List - Alphabetical by Signal Name	42
SEC	TION 2.	FUNCTIONAL DESCRIPTION	44
2.1	2.1.1 M 2.1.2 N	Device Interface Description	45 47
2.2	MAC Int	erfaces	48
	2.2.1 G 2.2.2 T 2.2.3 R 2.2.4 R 2.2.5 S	Sigabit Media Independent Interface (GMII/MII) en-Bit Interface Leduced Pin Count GMII (RGMII) Leduced Pin Count TBI (RTBI) GMII Interface Lerial MAC Interface	
2.3	88E1111	Device Modes of Operation	57
	2.3.1 M 2.3.2 M 2.3.3 G	Nodes of Operation for Copper Media	58 61 61
2.4	2.4.1 8	re Configuration	65
2.5	Synchro	onizing FIFO	69
2.6	2.6.1 T	Media Transmit and Receive Functionsransmit Side Network Interfacencoder	70

MARVELL CONFIDENTIAL



88E1111 Integrated 10/100/1000 Ultra Gigabit Ethernet Transceiver

	2.6.3	Receive Side Network Interface	.70
		Decoder	
2.7	Power	Supplies	73
		VDDO	
	2.7.2	VDDOH	.73
	2.7.3	VDDOX	.73
	2.7.4	AVDD	.73
	2.7.5	DVDD	.73
		WO P	
2.8		Management	
		Low Power Modes	
		Enabling Low Power Modes	
	2.8.3	Low Power Operating Modes	
	2.8.4	125CLK and MAC Interface Effect on Low Power Modes	.76
2 0	Manage	ement Interface	77
2.9			
		Extended Register Access	
		Preamble Suppression	
	2.9.3	Programming Interrupts	.79
2 10	Tw/0-14	vire Serial Interface	ደበ
2.10		Bus Operation	
		Read and Write Operations	
	2.10.2	Nead and Write Operations	.01
2.11	Auto-N	legotiation	84
		10/100/1000BASE-T Auto-Negotiation	
		1000BASE-X Auto-Negotiation	
		SGMII Auto-Negotiation	
		GBIC Mode Auto-Negotiation	
		Auto-Media Detect Auto-Negotiation	
		Serial Interface Auto-Negotiation Bypass Mode	
4		The state of the s	
2.12	Fiber/C	Copper Auto-Selection	88
	2.12.1	Preferred Media for Fiber/Copper Auto-Selection	.89
	_	shift Feature	
2 4 4	Looph	ack Modes	01
2.14	Loops	MAC Interfered Learnhealt	3 1
		MAC Interface Loopback	
		Copper Line Loopback	
		External 1000 Mbps Loopback	
2.15	Virtual	Cable Tester™ (VCT™) Feature	96
2.16	MDI/MI	DIX Crossover	97
2.17	Polarit	y Correction	98
		erminal Equipment (DTE) Detect	
2 . 10	Dala I	erminar Equipment (DTE) Detect	33
2.19		atic and Manual Impedance Calibration1	00
	2 19 1	MAC Interface Calibration Circuit	100

	2.19.2	MAC Interface Calibration Register Definitions	100
		Changing Auto Calibration Targets	
	2.19.4	Manual Settings to The Calibration Registers	102
		et Generator	
2.21	CRC E	Error Counter and Frame Counter	105
		Enabling The CRC Error Counter and Frame Counter	
	LEDI	nterface	407
2.22			
		Manual LED ControlLED Functionality	
	2.22.2	LED I difficionality	100
2.23		1149.1 Controller	
		Bypass Instruction	
	2.23.2	Sample/Preload Instruction	113
2.24	88E1	111 Device Boundary Scan Chain Order	114
		Extest Instruction	
		The Clamp Instruction	
		The HIGH-Z Instruction	
	2.24.4	ID CODE Instruction	116
SEC	TION 3	B. Register Description	117
		9 ¹ C	
SEC	TION 4	ELECTRICAL SPECIFICATIONS	189
			200
4.1		ute Maximum Ratings	
4.2	Recor	mmended Operating Conditions	190
8			
4.3	Packa	ge Thermal Information	191
	4.3.1	Thermal Conditions for 117-Pin TFBGA Package	
	4.3.2	Thermal Conditions for 96-Pin BCC Package	
	4.3.3	Thermal Conditions for 128-Pin PQFP Package	
4.4	DC El	ectrical Characteristics	
	4.4.1	Current Consumption AVDDH, AVDDL	194
	4.4.2	Current Consumption VDDO, VDDOX, VDDOH	
	4.4.3	Current Consumption Center_Tap	
	4.4.4	Current Consumption DVDD	195
4.5	DC Or	perating Conditions	196
	4.5.1	Digital Pins	
	4.5.2	Internal Resistor Description	
4.0		DC Transceiver Parameters	000
4.6			
	4.6.1	Serial and SGMII Interface	
4.7	AC Ti	ming Reference Values	206
		ectrical Specifications	
4.8	AC FI	ectrical Specifications	207
	4.8.1	Reset Timing	



88E1111 Integrated 10/100/1000 Ultra Gigabit Ethernet Transceiver

	4.8.2	XTAL1 Input Clock Timing	208
	4.8.3	125CLK Output Timing	209
4.9	CMILL	nterface Timing	210
7.5	4.9.1	GMII Transmit Timing	
	4.9.2	GMII Receive Timing	
4.10		erface Timing	
		100 Mbps MII Transmit Timing	
		10 Mbps MII Transmit Timing	
		100 Mbps MII Receive Timing	
	4.10.4	10 Mbps MII Receive Timing	214
4.11	TBI In	terface Timingterface Timing	215
		TBI Transmit Timing	
		TBI Receive Timing	
4 40	DCMII	/RTBI Interface Timing	247
4.12			
		RGMII AC Characteristics	
4.13	Serial	and SGMII Interface Timing	220
		Serial Interface and SGMII Transmitter AC Characteristics	
	4.13.2	Serial Interface and SGMII Receiver AC Characteristics	220
4.14	Laten	cy Timing	221
		GMII to 1000BASE-T Transmit Latency Timing	
		MII to 100BASE-TX Transmit Latency Timing	
		MII to 10BASE-T Transmit Latency Timing	
		1000BASE-T to GMII Receive Latency Timing	
		100BASE-TX to MII Receive Latency Timing	
		10BASE-T to MII Receive Latency Timing	
·6 ^T	4.14.7	GMII to 1000BASE-X Transmit Latency Timing	225
S.	4.14.8	1000BASE-X to GMII Receive Latency Timing	226
		RGMII to 1000BASE-T Transmit Latency Timing	
		RGMII to 100BASE-TX Transmit Latency Timing	
		RGMII to 10BASE-T Transmit Latency Timing	
		2 1000BASE-T to RGMII Receive Latency Timing	
		100BASE-TX to RGMII Receive Latency Timing	
		10BASE-T to RGMII Receive Latency Timing	
		RGMII to 1000BASE-X Transmit Latency Timing	
		1000BASE-X to RGMII Receive Latency Timing	
		' TBI to 1000BASE-T Transmit Latency Timing	
		3 1000BASE-T to TBI Receive Latency Timing	
		RTBI to 1000BASE-T Transmit Latency Timing	
		1000BASE-T to RTBI Receive Latency Timing	
		SGMII to 10/100/1000BASE-T Transmit Latency Timing	
		2 10/100/1000BASE-T to SGMII Receive Latency Timing	
		3 1000BASE-X to 1000BASE-T Transmit Latency Timing	
	4.14.24	1000BASE-T to 1000BASE-X Receive Latency Timing	∠১೬

4.15	Serial Management Interface, Two-Wire Serial Interface, and JTAG Timing	240
	4.15.1 Serial Management Interface Timing	
	4.15.2 Two-Wire Serial Interface (TWSI) Timing	241
	4.15.3 JTAG Timing	
4.16	IEEE AC Transceiver Parameters	243
	الآي.	
SEC	TION 5. PACKAGE MECHANICAL DIMENSIONS	244
5.1	117-pin TFBGA Package	244
5.2	96-pin BCC Package - Top View	246
5.3	96-Pin BCC Package - Bottom View	247
5.4	128-Pin PQFP Package	248
SEC	TION 6. ORDER INFORMATION	249
6.1	Ordering Part Numbers and Package Markings	249
	6.1.1 RoHS 6/6 Compliant Marking Examples	
	6.1.2 Non Lead-free Marking Examples	



Section 1. Signal Description


The 88E1111 device is a 10/100/1000BASE-T/1000BASE-X Gigabit Ethernet transceiver.

1.1 117-Pin TFBGA Package

Figure 1: 88E1111 Device 117-Pin TFBGA Package (Top View)

	1	2	3	4	5	6	7	8	9	
Α	RXD5	RXD6	S_IN+	S_IN-	S_CLK+	S_CLK-	S_OUT+	S_OUT-	LED_ LINK1000	А
В	RX_DV	RXD0	RXD3	VDDO	CRS	COL	AVDD	LED_ LINK100	VDDOH	В
С	RX_CLK	VDDO	RXD2	RXD4	RXD7	DVDD	DVDD	LED_ LINK10	LED_RX	С
D	TX_CLK	RX_ER	RXD1	VSS	VSS	VSS	DVDD	CONFIG[0]	LED_TX	D
Е	TX_EN	GTX_CLK	DVDD	VSS	VSS	VSS	DVDD	LED_ DUPLEX	CONFIG[1]	E
F	TXD0	TX_ER	DVDD	VSS	VSS	VSS	VDDOH	CONFIG[2]	CONFIG[4]	F
G	NC	TXD1	TXD2	VSS	VSS	VSS	CONFIG[3]	CONFIG[6]	CONFIG[5]	G
Н	TXD4	TXD3	TXD5	VSS	VSS	VSS	VSSC	SEL_ FREQ	XTAL1	Э
J O	TXD6	TXD7	DVDD	VSS	VSS	VSS	DVDD	VDDOH	XTAL2	J
K	VDDO	125CLK	RESETn	VSS	VSS	VSS	NC	TDO	VDDOX	К
L	INTn	VDDOX	MDC	COMA	VSS	VSS	TDI	TMS	TCK	L
М	MDIO	RSET	AVDD	AVDD	HSDAC+	HSDAC-	AVDD	AVDD	TRSTn	М
N	MDI[0]+	MDI[0]-	MDI[1]+	MDI[1]-	AVDD	MDI[2]+	MDI[2]-	MDI[3]+	MDI[3]-	N
	1	2	3	4	5	6	7	8	9	

Figure 2: Pin A1 Location




Doc. No. MV-S100649-00, Rev. G

256xg0euupqdu92f-elp5025j * Prophet Electronic Technology Ltd. * UNDER NDA# 12104893

1.2 96-Pin BCC Package

Figure 3: 88E1111 Device 96-Pin BCC Package (Top View)






1.3 128-Pin PQFP Package

88E1111

Figure 4: 88E1111 Device 128-Pin PQFP Package (Top View)



1.4 Pin Description

1.4.1 Pin Type Definitions

Pin Type	Definition
Н	Input with hysteresis
I/O	Input and output
1	Input only
0	Output only
PU	Internal pull up
PD	Internal pull down
D	Open drain output
Z	Tri-state output
mA	DC sink capability



Table 1: Media Dependent Interface

117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
N1 N2	29 31	41 42	MDI[0]+ MDI[0]-	I/O, D	Media Dependent Interface[0]. In 1000BASE-T mode in MDI configuration, MDI[0]± correspond to BI_DA±. In MDIX configuration, MDI[0]± correspond to BI_DB±. In 100BASE-TX and 10BASE-T modes in MDI configuration, MDI[0]± are used for the transmit pair. In MDIX configuration, MDI[0]± are used for the receive pair. MDI[0]± should be tied to ground if not used. See Section 2.16 "MDI/MDIX Crossover" on page 97.
N3 N4	33 34	46 47	MDI[1]+ MDI[1]-	I/O, D	Media Dependent Interface[1]. In 1000BASE-T mode in MDI configuration, MDI[1]± correspond to BI_DB±. In MDIX configuration, MDI[1]± correspond to BI_DA±. In 100BASE-TX and 10BASE-T modes in MDI configuration, MDI[1]± are used for the receive pair. In MDIX configuration, MDI[1]± are used for the transmit pair. MDI[1]± should be tied to ground if not used. See Section 2.16 "MDI/MDIX Crossover" on page 97.

Table 1: Media Dependent Interface (Continued)

117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
N6 N7	39 41	56 57	MDI[2]+ MDI[2]-	I/O, D	Media Dependent Interface[2]. In 1000BASE-T mode in MDI configuration, MDI[2]± correspond to BI_DC±. In MDIX configuration, MDI[2]± corresponds to BI_DD±. In 100BASE-TX and 10BASE-T modes, MDI[2]± are not used. MDI[2]± should be tied to ground if not used. See Section 2.16 "MDI/MDIX Crossover" on page 97.
N8 N9	42 43	61 62	MDI[3]+ MDI[3]-	I/O, D	Media Dependent Interface[3]. In 1000BASE-T mode in MDI configuration, MDI[3]± correspond to BI_DD±. In MDIX configuration, MDI[3]± correspond to BI_DC±. In 100BASE-TX and 10BASE-T modes, MDI[3]± are not used. MDI[3]± should be tied to ground if not used. See Section 2.16 "MDI/MDIX Crossover" on page 97.



The GMII interface supports both 1000BASE-T and 1000BASE-X modes of operation. The GMII interface pins are also used for the TBI interface. See Table 3 for TBI pin definitions. The MAC interface pins are 3.3V tolerant. See Section 4.5.1, "Digital Pins," on page 196 for details.

Table 2: GMII/MII Interfaces

88E1111

	1		200		
117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
E2	8	14	GTX_CLK	I	GMII Transmit Clock. GTX_CLK provides a 125 MHz clock reference for TX_EN, TX_ER, and TXD[7:0]. This clock can be stopped when the device is in 10/100BASE-T modes, and also during Auto-Negotiation.
D1	4		TX_CLK	O, Z	MII Transmit Clock. TX_CLK provides a 25 MHz clock reference for TX_EN, TX_ER, and TXD[3:0] in 100BASE-TX mode, and a 2.5 MHz clock reference in 10BASE-T mode.
	21:05				TX_CLK provides a 25 MHz, 2.5 MHz, or 0 MHz clock during 1000 Mbps Good Link, Auto-Negotiation, and Link Lost states depending on the setting of register 20.6:4.
300	33				The 2.5 MHz clock is the default rate, which may be programmed to another frequency by writing to register 20.6:4.
E1 JUNE	9	16	TX_EN	I	GMII and MII Transmit Enable. In GMII/MII mode when TX_EN is asserted, data on TXD[7:0] along with TX_ER is encoded and transmitted onto the cable.
					TX_EN is synchronous to GTX_CLK, and synchronous to TX_CLK in 100BASE-TX and 10BASE-T modes.
F2	7	13	TX_ER	-	GMII and MII Transmit Error. In GMII/MII mode when TX_ER and TX_EN are both asserted, the transmit error symbol is transmitted onto the cable. When TX_ER is asserted with TX_EN de-asserted, carrier extension symbol is transmitted onto the cable.
				100	TX_ER is synchronous to GTX_CLK, and synchronous to TX_CLK in 100BASE-TX and 10BASE-T modes.

117-TFBGA	96-BCC	128-PQFP	Pin Name	Pin	Description
Pin #	Pin #	Pin #		Type	
J2 J1 H3 H1 H2 G3 G2 F1	20 19 18 17 16 14 12 11	29 28 26 25 24 20 19 18	TXD[7] TXD[6] TXD[5] TXD[4] TXD[3]/TXD[3] TXD[2]/TXD[2] TXD[1]/TXD[1] TXD[0]/TXD[0]		GMII and MII Transmit Data. In GMII mode, TXD[7:0] present the data byte to be transmitted onto the cable in 1000BASE-T mode. In MII mode, TXD[3:0] present the data nibble to be transmitted onto the cable in 100BASE-TX and 10BASE-T modes. TXD[7:4] are ignored in these modes, but should be driven either high or low. These pins must not float. TXD[7:0] are synchronous to GTX_CLK, and synchronous to TX_CLK in 100BASE-TX and 10BASE-T modes. Inputs TXD[7:4] should be tied low if not used (e.g., RGMII mode).
C1	2	7	RX_CLK	O, Z	GMII and MII Receive Clock. RX_CLK provides a 125 MHz clock reference for RX_DV, RX_ER, and RXD[7:0] in 1000BASE-T mode, a 25 MHz clock reference in 100BASE-TX mode, and a 2.5 MHz clock reference in 10BASE-T mode. TX_TCLK comes from the RX_CLK pins used in jitter testing. Refer to Register 9 for jitter test modes.
B1	94	4	RX_DV	O, Z	GMII and MII Receive Data Valid. When RX_DV is asserted, data received on the cable is decoded and presented on RXD[7:0] and RX_ER. RX_DV is synchronous to RX_CLK.
D2	3	8	RX_ER	0, Z	GMII and MII Receive Error. When RX_ER and RX_DV are both asserted, the signals indicate an error symbol is detected on the cable. When RX_ER is asserted with RX_DV deasserted, a false carrier or carrier extension symbol is detected on the cable. RX_ER is synchronous to RX_CLK.



Table 2: GMII/MII Interfaces (Continued)

Table 2. Gi	viii/iviii iiiteii	aces (Contin	,		
117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
C5 A2 A1 C4 B3 C3 D3 B2	86 87 89 90 91 93 92 95	120 121 123 124 125 126 128 3	RXD[7] RXD[6] RXD[5] RXD[4] RXD[3]/RXD[3] RXD[2]/RXD[2] RXD[1]/RXD[1] RXD[0]/RXD[0]	O, Z	GMII and MII Receive Data. Symbols received on the cable are decoded and presented on RXD[7:0] in 1000BASE-T mode. In MII mode, RXD[3:0] are used in 100BASE-TX and 10BASE-T modes. In MII mode, RXD[7:4] are driven low. RXD[7:0] is synchronous to RX_CLK.
B5	84	115	CRS	O, Z	GMII and MII Carrier Sense. CRS asserts when the receive medium is non-idle. In half-duplex mode, CRS is also asserted during transmission. CRS assertion during half-duplex transmit can be disabled by programming register 16.11 to 0. CRS is asynchronous to RX_CLK, GTX_CLK, and TX_CLK.
B6 B6 III	83	114	COL	O, Z	GMII and MII Collision. In 10/100/ 1000BASE-T full-duplex modes, COL is always low. In 10/100/1000BASE-T half-duplex modes, COL asserts only when both the transmit and receive media are non-idle. In 10BASE-T half-duplex mode, COL is asserted to indicate signal quality error (SQE). SQE can be disabled by clearing register 16.2 to zero. COL is asynchronous to RX_CLK, GTX_CLK, and TX_CLK.

The TBI interface supports 1000BASE-T mode of operation. The TBI interface uses the same pins as the GMII interface. The MAC interface pins are 3.3V tolerant. See "Digital Pins" on page 196 for details.

Table 3: TBI Interface

Table 5: TBI Interface						
117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description	
E2	8	14	GTX_CLK/ TBI_TXCLK	I	TBI Transmit Clock. In TBI mode, GTX_CLK is used as TBI_TXCLK. TBI_TXCLK is a 125 MHz transmit clock. TBI_TXCLK provides a 125 MHz clock refer-	
		W.	18		ence for TX_EN, TX_ER, and TXD[7:0].	
D1	4	10	TX_CLK/RCLK1	O, Z	TBI 62.5 MHz Receive Clock- even code group. In TBI mode, TX_CLK is used as RCLK1.	
J2 J1 H3	20 19 18	29 28 26	TXD[7] TXD[6] TXD[5]	I	TBI Transmit Data. TXD[7:0] presents the data byte to be transmitted onto the cable.	
H1 H2 G3 G2	17 16 14 12	25 24 20 19	TXD[4] TXD[3] TXD[2] TXD[1]		TXD[9:0] are synchronous to GTX_CLK. Inputs TXD[7:4] should be tied low if not used (e.g., RTBI mode).	
E1	9	16	TXD[0] TX_EN/ TXD8	I	TBI Transmit Data. In TBI mode, TX_EN is used as TXD8. TXD[9:0] are synchronous to GTX_CLK.	
F2	7	13	TX_ER/ TXD9	I	TBI Transmit Data. In TBI mode, TX_ER is used as TXD9. TXD[9:0] are synchronous to GTX_CLK. TX_ER should be tied low if not used (e.g., RTBI mode).	
C1	2	7	RX_CLK/ RCLK0	O, Z	TBI 62.5 MHz Receive Clock- odd code group. In the TBI mode, RX_CLK is used as RCLK0.	
C5 A2 A1 C4 B3 C3 D3 B2	86 87 89 90 91 93 92 95	120 121 123 124 125 126 128 3	RXD[7] RXD[6] RXD[5] RXD[4] RXD[3] RXD[2] RXD[1] RXD[0]	0, Z	TBI Receive Data code group [7:0]. In the TBI mode, RXD[7:0] present the data byte to be transmitted to the MAC. Symbols received on the cable are decoded and presented on RXD[7:0]. RXD[7:0] are synchronous to RCLK0 and RCLK1.	
B1	94	4	RX_DV/ RXD8	O, Z	TBI Receive Data code group bit 8. In the TBI mode, RX_DV is used as RXD8. RXD[9:0] are synchronous to RCLK0 and RCLK1.	



Table 3: TBI Interface (Continued)

117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
D2	3	8	RX_ER/ RXD9	O, Z	TBI Receive Data code group bit 9. In the TBI mode, RX_ER is used as RXD9. RXD[9:0] are synchronous to RCLK0 and RCLK1.
B5	84	115	CRS/ COMMA	O, Z	TBI Valid Comma Detect. In the TBI mode, CRS is used as COMMA.
B6	83	114	COL/LPBK	ı	TBI Mode Loopback. In the TBI mode, COL is used to indicate loopback on the TBI. When a "0 - 1" transition is sampled on this pin, bit 0.14 is set to 1. When a "1 - 0" is sampled on this pin, bit 0.14 is reset to 0. If this feature is not used, the COL pin should be driven low on the board. This pin should not be left floating in TBI mode.

Table 4: RGMII Interface

Table 4: RGMII Interface							
117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description		
E2	8	14	GTX_CLK/ TXC	I	RGMII Transmit Clock provides a 125 MHz, 25 MHz, or 2.5 MHz reference clock with ± 50 ppm tolerance depending on speed. In RGMII mode, GTX_CLK is used as TXC.		
H2 G3 G2 F1	16 14 12 11	24 20 19 18	TXD[3]/TD[3] TXD[2]/TD[2] TXD[1]/TD[1] TXD[0]/TD[0]	I	RGMII Transmit Data. In RGMII mode, TXD[3:0] are used as TD[3:0]. In RGMII mode, TXD[3:0] run at double data rate with bits [3:0] presented on the rising edge of GTX_CLK, and bits [7:4] presented on the falling edge of GTX_CLK. In this mode, TXD[7:4] are ignored.		
	OFFI				In RGMII 10/100BASE-T modes, the transmit data nibble is presented on TXD[3:0] on the rising edge of GTX_CLK.		
E1 00 (1)	9	16	TX_EN/ TX_CTL	I	RGMII Transmit Control. In RGMII mode, TX_EN is used as TX_CTL. TX_EN is presented on the rising edge of GTX_CLK.		
CHAR					A logical derivative of TX_EN and TX_ER is presented on the falling edge of GTX_CLK.		
C1	2	7	RX_CLK/ RXC	O, Z	RGMII Receive Clock provides a 125 MHz, 25 MHz, or 2.5 MHz reference clock with ± 50 ppm tolerance derived from the received data stream depending on speed. In RGMII mode, RX_CLK is used as RXC.		
B1	94	4	RX_DV/ RX_CTL	O, Z	RGMII Receive Control. In RGMII mode, RX_DV is used as RX_CTL. RX_DV is presented on the rising edge of RX_CLK. A logical derivative of RX_DV and RX_ER is		
B3 C3 D3 B2	91 93 92 95	125 126 128 3	RXD[3]/RD[3] RXD[2]/RD[2] RXD[1]/RD[1] RXD[0]/RD[0]	O, Z	presented on the falling edge of RX_CLK. RGMII Receive Data. In RGMII mode, RXD[3:0] are used as RD[3:0]. In RGMII mode, RXD[3:0] run at double data rate with bits [3:0] presented on the rising edge of RX_CLK, and bits [7:4] presented on the fall- ing edge of RX_CLK. In this mode, RXD[7:4] are ignored. In RGMII 10/100BASE-T modes, the receive		
			CHAR		data nibble is presented on RXD[3:0] on the rising edge of RX_CLK. RXD[3:0] are synchronous to RX_CLK.		

The RTBI interface supports 1000BASE-T mode of operation. The RTBI interface uses the same pins as the RGMII interface. The MAC interface pins are 3.3V tolerant. See "Digital Pins" on page 196 for details.

Table 5: RTBI Interface

88E1111

				(0,0)		
117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description	
E2	8	14	GTX_CLK/ TXC	Î	RGMII Transmit Clock provides a 125 MHz reference clock with ± 50 ppm tolerance. In RTBI mode, GTX_CLK is used as TXC.	
H2 G3 G2 F1	16 14 12 11	24 20 19 18	TXD[3]/TD[3] TXD[2]/TD[2] TXD[1]/TD[1] TXD[0]/TD[0]	I	RTBI Transmit Data. In RTBI mode, TXD[3:0] are used as TD[3:0]. TD[3:0] run at double data rate with bits [3:0] presented on the rising edge of GTX_CLK, and bits [8:5] presented on the falling edge of GTX_CLK. In this mode, TXD[7:4] are ignored.	
E1	9	16	TX_EN/ TD4_TD9	I	RTBI Transmit Data. In RTBI mode, TX_EN is used as TD4_TD9. TD4_TD9 runs at a double data rate with bit 4 presented on the rising edge of GTX_CLK, and bit 9 presented on the falling edge of GTX_CLK.	
C1	2	7	RX_CLK/ RXC	O, Z	RTBI Receive Clock provides a 125 MHz reference clock with ± 50 ppm tolerance derived from the received data stream. In RTBI mode, RX_CLK is used as RXC.	
B3 C3 D3 B2	91 93 92 95	125 126 128 3	RXD[3]/RD[3] RXD[2]/RD[2] RXD[1]/RD[1] RXD[0]/RD[0]	O, Z	RTBI Receive Data. In RTBI mode, RXD[3:0] are used as RD[3:0]. RD[3:0] runs at double data rate with bits [3:0] presented on the rising edge of RX_CLK, and bits [8:5] presented on the fall- ing edge of RX_CLK. In this mode, RXD[7:4] are ignored.	
B1	94	4	RX_DV/ RD4_RD9	O, Z	RTBI Receive Data. In RTBI mode, RX_DV is used as RD4_RD9. RD4_RD9 runs at a double data rate with bit 4 presented on the rising edge of RX_CLK, and bit 9 presented on the fall- ing edge of RX_CLK.	

Table 6: SGMII Interface

Table 6. SGWII IIIterrace						
117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description	
A3 A4	82 81	113 112	S_IN+ S_IN-	I	SGMII Transmit Data. 1.25 GBaud input - Positive and Negative.	
		or o	S. D.		Input impedance on the S_IN± pins may be programmed for 50 ohm or 75 ohm impedance by setting register 26.6. The input impedance default setting is determined by the 75/50 OHM configuration pin. See Section 2.4 "Hardware Configuration" on page 63.	
A5 A6	79 80	110 109	S_CLK+ S_CLK-	I/O	SGMII 625 MHz Receive Clock.	
	2000 2000		0_02.1		For Serial Interface modes (HWCFG_MODE[3:0] = 1x00) the S_CLK± pins become Signal Detect± (SD±) inputs	
A7 A8	77 75	107 105	S_OUT+ S_OUT-	O, Z	SGMII Receive Data. 1.25 GBaud output - Positive and Negative.	
Selile III	Y				Output impedance on the S_OUT± pins may be programmed for 50 ohm or 75 ohm impedance by setting register 26.5. Output amplitude can be adjusted via register 26.2:0. The output impedance default setting is determined by the 75/50 OHM configuration pin. See Section 2.4 "Hardware Configuration" on page 63.	



Table 7: 1.25 GHz Serial High Speed Interface

117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
A3 A4	82 81	113 112	S_IN+ S_IN-	ĮV į	1.25 GHz input - Positive and Negative. When this interface is used as a MAC interface, the MAC transmitter's positive output connects to the S_IN+. The MAC transmitter's negative output connects to the S_IN When this interface is used as a fiber interface, the fiber-optic transceiver's positive output connects to the S_IN+. The fiber-optic transceiver's negative output connects to the S_IN Input impedance on the S_IN± pins may be programmed for 50 ohm or 75 ohm impedance by setting register 26.6. The input impedance default setting is determined by the 75/50 OHM configuration pin. See Section 2.4 "Hardware Configuration" on page 63.
A5 A6	79 80	110 109	S_CLK+/SD+ S_CLK-/SD-	I	Signal Detect input. For Serial Interface modes the S_CLK± pins become Signal Detect± (SD±) inputs.
A7 A8	77 75	107 105	S_OUT+ S_OUT-	0, z	1.25 GHz output – Positive and Negative. When this interface is used as a MAC interface, S_OUT+ connects to the MAC receiver's positive input. S_OUT- connects to the MAC receiver's negative input. When this interface is used as a fiber interface, S_OUT+ connects to the fiber-optic transceiver's positive input. S_OUT- connects to the fiber-optic transceiver's negative input. Output impedance on the S_OUT± pins may be programmed for 50 ohm or 75 ohm impedance by setting register 26.5. Output amplitude can be adjusted via register 26.2:0. The output impedance default setting is determined by the 75/50 OHM configuration pin. See Section 2.4 "Hardware Configuration" on page 63.

256xg0euupqdu92f-elp5025j * Prophet Electronic Technology Ltd. * UNDER NDA# 12104893

Table 7: 1.25 GHz Serial High Speed Interface (Continued)

117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
В3	91	125	RXD[3]	O, Z	Serial MAC interface Copper Link Status[1] connection. 1 = Copper link up 0 = Copper link down See "Serial MAC Interface" on page 56 for details.
С3	93	126	RXD[2]	O, Z	Serial MAC interface Copper Link Status[0] connection. 1 = Copper link down 0 = Copper link up See "Serial MAC Interface" on page 56 for details.
D3	92	128	RXD[1]	O, Z	Serial MAC interface PHY_SIGDET[1] connection. 1 = S_OUT± valid code groups according to clause 36. 0 = S_OUT± invalid See "Serial MAC Interface" on page 56 for details.
B2	95	3	RXD[0]	O, Z	Serial MAC interface PHY_SIGDET[0] connection. 1 = S_OUT± invalid 0 = S_OUT± valid code groups according to clause 36 See "Serial MAC Interface" on page 56 for details.



Table 8: Management Interface and Interrupt

117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
L3	25	35	MDC	3.3V Toleerant	MDC is the management data clock reference for the serial management interface. A continuous clock stream is not expected. The maximum frequency supported is 8.3 MHz.
M1	24	33	MDIO	I/O 3.3V Tol- erant	MDIO is the management data. MDIO transfers management data in and out of the device synchronously to MDC. This pin requires a pull-up resistor in a range from 1.5 kohm to 10 kohm.
L1	23	32*	INTn	D	The polarity of the INTn pin may be programmed at hardware reset by setting the INT_POL bit. Polarity: 0 = Active High 1 = Active Low
J20	Sylva				See Section 2.4 "Hardware Configuration" on page 63. See Section 2.9.3 "Programming Interrupts" on page 79.

Table 9: Two-Wire Serial Interface

117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
L3	25	35	MDC/SCL	1	Two-Wire Serial Interface (TWSI) serial clock line. When the 88E1111 device is connected to the bus, MDC connects to the serial clock line (SCL). Data is input on the rising edge of SCL, and output on the falling edge. See Section 2.10 "Two-wire Serial Interface" on page 80.
M1	24	33	MDIO/SDA	1/0	TWSI serial data line. When the 88E1111 device is connected to the bus, MDIO connects to the serial data line (SDA). This pin is open-drain and may be wire-ORed with any number of open-drain devices. See Section 2.10 "Two-wire Serial Interface" on page 80.

256xg0euupqdu92f-elp5025j * Prophet Electronic Technology Ltd. * UNDER NDA# 12104893

Table 10: LE	Dinterrace			<u> </u>	
117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
C8	76	100	LED_LINK10	Ö, mA	Parallel LED output for 10BASE-T link or speed. This active low LED pin may be programmed in direct drive or combined LED modes by programming register LED_LINK Control register 24.4:3.
		W.	8		In direct drive LED mode, this pin indicates 10 Mbps link up or down.
	×	Signal A)*		In combined LED mode, the output from LED_LINK10, LED_LINK100, and LED_LINK1000 must be read together to determine link and speed status.
					LED_LINK10 is a multi-function pin used to configure the 88E1111 device at the deassertion of hardware reset.
					See Section 2.22 "LED Interface" on page 107.
B8 B8	74	99	LED_LINK100	O, mA	Parallel LED output for 100BASE-TX link or speed. This active low LED pin may be programmed in direct drive or combined LED modes by programming register LED_LINK Control register 24.4:3. In direct drive LED mode, this pin indicates 100 Mbps link up or down.
					In combined LED mode, the output from LED_LINK10, LED_LINK100, and LED_LINK1000 must be read together to determine link and speed status.
				**	LED_LINK100 is a multi-function pin used to configure the 88E1111 device at the deassertion of hardware reset.
				10°0	See Section 2.22 "LED Interface" on page 107.



Table 10: LED Interface (Continued)

117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
A9	73	98	LED_LINK1000	O, mA	Parallel LED output for 1000BASE-T link/ speed or link indicator. This active low LED pin may be programmed in direct drive or combined LED modes by programming reg- ister LED_LINK Control register 24.4:3. In direct drive LED mode, this pin indicates 1000 Mbps link up or down. In combined LED mode, the output from
		STATISTICS OF THE PARTY OF THE	5		LED_LINK1000 indicates link status. LED_LINK1000 is a multi-function pin used to configure the 88E1111 device at the deassertion of hardware reset. See Section 2.22 "LED Interface" on page 107.
E8	70	95	LED_DUPLEX	O, mA	Parallel LED duplex or duplex/collision modes. The LED_DUPLEX pin may be programmed to Mode 1 or Mode 2 by setting register bit 24.2. Mode 1 Low = Full-duplex High = Half-duplex Blink = Collision Mode 2 Low = Full-duplex High = Half-duplex High = Half-duplex High = Fiber Link up High = Fiber Link down LED_DUPLEX is a multi-function pin used to configure the 88E1111 device at the deassertion of hardware reset. See Section 2.22 "LED Interface" on page 107.

Table 10: LED Interface (Continued)

Table 10: LE	Dinterrace	(Continued)		3)'	
117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
C9	69	92	LED_RX	O, mA	Parallel LED Receive Activity or Receive Activity/Link modes. LED_RX may be programmed to Mode 1 or Mode 2 by setting register bit 24.1.
			\$ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\		Mode 1 Low = Receiving High = Not receiving
	K	Sich)		Mode 2 Low = Link up High = Link down Blink = Receiving
	18 11 D				LED_RX is a multi-function pin used to configure the 88E1111 device at the de-assertion of hardware reset.
					See Section 2.22 "LED Interface" on page 107.
D9 JIJA	68	91	LED_TX	O, mA	Parallel LED Transmit Activity or RX/TX Activity/Link modes. LED_TX may be programmed to Mode 1 or Mode 2 by setting register bit 24.0. Mode 1 Low = Transmitting High = Not transmitting Mode 2 Low = Link up High = Link down Blink = Transmitting or receiving LED_TX is a multi-function pin used to configure the 88E1111 device at the de-assertion of hardware reset.
				1000 K	See Section 2.22 "LED Interface" on page 107.



Table 11: **JTAG Interface**

117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Type	Pin Name	Description
L7	44	67	TDI CI	I, PU	Boundary scan test data input. TDI contains an internal 150 kohm pull-up resistor.
L8	46	69	TMS	I, PU	Boundary scan test mode select input. TMS contains an internal 150 kohm pull-up resistor.
L9	49	70	TCK	I, PU	Boundary scan test clock input. TCK contains an internal 150 kohm pull-up resistor.
M9	47	68	TRSTn	I, PU	Boundary scan test reset input. Active low. TRSTn contains an internal 150 kohm pull-up resistor as per the 1149.1 specification. After power up, the JTAG state machine should be reset by applying a low signal on this pin, or by keeping TMS high and applying 5 TCK pulses, or by pulling this pin low by a 4.7 kohm resistor.
K8	50	72	TDO	O, Z	Boundary scan test data output.

Table 12: Clock/Configuration/Reset/I/O

117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
K2	22	31	125CLK	0	Clock 125. A generic 125 MHz clock reference generated for use on the MAC device. This output can be disabled via DIS_125 through the CONFIG[3] pin.
D8	65	88 RIP	CONFIG[0]		CONFIG[0] pin configures PHY_ADR[2:0] bits of the physical address. Each LED pin is hardwired to a constant value. The values associated to the CON-FIG[0] pin are latched at the de-assertion of hardware reset. CONFIG[0] pin must be tied to one of the pins shown in Table 28 based on the configuration options selected. They should not be left floating. For the Two-Wire Serial Interface (TWSI) device address, the lower 5 bits, which are PHYADR[4:0], are latched during hardware reset, and the device address bits [6:5] are fixed at '10'. See Section 2.4 "Hardware Configuration" on page 63.
E9	64	87	CONFIG[1]		CONFIG[1] pin configures PHY_ADR[4:3] and ENA_PAUSE options. Each LED pin is hardwired to a constant value. The values associated to the CON-FIG[1] pin are latched at the de-assertion of hardware reset. CONFIG[1] pin must be tied to one of the pins shown in Table 28 based on the configuration options selected. They should not be left floating. For the TWSI device address, the lower 5 bits, which are PHYADR[4:0], are latched during hardware reset, and the device address bits [6:5] are fixed at '10'. See Section 2.4 "Hardware Configuration" on page 63.

Table 12: Clock/Configuration/Reset/I/O (Continued)

Table 12. Clock/Colliguration/Researco (Continued)							
117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description		
F8	63	86	CONFIG[2]	10	CONFIG[2] pin configures ANEG[3:1] bits.		
			CHORA	V.	Each LED pin is hardwired to a constant value. The values associated to the CON-FIG[2] pin are latched at the de-assertion of hardware reset.		
		.81			CONFIG[2] pin must be tied to one of the pins shown in Table 28 based on the configuration options selected. They should not be left floating.		
		* PIP			See Section 2.4 "Hardware Configuration" on page 63.		
G7	61	82	CONFIG[3]	I	CONFIG[3] pin configures ANEG[0], ENA_XC, and DIS_125 options.		
>	197.00				Each LED pin is hardwired to a constant value. The values associated to the CON-FIG[3] pin are latched at the de-assertion of hardware reset.		
OCHIP					CONFIG[3] pin must be tied to one of the pins shown in Table 28 based on the configuration options selected. They should not be left floating.		
Rept 1					See Section 2.4 "Hardware Configuration" on page 63.		
F9	60	81	CONFIG[4]	I	CONFIG[4] pin configures HWCFG_MODE[2:0] options. See Section 2.4 "Hardware Configuration" on page 63.		
G9	59	80	CONFIG[5]	1	CONFIG[5] pin configures DIS_FC, DIS_SLEEP, and HWCFG_MODE[3] options. See Section 2.4 "Hardware Configuration" on page 63.		
G8	58	79	CONFIG[6]		CONFIG[6] pin configures SEL_TWSI, INT_POL, and 75/50 OHM options. See Section 2.4 "Hardware Configuration" on page 63.		

Table 12: Clock/Configuration/Reset/I/O (Continued)

117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
H8	56	77	SEL_FREQ		Frequency Selection for XTAL1 input NC = Selects 25 MHz clock input. Tied low = Selects 125 MHz clock input. Internally divided to 25 MHz. SEL_FREQ is internally pulled up.
H9	55	76	XTAL1	I	Reference Clock. 25 MHz ± 50 ppm or 125 MHz ± 50 ppm oscillator input. PLL clocks are not recommended, see "XTAL1 Input Clock Timing" on page 208 for details.
J9	54	75	XTAL2	0	Reference Clock. 25 MHz ± 50 ppm tolerance crystal reference. When the XTAL2 pin is not connected, it should be left floating. There is no option for a 125 MHz crystal. See "Crystal Oscillator" Application Note for details.
K3	28	36	RESETn	I	Hardware reset. Active low. XTAL1 must be active for a minimum of 10 clock cycles before the rising edge of RESETn. RESETn must be pulled high for normal operation.
CONTRACTOR OF THE PARTY OF THE	27	37	COMA	1	COMA disables all active circuitry to draw absolute minimum power. The COMA power mode can be activated by asserting high on the COMA pin. To deactivate the COMA power mode, tie the COMA pin low. Upon deactivating COMA mode, the 88E1111 device will continue normal operation. The COMA power mode cannot be enabled as long as hardware reset is enabled. In COMA mode, the PHY cannot wake up on its own by detecting activity on the CAT 5 cable.



Table 13: Test

117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
M5	37	53	HSDAC+	Analog	Test pins. These pins should be left floating but brought out for probing.
M6	38	54	HSDAC-	PD	

Table 14: Control and Reference

117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
M2	30	39	RSET	Analog I	Constant voltage reference. External 5.0 kohm 1% resistor connection to VSS required for each pin.

256xg0euupqdu92f-elp5025j * Prophet Electronic Technology Ltd. * UNDER NDA# 12104893

Table 15: Power & Ground

able 13. Fower & Ground								
117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description			
B7 M3 M4 M7 M8 N5	32 35 36 40 45 78	44 49 52 59 64 104	AVDD	Power	Analog Power. 2.5V.			
C6 C7 D7 E3 E7 F3 J3	1 6 10 15 57 62 67 71 85	2 6 12 17 23 27 78 85 90 96 117 118	DVDD	Power	Digital Power. 1.0V (Instead of 1.0V, 1.2V can be used).			
B9 F7 J8	52 66 72	73 89 97	VDDOH	Power	2.5V Power Supply for LED and CONFIG pins.			
K9 L2	26 48	34 71	VDDOX	Power	2.5V Supply for the MDC/MDIO, INTn, 125CLK, RESETn, JTAG pin Power.			
B4 C2 K1	5 21 88 96	5 11 30 122	VDDO	Power	2.5V I/O supply for the MAC interface pins.			

Table 15: Power & Ground (Continued)

		-	-		
117-TFBGA Pin #	96-BCC Pin #	128-PQFP Pin #	Pin Name	Pin Type	Description
D4	0	1	VSS	GND	Global ground
D5		9	70		3 11 3
D6		15	.O 1	V	
E4		21	C sk	•	
E5		22	10, D.		
E6		38	\$0.0°		
F4		40	07		
F5		43	47,2		
F6		45			
G4		48			
G5		51			
G6		55			
H4		58			
H5		60			
H6		63			
J4	C	65			
J5	50	66			
J6	18	83			No. of the control of
K4	0,5	84			
K5	0,20	93			
K6	9, O	94			
L5	2	101			0.0
L6		102			
.0.		103			100
15.5		106			1000
00		108			
0 41.		111			
45		116			20.7¥
(O)		119			"10 P
		127			
H7	53	74	VSSC	GND	Ground reference for XTAL1 and XTAL2
					pins. This pin must be connected to the ground.
					- 17
G1	13	50	NC	NC	No connect. Do not connect these pins to
K7	51				anything

1.5 I/O State at Various Test or Reset Modes

Pin(s)	Isolate	Loopback or Normal operation	Software Reset	Hardware Reset	Power Down	Coma	Power Down and Isolate
MDI[3:0]±	Active	Active	Tri-state	Tri-state	Tri-state	Tri-state	Tri-state
TX_CLK	Tri-state	Active	Reg. 16.3 state 0 = Low 1 = Active	Low	Reg. 16.3 state 0 = Low 1 = Active	Reg. 16.3 state 0 = Low 0 = Static but can be either high or low	Tri-state
RXD[0], RXD[2]	Tri-state	Active	High	High	High	High	Tri-state
RXD[7:3,1], RX_DV, RX_ER, CRS	Tri-state	Active	Low	Low	Low	Low	Tri-state
COL	Tri-state	TBI mode - input else -active	Tri-state	Tri-state	TBI mode - input else - low	TBI mode - input else - low	Tri-state
RX_CLK	Tri-state	Active	Reg. 16.3 state 0 = Low 1 = Active	Low	Reg. 16.3 state 0 = Low 1 = Active	Reg. 16.3 state 0 = Low 0 = Static but can be either high or low	Tri-state
S_CLK± S_OUT±	Active	Active	Tri-state	Tri-state	Reg. 16.3 state 0 = Tri-state 1 = Active	Tri-state	Active
MDIO	Active	Active	Active	Tri-state	Active	Tri-state	Active
INT	Active	Active	Tri-state	Tri-state	Tri-state	Tri-state	Tri-state
LED_***	Active	Active	High	High	High	High	High
TDO	Tri-state	Tri-state	Tri-state	Tri-state	Tri-state	Active	Tri-state
125CLK	Reg. 16.4 state 0 = Toggle 1 = Low	Reg. 16.4 state 0 = Toggle 1 = Low	Reg. 16.4 state 0 = Toggle 1 = Low	Toggle	Reg. 16.4 state 0 = Toggle 1 = Low	Reg. 16.3 state 0 = Static but can be either high or low 0 = Low	Reg. 16.4 state 0 = Toggle 1 = Low



1.6 117-Pin TFBGA Pin Assignment List - Alphabetical by Signal Name

- J		0.0	
Pin #	Pin Name	Pin #	Pin Name
K2	125CLK	A9	LED_LINK1000
B7	AVDD	C9	LED_RX
M3	AVDD	D9	LED_TX
M4	AVDD	L3	MDC
M7	AVDD	N2	MDI[0]-
M8	AVDD	N1	MDI[0]+
N5	AVDD	N4	MDI[1]-
B6	COL	N3	MDI[1]+
L4	COMA	N7	MDI[2]-
D8	CONFIG[0]	N6	MDI[2]+
E9	CONFIG[1]	N9	MDI[3]-
F8	CONFIG[2]	N8	MDI[3]+
G7	CONFIG[3]	M1	MDIO
F9	CONFIG[4]	G1	NC (S)
G9	CONFIG[5]	K7	NC CONTRACTOR
G8	CONFIG[6]	K3	RESETn
B5	CRS	M2	RSET
C6	DVDD	B2	RXD0
C7	DVDD	D3	RXD1
D7	DVDD	C3	RXD2
E3	DVDD	В3	RXD3
E7	DVDD	C4	RXD4
F3	DVDD	A1	RXD5
J3	DVDD	A2	RXD6
J7	DVDD	C5	RXD7
E2	GTX_CLK	C1	RX_CLK
M6	HSDAC-	B1	RX_DV
M5	HSDAC+	D2	RX_ER
L1	INTn	A6	S_CLK-
E8	LED_DUPLEX	A5	S_CLK+
C8	LED_LINK10	A4	S_IN-
B8	LED_LINK100	A3	S_IN+

Doc. No. MV-S100649-00, Rev. G

CONFIDENTIAL

1.6 117-Pin TFBGA Pin Assignment List - Alphabetical by Signal Name (Continued)

	,	0,0	
Pin #	Pin Name	Pin #	Pin Name
A8	S_OUT-	D4	VSS
A7	S_OUT+	D5	VSS
H8	SEL_FREQ	D6	VSS
L9	TCK	E4	VSS
L7	TDI W.S-	E5	VSS
K8	TDO	E6	VSS
L8	TMS	F4	VSS
M9	TRSTn	F5	VSS
F1	TXD0 *	F6	VSS
G2	TXD1	G4	VSS
G3	TXD2	G5	VSS
H2	TXD3	G6	VSS
H1	TXD4	H4	VSS
H3	TXD5	H5	vss
J1	TXD6	H6	vss
J2	TXD7	J4	vss
D1	TX_CLK	J5	vss
E1	TX_EN	J6	VSS
F2	TX_ER	K4	VSS
B4	VDDO	K5	VSS
C2	VDDO	K6	VSS
K1	VDDO	L5	VSS
B9	VDDOH	L6	VSS
F7	VDDOH	H7	VSSC
J8	VDDOH	H9 *	XTAL1
K9	VDDOX	J9	XTAL2
L2	VDDOX	60,00	



1.7 96-Pin BCC Pin Assignment List - Alphabetical by Signal Name

		C, C _k		
Pin Name	Pin #	Pin Name		
125CLK	74	LED_LINK100		
AVDD	73	LED_LINK1000		
AVDD	69	LED_RX		
AVDD	68	LED_TX		
AVDD	25	MDC		
AVDD	31	MDI[0]-		
AVDD	29	MDI[0]+		
COL	34	MDI[1]-		
COMA	33	MDI[1]+		
CONFIG[0]	41	MDI[2]-		
CONFIG[1]	39	MDI[2]+		
CONFIG[2]	43	MDI[3]-		
CONFIG[3]	42	MDI[3]+		
CONFIG[4]	24	MDIO		
CONFIG[5]	13	NC C		
CONFIG[6]	51	NC		
CRS	28	RESETn		
DVDD	30	RSET		
DVDD	95	RXD0		
DVDD	92	RXD1		
DVDD	93	RXD2		
DVDD	91	RXD3		
DVDD	90	RXD4		
DVDD	89	RXD5		
DVDD	87	RXD6		
DVDD	86	RXD7		
GTX_CLK	2	RX_CLK		
HSDAC-	94	RX_DV		
HSDAC+	3	RX_ER		
INTn	80	S_CLK-		
LED_DUPLEX	79	S_CLK+		
LED_LINK10	81	S_IN-		
	Pin Name 125CLK AVDD AVDD AVDD AVDD AVDD AVDD AVDD COL COMA CONFIG[0] CONFIG[1] CONFIG[3] CONFIG[4] CONFIG[6] CRS DVDD D	Pin Name Pin # 125CLK 74 AVDD 73 AVDD 69 AVDD 25 AVDD 31 AVDD 29 COL 34 COMA 33 CONFIG[0] 41 CONFIG[1] 39 CONFIG[2] 43 CONFIG[3] 42 CONFIG[4] 24 CONFIG[6] 51 CRS 28 DVDD 95 DVDD 95 DVDD 91 DVDD 90 DVDD 87 DVDD 86 GTX_CLK 2 HSDAC- 94 HSDAC- 94 HSDAC- 3 INTn 80 LED_DUPLEX 79		

Doc. No. MV-S100649-00, Rev. G

1.7 96-Pin BCC Pin Assignment List - Alphabetical by Signal Name (Continued)

Pin #	Pin Name	Pin #	Pin Name
82	S_IN+	4	TX_CLK
75	S_OUT-	9	TX_EN
77	S_OUT+	7	TX_ER
56	SEL_FREQ	5	VDDO
49	TCK	21	VDDO
44	TDI	88	VDDO
50	TDO	96	VDDO
46	TMS	52	VDDOH
47	TRSTn *	66	VDDOH
11	TXD0	72	VDDOH
12	TXD1	26	VDDOX
14	TXD2	48	VDDOX
16	TXD3	0	VSS
17	TXD4	53	VSSC
18	TXD5	55	XTAL1
19	TXD6	54	XTAL2
20	TXD7		40,5



1.8 128-Pin PQFP Pin Assignment List - Alphabetical by Signal Name

		C, C _A		
Pin #	Pin Name	Pin #	Pin Name	
31	125CLK	32	INTn	
44	AVDD	95	LED_DUPLEX	
49	AVDD	100	LED_LINK10	
52	AVDD	99	LED_LINK100	
59	AVDD	98	LED_LINK1000	
64	AVDD	92	LED_RX	
104	AVDD	91	LED_TX	
114	COL	35	MDC	
37	COMA	41	MDI[0]+	
88	CONFIG[0]	42	MDI[0]-	
87	CONFIG[1]	46	MDI[1]+	
86	CONFIG[2]	47	MDI[1]-	
82	CONFIG[3]	56	MDI[2]+	
81	CONFIG[4]	57	MDI[2]-	
80	CONFIG[5]	61	MDI[3]+	
79	CONFIG[6]	62	MDI[3]-	
115	CRS	33	MDIO	
2	DVDD	50	NC .	
6	DVDD	36	RESETn	
12	DVDD	39	RSET	
17	DVDD	7	RX_CLK	
23	DVDD	4	RX_DV	
27	DVDD	8	RX_ER	
78	DVDD	3	RXD0	
85	DVDD	128	RXD1	
90	DVDD	126	RXD2	
96	DVDD	125	RXD3	
117	DVDD	124	RXD4	
118	DVDD	123	RXD5	
14	GTX_CLK	121	RXD6	
53	HSDAC+	120	RXD7	
54	HSDAC-	110	S_CLK+	

Doc. No. MV-S100649-00, Rev. G

CONFIDENTIAL

1.8 128-Pin PQFP Pin Assignment List - Alphabetical by Signal Name (Continued)

Pin #	Pin Name	Pin #	Pin Name
109	S_CLK-	9	VSS
113	S_IN+	15	VSS
112	S_IN-	21	VSS
107	S_OUT+	22	VSS
105	S_OUT-	38	VSS
77	SEL_FREQ	40	VSS
70	TCK	43	VSS
67	TDI	45	VSS
72	TDO *	48	VSS
69	TMS	51	VSS
68	TRSTn	55	VSS
10	TX_CLK	58	VSS
16	TX_EN	60	VSS
13	TX_ER	63	VSS
18	TXD0	65	vss
19	TXD1	66	VSS
20	TXD2	83	VSS
24	TXD3	84	vss
25	TXD4	93	VSS
26	TXD5	94	vss
28	TXD6	101	VSS ()
29	TXD7	102	VSS
5	VDDO	103	VSS
11	VDDO	106	VSS
30	VDDO	108 *	VSS
122	VDDO	111	VSS
73	VDDOH	116	VSS
89	VDDOH	119	VSS
97	VDDOH	127	VSS
34	VDDOX	74	VSSC
71	VDDOX	76	XTAL1
1	VSS	75	XTAL2



Section 2. Functional Description

The 88E1111 device is a 10/100/1000BASE-T/1000BASE-X Gigabit Ethernet transceiver.

Figure 5: 88E1111 Device Functional Block Diagram

88E1111




Figure 5 shows the functional block diagram of the 88E1111 device. The transmitter and transmit PCS and PMA blocks are more fully described on Section 2.6.1 "Transmit Side Network Interface" on page 70. The receiver and receive PCS and PMA blocks are more fully described on Section 2.6.3 "Receive Side Network Interface" on page 70.

2.1 88E1111 Device Interface Description

The 88E1111 device supports a number of digital interfaces that support both copper and fiber-optic media. Refer to the connection diagrams further in this section.

2.1.1 Media Interface

2.1.1.1 Copper Interface

The copper interface consists of the MDI[3:0]± pins that connect to the physical media for 1000BASE-T, 100BASE-TX, and 10BASE-T modes of operation. The MDI pins should be terminated externally with 100 ohm differential impedance and connected to an RJ-45 connector through magnetics.

The CAT 5 UTP interface requires 100 ohm differential external terminations. See the "Alaska® Ultra Reference Design Schematics" for details.


2.1.1.2 Fiber Interface

Fiber cable connects to the fiber transceiver. The fiber transceiver is connected via the serial interface pins to the PHY device. The PHY device is then connected to the MAC through the GMII or RGMII interfaces. The serial interface consists of the S_IN±, S_OUT±, and SD± pins.

The input and output buffers of the SERDES interface are internally terminated by programmable 75/50 ohm impedance. The 75/50 OHM configuration bit can be used to select the input or output impedance. Refer to registers 26.5 or 26.6 in Table 97, "Extended PHY Specific Control 2 Register," on page 176 for details. No external termination is required. The SERDES I/Os are Current Mode Logic (CML) buffers. CML I/Os can be used to connect to other components with PECL or LVDS I/Os. See the "Reference Design Schematics" and "Fiber Interface" application note for details.

Figure 6: CML I/Os

MARVELL CONFIDENTIAL



Page 45



Table 16: Serial Interface Mapping for Fiber Transceiver

88E1111 Device	Description
S_OUT±	1.25 Gbaud transmit output - Positive and Negative
S_IN±	1.25 Gbaud receive input - Positive and Negative
SD±	Signal Detect input from Fiber Transceiver

Signal Detect Input for Fiber Mode

The fiber transceiver's signal detect outputs are typically directly connected to the MAC and there are no signal detect inputs to the PHY (e.g. SERDES PHY). In this case, the 88E1111 PHYs will default to signal detect always being good. If it is desired to use the signal detect output of the fiber transceiver as an input to the 88E1111 device, then the signal detect status will be determined by monitoring the signal detect inputs. To allow this mode of operation, Register 26.7 should be set to 1. One example of why the signal detect input might be needed is to prevent the LEDs from falsely indicating receive or transmit activity based on noise received on the S_IN± inputs when Auto-Negotiation is disabled and no fiber cable is connected.

2.1.2 MAC Interface

The MAC interface supports GMII/MII, RGMII/Modified MII, SGMII, and serial interface connections. These interfaces connect to a 10/100/1000 Mbps Media Access Controller (MAC).

Table 17: 88E1111 Device MAC Interface Pins

88E1111 Device Pins
GTX_CLK
TX_CLK
TX_ER
TX_EN
TXD[7:0]
RX_CLK
RX_ER
RX_DV
RXD[7:0]
CRS
COL
S_IN±
S_CLK±
S_OUT±



2.2 MAC Interfaces

88E1111

The following sections describes the 88E1111 device MAC Interfaces in detail.

2.2.1 Gigabit Media Independent Interface (GMII/MII)


Table 18 indicates the signal mapping of the 88E1111 device to the GMII interface. MII signaling to support 100BASE-TX and 10BASE-T modes is implemented by sharing pins of the GMII interface. The GMII/MII interface to copper interface is selected by setting the HWCFG_MODE[3:0] to'1111'. The GMII to fiber interface is selected by setting the HWCFG_MODE[3:0] bits to'0111'.

Table 18: GMII/MII Signal Mapping

88E1111 Device Pins	GMII	MII
GTX_CLK	GTX_CLK	-
TX_CLK		TX_CLK
TX_ER	TX_ER	TX_ER
TX_EN	TX_EN	TX_EN
TXD[7:0]	TXD[7:0]	TXD[3:0]
RX_CLK	RX_CLK	RX_CLK
RX_ER	RX_ER	RX_ER
RX_DV	RX_DV	RX_DV
RXD[7:0]	RXD[7:0]	RXD[3:0]
CRS	CRS	CRS
COL	COL	COL

Figure 7: GMII Signal Diagram

MARVELL CONFIDENTIAL




Doc. No. MV-S100649-00, Rev. G

Page 48

In 1000BASE-T mode, when the GMII interface is selected, a 125 MHz transmit clock is expected on GTX_CLK. Although not part of the GMII interface, TX_CLK is still available and can source 25 MHz, 2.5 MHz, or 0 MHz clock depending on the setting of register 20.6:4; and RX_CLK sources the 125 MHz receive clock. TXD[7:0] and RXD[7:0] signals are used.

In the 100BASE-TX and 10BASE-T modes, when the MII mode is selected, both TX_CLK and RX_CLK source 25 MHz or 2.5 MHz, respectively. TXD[3:0] and RXD[3:0] signals are used. GTX_CLK and TXD[7:4] signals must be pulled high or low and must not be left floating. RXD[7:4] pins are driven low.

Figure 8: MII Signal Diagram





MARVELL CONFIDENTIA

Note

During the transition from one speed to another, a dead time for a maximum duration of 1.5 clock cycles may occur on RX_CLK and TX_CLK to insure a glitch-free clock.

In GMII mode, Register 20.15 is the register bit used to block carrier extension.



2.2.2 **Ten-Bit Interface**


88E1111

The TBI interface pin mapping is shown below. This interface supports 1000 Mbps mode of operation. The TBI to copper interface is selected by setting HWCFG_MODE[3:0] bits to '1101'.

Table 19: **TBI Interface Pin Mapping**

88E1111 Device Pin Name	TBI Spec Pin Name	Description
GTX_CLK	TBI_TXCLK	125 MHz transmit clock
TX_CLK	RCLK1	62.5 MHz receive clock - even code group
TX_ER	TXD9	Transmit code group bit 9
TX_EN	TXD8	Transmit code group bit 8
TXD[7:0]	TXD[7:0]	Transmit code group bit 7 to 0
RX_CLK	RCLK0	62.5 MHz receive clock - odd code group
RX_ER	RXD9	Receive code group 9
RX_DV	RXD8	Receive code group 8
RXD[7:0]	RXD[7:0]	Receive code group 7 to 0
CRS	COMMA	Valid comma detected

TBI Signal Diagram Figure 9:



In 1000BASE-T mode, the 10-bit interface (TBI) can be used instead of the GMII. An additional layer of encoding and decoding is performed in the data paths, which results in additional latency through the transceiver.

Doc. No. MV-S100649-00, Rev. G

Any special symbols such as 1000BASE-X Auto-Negotiation link code words are ignored and treated as idle symbols. For more details on 1000BASE-X, refer to IEEE 802.3 clause 36.

2.2.2.1 TBI to Copper Mode

In 1000BASE-T mode (HWCFG_MODE[3:0] bits to '1101'), the TBI can be used instead of the GMII. An additional layer of encoding and decoding is performed in the data paths, which results in additional latency through the transceiver.

In the TBI to copper mode, the PHY will not send to the MAC any received data from the copper cable, if the MAC is not sending valid idles or valid data to the PHY.



2.2.3 Reduced Pin Count GMII (RGMII)

88E1111

The 88E1111 device supports the RGMII specification (Version 1.2a, 9/22/2000, version 2.0, 04/2002 - note that the 88E1111 device does not support HSTL, but does support the timing specified in RGMII version 2.0). Various other RGMII timing modes, with different clock to data timing, can be programmed by setting 20.1 and 20.7 described in Table 90 on page 169. See "RGMII/RTBI Delay Timing for different RGMII/RTBI timing modes" on Page 218 for timing details. This interface reduces the interconnection between the MAC and the PHY to 12 pins. Data paths and associated control signals are reduced, and control signals are multiplexed together.


The RGMII to copper mode is selected by setting HWCFG_MODE[3:0] bits to '1011'. Transmit and receive clocks operate at 125 MHz, 25 MHz, and 2.5 MHz depending on the speed selected. The RGMII to fiber is selected by setting HWCFG MODE[3:0] bits to '0011'.

When the RGMII mode is selected, transmit control (TX_CTL) is presented on both clock edges of GTX_CLK (TXC). Receive control (RX CTL) is presented on both clock edges of RX CLK (RXC).

Table 20: RGMII Signal Mapping

88E1111 Device	RGMII Spec Pin Name	Description
GTX_CLK	TXC	125 MHz, 25 MHz, or 2.5 MHz transmit clock with ±50 ppm tolerance based on the selected speed.
TX_EN	TX_CTL	Transmit Control Signals. TX_EN is encoded on the rising edge of GTX_CLK, TX_ER XORed with TX_EN is encoded on the falling edge of GTX_CLK.
TXD[3:0]	TD[3:0]	Transmit Data. In 1000BASE-T and 1000BASE-X modes, TXD[3:0] are presented on both edges of GTX_CLK. In 100BASE-TX and 10BASE-T modes, TXD[3:0] are presented on the rising edge of GTX_CLK.
RX_CLK	RXC	125 MHz, 25 MHz, or 2.5 MHz receive clock ± 50 ppm tolerance derived from the received data stream and based on the selected speed.
RX_DV	RX_CTL	Receive Control Signals. RX_DV is encoded on the rising edge of RX_CLK, RX_ER XORed with RX_DV is encoded on the falling edge of RX_CLK.
RXD[3:0]	RD[3:0]	Receive Data. In 1000BASE-T and 1000BASE-X modes, RXD[3:0] are presented on both edges of RX_CLK. In 100BASE-TX and 10BASE-T modes, RXD[3:0] are presented on the rising edge of RX_CLK.

Figure 10: RGMII Signal Diagram



2.2.3.1 **10/100 Mbps Functionality**

This interface can be used to implement 10/100 Mbps Ethernet Media Independent Interface (MII) by reducing the clock rate to 25 MHz for 100 Mbps operation, and 2.5 MHz for 10 Mbps. The GTX_CLK (TXC) signal is always generated by the MAC, and the RX_CLK (RXC) signal is generated by the PHY.

During packet reception, RX_CLK may be stretched on either the positive or negative pulse to accommodate the transition from the free running clock to a data synchronous clock domain. When the speed of the PHY changes, a similar stretching of the positive or negative pulse is allowed. No glitching of the clocks is allowed during speed transitions.

The MAC must hold TX_EN (TX_CTL) low until the MAC has ensured that TX_EN (TX_CTL) is operating at the same speed as the PHY.

2.2.3.2 TX_ER and RX_ER Coding

See the RGMII Specifications for definitions of RX_CTL, TX_CTL, and in band status coding

In RGMII mode, Register 20.15 is the register bit used to block carrier extension

February 10, 2006, Preliminary



2.2.4 Reduced Pin Count TBI (RTBI)


88E1111

The 88E1111 device supports RTBI. The RTBI interface pin mapping is shown below. This interface supports 1000 Mbps mode of operation. The RTBI to copper interface is selected by setting HWCFG_MODE[3:0] bits to '1001'.

Table 21: RTBI Signal Mapping

88E1111 Device Pin Name	RTBI Spec Pin Name	Description
GTX_CLK	TXC	125 MHz transmit clock ± 50 ppm tolerance.
TX_EN	TD4_TD9	Transmit - Code Group bits 4 and 9. TX_EN presents bit 4 on the rising edge of GTX_CLK and bit 9 on the falling edge of GTX_CLK.
TXD[3:0]	TD[3:0]	Transmit - Code Group bits 0 to 3 and 5 to 8. TXD[3:0] runs at a double data rate with bits [3:0] presented on the rising edge of GTX_CLK and bits [8:5] on the falling edge of GTX_CLK.
RX_CLK	RXC	125 MHz receive clock ±50 ppm tolerance.
RX_DV	RD4_RD9	Receive Data - Code Group bits 4 and 9. RX_DV presents bit 4 of the 10-bit Code Group on the rising edge of RX_CLK, and bit 9 on the falling edge of RX_CLK.
RXD[3:0]	RD[3:0]	Receive Data. RD[3:0] run at a double data rate with bits [3:0] presented on the rising edge of RX_CLK, and bits [8:5] on the falling edge of RX_CLK.

Figure 11: RTBI Signal Diagram



2.2.5 SGMII Interface

The 88E1111 device supports the SGMII Rev. 1.7 interface to copper. This interface supports 10, 100, and 1000 Mbps modes of operation. The 88E1111 device does not need a TXCLK input as it recovers this clock from input data. This feature has the advantage of reducing pin count, the number of traces on the board, as well as EMI and noise generation.


On the receive side, 2 modes of operation: one with a receive clock supplied to the MAC, and one without. The serial interface with clock is selected by setting HWCFG_MODE[3:0] bits to '0000'. The serial interface without clock is selected by setting HWCFG_MODE[3:0] bits to '0100'. The receive clock is required for MACs that do not have clock recovery capability. The SGMII signal mapping is shown in Table 22.

For SGMII mode, if the bypass logic brings up the fiber link, copper auto-negotiation will restart and advertise only gigabit speed.

Table 22: SGMII Serial Interface Pin Mapping


88E1111 Device Pin Name	SGMII Specification Pin Name	Description
S_OUT±	RX	1.25 Gbaud receive output - Positive and Negative
S_CLK±	RXCLK	625 MHz receive clock
S_IN±	TX	1.25 Gbaud transmit input - Positive and Negative

Figure 12: SGMII with Receive Reference Clock



A receive reference clock is available on the S_CLK± pins. This reference clock is for implementing SGMII for MACs without receive clock recovery.

Figure 13: SGMII without Receive Reference Clock



S CLK± pins can be disabled to save power for MACs with clock recovery capability.

Copyright © 2006 Marvell



2.2.6 Serial MAC Interface

88E1111

The serial MAC interface is selected by setting HWCFG_MODE[3:0] bits to '1000' or '1100'. The serial interface signal mapping is shown in Table 23.

Two signals (RXD[0] and RXD[1]) function as signal detect outputs. These pins are asserted when the signal on the S_OUT± pins is valid.


The PHY_SIGDET pins are valid in serial interface to copper modes. Note that RXD[0] and RXD[1] only indicate that the Alaska[®] Ultra device is outputting a clean signal on the S_OUT± pins. This is independent of whether the copper link status is up or down.

The signals RXD[2] and RXD[3] give the real time link status of the copper side. These signals can be used as signal detect.

Table 23: Serial MAC Interface Pin Mapping

88E1111 Device Pin Name	Serial MAC	Description
S_OUT±	RX	1.25 Gbaud transmit output - Positive and Negative
S_IN±	TX	1.25 Gbaud receive input - Positive and Negative
RXD[0]	PHY_SIGDET[0]	1 = S_OUT± invalid 0 = S_OUT ± valid code groups according to clause 36
RXD[1]	PHY_SIGDET[1]	1 = S_OUT± valid code groups according to clause 36 0 = S_OUT ± invalid
RXD[2]	Copper Link Status [0]	1 = Copper link down 0 = Copper link up
RXD[3]	Copper Link Status [1]	1 = Copper link up 0 = Copper link down

Figure 14: Serial MAC Interface



Doc. No. MV-S100649-00, Rev. G

2.3 88E1111 Device Modes of Operation

Table 24 shows data rates supported by each interface.

Table 24: Data Rates Supported through each Interface

MAC Interface	10BASE-T	100BASE-TX	1000BASE-T	Fiber
GMII	Š	50,	HWCFG_MODE[3:0] 1111	HWCFG_MODE[3:0] 0111
MII	HWCFG_MODE[3:0] 1111	HWCFG_MODE[3:0] 1111		
ТВІ	66,74		HWCFG_MODE[3:0] 1101	
RGMII	HWCFG_MODE[3:0] 1011	HWCFG_MODE[3:0] 1011	HWCFG_MODE[3:0] 1011	HWCFG_MODE[3:0] 0011
RTBI			HWCFG_MODE[3:0] 1001	
SGMII ¹	HWCFG_MODE[3:0] 0000 or 0100	HWCFG_MODE[3:0] 0000 or 0100	HWCFG_MODE[3:0] 0000 or 0100	1,0
Serial Interface ²			HWCFG_MODE[3:0] 1000 or 1100	1007

^{1.} Two SGMII modes are available: 1) with clock and SGMII Auto-Negotiation on, and 2) without clock and SGMII Auto-Negotiation on.

Table 25: Special Operation Modes

Modes ¹	Hardware Configuration Setting	NO PE
GMII - SGMII	HWCFG_MODE[3:0] = 1110	400
RGMII-SGMII	HWCFG_MODE[3:0] = 0110	

^{1.} These modes are used for converting GMII/RGMII MAC interfaces to SGMII MAC interface.

Two 1000BASE-X modes are available for the 88E1111 device: 1) legacy 88E1000S without 1000BASE-X Auto-Negotiation without clock, and 2) with 1000BASE-X Auto-Negotiation without clock (GBIC mode).



2.3.1 Modes of Operation for Copper Media

The 88E1111 device supports various modes of operation for connection to copper media. Figure 15 displays the MAC interfaces for copper modes of operation

Figure 15: MAC to Copper Connection

88E1111




Table 26 shows the mode to select MAC interfaces connecting to copper media.

Table 26: Mode Selection for MAC Interfaces for Copper Media

HWCFG_MODE[3:0]	Description
1111	GMII/MII to Copper
1101	TBI to Copper
1011	RGMII to Copper
1001	RTBI to Copper
0000	SGMII with clock to Copper
0100	SGMII without clock to Copper
1000	1000BASE-X with Auto-Negotiation to Copper
1100	1000BASE-X without Auto-Negotiation to Copper

2.3.1.1 GMII/MII to Copper Mode

The GMII/MII to copper mode is selected by setting HWCFG MODE[3:0] bits to '1111'.

2.3.1.2 TBI to Copper Mode

The TBI to copper mode is selected by setting HWCFG_MODE[3:0] bits to '1101'.

2.3.1.3 RGMII to Copper Mode

The RGMII to copper mode is selected by setting HWCFG_MODE[3:0] bits to '1011'.

2.3.1.4 RTBI to Copper Mode

The RTBI to copper mode is selected by setting HWCFG_MODE[3:0] bits to '1001'.

2.3.1.5 SGMII to Copper Modes

There are two SGMII to copper modes, SGMII with clock, and SGMII without clock.

The SGMII with clock to copper mode is selected by setting HWCFG_MODE[3:0] bits to '0000'. The SGMII without clock to copper mode is selected by setting HWCFG MODE[3:0] bits to '0100'.

When the copper interface is running in 1000BASE-T mode, the serial 1.25 GHz SGMII encoding is identical to that found in 1000BASE-X.


In 100BASE-TX and 10BASE-T modes, the SGMII interface still runs at 1.25 GHz using 1000BASE-X encoding. However, each byte of data in the packet is repeated 10 or 100 times, respectively. The synchronizing FIFOs are automatically enabled in these modes for both the transmit and receive paths.

The SGMII interface implements a modified 1000BASE-X Auto-Negotiation to indicate link, duplex, and speed to the MAC. The result of the Auto-Negotiation exchange on the copper side is encoded onto the serial interface via the modified Auto-Negotiation so that multi-port devices can adjust to the correct operating speed.

Figure 16 is an example of an 88E1111 device using the SGMII interface.

Figure 16: SGMII Interface


MARVELL CONFIDENTIAL



2.3.1.6 Serial Interface (SERDES) to Copper Modes

The GBIC mode is selected by setting HWCFG_MODE[3:0] bits to '1000'. Figure 17 is an example of the device used for a GBIC application. The GBIC/SERDES interface supports 1000 Mbps operation only.

Figure 17: Typical GBIC Application



Copyright © 2006 Marvell

88E1111

Integrated 10/100/1000 Ultra Gigabit Ethernet Transceiver

The 1000BASE-X Auto-Negotiation information received from the MAC is used by the PHY to control what abilities the PHY advertises on the copper side. For example, if the MAC advertises only full-duplex, but the PHY is configured to advertise both full-duplex and half-duplex, the PHY only advertises full-duplex. The advertise register settings or the configuration pin strap option settings are not modified, although what is advertised on the line is now different.

After the copper Auto-Negotiation is complete, the copper side Auto-Negotiation results are sent to the MAC using 1000BASE-X Auto-Negotiation. For example, the link partner's abilities such as flow control and duplex are indicated to the MAC. The MAC, based on this information, will determine the mode of operation.

This Auto-Negotiation mechanism is different from the SGMII modified 1000BASE-X Auto-Negotiation. In SGMII mode, the Auto-Negotiation is completely done by the PHY. The PHY only reports the results of the Auto-Negotiation such as speed and duplex, as well as link status to the MAC. The only way the MAC can control Auto-Negotiation in SGMII mode is by register writes using the MDC/MDIO interface.

There is also a legacy GBIC mode that does not support 1000BASE-X Auto-Negotiation. The legacy GBIC mode is selected by setting HWCFG_MODE[3:0] to '1100'. This legacy mode is currently used in the first generation of the Marvell[®] Alaska[®] PHYs. Changing from GBIC mode to HWCFG_MODE[3:0] '1100' (1000BASE-X without Clock without 1000BASE-X Auto-Neg to copper) does not disable serial interface Auto-Negotiation. A register write of zero to Register 0 1.12 is necessary when switching from GBIC mode to HWCFG MODE[3:0] '1100'.

In HWCFG_MODE[3:0] '0000', '0100', '1000', and '1100', RXD[1:0] outputs are used as signal detect to indicate when the fiber transmitter is transmitting valid data (when the 88E1111 device is powered up and not being reset). See Table 31 for connection details.

In HWCFG_MODE[3:0] '0000', '0100', '1000', and '1100', RXD[3:2] can be used to indicate the copper link status. In this mode the LED_LINK10, LED_LINK100, and LED_LINK1000 pins cannot be used to indicate copper link status because the LED_LINK10, LED_LINK100, and LED_LINK1000 toggle during configuration. The RXD[3:2] pins must strictly indicate copper link status and not mirror the LED output. The link status will be real time status.

The definition of RXD[2] is 1 = Copper link down, 0 = Copper link up. The definition of RXD[3] is 0 = Copper link down, 1 = Copper link up.

Note that during hardware reset it is undetermined whether the PHY will be configured in fiber or copper mode. Until the mode is determined, RXD[3:2] should be are forced to 01. Forcing RXD[3:2] to 01 will prevent problems and have not adverse effect on the other modes of operation.


See Table 23 for connection details.

Doc. No. MV-S100649-00, Rev. G

2.3.2 Modes of Operation for Fiber Media

Figure 18 displays the MAC interfaces for fiber modes of operation.

Figure 18: MAC to Fiber Connection



There are two modes of fiber operation. Table 27 shows the mode to select digital interfaces connecting to fiber media.

Table 27: Mode Selection for MAC Interfaces for Fiber Media

HWCFG_ MODE[3:0]	Description
0111	GMII to Fiber
0011	RGMII to Fiber

2.3.2.1 GMII to Fiber Mode

MARVELL CONFIDENTIAL

The GMII to fiber mode is selected by setting the HWCFG_MODE bits to '0111'. When GMII is connected to the MAC and the serial interface is connected to a fiber transceiver, only the 1000 Mbps mode is active.

On the transmit and receive sides, data is converted and sent to and from the serial interface. This mode supports 1000BASE-X Auto-Negotiation.

2.3.2.2 RGMII to Fiber Mode

The RGMII to fiber mode is selected by setting the HWCFG_MODE bits to '0011'. In RGMII to fiber mode, 1000 Mbps Auto-Negotiation is used.

2.3.3 GMII/MII to SGMII and RGMII to SGMII Mode

The 88E1111 device supports both GMII/MII to SGMII mode and RGMII to SGMII mode. GMII/MII to SGMII mode is selected by setting the HWCFG_MODE bits to '1110', and RGMII to SGMII mode is selected by setting the HWCFG_MODE bits to '0110'. The GMII/MII and RGMII to SGMII mode supports all three speeds (10/100/1000). The SGMII behaves as if it were the SGMII on the MAC side of the interface.

In the case of Auto-Negotiation enable, the SGMII Auto-Negotiation information (speed, duplex and link) received from the PHY is used to determine the mode of operation. The speed and duplex of GMII/MII and RGMII will be adjusted accordingly when SGMII Auto-Negotiation is completed. In GMII/MII and RGMII to SGMII modes, link is defined to be up and the corresponding speed LED will be active when Auto-Negotiation is complete and the PHY SGMII partner's link is up. In RGMII to SGMII mode this link up condition will be shown in the in-band status.

In the case of Auto-Negotiation disable, the speed and duplex is determined by Register 20.5:4 for speed and Register 0_1_8 for duplex. (20.5:4 = 00 selects 10 Mbps, 01 selects 100 Mbps, 10 selects 1000 Mbps.) In GMII/ MII and RGMII to SGMII modes, the link is defined to be up when valid idles are received.

The transmit and receive FIFOs are enabled in both modes. S_CLK± is enabled by default.

Copyright © 2006 Marvell



2.3.4 Mode Switching

The operating mode selected at power up may be changed by writing to Register 27.3:0 with the new mode as indicated on Table 31. Any mode change must be followed by a software reset. Operation may begin in the new mode when the software reset is completed. There are additional register changes required that are not automatically completed for some mode changes. These are summarized below:

- When switching from a mode that is only capable of 1000 Mbps to a 10/100 Mbps mode, the copper Register 4 must be set with the appropriate 10/100 Mbps advertisement.
- 0_1.12 must be appropriately set when changing between a serial interface to copper mode that uses Auto-Negotiation (HWCFG_MODE bits set to '1000' or '0x00') and one that doesn't (HWCFG_MODE bits set to '1100'). This is not done automatically.
- Register 27.12 must be reprogrammed when changing between modes that use Serial Interface Auto-Negotiation bypass mode (HWCFG_MODE bits set to '1000', '0011' or '0111') and those that do not (HWCFG_MODE bits set to '0x00').
- When changing MAC interfaces for auto selection, the mode programmed must always be the copper mode (as with the power up mode).

2.4 Hardware Configuration

Configuration options like physical address, PHY operating mode, Auto-Negotiation, MDI crossover (ENA_XC), and physical connection type are configured by using the configuration pins

CONFIG[6:0] pins must be tied to one of the pins shown in Table 28 based on the configuration options selected. They should not be left floating



Note

Configuration options can be overwritten by register writes, with the exception of the PHY addresses. Configuration options are specified by tying the CONFIG[6:0] pins to the LED output, VDDO, or VSS pins. The LED output, VDDO, and VSS pins are encoded to the values shown in Table 28.

Table 28: Pin to Constant Mapping

Pin	Bit[2:0]
VDDO	111
LED_LINK10	110
LED_LINK100	101
LED_LINK1000	100
LED_DUPLEX	011
LED_RX	010
LED_TX	001
VSS	000


The encoded values of the LED output tied to the CONFIG[6:0] pins are latched at the de-assertion of the RESETn pin. The 88E1111 device configuration options associated to each configuration pin are shown in Table 30.

Figure 19 illustrates a common configuration connection that will enable the conditions listed in Table 29.

Table 29: CONFIG Pin Connection Example

Pin	LED Pin Connection	Hardware Configuration Bit Setting	Configuration
CONFIG0	LED_RX	010	PHY Address bit [2:0] = 010
CONFIG1	LED_LINK10	110	Enable Pause, PHY address bit[4:3] = 10
CONFIG2	LED_LINK100	101	Auto-Neg advertise 1000BASE-T only, prefer master
CONFIG3	LED_DUPLEX	011	Enable MDI crossover, disable 125CLK
CONFIG4	VSS	000	1000BASE-X without clock with 1000BASE-X Auto- Neg to copper (GBIC)
CONFIG5	VDDO *	111	Disable fiber/copper Auto-detect, Disable sleep
CONFIG6	LED_LINK1000	100	Select TWSI interface, INT signal active high, 50 ohm SERDES (SFP application)


Figure 19: Configuration Connection Example



2.4.1 88E1111 Device Configuration Description

For the 88E1111 device, the encoded values of the LED output tied to the CONFIG[6:0] pins are latched at the deassertion of the RESETn pin. The CONFIG[6:0] inputs come out to the corresponding CONFIG pins. See Figure 20 for details.

Figure 20: 88E1111 Device Configuration Input



The 88E1111 device configuration options associated to each configuration pin are shown in Table 30.

Table 30: 88E1111 Device Pin to Configuration Bit Mapping

Bit[2]	Bit[1]	Bit[0]
PHYADR[2] ¹	PHYADR[1] ¹	PHYADR[0] ¹
ENA_PAUSE	PHYADR[4] ¹	PHYADR[3] ¹
ANEG[3]	ANEG[2]	ANEG[1]
ANEG[0]	ENA_XC	DIS_125
HWCFG_MODE[2]	HWCFG_MODE[1]	HWCFG_MODE[0]
DIS_FC	DIS_SLEEP	HWCFG_MODE[3]
SEL_TWSI	INT_POL *	75/50 OHM
	PHYADR[2] ¹ ENA_PAUSE ANEG[3] ANEG[0] HWCFG_MODE[2] DIS_FC	PHYADR[2] ¹ PHYADR[1] ¹ ENA_PAUSE PHYADR[4] ¹ ANEG[3] ANEG[2] ANEG[0] ENA_XC HWCFG_MODE[2] HWCFG_MODE[1] DIS_FC DIS_SLEEP

For the TWSI device address, the lower 5 bits (PHYADR[4:0]), are latched during hardware reset, and the device address bits ([6:5]) are fixed at '10'.

Refer to Table 31 for a detailed description of the 88E1111 device configuration options.

Table 31: 88E1111 Device Configuration Register Definitions

1	2.0
Configuration	Description
PHYADR[4:0]	PHY Address. PHY Address in MDC/MDIO mode Lower 5 address bits are used in bi-directional data transfer mode
ENA_PAUSE	Enable Pause. 0 = Default register 4.11:10 to 00 - copper 1 = Default register 4.11:10 to 11 - copper 0 = Default register 4.8:7 to 00 - fiber 1 = Default register 4.8:7 to 11 - fiber
ANEG[3:0]	Auto-Negotiation Configuration for copper modes. ANEG[3:0] determines whether Auto-Negotiation should be turned on, Master/Slave preference, and the speed and duplex at which to run. ANEG [3:2] also determines duplex advertised in 1000BASE-X mode. 0000 = Forced 10BASE-T half-duplex 0011 = Forced 10BASE-T half-duplex 0010 = Forced 100BASE-TX half-duplex 0011 = Forced 100BASE-TX full-duplex 0100 = Auto-Neg, advertise only 1000BASE-T half-duplex, forced Master 0101 = Auto-Neg, advertise only 1000BASE-T half-duplex, preferred Master 0110 = Auto-Neg, advertise only 1000BASE-T half-duplex, preferred Slave 1000 = Auto-Neg, advertise only 1000BASE-T full-duplex, forced Master 1001 = Auto-Neg, advertise only 1000BASE-T full-duplex, forced Master 1001 = Auto-Neg, advertise only 1000BASE-T full-duplex, preferred Slave 1010 = Auto-Neg, advertise only 1000BASE-T full-duplex, preferred Slave 1101 = Auto-Neg, advertise all capabilities, forced Master 1111 = Auto-Neg, advertise all capabilities, prefer Slave
ANEG[3:2]	Auto-Negotiation Configuration for fiber modes. ANEG[3:2] determines whether Auto-Negotiation should be turned on, and the speed and duplex at which to run. 01 = Forced 1000BASE-X half-duplex 10 = Forced 1000BASE-X full-duplex 11 = Auto-Negotiation enabled, 1000BASE-X full-duplex/Auto-Negotiation enabled, 1000BASE-X half-duplex ¹

^{1.} For Auto-Negotiation, half-duplex, set ANEG[3:2] = 11 AND change to half-duplex by disabling full-duplex in Register bit 0.8, and by disabling full-duplex advertisement in Register bit 4.5.

Table 31: 88E1111 Device Configuration Register Definition (Continued)

	Device Configuration Register Deminion (Continued)
Configuration	Description
ENA_XC	Enable Crossover. ENA_XC selects whether the MDI crossover function is enabled. If the MDI crossover function is disabled, then the device assumes the MDI configuration. 0 = Disable 1 = Enable
DIS_125	Disable 125MHz clock. 0 = Enable 125CLK 1 = Disable 125CLK
HWCFG MODE[3:0]	Hardware Configuration Mode. HWCFG_MODE[3:0] specifies the operating mode of the 88E1111 device. Modes 0001, 0101, 1001, 1101, 0111, 1111, 0011, and 1011 can be overridden if the automatic selection of the copper/fiber interface is enabled (e.g. if GMII to copper is selected but the PHY detects energy on the fiber lines, the mode will become GMII to fiber if DIS_FC = 0). 0000 = SGMII with Clock with SGMII Auto-Neg to copper 0100 = SGMII without Clock with SGMII Auto-Neg to copper 1000 = 1000BASE-X without Clock with 1000BASE-X Auto-Neg to copper 0001 = Reserved 0101 = Reserved 1001 = RTBI to copper 1101 = TBI to copper 0010 = Reserved 1110 = GMII to SGMII 0011 = RGMII to Fiber 0111 = GMII to Fiber 1011 = RGMII to Fiber 1011 = RGMII to copper
DIS_FC	Disable fiber/copper interface. DIS_FC is used to enable or disable the automatic selection of the fiber/copper interface. (The PHY automatically switches between the fiber and copper interface based on energy detected on those lines, and if Auto-Negotiation is complete.) 0 = Enable fiber/copper auto selection 1 = Disable fiber/copper auto selection
DIS_SLEEP	Energy detect. DIS_SLEEP is used to enable or disable energy detect. 0 = Enable energy detect 1 = Disable energy detect



Table 31: 88E1111 Device Configuration Register Definitions (Continued)

Configuration	Description
SEL_TWSI	Interface select. SEL_TWSI selects whether the MDC/MDIO interface or the Two-Wire Serial Interface (TWSI) is enabled. 0 = Select MDC/MDIO interface 1 = Select Two-Wire Serial Interface
INT_POL	Interrupt polarity 0 = INTn signal is active HIGH 1 = INTn signal is active LOW
75/50 OHM	Termination resistance. Selects default value 50 Ω or 75 Ω fiber (or SGMII) input or output impedance. Refer to Register 26.6 and 26.5 for details. 0 = 50 ohm termination for fiber 1 = 75 ohm termination for fiber

2.5 Synchronizing FIFO

The 88E1111 device controls transmit and receive synchronizing FIFOs to reconcile frequency differences between the clocks in all MAC interfaces, the serial interface, the management interface, and internal clocks. The depth of the transmit and receive FIFOs can be independently programmed by programming register bits 16.15:12. See the "Alaska[®] Ultra FAQs" for details on how to calculate required FIFO depth and the details of the different clocks used for transmit and receive in each mode of operation.

The FIFO depths can be increased in length by programming Register 16.15:12 to support longer frames. The 88E1111 device can handle jumbo frame sizes up to 10 Kbytes with up to \pm 150 PPM clock jitter. The deeper the FIFO depth, the higher the latency will be.

Table 32 shows when transmit and receive FIFOS are enabled or disabled for each mode.

Table 32: FIFO Enable/Disable based on the Mode Selected

Mode of Operation	10BASE-T		100BASE-T		1000BASE-T		1000BASE-X	
****	TX FIFO	RX FIFO	TX FIFO	RX FIFO	TX FIFO	RX FIFO	TX FIFO	RX FIFO
GMII/MII	Off	Off	Off	Off	On	Off	On	On
ТВІ	-	-	-	-	On	On	-	
RGMII/Modified MII	On	Off	On	Off	On	Off	On	On
RTBI	-	-	-	-	On	On	-	5
SGMII	On	On	On	On	On	On	- %	<u>o</u>
Serial Interface ¹	-	-	-	-	On	On	-50	2

^{1.} Two 1000BASE-X modes are available for the 88E1111 device: 1) legacy 88E1000S without 1000BASE-X Auto-Negotiation without clock, and 2) with 1000BASE-X Auto-Negotiation without clock (GBIC mode).



2.6 Copper Media Transmit and Receive Functions

The transmit and receive paths for the 88E1111 device are described in the following sections.

2.6.1 Transmit Side Network Interface

2.6.1.1 Multi-mode TX Digital to Analog Converter

The 88E1111 device incorporates a multi-mode transmit DAC to generate filtered 4D PAM 5, MLT3, or Manchester coded symbols. The transmit DAC performs signal wave shaping to reduce EMI. The transmit DAC is designed for very low parasitic loading capacitances to improve the return loss requirement, which allows the use of low cost transformers.

2.6.1.2 Slew Rate Control and Waveshaping

In 1000BASE-T mode, partial response filtering and slew rate control is used to minimize high frequency EMI. In 100BASE-TX mode, slew rate control is used to minimize high frequency EMI. In 10BASE-T mode, the output waveform is pre-equalized via a digital filter.

2.6.2 Encoder

2.6.2.1 1000BASE-T

In 1000BASE-T mode, the transmit data bytes are scrambled to 9-bit symbols and encoded into 4D PAM 5 symbols. Upon initialization, the initial scrambling seed is determined by the PHY address. This prevents multiple 88E1111 device from outputting the same sequence during idle, which helps to reduce EMI.

2.6.2.2 100BASE-TX

In 100BASE-TX mode, the transmit data stream is 4B/5B encoded, serialized, and scrambled. Upon initialization, the initial scrambling seed is determined by the PHY address. This prevents multiple 88E1111 device from outputting the same sequence during idle, which helps to reduce EMI.

2.6.2.3 10BASE-T

In 10BASE-T mode, the transmit data is serialized and converted to Manchester encoding

2.6.3 Receive Side Network Interface

2.6.3.1 Analog to Digital Converter

The 88E1111 device incorporates an advanced high speed ADC on each receive channel with greater resolution than the ADC used in the reference model of the 802.3ab standard committee. Higher resolution ADC results in better SNR, and therefore, lower error rates. Patented architectures and design techniques result in high differential and integral linearity, high power supply noise rejection, and low metastability error rate. The ADC samples the input signal at 125 MHz.

Doc. No. MV-S100649-00, Rev. G

2.6.3.2 Active Hybrid

The 88E1111 device employs a sophisticated on-chip hybrid to substantially reduce the near-end echo, which is the super-imposed transmit signal on the receive signal. The hybrid minimizes the echo to reduce the precision requirement of the digital echo canceller. The on-chip hybrid allows both the transmitter and receiver to use the same transformer for coupling to the twisted pair cable, which reduces the cost of the overall system.

2.6.3.3 Echo Canceller

Residual echo not removed by the hybrid and echo due to patch cord impedance mismatch, patch panel discontinuity, and variations in cable impedance along the twisted pair cable result in drastic SNR degradation on the receive signal. The 88E1111 device employs a fully developed digital echo canceller to adjust for echo impairments from more than 100 meters of cable. The echo canceller is fully adaptive to compensate for the time varying nature of channel conditions.

2.6.3.4 NEXT Canceller

The 1000BASE-T physical layer uses all 4 pairs of wires to transmit data to reduce the baud rate requirement to only 125 MHz. This results in significant high frequency crosstalk between adjacent pairs of cable in the same bundle. The 88E1111 device employs 3 parallel NEXT cancellers on each receive channel to cancel any high frequency crosstalk induced by the adjacent 3 transmitters. A fully adaptive digital filter is used to compensate for the time varying nature of channel conditions.

2.6.3.5 Baseline Wander Canceller

Baseline wander is more problematic in the 1000BASE-T environment than in the traditional 100BASE-TX environment due to the DC baseline shift in both the transmit and receive signals. The 88E1111 device employs an advanced baseline wander cancellation circuit to automatically compensate for this DC shift. It minimizes the effect of DC baseline shift on the overall error rate.

2.6.3.6 Digital Adaptive Equalizer

The digital adaptive equalizer removes inter-symbol interference at the receiver. The digital adaptive equalizer takes unequalized signals from ADC output and uses a combination of feedforward equalizer (FFE) and decision feedback equalizer (DFE) for the best-optimized signal-to-noise (SNR) ratio.

2.6.3.7 Digital Phase Lock Loop

In 1000BASE-T mode, the slave transmitter must use the exact receive clock frequency it sees on the receive signal. Any slight long-term frequency phase jitter (frequency drift) on the receive signal must be tracked and duplicated by the slave transmitter; otherwise, the receivers of both the slave and master physical layer devices have difficulty canceling the echo and NEXT components. In the 88E1111 device, an advanced DPLL is used to recover and track the clock timing information from the receive signal. This DPLL has very low long-term phase jitter of its own, thereby maximizing the achievable SNR.

2.6.3.8 Link Monitor

MARVELL CONFIDENTIA

The link monitor is responsible for determining if link is established with a link partner. In 10BASE-T mode, link monitor function is performed by detecting the presence of valid link pulses (NLPs) on the MDI± pins.

In 100BASE-TX and 1000BASE-T modes, link is established by scrambled idles.

If Force Link Good register 16.10 is set high, the link is forced to be good and the link monitor is bypassed for 100BASE-TX and 10BASE-T modes. In the 1000BASE-T mode, register 16.10 has no effect.

Copyright © 2006 Marvell



2.6.3.9 Signal Detection

88E1111

In 1000BASE-T mode, signal detection is based on whether the local receiver has acquired lock to the incoming data stream.

In 100BASE-TX mode, the signal detection function is based on the receive signal energy detected on the MDI± pins that is continuously qualified by the squelch detect circuit, and the local receiver acquiring lock.

2.6.4 Decoder

2.6.4.1 1000BASE-T

In 1000BASE-T mode, the receive idle stream is analyzed so that the scrambler seed, the skew among the 4 pairs, the pair swap order, and the polarity of the pairs can be accounted for. Once calibrated, the 4D PAM 5 symbols are converted to 9-bit symbols that are then descrambled into 8-bit data values. If the descrambler loses lock for any reason, the link is brought down and calibration is restarted after the completion of Auto-Negotiation.

2.6.4.2 100BASE-TX

In 100BASE-TX mode, the receive data stream is recovered and converted to NRZ. The NRZ stream is descrambled and aligned to the symbol boundaries. The aligned data is then parallelized and 5B/4B decoded. The receiver does not attempt to decode the data stream unless the scrambler is locked. The descrambler "locks" to the *scrambler* state after detecting a sufficient number of consecutive idle code-groups. Once locked, the descrambler continuously monitors the data stream to make sure that it has not lost synchronization. The descrambler is always forced into the *unlocked* state when a link failure condition is detected, or when insufficient idle symbols are detected.

2.6.4.3 10BASE-T

In 10BASE-T mode, the recovered 10BASE-T signal is decoded from Manchester to NRZ, and then aligned. The alignment is necessary to insure that the start of frame delimiter (SFD) is aligned to the nibble boundary.

Power Supplies 2.7

The 88E1111 device requires 2 power supplies: 2.5V, and 1.0V. 1.2V can be used instead of 1.0V, if it is available on the board. For the I/O pins, there are three separate groupings: VDDO, VDDOH, VDDOX.

2.7.1 VDDO

VDDO is used for the MAC interface I/O pins¹ only. There is one supply option for VDDO: 2.5V

2.7.2 VDDOH

VDDOH is used for the LED², CONFIG³, XTAL1, XTAL2, and SEL FREQ pin power. VDDOH supports 2.5V.

2.7.3 VDDOX

VDDOX is used for MDC/MDIO/INTn/125CLK/RESETn/JTAG4 pin power. This supply supports 2.5V. These pins have a fixed input threshold that is a function of supply voltage. This flexibility in supply voltage allows the user not to use any level shifters.

For the 88E1111 device internal logic, there are two separate supplies: AVDD and DVDD.

2.7.4 **AVDD**

AVDD is used for the analog high digital logic. AVDD is used as the 2.5V analog supply.

2.7.5 **DVDD**

MARVELL CONFIDENTIA

DVDD is used for the digital logic. DVDD is the 1.0V digital supply. 1.2V can be used instead of 1.0V if 1.0V supply is not available. If the 1.2V option is used, current consumption values shown in "Current Consumption DVDD" on page 195 will increase by 20%.

^{1.} GTX_CLK, TX_CLK, TX_EN, TX_ER, TXD[7:0], RX_CLK, RX_DV, RX_ER, RXD[7:0], CRS, and COL. 2. LED_LINK10, LED_LINK100, LED_LINK1000, LED_DUPLEX, LED_RX, and LED_TX.

^{3.} CONFIG[4:0], GCONFIG0, GCONFIG1.

^{4.} TDI, TMS, TCK, TRSTn, and TDO.



2.8 Power Management

The 88E1111 device supports several advanced power management modes that conserve power.

2.8.1 Low Power Modes

Four low power modes are supported in the 88E1111 device.

- COMA
- IEEE 22.2.4.1.5 compliant power down
- Energy Detect (Mode 1)
- Energy Detect+TM (Mode 2)

The COMA (deep sleep) mode disables all the active circuitry to draw absolute minimum power.

IEEE 22.2.4.1.5 power down compliance allows for the PHY to be placed in a low-power consumption state by register control.

Energy Detect (Mode 1) allows the 88E1111 device to wake up when energy is detected on the wire.

Energy Detect+TM (Mode 2) is identical to Mode 1 with the additional capability to wake up a link partner. In Mode 2, the 10BASE-T link pulses are sent once every second while listening for energy on the line.

Details of each mode are described below.

2.8.2 Enabling Low Power Modes

The 88E1111 device has one pin dedicated to support the low power modes.

- The COMA pin is a direct input from the MAC. It can be used to put the PHY into or out of the COMA mode.
 Refer to the Signal Description for COMA pin details.
- The CONFIG3 pin is sampled during power-on reset, and is used to select between normal modes of operation and the energy detect low power down modes. The default mode is Mode 2 when DIS_SLEEP is 0. See Section 2.4 "Hardware Configuration" on page 63.

Low power modes are also register programmable. Register 16.9:8 allows the user to select between Mode 1 and Mode 2. When the low power modes are not selected, Register 0.11 may be used. If during the energy detect modes, the PHY wakes up and starts operating at a normal mode, Register 16.9:8 settings are retained. When the link is lost and energy is no longer detected, the 88E1111 device returns to the mode stored in Register 16.9:8.

Table 33: Low Power Mode Activation

Power Mode	How to Activate Mode
COMA (Deep Sleep)	Dedicated pin to activate - COMA (see Table 12 for COMA pin details).
IEEE Power down	Register 0.11 write
Energy Detect	Configuration option & Register 16.9:8 write

2.8.3 Low Power Operating Modes

2.8.3.1 COMA Mode

The COMA mode can be activated by asserting "high" on the COMA pin. In the COMA mode, all the PHY functions including transmit, receive, and serial management interface are completely disabled. No circuitry is running, and all the internal clocks are stopped. The 125 MHz output clock is disabled as well. This mode is for applications that require absolute minimum power.

COMA mode can be deactivated by de-asserting "high" on the COMA pin only. Since the serial management interface is disabled during this mode, read or write to registers is not possible in COMA mode. Moreover, since all the active circuitry is disabled during this mode, the energy detect function is disabled. Upon exiting COMA mode a hardware reset must be completed for the 88E1111 device to resume normal operation. The COMA low power mode cannot be enabled as long as hardware reset is enabled.

In the COMA mode, the PHY cannot wake up on its own by detecting activity on the CAT 5 cable.

2.8.3.2 IEEE Power Down Mode

The standard IEEE power down mode is entered by setting Register 0.11 equal to one. In this mode, the PHY does not respond to any MAC interface signals except the MDC/MDIO. It also does not respond to any activity on the CAT 5 cable.

In this power down mode, the PHY cannot wake up on its own by detecting activity on the CAT 5 cable. It can only wake up by setting Register 0.11 to 0.

2.8.3.3 Energy Detect Power Down Modes

The 88E1111 device can be placed in energy detect power down modes by selecting either of the two energy detect modes. Both modes enable the PHY to wake up on its own by detecting activity on the CAT 5 cable.

In order to exit these modes of operation, bits 9:8 must be set to 00, and there must be a software reset. See Register 16.9:8 in the Section 3. "Register Description" on page 117.

2.8.3.4 Energy Detect (Mode 1)

MARVELL CONFIDENTIA

In Mode 1, only the signal detection circuitry and serial management interface are active. If the PHY detects energy on the line, it starts to Auto-Negotiate sending FLPs for 5 seconds. If at the end of 5 seconds the Auto-Negotiation is not completed, then the PHY stops sending FLPs and goes back to monitoring receive energy. If Auto-Negotiation is completed, then the PHY goes into normal 10/100/1000 Mbps operation. If during normal operation the link is lost, the PHY will re-start Auto-Negotiation. If no energy is detected after 5 seconds, the PHY goes back to monitoring receive energy.

2.8.3.5 Energy Detect +TM (Mode 2)

In Mode 2, the PHY sends out a single 10 Mbps NLP (Normal Link Pulse) every one second. Except for this difference, Mode 2 is identical to Mode 1 operation. If the 88E1111 device is in Mode 1, it cannot wake up a connected device; therefore, the connected device must be transmitting NLPs, or either device must be woken up through register access. If the 88E1111 device is in Mode 2, then it can wake a connected device. The default mode of operation is Mode 2 when DIS_SLEEP is 0.

2.8.3.6 Normal 10/100/1000 Mbps Operation

Normal 10/100/1000 Mbps operation can be entered by either using a configuration option or a register write during energy detect modes.

Copyright © 2006 Marvell



88E1111

2.8.4 125CLK and MAC Interface Effect on Low Power Modes

In some applications, the 125CLK or the clocks on the MAC interface must run continuously regardless of the state of the PHY. Additional power will be required to keep these clocks running during low power states.

If absolute minimal power consumption is required during the IEEE power down mode or the Energy Detect modes, then Register 16.4 should be set to 1 to disable the toggling of 125CLK, and Register 16.3 should be set to 0 to allow the MAC interface to power down. Note that for these settings to take effect a software reset must be issued.

Doc. No. MV-S100649-00, Rev. G

MARVELL CONFIDENTIA

2.9 Management Interface

The management interface provides access to the internal registers via the MDC and MDIO pins and is compliant with IEEE 802.3u clause 22. MDC is the management data clock input and, it can run from DC to a maximum rate of 8.3 MHz. At high MDIO fanouts the maximum rate may be decreased depending on the output loading. MDIO is the management data input/output and is a bi-directional signal that runs synchronously to MDC.

The MDIO pin requires a pull-up resistor in a range from 1.5 kohm to 10 kohm that pulls the MDIO high during the idle and turnaround.

PHY address is configured during the hardware reset sequence. Refer to Section 2.4 "Hardware Configuration" on page 63 for more information on how to configure PHY addresses.

Typical read and write operations on the management interface are shown in Figure 21 and Figure 22. All the required serial management registers are implemented as well as several optional registers. A description of the registers can be found in the Register Description.

Figure 21: Typical MDC/MDIO Read Operation





Figure 22: Typical MDC/MDIO Write Operation



Copyright © 2006 Marvell

MARVELL CONFIDENTIAL



Table 34 is an example of a read operation.

Table 34: Serial Management Interface Protocol

88E1111

32-Bit Preamble	Start of Frame	OpCode Read = 10 Write = 01	5-Bit PHY Device Address	5-Bit PHY Register Address (MSB)	2-Bit Turn around Read = z0 Write = 10	16-Bit Data Field	Idle
11111111	01	10	01100	00000	z0	0001001100000000	11111111

2.9.1 Extended Register Access

MDC/MDIO protocol only supports 32 registers. Since the 88E1111 device has more than 32 registers, a paging scheme is used to address more than 32 registers. The different pages might be accessed automatically based on the operating mode or they can be selected by setting bit in other registers. For example, Register 29 sets the applicable page of Register 30. Register 22 is used to select the different pages of various registers. See Section 3. "Register Description" on page 117 for details.

2.9.2 Preamble Suppression

The 88E1111 device is permanently programmed for preamble suppression. A minimum of one idle bit is required between operations.

2.9.3 Programming Interrupts

In the 88E1111 device, the polarity of the interrupt pin is programmable through the hardware configuration option INT_POL. The interrupt function drives high or low based on the INT_POL setting and when register 18 is enabled for an interrupt event and an interrupt is detected. This function minimizes the need for polling via the serial management interface. An external pull-up resistor is used when the INTn pin is active low. and a pull-down resistor is used when the INTn pin is active high.

Table 35 shows the interrupts that may be programmed.

Table 35: Programmable Interrupts

Register Address	Programmable Interrupts
18.15	Auto-Negotiation Error Interrupt Enable
18.14	Speed Changed Interrupt Enable
18.13	Duplex Changed Interrupt Enable
18.12	Page Received Interrupt Enable
18.11	Auto-Negotiation Completed Interrupt Enable
18.10	Link Status Changed Interrupt Enable
18.9	Symbol Error Interrupt Enable
18.8	False Carrier Interrupt Enable
18.7	FIFO Over/Underflow Interrupt Enable
18.6	MDI Crossover Changed Interrupt Enable
18.5	Downshift Interrupt Enable
18.4	Energy Detect Interrupt Enable
18.3	Reserved
18.2	DTE Power Detection Status Changed Interrupt Enable
18.1	Polarity Changed Interrupt Enable
18.0	Jabber Interrupt Enable

Register 18 determines whether the INTn pin is asserted when an interrupt event occurs. Register 19 reports interrupt status. When an interrupt event occurs, the corresponding bit in register 19 is set and remains set until register 19 is read via the serial management interface. When interrupt enable bits are not set in register 18, interrupt status bits in register 19 are still set when the corresponding interrupt events occur. However, the INTn pin is not asserted.

The INTn pin is asserted as long as one interrupt status bit is set in register 19 with its corresponding interrupt enable bit set in register 18.

To de-assert the INTn pin

MARVELL CONFIDENTIAL

- Clear register 19 via a management read
- Disable the interrupt enable by writing register 18



2.10 Two-wire Serial Interface

88E1111

The 88E1111 device supports a Two-wire Serial Interface (TWSI). The TWSI operates with a serial data line (SDA) and a serial clock line (SCL). The bus interface is enabled through CONFIG6 bit 2, and, during data transfer, the MDC/MDIO pins are utilized as the bus interface connections. For the TWSI device address, the lower 5 bits (PHYADR[4:0]), are latched during hardware reset, and the device address bits ([6:5]) are fixed at '10'. The SDA is a bi-directional line, while the SCL line is not. SDA requires a 1.5 kohm pull-up resistor. The 88E1111 device operates as the Slave port of the bus interface, and all references to Slave refer to the 88E1111 device.

The 88E1111 device will be available for read/write operations 5 ms after hardware reset.

Table 36 indicates the pin mapping of the 88E1111 device to the TWSI.

Table 36: 88E1111 device to Two-Wire Serial Interface Signal Mapping

88E1111 Device Pins	100/400 Kbps Mode	Description
MDI	SDA	Serial data line
MDC	SCL	Serial clock line

The 88E1111 device TWSI features are:

- 7-bit device address/8-bit data transfers
- 100 Kbps mode
- 400 Kbps mode

Multiple devices using the TWSI can share and lump up the MDC and MDIO lines, and are pulled up with a resistor ranging from 4.5 kohm to 10 kohm.

The 88E1111 device will be available for read/write operations 5 ms after hardware reset.

2.10.1 Bus Operation

The Master generates one clock pulse for each data bit transferred. The high or low state of the data line can only change when the clock signal on the SCL line is low. A high to low transition on the SDA line while SCL is high defines a Start. A low to high transition on the SDA line while the SCL is high defines a Stop. Start (S), Repeated Start (Sr), and Stop (P) conditions are always generated by the Master. Acknowledge (A) and Not Acknowledge (A) can be generated by either the Slave or Master.

The Master continuously monitors for Start and Stop conditions. Whenever a Stop is detected, the 88E1111 device goes into standby mode, and the current operation is cancelled. The Slave recovers from this error condition, and waits for the next transfer to begin.

Data transfer with Acknowledge is always obligatory. The receiver must pull down the SDA line during the Acknowledge clock pulse so that it remains stable low during the high period of this clock pulse.

If the Slave does not Acknowledge the device address, but some time later in the transfer cannot receive any more data bytes, the Master must abort the transfer. This is indicated by the Slave generating the Not Acknowledge on the first byte to follow. The Slave device then leaves the data line high, and the Master must generate a Stop or a Repeated Start condition. When the Slave is transmitting data on the bus and the Master responds with a Not Acknowledge, the Slave must receive a Stop or a Repeated Start condition. If neither is received, it is an error condition. The Slave recovers from this error condition and waits for the next transfer to begin.

The bus interface is also active in power down mode. (See Section 2.8 "Power Management" on page 74 for power down mode details.) Whenever the Slave is addressed by the Master, the 88E1111 device comes out of power down mode if it is in power down mode. Read and Write operations are detailed in the following section.

Doc. No. MV-S100649-00, Rev. G

2.10.2 Read and Write Operations

Write operations require an 8-bit Slave address followed by the register address and Acknowledgement. The Slave address is 7 bits long followed by an eighth bit. The first bit of a data transfer is the most significant bit (MSb). The eighth bit is the least significant bit (LSb), which is a direction bit (R/W) - Read = 1, Write = 0). Read operations are executed the same way as Write operations with the exception that the R/W bit is set to one.

A complete byte write operation includes the upper and lower bytes. The upper byte is written first, followed by the lower byte.


The register address counter maintains the last address accessed during the last read or write operation, incremented by one. The address remains valid between operations as long as chip power is maintained. The register limit is 32 registers. Once the counter reaches the lower byte of register 31, it rolls over to the upper byte of register 0.

2.10.2.1 Random Write

MARVELL CONFIDENTIAL

For random writes, both the upper byte and lower byte must be written to the Slave before the data is written to the addressed register.

Figure 23: Random Write Operation






2.10.2.2 Sequential Write

A sequential write is started by a random address write. After the register address is received by the Slave, the Slave responds with an Acknowledge. The Slave generates an Acknowledge as long as the Master does not generate a Stop. In sequential write, only the even transfer of bytes is accepted by the 88E1111 device. If the last byte is odd, it is held internally by the Slave, but is not written to the Slave register.

Figure 24: Sequential Write Operation


88E1111



2.10.2.3 Current Address Read

A current address read is used to read the data at the current register address. A Start begins a current address read and resets the Slave to synchronize with the Master.


Figure 25: Current Address Read



2.10.2.4 Random Read

A random read is used to access any particular register. A "dummy" byte write is required to load in the data word address. When the device address and the data word address are Acknowledged, another Start condition must be generated. Figure 26 is an example of a random read.

Figure 26: Random Read Operation




2.10.2.5 Sequential Read

MARVELL CONFIDENTIAL

A sequential read is used to read particular registers in their address order. A sequential read is initiated by either a current or random address read. After the Master receives the register data, it responds with an Acknowledge. As long as the Slave receives an Acknowledge, register data continues to be read incrementally. The sequential read operation is stopped when the Master does not respond with a zero, but does generate a Stop condition.

Figure 27 is an example of a sequential read started by a random read.

Figure 27: Sequential Read Operation





2.11 Auto-Negotiation

The 88E1111 device supports 5 types of Auto-Negotiation.

- 10/100/1000BASE-T Copper Auto-Negotiation. (IEEE 802.3 Clauses 28 and 40)
- 1000BASE-X Auto-Negotiation (IEEE 802.3 Clause 37)
- SGMII Auto-Negotiation (CISCO specification)
- GBIC Mode Auto-Negotiation (Marvell patent)
- Auto Media Select Auto-Negotiation

Auto-Negotiation provides a mechanism for transferring information from the local station to the link partner to establish speed, duplex, and Master/Slave preference during a link session.

Auto-Negotiation for 1000BASE-X supports 1000 Mbps operation only.

Auto-Negotiation is initiated upon any of the following conditions:

- Power up reset
- Hardware reset
- Software reset (Register 0.15)
- Restart Auto-Negotiation (Register 0.9)
- Transition from power down to power up (Register 0.11)
- The link goes down

The option to select 10/100/1000BASE-T or 1000BASE-X Auto-Negotiation is determined by hardware configuration settings at RESETn and based on the digital interface being used.

The following sections describe each of the Auto-Negotiation modes in detail.

2.11.1 10/100/1000BASE-T Auto-Negotiation

The 10/100/1000BASE-T Auto-Negotiation (AN) is based on Clause 28 and 40 of the IEEE802.3 specification. It is used to negotiate speed, duplex, and flow control over CAT5 UTP cable. Once Auto-Negotiation is initiated, the 88E1111 device determines whether or not the remote device has Auto-Negotiation capability. If so, the 88E1111 device and the remote device negotiate the speed and duplex with which to operate.

If the remote device does not have Auto-Negotiation capability, the 88E1111 device uses the parallel detect function to determine the speed of the remote device for 100BASE-TX and 10BASE-T modes. If link is established based on the parallel detect function, then it is required to establish link at half-duplex mode only. Refer to IEEE 802.3 clauses 28 and 40 for a full description of Auto-Negotiation.

After hardware reset, 10/100/1000BASE-T Auto-Negotiation can be enabled and disabled via Register 0.12. Auto MDI/MDIX and Auto-Negotiation may be disabled and enabled independently. When Auto-Negotiation is disabled, the speed and duplex can be set via registers 0.13, 0.6, and 0.8 respectively. When Auto-Negotiation is enabled the abilities that are advertised can be changed via registers 4 and 9.

Auto-Negotiation options are configured using the CONFIG[2] pins, or by registers. See Section 2.4 "Hardware Configuration" on page 63 for more information.

Upon the de-assertion of hardware reset the 88E1111 device can be configured to have Auto-Negotiation enabled for all capabilities (1000BASE-T, 100BASE-TX, or 10BASE-T modes), or the device may be configured to operate in either 1000BASE-T, 100BASE-TX, or 10BASE-T modes.

Auto-Negotiation can also be configured via registers 0, 4, and 9. Changes to registers 0.12, 0.13, 0.6 and 0.8 do not take effect unless one of the following takes place:

- Software reset (Register 0.15)
- Restart Auto-Negotiation (Register 0.9)

Doc. No. MV-S100649-00, Rev. G

- Transition from power down to power up (Register 0.11)
- The link goes down

To enable or disable Auto-Negotiation, Register 0.12 should be changed simultaneously with either Register 0.15 or 0.9. For example, to disable Auto-Negotiation and force 10BASE-T half-duplex mode, Register 0 should be written with 0x8000.

Registers 4 and 9 are internally latched once every time the Auto-Negotiation enters the Ability Detect state in the arbitration state machine. Hence, a write into Register 4 or 9 has no effect once the 88E1111 device begins to transmit Fast Link Pulses (FLPs). This guarantees that sequences of FLPs transmitted are consistent with one another.

Register 7 is treated in a similar way as registers 4 and 9 during additional next page exchanges.

If Auto-Media detect is enabled, Register 22.0 must be set to zero to view the copper auto-negotiation registers.

If 1000BASE-T mode is advertised, then the 88E1111 device automatically sends the appropriate next pages to advertise the capability and negotiate master/slave mode of operation. If the user does not wish to transmit additional next pages, then the next page bit (Register 4.15) can be set to zero, and the user needs to take no further action.

If next pages in addition to the ones required for 1000BASE-T are needed, then the user can set Register 4.15 to one, and send and receive additional next pages via registers 7 and 8, respectively.

Note that 1000BASE-T next page exchanges are automatically handled by the 88E1111 device without user intervention, regardless of whether or not additional next pages are sent.

Once the 88E1111 device completes Auto-Negotiation, it updates the various status in registers 1, 5, 6, and 10. Speed, duplex, page received, and Auto-Negotiation completed status are also available in registers 17 and 19. See Section 3. "Register Description" on page 117 for details.

2.11.2 1000BASE-X Auto-Negotiation

1000BASE-X Auto-Negotiation is defined in Clause 37 of the IEEE802.3 specification. It is used to auto-negotiate duplex and flow control over fiber cable. Registers 0, 4, 5, 6, and 15 are used to enable AN, advertise capabilities, determine link partner's capabilities, show AN status, and show the duplex mode of operation respectively.

- If HWCFG_MODE[3:0] = 0011 or 0111, Register 0_1.12 determines whether 1000BASE-X Auto-Negotiation is on or off.
- Register 4.5 and 4.6 control 1000BASE-X full-duplex and half-duplex advertisement, respectively. Bits 4.8:7 advertise flow control capabilities.
- Register 5.5 and 5.6 show link partner 1000BASE-X full-duplex/half-duplex capability.
- Register 15.14 and 15.15 show duplex status of the 88E1111 device.

If Auto-Media detect is enabled, Register 22.0 must be set to one to view the fiber auto-negotiation registers.

The 88E1111 device supports Next Page option for 1000BASE-X Auto-Negotiation when the GMII or RGMII interface are used. The 88E1111 device supports Next Pages per IEEE Clause 27 (fiber Auto-Negotiation) in the following modes:

• GMII to 1000BASE-X

MARVELL CONFIDENTIA

- GMII to Auto-Media detection
- RGMII to 1000BASE-X
- RGMII to Auto-Media detection

Register 7 of the fiber pages is used to transmit Next Pages, and register 8 of the fiber pages is used to store the received Next Pages. The Next Page exchange occurs with software intervention. The user must set the fiber bank (Page 1) Register 4.15 to enable fiber Next Page exchange. Each Next Page received in the registers should be read before a new Next Page to be transmitted is loaded in Register 7.



2.11.3 SGMII Auto-Negotiation

SGMII is a de facto standard designed by CISCO. SGMII uses 1000BASE-X coding to send data as well as Auto-Negotiation information between the PHY and the MAC. However, the contents of the SGMII Auto-Negotiation are different than the 1000BASE-X Auto-Negotiation. See the "CISCO SGMII Specification" and the "MAC Interfaces and Auto-Negotiation" application note for further details. For 1000BASE-X operation, registers 4 and 5 are updated.

The 88E1111 device supports SGMII interface with and without Auto-Negotiation. If SGMII mode is selected, Auto-Negotiation can be enabled or disabled by writing to Register 0_1.12 (fiber bank) followed by a soft reset. If SGMII Auto-Negotiation is disabled, (0_1.12 = 0) the MAC interface link, speed, and duplex status (determined by the copper side) cannot be conveyed to the MAC from the PHY. The user must program the MAC with this information in some other way (e.g., by reading PHY registers for link, speed, and duplex status). When SGMII Auto-Negotiation is disabled in GMII/RGMII to SGMII mode, the speed of operation is determined by Register 20.5:4.

2.11.4 GBIC Mode Auto-Negotiation

GBIC Auto-Negotiation is a Marvell® proprietary feature which translates 1000BASE-X Auto-Negotiation from the MAC side to and from 10/100/1000BASE-T Auto-Negotiation on the copper side. See Section 2.3.1.6 "Serial Interface (SERDES) to Copper Modes" on page 59 for details. If GBIC mode is selected, Auto-Negotiation can be enabled and disabled by writing to Register fiber Register 0_1.12 followed by a soft reset. The GBIC mode Auto-Negotiation can also be enabled/disabled by hardware configuration strap options.

2.11.5 Auto-Media Detect Auto-Negotiation

The 88E1111 device supports two separate media interfaces: fiber interface and copper interface. It can monitor both interfaces simultaneously and establish link with whatever media is connected. In this mode of operation, the 88E1111 device simultaneously carries both 1000BASE-X and 10/100/1000BASE-T Auto-Negotiation in its two media interfaces. The first media to complete Auto-Negotiation and link up will be enabled and the other media will be powered down to save power.

Auto-Negotiation registers 4 and 5 have dual functionality. If the media of operation is copper, then they represent the 10/100/1000BASE-T Auto-Negotiation advertised capabilities and link partner's capabilities respectively. If the media of operation is fiber, they contain the 1000BASE-X Auto-Negotiation information. When Auto-Media detect is enabled, either register set can be read or written to by selecting Register 22.7:0.

2.11.6 Serial Interface Auto-Negotiation Bypass Mode

The IEEE standard Auto-Negotiation state machine, per the 802.3X Clause 37 1000BASE-X, requires that both link partners support Auto-Negotiation before link is established. If one link partner implements the Auto-Negotiation function and the other does not, two-way communication is not possible unless Auto-Negotiation is manually disabled and both sides are configured to work in the same operational modes. To solve this problem, the 88E1111 device implements the Serial Interface Auto-Negotiation Bypass Mode. The functional details of the Serial Interface Auto-Negotiation Bypass Mode for GMII/RGMII, SGMII, and GBIC modes are described in Table 37: "Serial Interface Auto-Negotiation in GMII/RGMII, SGMII, and GBIC modes" on page 87. Registers 0.12 and 27.12 must be set to 1 for the Serial Interface Auto Negotiation Bypass Mode to operate.



Note

For the GMII/RGMII and GBIC modes, Register 27.12 = 1 by default, indicating the 88E1111 device automatically enters Serial Interface Auto Negotiation Bypass Mode by default and bypasses Auto-Negotiation after 200 ms if Serial Interface Auto-Negotiation is unsuccessful.

Doc. No. MV-S100649-00, Rev. G

MARVELL CONFIDENTIA

Serial Interface Auto-Negotiation in GMII/RGMII, SGMII, and GBIC modes Table 37:

Mode	HWCFG_ MODE[3:0]	Reg. 27.12 Default Value at H/W Reset	Reg. 27.11 Status	Bypass Timer	Action Taken if Link Up due to bypass
GMII/ RGMII	0111 = GMII to fiber 0011 = RGMII to fiber		If Serial Interface- Aneg Enabled (0_1.12 = 1) and serial interface link is up (17.10 = 1) and: 27.11 = 1 - Link up due to bypass 27.11 = 0 - Link up due to standard Auto-Negotiation	200 ms	Full-duplex and pause bits are set to Register 4 advertised values.
SGMII	0000 = SGMII to copper with clock 0100 = SGMII to copper without clock	0	If Serial Interface- Aneg Enabled (0_1.12) and serial interface link is up (17.10 = 1) and: 27.11 = 1 - Link up due to bypass 27.11 = 0 - Link up due to standard Auto-Negotiation	200 ms	Copper Auto-Negotiation restarted with: Full-duplex =1 Half-duplex = 1 Pause = 00 Speed = 1000 Mbps only
GBIC	1000	1	N/A	200 ms (timer starts after cop- per link is up)	Copper Auto-Negotiation NOT restarted and the pause value is the copper Auto-Negotiation resolution value.

The Serial Interface Auto-Negotiation discussion herein applies to the fiber side when in GMII/RGMII to fiber mode (Register 0 1.12=1), and to the MAC or serial interface side in the SGMII to copper (Register 0 1.12 =1) or in the GBIC mode (Register 0_1.12 =1). When entering the state "Ability_Detect", a bypass timer begins to count down from an initial value of approximately 200 ms. If the 88E1111 device receives idles during the 200 ms, the 88E1111 device will interpret that the other side is "alive" but cannot send configuration codes to perform Auto-Negotiation. After 200 ms, the state machine will move to a new state called "Bypass_Link_Up" in which the 88E1111 device assumes a link-up status and the operational mode is set to the value listed under the "Action Taken if Link Up due to bypass" column of Table 37. The Serial Interface Auto-Negotiation Bypass Mode is performed if the ability_match is not asserted for the bypass timer duration. In the case where the Serial Interface Auto-Negotiation Bypass is performed, the 88E1111 device will report the bypass status via Register 27.11 together with Register 17 1.10 stating link change. Register 27.11 and 17 1.10 indicate whether the link was resumed due to standard Auto-Negotiation or bypass.

February 10, 2006, Preliminary



2.12 Fiber/Copper Auto-Selection

The 88E1111 device has a patented feature to automatically detect and switch between fiber and copper cable connections. The 88E1111 device monitors the signals of the serial interface lines and the MDI lines. If a fiber optic cable is plugged in, the 88E1111 device will adjust itself to be in fiber mode. If an RJ-45 cable is plugged in, the 88E1111 device will adjust itself to be in copper mode. If both cables are connected then the first media to establish link will be enabled. The media which is not enabled will turn off to save power. If the link on the first media is lost, then the inactive media will be powered up, and both media will once again start searching for link.

Depending on the media selected, the internal Auto-Negotiation register bits will reflect the copper or fiber modes. In this case, registers 1, 4, 5, 6, 17, and 19 are affected. Register 27 and Register 22 are used for the control and status of Fiber/Copper Auto-Selection. Refer to Table 98, "Extended PHY Specific Status Register," on page 179 for details.

Fiber/Copper Auto-Selection can be enabled by either hardware configuration strap options or by register writes. For configuration strap options see Section 2.4 "Hardware Configuration" on page 63. The configuration strap option for enabling/disabling this feature can be overwritten by writing the desired bit value to Register 27.15 followed by a software reset. Once a media is selected, register access is automatically updated to that media's registers. To disable this, set Register 27.9 = 1.

Fiber/Copper Auto-Selection requires that the configuration strap option for the MAC/media interface should be set for copper. For example, if the MAC interface is GMII, then GMII to copper mode of operation should be strapped. This can be done by setting the HWFG_MODE [3:0] = 1111. Similarly, for modes other than the GMII, the media selection should be strapped to copper. If it is required to change the mode of operation to GMII to fiber, then the Fiber/Copper Auto-Selection should be disabled by writing to Register 27.15=1. Selection of fiber or copper can be performed through software by using Register 27.3:0.

If Fiber/Copper Auto-Selection is selected, then the ANEG [3:0] strap option bits select not only the Auto-Negotiation options for the copper 10/100/1000BASE-T Auto-Negotiation, but they also affect the Fiber 1000BASE-X Auto-Negotiation.

ANEG [3:2] has to be equal to 11 to allow Fiber Auto-Negotiation to operate; however, this will also specify 10/ 100BASE-T capabilities for the copper side Auto-Negotiation. To not advertise 10/100BASE-T capabilities, re-program Register 4 page 0.

Fiber-copper Auto-Selection described above is not available in "Energy Detect" sleep mode. See Page 74 for a description of Energy Detect sleep mode.

When doing MAC interface loopback testing, disable auto-selection by setting Register 27.15 = 1. Loopback is enabled by setting Register 0.14 = 1.

Doc. No. MV-S100649-00, Rev. G

MARVELL CONFIDENTIA

2.12.1 Preferred Media for Fiber/Copper Auto-Selection

The 88E1111 device can be programmed to give one media priority over the other. In other words if the non-preferred media establishes link first and subsequently energy is detected on the preferred media, the PHY will drop link on the non-preferred media for 4 seconds and give the preferred media a chance to establish link. Register 26.11:10 selects the preferred media.

- 00 = Link with the first media to establish link
- 01 = Prefer fiber media
- 10 = Prefer copper media

The determination of when to switch from one media to another can also be managed under software instead of being done automatically. Register 26.11:10 can be set to 00 to not give any media any preference. The software then polls register 17_0.4 and 17_1.4 to see if energy is detected is detected on the copper or fiber media respectively. If link is already up for one media but the second media indicate energy is being detected via register 17_0.4 or 17_1.4 then the management software has the option of setting 26.11:10 to prefer the second media when it is ready. Once link is established on the second media register 26.11:10 can then be set back to 00.

Registers 19_0.4 and 19_1.4 are sticky bits that report when the energy detect on the copper or fiber media respectively has changed.

If there is a preference for one medium and it is selected, then the Energy Detect status for the other medium has no meaning. Hence, if the user wants to be able to monitor the Energy Detect status for the other medium, the preference bits in Register 26 should not be set.

Fiber media activity is determined by the Signal Detect pins (SD±). The user must program the 88E1111 device to use the external Signal Detect in Register 26.7.



2.13 Downshift Feature

88E1111

Without the downshift feature enabled, connecting between two Gigabit link partners requires a four-pair RJ-45 cable to establish 10, 100, or 1000 Mbps link. However, there are existing cables that have only two-pairs, which are used to connect 10 Mbps and 100 Mbps Ethernet PHYs. With the availability of only pairs 1, 2 and 3,6, Gigabit link partners can Auto-Negotiate to 1000 Mbps, but fail to link. The Gigabit PHY will repeatedly go through the Auto-Negotiation but fail 1000 Mbps link and never try to link at 10 Mbps or 100 Mbps.

With the Marvell® downshift feature enabled, the 88E1111 device is able to Auto-Negotiate with another Gigabit link partner using cable pairs 1,2 and 3,6 to downshift and link at 10 Mbps or 100 Mbps, whichever is the next highest advertised speed common between the two Gigabit PHYs.

In the case of a three pair cable (additional pair 4,5 or 7,8 - but not both) the same downshift function for two-pair cables applies.

By default, the downshift feature is turned off. Refer to Register 20.11:8 which describe how to enable this feature and how to control the downshift algorithm parameters.

To enable the downshift feature, the following registers must be set:

- Register 20.8 = 1 enables downshift
- Register 20.11:9 sets the number of link attempts before downshifting

MARVELL CONFIDENTIA

2.14 Loopback Modes

2.14.1 MAC Interface Loopback


The functionality, timing, and signal integrity of the MAC interface can be tested by placing the Alaska[®] Ultra device in MAC interface loopback mode. This can be accomplished by setting Register 0.14 = 1. In loopback mode, the data received from the MAC is not transmitted out on the media interface. Instead, the data is looped back and sent to the MAC. For copper media, during loopback, link will be lost and packets will not be received. When performing a Register 0.14 MAC Interface loopback during a mode that uses copper medium, the copper receiver will be powered down, link will not come up and any data received will not be transferred. Idles will be transmitted out the copper transmitter.

If while auto-negotiating and loopback is enabled, FLP Auto-Negotiation codes will be transmitted. If in forced 10BASE-T mode and loopback is enabled, 10BASE-T idle link pulses will be transmitted on the copper side. If in forced 100BASE-T mode and loopback is enabled, 100BASE-T idles will be transmitted on the copper side.

When performing a Register 0.14 loopback during a mode that uses the fiber medium, the fiber transceiver will be powered up and sync status will be up if valid code groups are received. Any data received from the MAC will not be transmitted on the cable. Idles will be transmitted out the fiber transmitter.

The following sections describe the loopback speed determination for GMII/MII mode to copper, RGMII to copper, and SGMII to copper.

Figure 28: MAC Interface Loopback Diagram



Fiber/Copper Interface

2.14.1.1 Loopback when Auto-Negotiation is Enabled

If Auto-Negotiation is enabled, and link is down, the speed is determined by Register 20.6:4. A software update is required to update Register 20.6:4. Loopback can then be enabled by setting Register 0.14 = 1. For example, when Auto-Negotiation is enabled, write:

Register 20.6:4 = '101' MAC interface speed is set to 100 Mbps

Register 0.15 = 1 Software reset. Need to update Register 20.6:4 setting.

Register 0.14 = 1 Enable loopback

Copyright © 2006 Marvell

February 10, 2006, Preliminary

MARVELL CONFIDENTIA



2.14.1.2 Loopback when Auto-Negotiation is Disabled

If in forced speed mode, (Auto-Negotiation is disabled), the speed is determined by setting Registers 0.6 and 0.13. A software update is required to update 0.6 and 0.13. Loopback can then be enabled by setting Register 0.14 = 1. For example, when Auto-Negotiation is disabled (MAC interface speed forced to 100 Mbps), write:

Register 0.13 = 1 MAC interface speed is set to 100 Mbps

Register 0.6 = 0

Register 0.15 = 1 Software reset. Need to update Registers 0.13 and 0.6 settings.

(e.g., Register 0 = 0xa100) Loopback bit setting 0x6100

Register 0.14 = 1 Enable loopback

88E1111

2.14.1.3 GBIC and SGMII Mode Loopback

For GBIC and SGMII modes, loopback may be performed as long as serial interface Auto-Negotiation is disabled.

For example, starting with a strap option of GBIC mode (HWCFG_MODE [3:0] = 1000) perform the following register writes.

22.7:0 = 0x01 Select fiber register banks of the PHY.

Register 0.12 = 0 and 0.15 = 1 Disable Fiber Auto-Negotiation and apply soft reset.

Register 0.14 = 1 Enable loopback

To return to normal operation, perform the following register writes.

Register 0.14 = 0 Disable loopback


Register 0.12 = 1 and 0.15 = 1 Enable SERDES (or SGMII) Auto-Negotiation and apply soft reset.

22.7:0 = 0x00 Select copper register banks of the PHY.

For media converter and GBIC/SFP applications, the serial interface is treated as a MAC interface for loopback purposes.

Figure 29: GBIC Loopback

MARVELL CONFIDENTIA




Doc. No. MV-S100649-00, Rev. G

2.14.2 Copper Line Loopback

Line loopback allows a link partner to send frames into the 88E1111 device to test the transmit and receive data path. Frames from a link partner into the PHY, before reaching the MAC interface pins, are looped back and sent out on the copper line. They are also sent to the MAC. The packets received from the MAC are ignored during copper line loopback. Refer to Figure 30. This allows the link partner to receive its own frames.

Figure 30: Line Loopback Data Path



Before enabling the line loopback feature, the PHY must first establish link to another PHY link partner. If Auto-Negotiation is enabled, both link partners should advertise the same speed and full-duplex. If Auto-Negotiation is disabled, both link partners need to be forced to the same speed and full-duplex. Once link is established, enable the line loopback mode by writing to Register 20.14.

20.14 = 1 (Enable line loopback)

MARVELL CONFIDENTIA

20.14 = 0 (Disables line loopback)

2.14.3 External 1000 Mbps Loopback

For production testing, an external loopback stub allows testing of the complete data path for 10/100/1000 Mbps modes. For 10/100 Mbps modes, the loopback test requires no register writes. For 1000 Mbps mode, a series of register writes will setup the PHY for external 1000 Mbps loopback. All modes require an external loopback stub. See the following sections and Figure 31 for details.


2.14.3.1 Loopback Stub

The loopback stub consists of a plastic RJ-45 header, connecting RJ-45 pair 1,2 to pair 3,6 and connecting pair 4,5 to pair 7,8, as seen in Figure 31.



Figure 31: Loopback Stub (Top View with Tab up)

88E1111



2.14.3.2 Enabling 1000 Mbps Stub Loopback

To enable the 1000 Mbps Stub Loopback mode, write to the following registers:

Register 18 = 0x0000 (disable all interrupts)

Register 9.12:11 = '11' (force Master, e.g. reg9: 0x1B00)

Register 0.15 = '1' (e.g. reg: 0x9140, to perform softreset)

Register 29 = 0x0007 (points to page 7 of Register 30)

Register 30.3 = '1' (e.g. reg 30: 0x0808)

Register 29 = 0x0010 (points to page 16 of Register 30)

Register 30.1 = '1' (e.g. reg30: 0x0042)

Register 29 = 0x0012 (points to page 18 of Register 30)

Register 30.0 = '1' (e.g. reg30: 0x8901)

2.14.3.3 Disabling 1000 Mbps Stub Loopback

To disable the Gigabit Stub Loopback mode, restore the default settings to the related registers above.



Note

Register 29 is a pointer to hidden registers.

Register 9.12:11 = Restore original values (e.g. reg9: 0x0300)

Register 0.15 = '1' (e.g. reg: 0x9140, to perform softreset)

Register 29 = 0x0007 (points to page 7 of Register 30)

Register 30.3 = '0' (e.g. reg 30: 0x0800)

Register 29 = 0x0010 (points page 16 of Register 30)

Register 30.1 = '0' (e.g. reg30: 0x0040)

Register 29 = 0x0012 (points to page 18 of Register 30)


Register 30.0 = '0' (e.g. reg30: 0x8900)

Register 18 = Restore desired interrupts

2.14.3.4 External Gigabit Loopback Test Setup

The external loopback test setup requires the presence of a MAC that will originate the frames to be sent out through the PHY. Instead of a normal RJ-45 cable, the loopback stubs allows the PHY to self-link at 1000 Mbps. It also allows the actual external loopback. See Figure 32. The MAC should see the same packets it sent, looped back to it.

Figure 32: Test Setup for 10/100/1000 Mbps Modes using an External Loopback Stub



MARVELL CONFIDENTIAL



2.15 Virtual Cable Tester™ (VCT™) Feature

The 88E1111 device Virtual Cable Tester™ feature uses Time Domain Reflectometry (TDR) to determine the quality of the cables, connectors, and terminations. Some of the possible problems that can be diagnosed include opens, shorts, cable impedance mismatch, bad connectors, termination mismatch, and bad magnetics.

The 88E1111 device transmits a signal of known amplitude (+1V) down each of the four pairs of an attached cable. It will conduct the cable diagnostic test on each pair, testing the MDI[0], MDI[1], MDI[2], and MDI[3] pairs sequentially. The transmitted signal will continue down the cable until it reflects off of a cable imperfection. The magnitude of the reflection and the time it takes for the reflection to come back are shown in register 28.12:8 and 28.7:0 respectively.

Using the information from register 28, the distance to the problem location and the type of problem can be determined. For example, the time it takes for the reflection to come back, can be converted to distance using table on register 28 (Table 98). The polarity and magnitude of the reflection together with the distance will indicate the type of discontinuity. For example, a +1V reflection will indicate an open close to the PHY and a -1V reflection will indicate a short close to the PHY.

Register 22 is used to select which MDI pair has its results shown in Register 28.

If the cable is properly terminated and there are no discontinuities, then there will be no reflections. If there are no reflections cable length can not be determined by TDR methods. Instead, if there is good link then DSP algorithms are used to determine cable length as indicated by register 17.9:7.

When the cable diagnostic feature is activated by setting Register 28.15=1, a pre-determined amount of time elapses before a test pulse is transmitted. This is to ensure that the link partner loses link, so that it stops sending 1000BASE-T or 100BASE-TX idles or 10 Mbit data packets. This is necessary to be able to perform the TDR test. The TDR test can be performed either when there is no link partner or when the link partner is Auto-Negotiating or sending 10 Mbit idle link pulses. If the 88E1111 device receives a continuous signal for 125 ms, it will declare test failure because it cannot start the TDR test. In the test fail case, the received data is not valid. The results of the test are also summarized in register bit 28.14:13.

- 11 = Test fail (The TDR test could not be run for reasons explained above)
- 00 = valid test, normal cable (no short or open in cable)
- 10 = valid test, open in cable (Impedance > 333 ohms)
- 01 = valid test, short in cable (Impedance < 33 ohms)</p>

The definition for shorts and opens is arbitrary and the user can define it in anyway they desire using the information in register 28. The impedance mismatch at the location of the discontinuity could also be calculated knowing the magnitude of the reflection. Refer to the App Note "Virtual Cable Tester -- How to use TDR results" for details.

When 1000BASE-T link is established, additional information about the cable can be established. Page 4 Register 28 summarizes the pair skew among the four pairs of cables.

Page 5 Register 28.3:0 report the polarity on each pair of cables, and bits 5:4 report which channel is connected to which pair of wires.

The contents on page 4 and page 5 Register 28 are only valid if Page 5 Register 28.6 is set to 1.

2.16 MDI/MDIX Crossover

The 88E1111 device automatically determines whether or not it needs to cross over between pairs as shown in Table 38 so that an external crossover cable is not required. If the 88E1111 device interoperates with a device that cannot automatically correct for crossover, the 88E1111 device makes the necessary adjustment prior to commencing Auto-Negotiation. If the 88E1111device interoperates with a device that implements MDI/MDIX crossover, a random algorithm as described in IEEE 802.3 clause 40.4.4 determines which device performs the crossover.

When the 88E1111 device interoperates with legacy 10BASE-T devices that do not implement Auto-Negotiation, the 88E1111 device follows the same algorithm as described above since link pulses are present. However, when interoperating with legacy 100BASE-TX devices that do not implement Auto-Negotiation (i.e. link pulses are not present), the 88E1111 device uses signal detect to determine whether or not to crossover.

The auto MDI/MDIX crossover function can be disabled via register 16.6:5.

The 88E1111 device is set to MDI mode by default. See ENA_XC in Hardware Configuration and register 16.6:5.

The pin mapping in MDI and MDIX modes is shown in Table 38.

Table 38: Media Dependent Interface Pin Mapping

Pin	MDI SON			MDIX		
	1000BASE-T	100BASE-TX	10BASE-T	1000BASE-T	100BASE-TX	10BASE-T
MDI[0]±	BI_DA±	TX±	TX±	BI_DB±	RX±	RX±
MDI[1]±	BI_DB±	RX±	RX±	BI_DA±	TX±	TX±
MDI[2]±	BI_DC±	unused	unused	BI_DD±	unused	unused
MDI[3]±	BI_DD±	unused	unused	BI_DC±	unused	unused



MARVELL CONFIDENTIA

Note

Table 47 assumes no crossover on PCB.

The MDI/MDIX status is indicated by Register 17.6. This bit indicates whether the receive pairs (3,6) and (1,2) are crossed over. In 1000BASE-T operation, the 88E1111 device can correct for crossover between pairs (4,5) and (7,8) as shown in the table above. However, this is not indicated by Register 17.6.

See Register 28 page 5 bits 5:4 for crossover status of all pairs.



2.17 Polarity Correction

The 88E1111 device automatically corrects polarity errors on the receive pairs in 1000BASE-T and 10BASE-T modes. In 100BASE-TX mode, the polarity does not matter.

In 1000BASE-T mode, receive polarity errors are automatically corrected based on the sequence of idle symbols. Once the descrambler is locked, the polarity is also locked on all pairs. The polarity becomes unlocked only when the receiver loses lock.

In 10BASE-T mode, polarity errors are corrected based on the detection of validly spaced link pulses. The detection begins during the MDI crossover detection phase and locks when the 10BASE-T link is up. The polarity becomes unlocked when link is down.

The polarity correction status is indicated by Register 17.1. This bit indicates whether the receive pair (3,6) is polarity reversed in MDI mode of operation. In MDIX mode of operation, the receive pair is (1,2) and Register 17.1 indicates whether this pair is polarity reversed. Although all pairs are corrected for receive polarity reversal, Register 17.1 only indicates polarity reversal on the pairs described above. See Register 28 page 5 bits 3:0 for polarity status on each of the four pairs.

2.18 Data Terminal Equipment (DTE) Detect

The 88E1111 device supports the Data Terminal Equipment (DTE) power function. The DTE power function is used to detect if a link partner requires power supplied by the 88E1111 device.

The DTE power function can be enabled by writing to Register 20.2, followed by a software reset. When DTE is enabled, the 88E1111 device will first monitor for any activity transmitted by the link partner. If the link partner is active, then the link partner has power and power from the 88E1111 device is not required. If there is no activity coming from the link partner, DTE power engages, and special pulses are sent to detect if the link partner requires DTE power. If the link partner has a low pass filter (or similar fixture) installed, the link partner will be detected as requiring DTE power.

The detection of the DTE power requirement can be reported to the 88E1111 device in two ways.

- The DTE power status register (Register 27.4) immediately comes up as soon as link partner is detected as a
 device requiring DTE power. The 88E1111 device will continually poll this register to detect if the link partner
 requires DTE power.
- If the DTE power status change interrupt is enabled (Register 18.2), an interrupt can be generated if a DTE powered device is detected. The 88E1111 device will then read the DTE power status changed (Register 19.2) and the DTE power status register (Register 27.4).

If a link partner that requires DTE power is unplugged, the DTE power status (Register 27.4) will drop after a user controlled delay (default is 20 seconds - Register 27.8:5) to avoid DTE power status register drop during the link partner powering up (for most applications), since the low pass filter (or similar fixture) is removed during power up. If DTE power status drop is desired to be reported immediately, write Register 27.8:5 to 4'b0000.

For further DTE Detect details, refer to the "DTE Detect Application Note".

A detailed description of the register bits used for DTE power detection for the 88E1111 device is shown in Table 39.

Table 39: Registers for DTE Power

MARVELL CONFIDENTIAL

	200
Register	Description
20.2 - Enable power over Ethernet detection	0 = Disable DTE detect 1 = Enable DTE detect A soft reset is required to enable this feature (0.15=1) HW reset: DIS_POWER bit of configuration SW reset: Update
27.4 - Power over Ethernet detection status	0 = Do not need power 1 = Need power HW reset: 0 SW reset: 0
18.2 - Power over Ethernet detection state changed interrupt enable	0 = Disable 1 = Enable HW reset: 0 SW reset: retain
19.2 Power over Ethernet detection state changed interrupt	0 = No change 1 = Changed HW reset: 0 SW reset: 0
27.8:5 DTE detect status drop	Once the PHY no longer detects that the link partner filter, the PHY will wait a period of time before clearing the power over Ethernet detection status bit (27.4). The wait time is 5 seconds multiplied by the value of these bits. Example: (5 * 0x4 = 20 seconds) Default at HW reset: 0x4 At SW reset: retain

Copyright © 2006 Marvell



2.19 Automatic and Manual Impedance Calibration

2.19.1 MAC Interface Calibration Circuit

88E1111

The auto calibration is available for the MAC interface I/Os. The PHY runs the automatic calibration circuit with a 30 ohm impedance target by default after hardware reset. Other impedance targets are available by changing the impedance target and restarting the auto calibration through register writes. Individual NMOS and PMOS output transistors could be controlled for 22 to 55 ohm targets in various increments.

Manual NMOS and PMOS settings are available if the automatic calibration is not desired. If the PCB traces are different from 50 ohms, the output impedance of the MAC interface I/O buffers can be programmed to match the trace impedance. Users can adjust the NMOS and PMOS driver output strengths to perfectly match the transmission line impedance and eliminate reflections completely.

2.19.2 MAC Interface Calibration Register Definitions

If Register 29 = 0x0003, then Register 30 is defined as follows:

Table 40: Register 30 Page 3 - MAC Interface Calibration Definitions

Reg bit	Function	Setting description	Mode	HW Reset	SW Reset
15	Restart Calibration	0 = Normal 1 = Restart Bit 15 is a self-clearing register. Calibration will start once the register is cleared.	R/W	0	Retain
140	Calibration Complete	0 = Calibration in progress 1 = Calibration complete	RO	0	Retain
13	Reserved	0	R/W	0	Retain
12:8	PMOS Value	00000 = All fingers off 11111 = All fingers on The automatic calibrated values are stored here after calibration completes. Once the LATCH bit is set to 1, the new calibration value is written. The automatic calibrated value is lost.	R/W	Auto cal- ibrated value	Retain
7	Reserved	0	R/W	0	Retain
6	Latch	1 = Latch in new value. This bit self clears. (Used for manual settings)	R/W, SC	0	Retain

Doc. No. MV-S100649-00, Rev. G

Table 40: Register 30 Page 3 - MAC Interface Calibration Definitions

Reg bit	Function	Setting description	Mode	HW Reset	SW Reset
5	PMOS/NMOS select	0 = NMOS value is written when LATCH is set to 1	R/W	0	Retain
		1 = PMOS value is written when LATCH is set to 1			
4:0	NMOS Value	00000 = All fingers off	R/W	Auto cal-	Retain
		11111 = All fingers on		ibrated value	
		The automatic calibrated values are stored here after calibration completes.		value	
	.* 2.0	Once the LATCH bit is set to 1, the new calibration value is written. The automatic calibrated value is lost.			

2.19.3 Changing Auto Calibration Targets

The PHY runs the automatic calibration circuit with a 30 ohm impedance target by default after hardware reset. Other impedance targets are available by changing the impedance target and restarting the auto calibration through register writes.

To change the auto calibration targets, write to the following registers:

Write to register 29 = 0x0012

Write to register 30, bit 11:9 = ppp (write new PMOS Target value)

Write to register 30, bit 8:6 = nnn (write new NMOS Target value)

Write to register 29 = 0x0003

Write to register 30 = 0x8000 (Restarts the auto calibration with the new target)

Example: To set the approximate 55 ohm auto calibration target, write the following:

Reg29 = 0x0012

Reg30, bit 11:9 = '000' and bit 18:6 = '000'

Reg29 = 0x0003

Reg30 = 0x8000



2.19.4 Manual Settings to The Calibration Registers

To use manual calibration, write to the following registers:

Write to register 29 = 0x0003

Write to register 30 = b'000P PPPP 011N NNNN -- adjusts PMOS strength

Write to register 30 = b'000P PPPP 010N NNNN -- adjusts NMOS strength

Where PPPPP is the 5 bit value for the PMOS strength.

Where NNNNN is the 5 bit value for the NMOS strength.

The value of PPPPP or NNNNN will depend on your board. The '11111' value enables all fingers for maximum drive strength, for minimum impedance. The '00000' value turns all fingers off for minimum drive strength, for maximum impedance. Use a scope to monitor the RX_CLK pin close to the destination. Start with the default auto-calibrated value and move in each direction to see how it affects signal integrity on your board.

Example: The automatic calibration has a 50 ohm target, but if the GMII trace impedance on board was 60 ohms, you see reflections from a scope capture taken at the destination. See Figure 35. After manual calibration, you see that the reflections are eliminated in Figure 36.

Figure 33 and Figure 34 display the trend lines for 1.8V, 2.5V, and 3.3V PMOS and NMOS impedance settings. **NOTE:** The trend lines displayed in Figure 33 and Figure 34 use nominal values and may vary in production.

Figure 33: PMOS Output Impedance (1.8V, 2.5V) Trend Lines





Figure 34: NMOS Output Impedance (1.8V, 2.5V) Trend Lines



88E1111

Example: The automatic calibration has a 50 ohm target, but if the GMII trace impedance on board was 60 ohms, you see reflections from a scope capture taken at the destination. Refer to Figure 35. After manual calibration, you see that the reflections are eliminated as in Figure 36.

Figure 35: Signal Reflections, using the 50 ohm Setting, 60 ohm line





Figure 36: Clean signal after manual calibration for the 60 ohm



2.20 Packet Generator

The 88E1111 device contains a very simple packet generator. When enabled the transmit data from the MAC is ignored. Link should be established first prior to enabling the packet generator. The generator will generate packets at the speed of the established link.

Once enabled, fixed length packet of 64 or 1518 byte frame (including CRC) will be transmitted continuously separated by 12 bytes of IPG. The preamble length will be 8 bytes. The payload of the frame is either a fixed 5A, A5, 5A, A5 pattern or a pseudo random pattern. A correct IEEE CRC is appended to the end of the frame. An error packet can also be generated.

The registers are as follows:

If Register 30 page 18:

Bit 5: 1 = Packet generation enable, 0 = disable

Bit 4: 0 = Random, 1 = 0x5a (packet pattern select)

Bit 3: 0 = 64 byte, 1 = 1518 byte (packet length select)

Bit 2: 1 = Generate error packet, 0 = no error

2.21 CRC Error Counter and Frame Counter

The CRC counter and frame counters, normally found in MACs, are available in the 88E1111 device. The error counter and frame counter features are enabled through register writes and each counter is stored in eight register bits.

2.21.1 Enabling The CRC Error Counter and Frame Counter

2.21.1.1 Enabling Counters

Write to the following registers will enable both counters.

Register 29: 0x0010 (points to page 16 of Register 30)

Register 30: 0x0001 (enables both CRC error and frame counter)

2.21.1.2 Disabling and Clearing Counters

Write to the following register will disable and clear both counters.

Register 29: 0x0010 (points to page 16 of Register 30)

Register 30: 0x0000 (disable and clear CRC error and frame counter)

2.21.1.3 Reading Counter Contents

To read the CRC counter and frame counter, write to the following registers.

Register 29: 0x000C (points to page 12 of Register 30)

Register 30: bits 15:8 (Frame count is stored in these bits), bits 7:0 (CRC error count is stored in these bits)

The counter does not clear on a read command. To clear the CRC error counter, disable and enable the counters. See Page 12 of Register 30 for details.

Copyright © 2006 Marvell



88E1111

2.21.1.4 Copper versus Fiber CRC Checking and Packet Counting

CRC error checking is done on the received packets and not on transmitted packets. Packet counting is done on the packets received from the media.

In GMII/RGMII to fiber modes, CRC checking will check for errors in packets received from the fiber media.

In media converter, GBIC and SFP applications, the CRC checking is done only on the packets received from the copper media.

In GMII/RGMII/TBI/SGMII to copper modes, the CRC checking is done on the packets received from the copper media.

2.22 LED Interface

The LED interface consists of 6 pins: LED_LINK10, LED_LINK100, LED_LINK1000, LED_DUPLEX, LED_RX, and LED_TX. The LEDs can either be controlled by the PHY or controlled manually, independent of the state of the PHY. Manual control is achieved by writing to Register 25. Any one of the LEDs can be controlled independently of the other LEDs (i.e. one LED can be externally controlled while another LED can be controlled by the state of the PHY).

2.22.1 Manual LED Control

Independent of the state of the PHY, any of the LEDs can be turned on, off, or made to blink at variable rates. This can be achieved by writing 11, 10, or 01 respectively to the register 25 bits [11:0], which control manual LED operation for each of the six LEDs. This eliminates the need for driving LEDs manually from the MAC or the CPU. If LEDs are driven from the CPU located at the back of the board, the LED lines crossing the entire board will pick up noise. This noise will cause EMI issues. Also, the PCB layout will be more difficult due to the additional lines routed across the board.

2.22.1.1 LED Connections

The LEDs can be used either in single LED mode, or bi-color LED mode.

Single LED connection is shown in Figure 37 below. The LED outputs are low active. The positive terminal of the LED should be pulled up to VDDO with a 300 ohm pull-up resistor. The negative terminal should be tied to the LED pin.

Figure 37: Single LED Connection

MARVELL CONFIDENTIA



The bi-color LED connection in shown in Figure 38. Any two LED output pins can be chosen to implement the desired bi-color functionality. The LED functionality of the individual LED pins is described in the following sections. The LED pins and modes should be chosen such that the combined functionality of the individual LEDs will give the desired bi-color LED behavior. For example, if it is desired to have the green LED to indicate 100 Mbps speed, while the amber LED indicates 1000 Mbps speed, the following connections should be made.


- LED LINK1000 tied to the negative terminal of the amber colored LED (LED x).
- LED LINK100 tied to the negative terminal of the green colored LED (LED y).

Copyright © 2006 Marvell



Figure 38: Bi-Color LED Connection

88E1111



2.22.2 LED Functionality

If the LEDs are controlled by the PHY, then the activity of the LEDs is determined by the state of the PHY. Each LED can be programmed to indicate various PHY states, with variable blink rate. There are four modes of link LED operation when the LEDs are controlled by the state of the PHY.

- Register 24.5:3 = 000 (Direct LED mode)
- Register 24.5:3 = 001, 010, 011, 100, 111 (Combined LED modes. There are three different combined LED modes as described below.)

2.22.2.1 Direct Drive Link LED Mode

When register 24.5:3 = '000', LED output is in direct drive LED mode.

Table 41: LED LINK Control for Register 24.5:3 = '000' (Default)

<i>20 60.</i> –	•	,
88E1111 Device Pins	LED Output Level	
LED_LINK10	Low = 10 Link Up High = 10 Link Down	4
LED_LINK100	Low = 100 Link Up High = 100 Link Down	No.
LED_LINK1000	Low = 1000 Link Up High = 1000 Link Down	Right,

MARVELL CONFIDENTIAL

2.22.2.2 Combined Link LED Modes

There are three combined link LED modes. When register 24.5:3 = '011', LED output is shown in Table 42.

Table 42: LED_Link Control Register 24.5:3 = 011

88E1111 Device Pins		Selected	Link Status	
LED_LINK1000	LED_LINK100	LED_LINK10	Speed	
High	High	High	Any Speed	Link down
High	High	Low	10 Mbps	Link up
High	Low	High	100 Mbps	Link up
Low	High	High	1000BASE-T (slave)	Link up
Low	High	Low	1000BASE-T (master)	Link up
Low	High	High	1000BASE-X	Link up

When register 24.5:3 = '001', LED output is shown in Table 43. In this mode, LED_LINK1000 pin is used as a global link indicator.

Table 43: LED_Link Control for Register 24.5:3 = '001'

88E1111 Device Pins				
LED_LINK1000	LED_LINK100	LED_LINK10	Selected Speed	Link Status
Low	Low	Low	1000 Mbps	Link up
Low	Low	High	100 Mbps	Link up
Low	High	Low	10 Mbps	Link up
High	High	High	Any speed	Link down

When register 24.5:3 = '010', LED output is shown in Table 44.

Table 44: LED_LINK Control for Register 24.5:3 = '010'

88E1111 Device Pins			6	
LED_LINK1000	LED_LINK100	LED_LINK10	Selected Speed	Link Status
Low	High	Low	1000 Mbps	Link up
High	Low	Low	100 Mbps	Link up
High	High	Low	10 Mbps	Link up
High	High	High	Any speed	Link Down



When register 24.5:3 = '100', LED output is shown in Table 45.

Table 45: LED_LINK Control for Register 24.5:3 = '100'

88E1111 Device Pins			(1)	
LED_LINK1000	LED_LINK100	LED_LINK10	Selected Speed	Link Status
Low	High	High	1000 Mbps Link AND not in GMII/RGMII to 1000BASE-X mode	Link up
High	Low	High	100 Mbps	Link up
High	High	Low	10 Mbps	Link up
High	High	High	Any speed	Link Down

When register 24.5:3 = '111', LED output is shown in Table 46.

Table 46: LED_LINK Control for Register 24.5:3 = '111'

88E1111 Device Pins			_	
LED_LINK1000	LED_LINK100	LED_LINK10	Selected Speed	Link Status
Low	Low	High	1000 Mbps Link (1000BASE-X)	Link
Low	High	Low	1000 Mbps Link (Master)	Link up
Low	High	High	1000 Mbps Link (Slave)	Link up
High	Low	High	100 Mbps	Link up
High	High	Low	10 Mbps	Link up
High	High	High	Any speed	Link Down

2.22.2.3 Duplex, RX, and TX LEDs

The LED outputs for the LED_DUPLEX, and LED_TX pins are programmed by setting the bits in the LED Control register. There are eight LED programming combinations available.

The tables below shows the LED Control register bit settings and the corresponding functionality of the LED_DUPLEX, and LED_TX LEDs.

Table 47: LED Output for LED_DUPLEX pins

Register 24.2	Register 24.7	LED_DUPLEX pin LED Indication
0	0	Low = Full-duplex High = Half-duplex Blink = Collision
1	0	Low = Full-duplex High = Half-duplex
0	1 * 1	Low = Fiber link up High = Fiber lin down
1	OV	Reserved

Table 48: LED outputs for LED_RX pins

Register 24.1	LED_RX pin LED Indication
0 111	Low = Link Up High = Link Down Blink = Receiving
-1	Low = Receiving High = Not Receiving

Table 49: LED outputs for LED TX pins

Register 24.6	Register 24.0	LED_TX pin LED Indication
0	0	Low = Transmitting High = Not Transmitting
0	1	Low = Link Up High = Link Down BLINK = Transmitting or Receiving
1	0	LOW = Transmitting or Receiving HIGH = Not Transmitting or Receiving
1	1	HIGH = Not Transmitting or Receiving BLINK = Transmitting or Receiving



2.22.2.4 LED Pulse Stretching and Blink Rate

88E1111

Some of the statuses can be pulse-stretched. Pulse stretching is necessary, because the duration of these status events may be too short to be observable on the LEDs. The pulse-stretch duration can be programmed via register 24.14:12. The default pulse-stretch duration is set to 170 to 340 ms. The pulse-stretch duration applies only to the applicable LEDs as described next.

Pulse stretching only applies to Duplex pin in Collision mode, or LED_RX and LED_TX pins (not applicable to Link, Speed, and Duplex signals).

Some of the statuses indicate multiple events by blinking LEDs. The blink period can be programmed via register 24.10:8. The default blink period is set to 84 ms. Blink rate only applies to Duplex pin in Collision mode, LED_RX and LED_TX pins (not applicable to Link, Speed, and Duplex signals). The Blink rate defines the frequency at which an LED blink

2.23 IEEE 1149.1 Controller

The IEEE 1149.1 standard defines a test access port and boundary-scan architecture for digital integrated circuits and for the digital portions of mixed analog/digital integrated circuits.

The standard provides a solution for testing assembled printed circuit boards and other products based on highly complex digital integrated circuits and high-density surface-mounting assembly techniques.

The 88E1111 device implements 5 basic instructions: bypass, sample/preload, extest, clamp, HIGH-Z, and ID CODE. Upon reset, ID_CODE instruction is selected. The instruction opcodes are shown in Table 50.

Table 50: TAP Controller Op Codes

Instruction	OpCode
EXTEST	00000000
SAMPLE/PRELOAD	0000001
CLAMP	00000010
HIGH-Z	00000011
BYPASS	11111111
ID CODE	00000100

The 88E1111 device reserves 5 pins called the Test Access Port (TAP) to provide test accessTest Mode Select Input (TMS), Test Clock Input (TCK), Test Data Input (TDI), and Test Data Output (TDO), and Test Reset Input (TRSTn). To ensure race-free operation all input and output data is synchronous to the test clock (TCK). TAP input signals (TMS and TDI) are clocked into the test logic on the rising edge of TCK, while output signal (TDO) is clocked on the falling edge. For additional details refer to the IEEE 1149.1 Boundary Scan Architecture document.

2.23.1 Bypass Instruction

MARVELL CONFIDENTIA

The bypass instruction uses the bypass register. The bypass register contains a single shift-register stage and is used to provide a minimum length serial path between the TDI and TDO pins of the 88E1111 device. This allows rapid movement of test data to and from other testable devices in the system.

2.23.2 Sample/Preload Instruction

The sample/preload instruction allows scanning of the boundary-scan register without causing interference to the normal operation of the 88E1111 device. Two functions are performed when this instruction is selected: sample and preload.

Sample allows a snapshot to be taken of the data flowing from the system pins to the on-chip test logic or vice versa, without interfering with normal operation. The snapshot is taken on the rising edge of TCK in the *Capture-DR* controller state, and the data can be viewed by shifting through the component's TDO output.

While sampling and shifting data out through TDO for observation, preload allows an initial data pattern to be shifted in through TDI and to be placed at the latched parallel output of the boundary-scan register cells that are connected to system output pins. This ensures that known data is driven through the system output pins upon entering the extest instruction. Without preload, indeterminate data would be driven until the first scan sequence is complete. The shifting of data for the sample and preload phases can occur simultaneously. While data capture is being shifted out, the preload data can be shifted in.

Copyright © 2006 Marvell



2.24 88E1111 Device Boundary Scan Chain Order

Table 51: Boundary Scan Chain Order

One scan chain is available for the 88E1111 device.

Pin	1/0
RESETn	Input
125CLK	Output
CONFIG[6]	Input
CONFIG[5]	Input 40,4
COMA	Input
TXD7	Input
TXD6	Input
TXD5	Input
TXD4	Input
TXD3	Input
TXD2	Input
TXD1	Input
TXD0	Input
TX_EN	Input
GTX_CLK	Input
TX_ER	Input
TX_CLK	Output
CRS	Output
COL_IN	Input
COL_OUT	Output
COL_OEN	Output enable for COL
RX_ER	Output
RX_CLK	Output
RX_DV	Output *
RXD0	Output
RXD1	Output
RXD2	Output
RXD3	Output
RXD4	Output
RXD5	Output
RXD6	Output
RXD7	Output

Doc. No. MV-S100649-00, Rev. G

Table 51: Boundary Scan Chain Order

One scan chain is available for the 88E1111 device.

Pin	1/0
G_OEN	Output enable for TX_CLK, CRS, COL, RX_ER, RX_DV, RXD[7:0], RX_CLK
MDC	Input
MDIO	Input
MDIO	Output
MDIO_EN	Output enable for MDIO
INTn	Output
INTn_EN	Output enable for INTn
LED_LINK10	Output
LED_LINK100	Output
LED_LINK1000	Output
LED_DUPLEX	Output
LED_RX	Output
LED_TX	Output
LED_OEN	Output enable for LED
CONFIG[0]	Input
CONFIG[1]	Input
CONFIG[2]	Input
CONFIG[3]	Input
CONFIG[4]	Input



2.24.1 Extest Instruction

88E1111

The extest instruction allows circuitry external to the 88E1111 device (typically the board interconnections) to be tested. Prior to executing the extest instruction, the first test stimulus to be applied is shifted into the boundaryscan registers using the sample/preload instruction. Thus, when the change to the extest instruction takes place, known data is driven immediately from the 88E1111 device to its external connections.

2.24.2 The Clamp Instruction

The clamp instruction allows the state of the signals driven from component pins to be determined from the boundary-scan register while the bypass register is selected as the serial path between TDI and TDO. The signals driven from the component pins will not change while the clamp instruction is selected.

2.24.3 The HIGH-Z Instruction

The HIGH-Z instruction places the component in a state in which all of its system logic outputs are placed in an inactive drive state (e.g., high impedance). In this state, an in-circuit test system may drive signals onto the connections normally driven by a component output without incurring the risk of damage to the component.

2.24.4 ID CODE Instruction

The ID CODE contains the manufacturer identity, part and version.

Table 52: ID CODE

Version	Part Number	Manufacturer Identity	10,0h
Bit 31 to 28	Bit 27 to 12	Bit 11 to 1	0 .0 .0
0000	0000 0000 0000 0000	001 1110 1001	1

Section 3. Register Description

The IEEE defines only 32 registers address space for the PHY. In order to extend the number of registers address space available a paging mechanism is used. For register address 0 to 21, and 23 to 28 register 22 bits 7 to 0 are used to specify the page. For registers 30 and 31 register 29 bits 5:0 are used to specify the page. There is no paging for registers 22 and 29.

In this document, the short hand used to specify the registers take the form register_page.bit:bit, register_page.bit, register_bit:bit, or register.bit.

For example:

MARVELL CONFIDENTIAL

Register 0 page 1 bits 5 to 2 is specified as 0_1.5:2.

Register 0 page 1 bits 5 is specified as 0_1.5.

Register 2 bit 3 to 0 is specified as 2.3:0.

Note that In this context the setting of the page register (register 22) has no effect.

Register 2 bit 3 is specified as 2.3.

Note that in order for the paging mechanism to work correctly register 22.15 must be set to 0 to disable the automatic medium register selection.

Figure 39: Register Map Summary

		Page Address								
		Page 0 (Copper)	Page 1 (Fiber)							
	0	Control Register	Control Register							
	1	Status Register	Status Register							
	2	PHY Identifier								
	3	PHY Identifier								
	4	Auto-Neg Advertisement Register	Auto-Neg Advertisement Register							
	5	Link Partner Ability Register	Link Partner Ability Register							
	6	Auto-Neg Expansion Register	Auto-Neg Expansion Register							
	7	Next Page Transmit Register	Next Page Transmit Register							
	8	Link Partner Next Page Register	Link Partner Next Page Register							
	9	1000BASE-T C	Control Register							
	10	1000BASE-T S	Status Register							
	11	Reserved Reg	ister							
	12	Reserved Register								
"	13	Reserved Register								
res	14	Reserved Register								
Register Address	15	Extended Sta	atus Register							
er /	16	PHY Specific Control Register								
gist	17	PHY Specific Status Register	PHY Specific Status Register							
Re	18	Interrupt Enable Register	Interrupt Enable Register							
	19	Interrupt Status Register	Interrupt Status Register							
	20	Extended PHY Spec	cific Control Register							
	21	Receive Error C	Counter Register							
	22	Extended Add	dress Register							
	23	Global Stat	us Register							
	24	LED Contr	ol Register							
	25	Manual LED Ov	verride Register							
	26	Extended PHY Speci	fic Control 2 Register							
	27	Extended PHY Spec	· ·							
	28	MDI[0:3] Virtual Cable Tester™ Status (Page 4); 100BASE-T Pair, 1000BAS	s (Pages 0-3); 1000BASE-T Pair Skew SE-T Pair Swap and Polarity (Page 5)							
	29	Extended								
	30		gabit (Page7); Class A (Page 11); CRC ble Control (Page 16); Miscellaneous Page 18)							
	31	Reserved Reg								

Doc. No. MV-S100649-00, Rev. G

Table 53: Register Map

Table 53: Register Map	0,0	
Register Name	Register Address	Table and Page
Control Register - Copper	Page 0, Register 0	Table 54, p. 121
Control Register - Fiber	Page 1, Register 0	Table 55, p. 126
Status Register - Copper	Page 0, Register 1	Table 56, p. 129
Status Register - Fiber	Page 1, Register 1	Table 57, p. 132
PHY Identifier	Page Any, Register 2	Table 58, p. 133
PHY Identifier	Page Any, Register 3	Table 59, p. 134
Auto-Negotiation Advertisement Register - Copper	Page 0, Register 4	Table 60, p. 135
Auto-Negotiation Advertisement Register - Fiber (GMII/RGMII Mode)	Page 1, Register 4	Table 61, p. 141
Auto-Negotiation Advertisement Register - (SGMII to Copper Modes) (Mode = 0x00)	Page 1, Register 4	Table 62, p. 143
Auto-Negotiation Advertisement Register - Fiber (SGMII to R-GMII Modes) (Mode = x110)	Page 1, Register 4	Table 63, p. 143
Auto-Negotiation Advertisement Register - Fiber (GBIC Mode) (Mode = 1000)	Page 1, Register 4	Table 64, p. 144
Link Partner Ability Register - Base Page, Copper	Page 0, Register 5	Table 65, p. 145
Link Partner Ability Register - Base Page, Fiber (RGMII or GMII Modes)	Page 1, Register 5	Table 66, p. 147
Link Partner Ability Register - Base Page, Fiber (SGMII to Copper Modes) (Mode = 0x00)	Page 1, Register 5	Table 67, p. 148
Link Partner Ability Register - Base Page, Fiber (SGMII to R-GMII Modes) (Mode = x110)	Page 1, Register 5	Table 68, p. 148
Link Partner Ability Register - Base Page, Fiber (GBIC Mode) (Mode = 1000)	Page 1, Register 5	Table 69, p. 149
Auto-Negotiation Expansion Register - Copper	Page 0, Register 6	Table 70, p. 150
Auto-Negotiation Expansion Register - Fiber	Page 1, Register 6	Table 71, p. 151
Next Page Transmit Register - Copper	Page 0, Register 7	Table 72, p. 152
Next Page Transmit Register - Fiber	Page 1, Register 7	Table 73, p. 152
Link Partner Next Page Register - Copper	Page 0, Register 8	Table 74, p. 153
Link Partner Next Page Register - Fiber	Page 1, Register 8	Table 75, p. 153
1000BASE-T Control Register	Page 0, Register 9	Table 76, p. 154
1000BASE-T Status Register	Page 0, Register 10	Table 77, p. 156
Reserved Registers	Page Any, Register 11	Table 78, p. 157



88E1111 Integrated 10/100/1000 Ultra Gigabit Ethernet Transceiver

Table 53: Register Map

Register Name	Register Address	Table and Page
Reserved Registers	Page Any, Register 12	Table 79, p. 157
Reserved Registers	Page Any, Register 13	Table 80, p. 157
Reserved Registers	Page Any, Register 14	Table 81, p. 157
Extended Status Register	Page Any, Register 15	Table 82, p. 158
PHY Specific Control Register	Page Any, Register 16	Table 83, p. 159
PHY Specific Status Register - Copper	Page 0, Register 17	Table 84, p. 161
PHY Specific Status Register - Fiber	Page 1, Register 17	Table 85, p. 163
Interrupt Enable Register	Page 0, Register 18	Table 86, p. 164
Interrupt Enable Register - Fiber	Page 1, Register 18	Table 87, p. 166
Interrupt Status Register	Page 0, Register 19	Table 88, p. 167
Interrupt Status Register	Page 1, Register 19	Table 89, p. 168
Extended PHY Specific Control Register	Page Any, Register 20	Table 90, p. 169
Receive Error Counter Register	Page Any, Register 21	Table 91, p. 171
Extended Address	Page Any, Register 22	Table 92, p. 172
Global Status Register	Page Any, Register 23	Table 94, p. 174
LED Control Register	Page Any, Register 24	Table 95, p. 174
Manual LED Override Register	Page Any, Register 25	Table 96, p. 175
Extended PHY Specific Control 2 Register	Page Any, Register 26	Table 97, p. 176
Extended PHY Specific Status Register	Page Any, Register 27	Table 98, p. 179
MDI[0] Virtual Cable Tester™ Status Register, Page 0	Page 0, Register 28	Table 99, p. 180
MDI[1] Virtual Cable Tester™ Status Register, Page 1	Page 1, Register 28	Table 100, p. 181
MDI[2] Virtual Cable Tester™ Status Register, Page 2	Page 2, Register 28	Table 101, p. 182
MDI[3] Virtual Cable Tester™ Status Register, Page 3	Page 3, Register 28	Table 102, p. 182
1000 BASE-T Pair Skew Register, Page 4	Page 4, Register 28	Table 103, p. 183
1000 BASE-T Pair Swap and Polarity, Page 5	Page 5, Register 28	Table 104, p. 184
Extended Address	Page Any, Register 29	Table 105, p. 185
Extended Registers	Pages 3, 7, 11, 12, 16, and 18 of Register 30	Table 109, p. 187
Reserved Registers	Page Any, Register 31	Table 112, p. 188

Doc. No. MV-S100649-00, Rev. G

Table 54: Control Register - Copper Page 0, Register 0

rage 0, Register 0			r	<u> </u>	N. 96"
Bits	Field	Mode	HW Rst	SW Rst	Description
15	Reset	R/W, SC	0x0	SC	PHY Software Reset. Writing a 1 to this bit causes the PHY state machines to be reset. When the reset operation is done, this bit is cleared to 0 automatically. The reset occurs immediately. This bit is identical to 0_1.15. 1 = PHY reset 0 = Normal operation
14	Loopback	R/W	0x0	0x0	When loopback is activated, the transmitter data presented on TXD is looped back to RXD internally. Link is broken when loopback is enabled. Loopback speed is determined by the mode the device is in Registers 20.6:4. In TBI Mode, this bit is set when the COL pin samples a rising edge after the RESET pin is deasserted. It is reset when the COL pin samples a falling edge. In all Copper modes, the loopback speed is determined by Register 20[6:4] if copper Auto-Negotiation is enabled. If copper Auto-Negotiation is disabled, the loopback speed is determined by speed set in register 0.6 and 0.13 In GMII or RGMII to Fiber Modes the loopback speed is set to 1000 Mbps. In SGMII to GMII or RGMII Modes, the loopback speed is set to SGMII Link partner advertised speed (which is the SGMII Link partners Copper Link speed) if fiber Auto-Negotiation is enabled.' If fiber Auto-Negotiation is disabled, the loopback speed is set from register 20 bits [6:4] Register bit 0.15 must be cleared to 0 before enabling loopback. This bit is identical to 0_1.14. 1 = Enable Loopback 0 = Disable Loopback



Table 54: Control Register - Copper (Continued)
Page 0, Register 0

Bits	Field	Mode	HW Rst	SW Rst	Description
13	Speed Select (LSB)	R/W	See Descr	Update	Changes to this bit are disruptive to the normal operation; therefore, any changes to these registers must be followed by a software reset to take effect. A write to this register bit does not take effect until any one of the following also occurs: Software reset is asserted (Register 0.15) Power down (Register 0.11) transitions from power down to normal operation. Upon hardware reset this bit defaults as follows: ANEG[3:0] HWCFG_MODE[3:0] Bit 0_0.13 001x 0x00 1 001x 1x11 1 001x 1x10 1 001x 0110 1 all other configurations 0 A write to this register bit will have no effect if MODE[3:0] (either HWCF_MODE or Reg27[3:0] after a software reset) is one of the following: 1x0x, 01x1, 001x In these modes the bit will always be 0. Bit 6, 13 11 = Reserved 10 = 1000 Mbps 01 = 100 Mbps

Control Register - Copper (Continued) Table 54: Page 0, Register 0

	Page U, Register U				
Bits	Field	Mode	HW Rst	SW Rst	Description
12	Auto-Negotia- tion Enable	R/W	See Descr	Update	Changes to this bit are disruptive to the normal operation; therefore, any changes to these registers must be followed by a software reset to take effect. A write to this register bit does not take effect until any one of the following occurs: Software reset is asserted (Register 0.15) Power down (Register 0.11) transitions from power down to normal operation.
	Ş	* PTO	95		When Auto-Negotiation is enabled (0.12 = 1), the speed, duplex, and pause capabilities are advertised in Register 4 and Register 9. If the Auto-Negotiation is disabled (0.12 = 0), then the speed and duplex capabilities take on the settings of register bits 0.13, 0.6, and 0.8.
OS AL	STONE				If Register 0_0.12 is set to 0 and speed is manually forced to 1000 Mbps in Registers 0_0.13 and 0_0.6, then Auto-Negotiation will still be enabled and only 1000BASE-T full-duplex is advertised if register 0_0.8 is set to 1, and 1000BASE-T half-duplex is advertised if 0_0.8 is set to 0. Registers 4_0.8:5 and 9_0.9:8 are ignored. Auto-Negotiation is mandatory per IEEE for proper operation in 1000BASE-T. Upon hardware reset this bit defaults as follows: ANEG[3:2] Bit 0.12 11 all other configurations 0
					1 = Enable Auto-Negotiation Process 0 = Disable Auto-Negotiation Process
11	Power Down	R/W	See Descr	0x0	When the port is switched from power down to normal operation, software reset and restart Auto-Negotiation are performed even when bits Reset (0.15) and Restart Auto-Negotiation (0_0.9) are not set by the user. IEEE power down shuts down the chip except for the MAC interface if 16.3 is set to 1. If 16.3 is set to 0, then the MAC interface also shuts down. Power down also has no effect on the 125CLK output if 16.4 is set to 0. This bit is identical to 1_0.11. 1 = Power down 0 = Normal operation
10	Isolate	R/W	0x0	0x0	The GMII/MII/TBI output pins are tristated when this bit is set to 1. The GMII/MII/TBI inputs are ignored. This bit is identical to 0_1.10. 1 = Isolate 0 = Normal operation



Table 54: Control Register - Copper (Continued)
Page 0, Register 0

					0.0		
Bits	Field	Mode	HW Rst	SW Rst	Description		
9	Restart Copper Auto-Negotia- tion	R/W, SC	0x0	SC	Auto-Negotiation automatically restarts after hardware or software reset regardless of whether or not the restart bit (0_0.9) is set. Restart Auto-Negotiation bit should be used when the Auto-Neg bit (0.12) is enabled. 1 = Restart Auto-Negotiation Process 0 = Normal operation		
8	Copper Duplex Mode	R/W	See Descr	Update	Changes to this bit are disruptive to the normal operation; therefore, any changes to these registers must be followed by a software reset to take effect. A write to this register bit does not take effect until any one of the following also occurs: Software reset is asserted (Register 0.15) Power down (Register 0.11) transitions from power down to normal operation Upon hardware reset this bit defaults as follows: ANEG[3:0] Bit 0_0.8 00x1 1 xxx 1 all other configurations 0 1 = Full-duplex 0 = Half-duplex		
7 0	Collision Test	R/W	0x0	0x0	Setting this bit to 1 will cause the COL pin to assert whenever the TX_EN pin is asserted. This bit is identical to 0_1.7. 1 = Enable COL signal test 0 = Disable COL signal test		

Control Register - Copper (Continued) Table 54: Page 0, Register 0

Bits	Field	Mode	HW Rst	SW Rst	Description
6	Speed Selection (MSB)	R/W	See Descr	Update	Changes to this bit are disruptive to the normal operation; therefore, any changes to these registers must be followed by a software reset to take effect. A write to this register bit does not take effect until any one of the following occurs: Software reset is asserted (Register 0.15) Power down (Register 0.11) transitions from power down to normal operation Upon hardware reset this bit defaults as follows: ANEG[3:0] HWCFG_MODE[3:0] Bit 0_0.6 1xxx xxxx 1xxx 1 xxxx xxxx 1 xxxx xxxx 1 xxxx xxxx 1 xxxx xxxx 1 xxxx 001 1 xxxx 0011 1 xxxx 0011 1 xxxx 0010 1 all other configurations 0 bit 6, 13 11 = Reserved 10 = 1000 Mbps 01 = 100 Mbps 00 = 10 Mbps
5:0	Reserved				These bits must be read and left unchanged when performing a write.



Table 55: Control Register - Fiber Page 1, Register 0

	1		1		10. 30
Bits	Field	Mode	HW Rst	SW Rst	Description
15	Reset	R/W	0x0	SC	PHY Software Reset. Writing a 1 to this bit causes the PHY state machines to be reset. When the reset operation is done, this bit is cleared to 0 automatically. The reset occurs immediately. This bit is identical to 0_0.15. 1 = PHY reset 0 = Normal operation
14	Loopback	R/W	0x0	0x0	When loopback is activated, the transmitter data presented on TXD is looped back to RXD internally. Link is broken when loopback is enabled. Loopback speed is determined by the mode the device is in Registers 20.6:4. In all Copper modes, the loopback speed is determined by Register 20[6:4] if copper Auto-Negotiation is enabled. If copper Auto-Negotiation is disabled, the loopback speed is determined by speed set in register 0.6 and 0.13 In GMII or RGMII to Fiber Modes the loopback speed is set to 1000Mbps
15. C.					In SGMII to GMII or RGMII Modes, the loopback speed is set to SGMII Link partner advertised speed (which is the SGMII Link partners Copper Link speed) if fiber Auto-Negotiation is enabled. If fiber Auto-Negotiation is disabled, the loopback speed is set from register 20 bits [6:4] This bit is identical to 0_0.14. 1 = Enable Loopback 0 = Disable Loopback
13	Speed Select (LSB)	RO	Always 0	Always 0	bit 6,13 10 = 1000 Mbps

Table 55: Control Register - Fiber (Continued)
Page 1, Register 0

rage I, Register 0					
Bits	Field	Mode	HW Rst	SW Rst	Description
12	Auto-Negotia- tion Enable	R/W	See Descr	Update	Changes to this bit are disruptive to the normal operation; therefore, any changes to these registers must be followed by a software reset to take effect. A write to this register bit does not take effect until any one of the following occurs: Software reset is asserted (Register 0.15) Restart Auto-Negotiation is asserted (Register 0_1.9) Power down (Register 0.11) transitions from power down to normal operation Fiber link goes down. This bit enables Auto-Negotiation on the fiber interface in all configurations where the serdes is used. Upon hardware reset this bit defaults as follows: MODE [3:0] ANEG[3:2] Bit 0.12 x000 xx 1 x110 xx 1 0100 xx 1 all other configurations 0 When this bit gets set/reset, Auto-Negotiation is restarted (bit 1.0.9 is set to 1) 1 = Enable Auto-Negotiation Process 0 = Disable Auto-Negotiation Process
11	Power Down	R/W	See Descr	0x0	When the port is switched from power down to normal operation, software reset and restart Auto-Negotiation are performed even when bits Reset (0.15) and Restart Auto-Negotiation (0_1.9) are not set by the user. IEEE power down shuts down the chip except for the MAC interface if 16.3 is set to 1. If 16.3 is set to 0, then the MAC interface also shuts down. Power down also has no effect on the 125CLK output if 16.4 is set to 0. This bit is identical to 0_0.11. 1 = Power down 0 = Normal operation
10	Isolate	R/W	0x0	0x0	The GMII/MII output pins are tristated when this bit is set to 1. The GMII/MIII inputs are ignored. This bit is identical to 0_0.10. 1 = Isolate 0 = Normal operation
9	Restart Fiber Auto-Negotia- tion	R/W, SC	0x0	SC 6000	Auto-Negotiation automatically restarts after hardware or software reset regardless of whether or not the restart bit (0_1.9) is set. The bit is set when Auto-Negotiation is Enabled or Disabled in 1.0.12 1 = Restart Auto-Negotiation Process 0 = Normal operation



Table 55: Control Register - Fiber (Continued)
Page 1, Register 0

Bits	Field	Mode	HW Rst	SW Rst	Description
8	Fiber Duplex Mode	R/W	See Descr	Update	Changes to this bit are disruptive to the normal operation; therefore, any changes to these registers must be followed by a software reset to take effect. A write to this register bit does not take effect until any one of the following also occurs: Software reset is asserted (Register 0.15) Restart Auto-Negotiation is asserted (Register 0_1.9) Power down (Register 0.11) transitions from power down to normal operation Upon hardware reset this bit defaults as follows: ANEG[3:0] Bit 0_1.8 00x1 1 xxx 1 all other configurations 0 1 = Full-duplex 0 = Half-duplex
7	Collision Test	R/W	0x0	0x0	Setting this bit to 1 will cause the COL pin to assert whenever the TX_EN pin is asserted. This bit is identical to 0_0.7. 1 = Enable COL signal test 0 = Disable COL signal test
6	Speed Selection (MSB)	RO	Always 1	Always 1	bit 6, 13 10 = 1000 Mbps
5:0	Reserved				These bits must be read and left unchanged when performing a write.

Table 56: Status Register - Copper Page 0, Register 1

				- 30	<u> </u>		
Bits	Field	Mode	HW Rst	SW Rst	Description		
15	100BASE-T4	RO	Always 0	Always 0	100BASE-T4. This protocol is not available. 0 = PHY not able to perform 100BASE-T4		
14	100BASE-X Full-Duplex	RO	See Descr	See Descr	Upon hardware reset this bit defaults as follows: HWCFG_MODE[3:0] Bit 1.14 xx01 0 1x00 0 0x11 0 xx00 0 all other configurations 1 Upon software reset this bit defaults as follows: HWCFG_MODE[3:0] Bit 1.14 xx01 0 1x00 0 0x11 0 all other configurations 1 1 = PHY able to perform full-duplex 100BASE-X 0 = PHY not able to perform full-duplex 100BASE-X		
13	100BASE-X Half-Duplex	RO	See Descr	See Descr	Upon hardware reset this bit defaults as follows: HWCFG_MODE[3:0] Bit 1.13 xx01 0 1x00 0 0x11 0 xx00 0 all other configurations 1 Upon software reset this bit defaults as follows: HWCFG_MODE[3:0] Bit 1.13 xx01 0 1x00 0 0x11 0 all other configurations 1 1 = PHY able to perform half-duplex 100BASE-X 0 = PHY able to perform half-duplex 100BASE-X		



Table 56: Status Register - Copper (Continued)
Page 0, Register 1

F	- age o, regi				
Bits	Field	Mode	HW Rst	SW Rst	Description
12	10 Mbps Full- Duplex	RO	See Descr	See Descr	Upon hardware reset this bit defaults as follows: HWCFG_MODE[3:0] Bit 1.12 xx01 0 1x00 0 0x11 0 xx00 0 all other configurations 1 Upon software reset this bit defaults as follows: HWCFG_MODE[3:0] Bit 1.12 xx01 0 1x00 0 0x11 0 all other configurations 1 1 = PHY able to perform full-duplex 10BASE-T 0 = PHY not able to perform full-duplex 10BASE-T
11	10 Mbps Half- Duplex	RO	See Descr	See Descr	Upon hardware reset this bit defaults as follows: HWCFG_MODE[3:0] Bit 1.11 xx01 0 1x00 0 0x11 0 xx00 0 all other configurations 1 Upon software reset this bit defaults as follows: HWCFG_MODE[3:0] Bit 1.11 xx01 0 1x00 0 0x11 0 all other configurations 1 1 = PHY able to perform half-duplex 10BASE-T 0 = PHY not able to perform half-duplex 10BASE-T
10	100BASE-T2 Full-Duplex	RO	Always 0	Always 0	This protocol is not available. 0 = PHY not able to perform full-duplex
9	100BASE-T2 Half-Duplex	RO	Always 0	Always 0	This protocol is not available. 0 = PHY not able to perform half-duplex
8	Extended Status	RO	Always 1	Always 1	1 = Extended status information in Register 15
7	Reserved				This bit must be read and left unchanged when performing a write.
6	MF Preamble Suppression	RO	Always 1	Always 1	1 = PHY accepts management frames with preamble suppressed

Doc. No. MV-S100649-00, Rev. G

Table 56: Status Register - Copper (Continued)
Page 0, Register 1

Bits	Field	Mode	HW Rst	SW Rst	Description
5	Copper Auto- Negotiation Complete	RO	0x0	0x0	1 = Auto-Negotiation process complete 0 = Auto-Negotiation process not complete
4	Copper Remote Fault	RO,LH	0x0	0x0	Remote Fault bit is only supported in 1000BASE-T mode. 1 = Remote fault condition detected 0 = Remote fault condition not detected
3	Auto- Negotiation Ability	RO	Always 1	Always 1	1 = PHY able to perform Auto-Negotiation
2	Copper Link Status	RO,LL	0x0	0x0	This register bit indicates whether link was lost since the last read. For the current link status, either read this register back-to-back or read Register 17_0.10 Link Real Time. 1 = Link is up 0 = Link is down
1	Jabber Detect	RO,LH	0x0	0x0	1 = Jabber condition detected 0 = Jabber condition not detected
0	Extended Capability	RO	Always 1	Always 1	1 = Extended register capabilities



Table 57: Status Register - Fiber Page 1, Register 1

					W. 10
Bits	Field	Mode	HW Rst	SW Rst	Description
15	100BASE-T4	RO	Always 0	Always 0	100BASE-T4. This protocol is not available. 0 = PHY not able to perform 100BASE-T4
14	100BASE-X Full-Duplex	RO	Always 0	Always 0	0 = PHY not able to perform full-duplex 100BASE-X
13	100BASE-X Half-Duplex	RO	Always 0	Always 0	0 = PHY not able to perform full-duplex 100BASE-X
12	10 Mb/s Full Duplex	RO *	Always 0	Always 0	0 = PHY not able to perform full-duplex 10BASE-T
11	10 Mbps Half- Duplex	RO	Always 0	Always 0	0 = PHY not able to perform half-duplex 10BASE-T
10	100BASE-T2 Full-Duplex	RO	Always 0	Always 0	This protocol is not available. 0 = PHY not able to perform full-duplex
9	100BASE-T2 Half-Duplex	RO	Always 0	Always 0	This protocol is not available. 0 = PHY not able to perform half-duplex
8	Extended Sta- tus	RO	Always 1	Always 1	1 = Extended status information in Register 15
7	Reserved				This bit must be read and left unchanged when performing a write.
6	MF Preamble Suppression	RO	Always 1	Always 1	1 = PHY accepts management frames with preamble suppressed
5	Fiber Auto- Negotiation Complete	RO	0x0	0x0	1 = Auto-Negotiation process complete 0 = Auto-Negotiation process not complete Bit is not set when link is up due of Fiber Auto-Negotiation Bypass or if Auto-Negotiation is disabled.
4	Fiber Remote Fault	RO,LH	0x0	0x0	1 = Remote fault condition detected 0 = Remote fault condition not detected This bit is always 0 in SGMII to Copper and SGMII to GMII or RGMII Modes.
3	Auto- Negotiation Ability	RO	Always 1	Always 1	1 = PHY able to perform Auto-Negotiation

Table 57: Status Register - Fiber (Continued)
Page 1, Register 1

Bits	Field	Mode	HW Rst	SW Rst	Description
2	Fiber Link Status	RO,LL	0x0	0x0	This register bit indicates when link was lost since the last read. For the current link status, either read this register back-to-back or read Register 17_1.10 Link Real Time. 1 = Link is up 0 = Link is down
1	Reserved	~	ž O		This bit must be read and left unchanged when performing a write.
0	Extended Capability	RO	Always 1	Always 1	1 = Extended register capabilities

Table 58: PHY Identifier Page Any, Register 2

Bits	Field	Mode	HW Rst	SW Rst	Description
15:0	Organization- ally Unique Identifier Bits 3:18	RO	0x0141	0x0141	Marvell® OUI is 0x005043 0000 0000 0101 0000 0100 0011 ^



Table 59: PHY Identifier Page Any, Register 3

Bits	Field	Mode	HW Rst	SW K	Description
15:10	OUILSb	RO	Always 000011	0x00	Organizationally Unique Identifier bits 19:24 000011 ^ bit 19bit24
9:4	Model Number	RO	Always 001100	0x00	Model Number 88E1111 = 001100
3:0	Revision Number	RO *	See Descr	See Descr	Rev Number Contact Marvell [®] FAEs for information on the device revision number.

Table 60: Auto-Negotiation Advertisement Register - Copper Page 0, Register 4

		ı			- 13
Bits	Field	Mode	HW Rst	SW Rst	Description
15	Next Page	R/W	0x0	Retain	A write to this register bit does not take effect until any one of the following occurs: Software reset is asserted (Register 0.15) Restart Auto-Negotiation is asserted (Register 0_0.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down If 1000BASE-T is advertised then the required next pages are automatically transmitted. Register 4_0.15 should be set to 0 if no additional next pages are needed. If 4_0.15 is set to 1, then Register 7_0 should be programmed with the desired value and 7_0 will be sent when 7_0.15 = 1. In GBIC mode, a Write to this register is inconsequential. 1 = Advertise 0 = Not advertised
14	Ack	RO	Always 0	Always 0	Must be 0.
13	Remote Fault	R/W	0x0	Retain	A write to this register bit does not take effect until any one of the following occurs: Software reset is asserted (Register 0.15) Restart Auto-Negotiation is asserted (Register 0.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down In GBIC mode, a Write to this register is inconsequential. 1 = Set Remote Fault bit 0 = Do not set Remote Fault bit
12	Reserved	R/W	0x0	Retain	This bit must be read and left unchanged when performing a write.



Table 60: Auto-Negotiation Advertisement Register - Copper (Continued)
Page 0, Register 4

					-0'-13
Bits	Field	Mode	HW	sw	Description
			Rst	Rst	C, O _k
11	Asymmetric Pause	R/W	See Descr	Retain	A write to this register bit does not take effect until any one of the following occurs: Software reset is asserted (Register 0.15) Restart Auto-Negotiation is asserted (Register 0_0.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down In GBIC mode, a Write to this register is inconsequential. Upon hardware reset this bit defaults as follows: ENA_PAUSE Bit 4_0.11 0 0 1 1 1 = Asymmetric Pause 0 = No asymmetric Pause
10	Pause	R/W	See Descr	Retain	A write to this register bit does not take effect until any one of the following occurs: Software reset is asserted (Register 0.15) Restart Auto-Negotiation is asserted (Register 0_0.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down In GBIC mode, a Write to this register is inconsequential. Upon hardware reset, this bit defaults as follows: ENA_PAUSE Bit 4_0.10 0 1 1 = MAC PAUSE implemented 0 = MAC PAUSE not implemented
9	100BASE-T4	R/W	0x0	0x0	0 = Not capable of 100BASE-T4

Table 60: Auto-Negotiation Advertisement Register - Copper (Continued)
Page 0, Register 4

Bits	Field	Mode	HW Rst	SW Rst	Description
8	100BASE-TX Full-Duplex	R/W	See Descr	Retain	A write to this register bit does not take effect until any one of the following occurs: Software reset is asserted (Register 0.15) Restart Auto-Negotiation is asserted (Register 0_0.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down In GBIC mode, a Write to this register is inconsequential. If register 0_0.12 is set to 0 and speed is manually forced to 1000 Mbps in Registers 0_0.13 and 0_0.6, then Auto-Negotiation will still be enabled and only 1000BASE-T full-duplex is advertised if register 0_0.8 is set to 1, and 1000BASE-T half-duplex is advertised if 0_0.8 set to 0. Registers 4_0.8:5 and 9_0.9:8 are ignored. Auto-Negotiation is mandatory per IEEE for proper operation in 1000BASE-T. Upon hardware reset this bit defaults as follows: ANEG[3:0] HWCFG_MODE[3:0] Bit 4_0.8 0011 0x00 1 11xx 0x00 1 11xx 1x11 1 all other configurations 0 1 = Advertise 0 = Not advertised



Table 60: Auto-Negotiation Advertisement Register - Copper (Continued)
Page 0, Register 4

Bits	Field	Mode	HW Rst	SW Rst	Description
7	100BASE-TX Half-Duplex	R/W	See Descr	Retain	A write to this register bit does not take effect until any one of the following occurs: Software reset is asserted (Register 0.15) Restart Auto-Negotiation is asserted (Register 0_0.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down In GBIC mode, a Write to this register is inconsequential. If register 0_0.12 is set to 0 and speed is manually forced to 1000 Mbps in registers 0_0.13 and 0_0.6, then Auto-Negotiation will still be enabled and only 1000BASE-T full-duplex is advertised if Register 0_0.8 is set to 1, and 1000BASE-T half-duplex is advertised if 0_0.8 set to 0. Registers 4_0.8:5 and 9_0.9:8 are ignored. Auto-Negotiation is mandatory per IEEE for proper operation in 1000BASE-T. Upon hardware reset this bit defaults as follows: ANEG[3:0] HWCFG_MODE[3:0] Bit 4_0.7 0010 0x00 1 11xx 0x00 1 11xx 1x11 1 all other configurations 0 1 = Advertise 0 = Not advertised

Table 60: Auto-Negotiation Advertisement Register - Copper (Continued)
Page 0, Register 4

Bits	Field	Mode	HW Rst	SW Rst	Description
	10BASE-TX Full-Duplex	R/W	See Descr	Retain	A write to this register bit does not take effect until any one of the following occurs: Software reset is asserted (Register 0.15) Restart Auto-Negotiation is asserted (Register 0_0.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down In GBIC mode, a Write to this register is inconsequential. If Register 0_0.12 is set to 0 and speed is manually forced to 1000 Mbps in Registers 0_0.13 and 0_0.6, then Auto-Negotiation will still be enabled and only 1000BASE-T full-duplex is advertised if Register 0_0.8 is set to 1, and 1000BASE-T half-duplex is advertised if 0_0.8 set to 0. Registers 4_0.8:5 and 9_0.9:8 are ignored. Auto-Negotiation is mandatory per IEEE for proper operation in 1000BASE-T. Upon hardware reset this bit defaults as follows: ANEG[3:0] HWCFG_MODE[3:0] Bit 4_0.6 0001 0x00 1 11xx 0x00 1 11xx 1x11 1 all other configurations 0 1 = Advertise 0 = Not advertised



Table 60: Auto-Negotiation Advertisement Register - Copper (Continued)
Page 0, Register 4

Bits	Field	Mode	HW Rst	SW Rst	Description
5	10BASE-TX Half-Duplex	R/W	See Descr	Retain	A write to this register bit does not take effect until any one of the following occurs: Software reset is asserted (Register 0.15) Restart Auto-Negotiation is asserted (Register 0_0.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down In GBIC mode, a Write to this register is inconsequential. If Register 0_0.12 is set to 0 and speed is manually forced to 1000 Mbps in Registers 0_0.13 and 0_0.6, then Auto-Negotiation will still be enabled and only 1000BASE-T full-duplex is advertised if Register 0_0.8 is set to 1, and 1000BASE-T half-duplex is advertised if 0_0.8 set to 0. Registers 4_0.8:5 and 9_0.9:8 are ignored. Auto-Negotiation is mandatory per IEEE for proper operation in 1000BASE-T. Upon hardware reset this bit defaults as follows: ANEG[3:0] HWCFG_MODE[3:0] Bit 4_0.5 0000 0x00 1 11xx 0x00 1 11xx 0x00 1 11xx 1x11 1 all other configurations 0 1 = Advertise 0 = Not advertised
4:0	Selector Field	R/W	Always 00001	Always 00001	Selector Field mode 00001 = 802.3

Table 61: Auto-Negotiation Advertisement Register - Fiber (GMII/RGMII Mode)
Page 1, Register 4

Page 1, Register 4				<u> </u>		
Bits	Field	Mode	HW Rst	SW Rst	Description	
15	Next Page	R/W	0x0	Retain	A write to this register bit does not take effect until any one of the following occurs: Software reset is asserted (Register 0.15) Restart Auto-Negotiation is asserted (Register 0_1.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down 1 = Advertise 0 = Not advertised	
14	Reserved				This bit must be read and left unchanged when performing a write.	
13:12	Remote Fault 2 RemoteFault 1	R/W	0x0	Retain	A write to this register bit does not take effect until any one of the following also occurs: Software reset is asserted (Register 0.15) Re-start Auto-Negotiation is asserted (Register 0_1.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down Device has no ability to detect remote fault. 00 = No error, link OK (default) 01 = Link Failure 10 = Offline 11 = Auto-Negotiation Error	
11:9	Reserved				These bits must be read and left unchanged when performing a write.	
8:7	Pause	R/W	See Descr	Retain	A write to this register bit does not take effect until any one of the following also occurs: Software reset is asserted (Register 0.15) Re-start Auto-Negotiation is asserted (Register 0_1.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down Upon hardware reset, this bit defaults as follows: ENA_PAUSE Bits 4_1.8:7 0 00 1 11 00 = No PAUSE 01 = Symmetric PAUSE 10 = Asymmetric PAUSE toward link partner 11 = Both Symmetric PAUSE and Asymmetric PAUSE toward local device.	



Table 61: Auto-Negotiation Advertisement Register - Fiber (GMII/RGMII Mode) (Continued)
Page 1, Register 4

Bits	Field	Mode	HW Rst	SW Rst	Description
6	1000BASE-X Half-Duplex	R/W	See Descr	Retain	A write to this register bit does not take effect until any one of the following also occurs: Software reset is asserted (Register 0.15) Re-start Auto-Negotiation is asserted (Register 0_1.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down Upon hardware reset this bit defaults as follows: ANEG[3:0] Bit 4_1.6 x1xx 1 all other configurations 0 1 = Advertise 0 = Not advertised
5	1000BASE-X Full-Duplex	R/W	See Descr	Retain	A write to this register bit does not take effect until any one of the following also occurs: Software reset is asserted (Register 0.15) Re-start Auto-Negotiation is asserted (Register 0_1.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down Upon hardware reset this bit defaults as follows: ANEG[3:0] Bit 4_1.5 1xxx 1 all other configurations 0 1 = Advertise 0 = Not advertised
4:0	Reserved				These bits must be read and left unchanged when performing a write.

Table 62: Auto-Negotiation Advertisement Register - (SGMII to Copper Modes) (Mode = 0x00)
Page 1, Register 4

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Copper Link Status	RO	0x0	0x0	0 = Link is Not up on the Copper Interface 1 = Link is UP on the Copper Interface
14	Reserved		47.8		This bit must be read and left unchanged when performing a write.
13	Reserved	8	STO'S		This bit must be read and left unchanged when performing a write.
12	Copper Duplex Status	RO *	0x0	0x0	0 = Copper Interface Resolved to Half-duplex 1 = Copper Interface Resolved to Full-duplex
11:10	Copper Speed[1:0]	RO	0x0	0x0	00 = Copper Interface speed is 10 Mbps 01 = Copper Interface speed is 100 Mbps 10 = Copper Interface speed is 1000 Mbps 11 = Reserved
9:0	Reserved				These bits must be read and left unchanged when performing a write.

Table 63: Auto-Negotiation Advertisement Register - Fiber (SGMII to R-GMII Modes) (Mode = x110)
Page 1, Register 4

Bits	Field	Mode	HW Rst	SW Rst	Description
15:0	Reserved				These bits must be read and left unchanged when performing a write.



Table 64: Auto-Negotiation Advertisement Register - Fiber (GBIC Mode) (Mode = 1000)
Page 1, Register 4

Bits	Field	Mode	HW Rst	SW Rst	Description
15:9	Reserved			NO P	These bits must be read and left unchanged when performing a write.
8:7	Pause	RO	Always 00	Always 00	Pause Status as Indicated by the Link Partner on the Copper Interface 00 = No PAUSE 01 = Symmetric PAUSE 10 = Asymmetric PAUSE toward link partner 11 = Both Symmetric PAUSE and Asymmetric PAUSE toward local device.
6	1000BASE-X Half-Duplex	RO	Always 00	Always 00	Copper Link Partners Half-duplex Status' 1 = Half-duplex Capable 0 = Half-duplex Incapable
5	1000BASE-X Full-Duplex	RO	Always 00	Always 00	Copper Link Partners Full-duplex Status' 1 = Full-duplex Capable 0 = Full-duplex Incapable
4:0	Reserved				These bits must be read and left unchanged when performing a write.

Table 65: Link Partner Ability Register - Base Page, Copper Page 0, Register 5

	Page U, Regis			<u> </u>	<u> </u>
Bits	Field	Mode	HW Rst	SW Rst	Description
15	Next Page	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received. Received Code Word Bit 15 1 = Link partner capable of next page 0 = Link partner not capable of next page
14	Acknowledge	RO **	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page receives Acknowledge Received Code Word Bit 14 1 = Link partner received link code word 0 = Link Partner has not received link code word
13	Remote Fault	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received. Remote Fault Received Code Word Bit 13 1 = Link partner detected remote fault 0 = Link partner has not detected remote fault
12	Technology Ability Field	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received Received Code Word Bit 12
11.00	Asymetric Pause	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received. Received Code Word Bit 11 1 = Link partner requests asymmetric pause 0 = Link partner does not request asymmetric pause
10	Pause Capable	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received. Received Code Word Bit 10 1 = Link partner is capable of symmetric pause operation 0 = Link partner is not capable of symmetric pause operation
9	100BASE-T4 Capability	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received. Received Code Word Bit 9 1 = Link partner is 100BASE-T4 capable 0 = Link partner is not 100BASE-T4 capable
8	100BASE-TX Full-Duplex Capability	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received. Received Code Word Bit 8 1 = Link partner is 100BASE-TX full-duplex capable 0 = Link partner is not 100BASE-TX full-duplex capable



Table 65: Link Partner Ability Register - Base Page, Copper (Continued)
Page 0, Register 5

Bits	Field	Mode	HW Rst	SW Rst	Description
7	100BASE-TX Half-Duplex Capability	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received. Received Code Word Bit 7 1 = Link partner is 100BASE-TX half-duplex capable 0 = Link partner is not 100BASE-TX half-duplex capable
6	10BASE-T Full-Duplex Capability	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received. Received Code Word Bit 6 1 = Link partner is 10BASE-T full-duplex capable 0 = Link partner is not 10BASE-T full-duplex capable
5	10BASE-T Half-Duplex Capability	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received. Received Code Word Bit 5 1 = Link partner is 10BASE-T half-duplex capable 0 = Link partner is not 10BASE-T half-duplex capable
4:0	Selector Field	RO	0x00	0x00	Register bit is cleared when link goes down and loaded when a base page is received. Selector Field Received Code Word Bit 4:0

Table 66: Link Partner Ability Register - Base Page, Fiber (RGMII or GMII Modes)
Page 1, Register 5

rage 1, Register 5					N. 95
Bits	Field	Mode	HW Rst	SW Rst	Description
15	Next Page	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received Received Code Word Bit 15 1 = Link partner capable of next page 0 = Link partner not capable of next page
14	Acknowledge	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received. Acknowledge Received Code Word Bit 14 1 = Link partner received link code word 0 = Link partner has not received link code word
13:12	Remote Fault 2 Remote Fault 1	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received. Received Code Word Bit 13:12 00 = No error, link OK (default) 01 = Link Failure 10 = Offline 11 = Auto-Negotiation Error
11:9	Reserved				These bits must be read and left unchanged when performing a write.
8:7	Asymetric Pause	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received. Received Code Word Bit 8:7 00 = No PAUSE 01 = Symmetric PAUSE 10 = Asymmetric PAUSE toward link partner 11 = Both Symmetric PAUSE and Asymmetric PAUSE toward local device.
6	1000BASE-X Half-Duplex	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received. Received Code Word bit 6 1 = Link partner capable of 1000BASE-X half-duplex. 0 = Link partner not capable of 1000BASE-X half-duplex.
5	1000BASE-X Full-Duplex	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received. Received Code Word bit 5 1 = Link partner capable of 1000BASE-X full-duplex. 0 = Link partner not capable of 1000BASE-X full-duplex.
4:0	Reserved		S		These bits must be read and left unchanged when performing a write.

Table 67: Link Partner Ability Register - Base Page, Fiber (SGMII to Copper Modes) (Mode = 0x00)
Page 1, Register 5

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Reserved			100P	This bit must be read and left unchanged when performing a write.
14	Acknowledge	RO	0x0	0x0	Acknowledge Register bit is cleared when link goes down and loaded when a base page is received. Received Code Word Bit 14 1 = Link partner received link code word 0 = Link partner has not received link code word
13:0	Reserved	*	R		These bits must be read and left unchanged when performing a write.

Table 68: Link Partner Ability Register - Base Page, Fiber (SGMII to R-GMII Modes) (Mode = x110)
Page 1, Register 5

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Copper Link	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received Received Code Word Bit 15 1 = Copper Link is up on the link partner 0 = Copper Link is not up on the link partner
14	Acknowledge	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received Acknowledge Received Code Word Bit 14 1 = Link partner received link code word 0 = Link partner has not received link code word
13	Reserved				This bit must be read and left unchanged when performing a write.
12	Copper Duplex Status	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received Received Code Word Bit 12 1 = Copper Interface on the Link Partner is capable of Full-duplex 0 = Copper Interface on the link partner is capable of Half-duplex

Table 68: Link Partner Ability Register - Base Page, Fiber (SGMII to R-GMII Modes) (Mode = x110)
Page 1, Register 5

Bits	Field	Mode	HW Rst	SW Rst	Description
11:10	Copper Speed Status	RO	0x0	0x0	Register bits are cleared when link goes down and loaded when a base page is received Received Code Word Bit 11:10 00 = 10 Mbps 01 = 1000 Mbps 10 = 1000 Mbps 11 = Reserved
9:0	Reserved	Ø,			These bits must be read and left unchanged when performing a write.

Table 69: Link Partner Ability Register - Base Page, Fiber (GBIC Mode) (Mode = 1000)
Page 1, Register 5

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Reserved				This bit must be read and left unchanged when performing a write.
14	Acknowledge	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received Acknowledge Received Code Word Bit 14 1 = Link partner received link code word 0 = Link partner has not received link code word
13:9	Reserved				These bits must be read and left unchanged when performing a write.
8:7	Asymetric Pause	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received Received Code Word Bit 8:7 00 = No PAUSE 01 = Symmetric PAUSE 10 = Asymmetric PAUSE toward link partner 11 = Both Symmetric PAUSE and Asymmetric PAUSE toward local device.
6	1000BASE-X Half-Duplex	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received Received Code Word bit 6 1 = Link partner capable of 1000BASE-T half-duplex. 0 = Link partner not capable of 1000BASE-T half-duplex.



Table 69: Link Partner Ability Register - Base Page, Fiber (GBIC Mode) (Mode = 1000) (Continued)
Page 1, Register 5

Bits	Field	Mode	HW Rst	SW Rst	Description
5	1000BASE-X Full-Duplex	RO	0x0	0x0	Register bit is cleared when link goes down and loaded when a base page is received Received Code Word bit 5 1 = Link partner capable of 1000BASE-T full-duplex. 0 = Link partner not capable of 1000BASE-T full-duplex.
4:0	Reserved		W 6		These bits must be read and left unchanged when performing a write.

Table 70: Auto-Negotiation Expansion Register - Copper Page 0, Register 6

Bits	Field	Mode	HW Rst	SW Rst	Description
15:5	Reserved				These bits must be read and left unchanged when performing a write.
4	Parallel Detection Fault	RO,LH	0x0	0x0	 6_0.3 is set when a base page is received and the received link control word has bit 15 set to 1. The bit is cleared when link goes down. 1 = A fault has been detected via the Parallel Detection function 0 = A fault has not been detected via the Parallel Detection function
3	Link Partner Next page Able	RO	0x0	0x0	Register 6_0.3 is not valid until the Auto-Negotiation complete bit (Reg 1_0.5) indicates completed. 1 = Link Partner is Next Page able 0 = Link Partner is not Next Page able
2	Local Next Page Able	RO	Always 1	Always 1	1 = Local Device is Next Page able
1	Page Received	RO, LH	0x0	0x0	Register 6_0.1 is set when a valid page is received. 1 = A New Page has been received 0 = A New Page has not been received
0	Link Partner Auto- Negotiation Able	RO	0x0	0x0	This bit is set when the device receives 3 matching FLP bursts and the Auto-Negotiation is enabled in register 0.0.12 1 = Link Partner is Auto-Negotiation able 0 = Link Partner is not Auto-Negotiation able

Table 71: Auto-Negotiation Expansion Register - Fiber Page 1, Register 6

				<u></u>		
Bits	Field	Mode	HW Rst	SW Rst	Description	
15:4	Reserved			S. P.W	These bits must be read and left unchanged when performing a write.	
3	Link Partner Next page Able	RO	0x0	0x0	In SGMII to Copper, SGMII to RGMII, GBIC and Legacy GBIC Modes this bit is always 0. In all the other modes register 6_1.3 is set when a base page is received and the received link control word has bit 15 set to 1. The bit is cleared when link goes down. 1 = Link Partner is Next Page able 0 = Link Partner is not Next Page able	
2	Local Next Page Able	RO	Always 1	Always 1	1 = Local Device is Next Page able	
1	Page Received	RO, LH	0x0	0x0	Register 6_1.1 is set when a valid page is received. 1 = A New Page has been received 0 = A New Page has not been received	
0011	Link Partner Auto- Negotiation Able	RO	0x0	0x0	This bit is set when there is sync status, the fiber receiver has received 3 non-zero matching valid configuration code groups and Auto-Negotiation is enabled in register 1.0.12 1 = Link Partner is Auto-Negotiation able 0 = Link Partner is not Auto-Negotiation able	



Table 72: Next Page Transmit Register - Copper Page 0, Register 7

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Next Page	R/W	0x0	0x0	A write to register 7_0 implicitly sets a variable in the Auto-Negotiation state machine indicating that the next page has been loaded. Transmit Code Word Bit 15
14	Reserved		NO S	Y	This bit must be read and left unchanged when performing a write.
13	Message Page Mode	R/W	0x1	0x1	Transmit Code Word Bit 13
12	Acknowledge2	R/W	0x0	0x0	Transmit Code Word Bit 12
11	Toggle	RO	0x0	0x0	Transmit Code Word Bit 11. This bit is internally set to the opposite value each time a page is received
10:0	Message/ Unformatted Field	R/W	0x001	0x001	Transmit Code Word Bit 10:0

Table 73: Next Page Transmit Register - Fiber Page 1, Register 7

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Next Page	R/W	0x0	0x0	A write to register 7_1 implicitly sets a variable in the Auto-Negotiation state machine indicating that the next page has been loaded. Transmit Code Word Bit 15
14	Reserved				This bit must be read and left unchanged when performing a write.
13	Message Page Mode	R/W	0x1	0x1	Transmit Code Word Bit 13
12	Acknowledge2	R/W	0x0	0x0	Transmit Code Word Bit 12
11	Toggle	RO	0x0	0x0	Transmit Code Word Bit 11. This bit is internally set to the opposite value each time a page is received.
10:0	Message/ Unformatted Field	R/W	0x001	0x001	Transmit Code Word Bit 10:0

Doc. No. MV-S100649-00, Rev. G

Table 74: Link Partner Next Page Register - Copper Page 0, Register 8

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Next Page	RO	0x0	0x0	The register is loaded only when a next page is received from the link partner. It is cleared each time the link goes down. Received Code Word Bit 15
14	Acknowledge	RO	0x0	0x0	Received Code Word Bit 14
13	Message Page	RO 🍣	0x0	0x0	Received Code Word Bit 13
12	Acknowledge2	RO	0x0	0x0	Received Code Word Bit 12
11	Toggle	RO	0x0	0x0	Received Code Word Bit 11
10:0	Message/ Unformatted Field	RO	0x000	0x000	Received Code Word Bit 10:0

Table 75: Link Partner Next Page Register - Fiber Page 1, Register 8

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Next Page	RO	0x0	0x0	The register is loaded only when a next page is received from the link partner. It is cleared each time the link goes down. Received Code Word Bit 15
14	Acknowledge	RO	0x0	0x0	Received Code Word Bit 14
13	Message Page	RO	0x0	0x0	Received Code Word Bit 13
12	Acknowledge2	RO	0x0	0x0	Received Code Word Bit 12
11	Toggle	RO	0x0	0x0	Received Code Word Bit 11
10:0	Message/ Unformatted Field	RO	0x000	0x000	Received Code Word Bit 10:0



Table 76: 1000BASE-T Control Register Page 0, Register 9

Page U, Register 9				\(\frac{1}{2}\)	
Bits	Field	Mode	HW Rst	SW Rst	Description
15:13	Test Mode	R/W	0x0	Retain	After exiting the test mode, hardware reset or software reset (Register 0.15) should be issued to ensure normal operation. A restart of Auto-Negotiation will clear these bits. 000 = Normal Mode 001 = Test Mode 1 - Transmit Waveform Test 010 = Test Mode 2 - Transmit Jitter Test (MASTER mode) 011 = Test Mode 3 - Transmit Jitter Test (SLAVE mode) 100 = Test Mode 4 - Transmit Distortion Test 101, 110, 111 = Reserved The transmitting clock which is synchronous to the test data is sourcing from the RX_CLK pin for jitter testing in test modes 2 and 3.
12	MASTER/ SLAVE Manual Config- uration Enable	R/W	See Descr	Retain	A write to this register bit does not take effect until any of the following also occurs: Software reset is asserted (Register 0.15) Restart Auto-Negotiation is asserted (Register 0_0.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down Upon hardware reset this bit defaults as follows: ANEG[3:0] Bit 9_0.12 xx1x 0 all other configurations 1 1 = Manual MASTER/SLAVE configuration 0 = Automatic MASTER/SLAVE configuration
11	MASTER/ SLAVE Configuration Value	R/W	See Descr	Retain	A write to this register bit does not take effect until any of the following also occurs: Software reset is asserted (Register 0.15) Restart Auto-Negotiation is asserted (Register 0_0.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down Register 9_0.11 is ignored if Register 9_0.12 is equal to 0. Upon hardware reset this bit defaults as follows: ANEG[3:0] Bit 9_0.11 xxx1 0 all other configurations 1 1 = Manual configure as MASTER 0 = Manual configure as SLAVE

Table 76: 1000BASE-T Control Register (Continued)
Page 0, Register 9

Page 0, Register 9					
Bits	Field	Mode	HW Rst	SW Rst	Description
10	Port Type	R/W	See Descr	Retain	A write to this register bit does not take effect until any of the following also occurs: Software reset is asserted (Register 0.15) Restart Auto-Negotiation is asserted (Register 0_0.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down Register 9_0.10 is ignored if Register 9_0.12 is equal to 1. Upon hardware reset this bit defaults as follows: ANEG[3:0] Bit 9_0.10 xxx1 0 all other configurations 1 1 = Prefer multi-port device (MASTER) 0 = Prefer single port device (SLAVE)
9	1000BASE-T Full-Duplex	R/W	See Descr	Retain	A write to this register bit does not take effect until any of the following also occurs: Software reset is asserted (Register 0.15) Restart Auto-Negotiation is asserted (Register 0.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down Upon hardware reset this bit defaults as follows: ANEG[3:0] Bit 9_0.9 1xxx 1 all other configurations 0 1 = Advertise 0 = Not advertised
8	1000BASE-T Half-Duplex	R/W	See Descr	Retain	A write to this register bit does not take effect until any of the following also occurs: Software reset is asserted (Register 0.15) Restart Auto-Negotiation is asserted (Register 0_0.9) Power down (Register 0.11) transitions from power down to normal operation Link goes down Upon hardware reset this bit defaults as follows: ANEG[3:0] Bit 9_0.8 x1xx 1 all other configurations 0 1 = Advertise 0 = Not advertised
7:0	Reserved				These bits must be read and left unchanged when performing a write.



Table 77: 1000BASE-T Status Register Page 0, Register 10

					10.10	
Bits	Field	Mode	HW Rst	SW Rst	Description	
15	MASTER/ SLAVE Configuration Fault	RO,LH	0x0	0x0	This register bit will clear on read and restart autoneg It is set to 0 when Auto-Negotiation is off 1 = MASTER/SLAVE configuration fault detected 0 = No MASTER/SLAVE configuration fault detected	
14	MASTER/ SLAVE Configuration Resolution	RO	0x0	0x0	1 = Local PHY configuration resolved to MASTER 0 = Local PHY configuration resolved to SLAVE	
13	Local Receiver Status	RO	0x0	0x0	1 = Local Receiver OK 0 = Local Receiver is Not OK	
12	Remote Receiver Status	RO	0x0	0x0	1 = Remote Receiver OK 0 = Remote Receiver Not OK	
11	Link Partner 1000BASE-T Full-Duplex Capability	RO	0x0	0x0	1 = Link Partner is capable of 1000BASE-T full-duplex 0 = Link Partner is not capable of 1000BASE-T full-duplex	
10	Link Partner 1000BASE-T Half-Duplex Capability	RO	0x0	0x0	1 = Link Partner is capable of 1000BASE-T half-duplex 0 = Link Partner is not capable of 1000BASE-T half-duplex duplex	
9:8	Reserved				These bits must be read and left unchanged when performing a write.	
7:0	Idle Error Count	RO, SC	0x00	0x00	MSB of Idle Error Counter These register bits report the idle error count since the last time this register was read. The counter pegs at 11111111 and will not roll over.	

Table 78: Reserved Registers
Page Any, Register 11

Bits	Field	Mode	HW Rst	SW Rst	Description
15:0	Reserved			SC PA	These bits must be read and left unchanged when performing a write.

Table 79: Reserved Registers Page Any, Register 12

Bits	Field	Mode	HW Rst	SW Rst	Description
15:0	Reserved				These bits must be read and left unchanged when performing a write.

Table 80: Reserved Registers Page Any, Register 13

MARVELL CONFIDENTIAL

Bits	Field	Mode	HW Rst	SW Rst	Description
15:0	Reserved				These bits must be read and left unchanged when performing a write.

Table 81: Reserved Registers Page Any, Register 14

Bits	Field	Mode	HW Rst	SW Rst	Description
15:0	Reserved				These bits must be read and left unchanged when performing a write.



Table 82: Extended Status Register Page Any, Register 15

					X V
Bits	Field	Mode	HW Rst	SW Rst	Description
15	1000BASE-X Full-Duplex	RO	See Descr	See Descr	This bit is set to 1 when mode is one of these: 0011, 0110, 0111, 1000 This bit is also set to 1 if auto fiber/copper mode is on when mode is one of these: 1001, 1011, 1101, 1111 Any other mode/auto-fiber-copper combination, this bit is set to 0 1 = 1000 BASE-X full-duplex capable 0 = Not 1000 BASE-X full-duplex capable
14	1000BASE-X Half-Duplex	RO	See Descr	See Descr	This bit is set to 1 when mode is one of these: 0011, 0110, 0111, 1000 This bit is also set to 1 if auto fiber/copper mode is on when mode is one of these: 1001, 1011, 1101, 1111 Any other mode/auto-fiber-copper combination, this bit is set to 0 1 = 1000 BASE-X full-duplex capable 0 = Not 1000 BASE-X full-duplex capable
13	1000BASE-T Full-Duplex	RO	See Descr	See Descr	This bit is set to 1 when mode is one of these: 0000, 0100, 1000, 1001, 1011, 1101, 1111 Any other mode, this bit is set to 0 1 = 1000 BASE-X full-duplex capable 0 = Not 1000 BASE-X full-duplex capable
12	1000BASE-T Half-Duplex	RO	See Descr	See Descr	This bit is set to 1 when mode is one of these: 0000, 0100, 1000, 1001, 1011, 1101, 1111 Any other mode, this bit is set to 0 1 = 1000 BASE-X full-duplex capable 0 = Not 1000 BASE-X full-duplex capable
11:0	Reserved				These bits must be read and left unchanged when performing a write.

Table 83: PHY Specific Control Register Page Any, Register 16

				10° 90°		
Bits	Field	Mode	HW Rst	SW Rst	Description	
15:14	Transmit FIFO Depth	R/W	0x0	Retain	See "Synchronizing FIFO" on page 69 to determine when the transmit FIFO is enabled. 1000BASE-T 10/100BASE-T 00 = \pm 16 Bits 00 = \pm 8 Bits 01 = \pm 24 Bits 01 = \pm 12 Bits 10 = \pm 32 Bits 10 = \pm 16 Bits 11 = \pm 40 Bits 11 = \pm 20 Bits	
13:12	Receive FIFO Depth	R/W	0x0	Retain	See "Synchronizing FIFO" on page 69 to determine when the transmit FIFO is enabled. $1000BASE-T \qquad 10/100BASE-T \qquad 00 = \pm 16 \text{ Bits} \qquad 00 = \pm 8 \text{ Bits} \qquad 01 = \pm 24 \text{ Bits} \qquad 01 = \pm 12 \text{ Bits} \qquad 10 = \pm 32 \text{ Bits} \qquad 10 = \pm 16 \text{ Bits} \qquad 11 = \pm 40 \text{ Bits} \qquad 11 = \pm 20 \text{ Bits}$	
11	Assert CRS on Transmit	R/W	0x0	Retain	This bit has no effect in full-duplex. 1 = Assert on transmit 0 = Never assert on transmit	
10	Force Link Good	R/W	0x0	Retain	If link is forced to be good, the link state machine is bypassed and the link is always up. In 1000BASE-T mode this has no effect. 1 = Force link good 0 = Normal operation	
9:8	Energy Detect	R/W	See Descr	Update	Upon hardware reset this bit defaults as follows DIS_SLEEP Bits 16.9:8 0 11 1 00 0x = Off 10 = Sense only on Receive (Energy Detect) 11 = Sense and periodically transmit NLP (Energy Detect+™)	
7	Enable Extended Dis- tance	R/W	0x0	Retain	When using cable exceeding 100m, the 10BASE-T receive threshold must be lowered in order to detect incoming signals. 1 = Lower 10BASE-T receive threshold 0 = Normal 10BASE-T receive threshold	



Table 83: PHY Specific Control Register (Continued)
Page Any, Register 16

	r age Any, register to				
Bits	Field	Mode	HW Rst	SW Rst	Description
6:5	MDI Crossover Mode	R/W	See Descr	Update	Changes to these bits are disruptive to the normal operation; therefore, any changes to these registers must be followed by a software reset to take effect. Upon hardware reset this bit defaults as follows ENA_XC ANEG[3:0] Bits 16.6:5 1 1xxx 11 1 x1xx 11 0 xxxx 01(for multiple port device) 0 xxxx 00(for single port device) x 00xx 01(for multiple port device) x 00xx 00(for single port device) 0 = Manual MDI configuration 01 = Manual MDIX configuration 10 = Reserved 11 = Enable automatic crossover for all modes
4	Disable 125CLK	R/W	See Descr	Update	Changes to this bit are disruptive to the normal operation; therefore, any changes to these registers must be followed by a software reset to take effect. Upon hardware reset this bit defaults as follows DIS_125 Bit 16.4 0 0 1 1 1 = 125CLK low 0 = 125CLK toggle
37	MAC Interface Power Down	R/W	0x1	Update	Changes to this bit are disruptive to the normal operation; therefore, any changes to these registers must be followed by a software reset to take effect. This bit determines whether MAC interface powers down when Register 0.11 is used to power down the device or when the PHY enters the energy detect state. In modes 0111 or 0011 RX_CLK will not toggle when in Power Down mode. 1 = Always power up 0 = Can power down
2	SQE test	R/W	0x0	Retain	SQE Test is automatically disabled in full-duplex mode regardless of the state of Register 16.2. 1 = SQE test enabled 0 = SQE test disabled
1	Polarity Reversal	R/W	0x0	Retain	If polarity is disabled, then the polarity is forced to be normal in 10BASE-T. 1 = Polarity Reversal Disabled 0 = Polarity Reversal Enabled

Table 83: PHY Specific Control Register (Continued)
Page Any, Register 16

Bits	Field	Mode	HW Rst	SW Rst	Description
0	Disable Jabber	R/W	0x0	Retain	Jabber has effect only in 10BASE-T half-duplex mode. 1 = Disable jabber function 0 = Enable jabber function

Table 84: PHY Specific Status Register - Copper Page 0, Register 17

r ago o, rrogistor in							
Bits	Field	Mode	HW Rst	SW Rst	Description		
15:14	Speed	RO	0x0	Retain	These status bits are valid only after resolved bit 17_0.11 = 1. The resolved bit is set when Auto-Negotiation is completed or Auto-Negotiation is disabled. 11 = Reserved 10 = 1000 Mbps 01 = 100 Mbps 00 = 10 Mbps		
13	Duplex	RO	0x0	Retain	This status bit is valid only after resolved bit 17_0.11 = 1. The resolved bit is set when Auto-Negotiation is completed or Auto-Negotiation is disabled. 1 = Full-duplex 0 = Half-duplex		
12	Page Received	RO, LH	0x0	0x0	1 = Page received 0 = Page not received		
11	Speed and Duplex Resolved	RO	0x0	0x0	When Auto-Negotiation is not enabled 17_0.11 = 1. 1 = Resolved 0 = Not resolved (If bit 27.11 is 1, then this bit will be 0.)		
10	Link (real time)	RO	0x0	0x0	1 = Link up 0 = Link down		



Table 84: PHY Specific Status Register - Copper (Continued)
Page 0, Register 17

Bits	Field	Mode	HW Rst	SW Rst	Description	
9:7	Cable Length (1000 mode only)	RO	0x0	0x0	Cable length measurement is only a rough estimate. Actual value depends on the attenuation of the cable, output levels of the remote transceiver, connector impedance, etc. 000 = < 50m 001 = 50 - 80m 010 = 80 - 110m 011 = 110 - 140m 100 = greater than 140m A new improved DSP based cable length estimation is also available as described in the application note: "VCT™ − Cable Status Extended Features Plus How to Use TDR Results For Gigabit PHYs."	
6	MDI Crossover Status	RO	0x0	0x0	This status bit is valid only after resolved bit 17_0.11 = 1. The resolved bit is set when Auto-Negotiation is completed or Auto-Negotiation is disabled. This bit is 0 or 1 depending on what is written to 16.6:5 in manual configuration mode. Register 16.6:5 are updated with software reset. 1 = MDIX 0 = MDI	
5	Downshift Sta- tus	RO	0x0	0x0	1 = Downshift 0 = No Downshift	
4	Copper Energy Detect Status	RO	0x0	0x0	The PHY will go into sleep mode if it does not detect energy for six seconds. The PHY will start in active mode after six seconds once power-up, hardware or software reset is complete. 1 = Sleep 0 = Active	
3	Transmit Pause Enabled	RO	0x0	0x0	This is a reflection of the MAC pause resolution. This bit is for information purposes and is not used by the device. This status bit is valid only after resolved bit 17_0.11 = 1. The resolved bit is set when Auto-Negotiation is completed or Auto-Negotiation is disabled. 1 = Transmit pause enabled 0 = Transmit pause disable	

PHY Specific Status Register - Copper (Continued)
Page 0, Register 17

Bits	Field	Mode	HW Rst	SW Rst	Description
2	Receive Pause Enabled	RO	0x0	0x0	This is a reflection of the MAC pause resolution. This bit is for information purposes and is not used by the device. This status bit is valid only after resolved bit 17_0.11 = 1. The resolved bit is set when Auto-Negotiation is completed or Auto-Negotiation is disabled. 1 = Receive pause enabled 0 = Receive pause disabled
1	Polarity (real time)	RO	0x0	0x0	1 = Reversed 0 = Normal
0	Jabber (real time)	RO	0x0	retain	1 = Jabber 0 = No jabber

Table 85: PHY Specific Status Register - Fiber Page 1, Register 17

Bits	Field	Mode	HW Rst	SW Rst	Description
15:14	Speed	RO	0x0	Retain	These status bits are valid only after resolved bit 17_1.11 = 1. The resolved bit is set when Auto-Negotiation is completed or Auto-Negotiation is disabled. 11 = Reserved 10 = 1000 Mbps 01 = 100 Mbps 00 = 10 Mbps
13	Duplex	RO	0x0	Retain	This status bit is valid only after resolved bit 17_1.11 = 1. The resolved bit is set when Auto-Negotiation is completed or Auto-Negotiation is disabled. 1 = Full-duplex 0 = Half-duplex
12	Page Received	RO, LH	0x0	0x0	1 = Page received 0 = Page not received
11	Speed and Duplex Resolved	RO	0x0	0x0	When Auto-Negotiation is not enabled or mode is 0001 or 0101 17_1.11 = 1. 1 = Resolved 0 = Not resolved If bit 27.11 is 1, then this bit will be 0.
10	Link (real time)	RO	0x0	0x0	1 = Link up 0 = Link down
9:5	Reserved			107	These bits must be read and left unchanged when performing a write.



Table 85: PHY Specific Status Register - Fiber (Continued)
Page 1, Register 17

	1	1		ı	0.0
Bits	Field	Mode	HW Rst	SW Rst	Description
4	Fiber Energy Detect Status	RO	0x1	0x1	1 = No energy detected 0 = Energy Detected
3	Transmit Pause Enabled	RO	0x0	0x0	This is a reflection of the MAC pause resolution. This bit is for information purposes and is not used by the device. This status bit is valid only after resolved bit 17_1.11 = 1. The resolved bit is set when Auto-Negotiation is completed or Auto-Negotiation is disabled. 1 = Transmit pause enabled 0 = Transmit pause disable
2	Receive Pause Enabled	RO	0x0	0x0	This is a reflection of the MAC pause resolution. This bit is for information purposes and is not used by the device. This status bit is valid only after resolved bit 17_1.11 = 1. The resolved bit is set when Auto-Negotiation is completed or Auto-Negotiation is disabled. 1 = Receive pause enabled 0 = Receive pause disabled
1:0	Reserved				These bits must be read and left unchanged when performing a write.

Table 86: Interrupt Enable Register¹
Page 0, Register 18

~					
Bits	Field	Mode	HW Rst	SW Rst	Description
15	Auto-Negotia- tion Error Inter- rupt Enable	R/W	0	Retain	1 = Interrupt enable 0 = Interrupt disable
14	Speed Changed Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
13	Duplex Changed Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
12	Page Received Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable

Table 86: Interrupt Enable Register¹ (Continued)
Page 0, Register 18

	r age o, regi	-			<u></u>
Bits	Field	Mode	HW Rst	SW Rst	Description
11	Auto-Negotia- tion Completed Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
10	Link Status Changed Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
9	Symbol Error Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
8	False Carrier Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
7	FIFO Over/ Underflow Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
6	MDI Crossover Changed Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
5	Downshift Inter- rupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
4	Energy Detect Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
3	Reserved				This bit must be read and left unchanged when performing a write.
2	DTE power detection sta- tus changed interrupt enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
1	Polarity Changed Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
0	Jabber Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable

^{1.} Interrupts should only be enabled during normal operation (not in test modes, power down, etc.).

Table 87: Interrupt Enable Register¹ - Fiber Page 1, Register 18

88E1111

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Reserved				This bit must be read and left unchanged when performing a write.
14	Speed Changed Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
13	Duplex Changed Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
12	Page Received Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
11	Auto-Negotia- tion Completed Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
10	Link Status Changed Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
200	Symbol Error Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
8	False Carrier Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
7	FIFO Over/ Underflow Interrupt Enable	R/W	0x0	Retain	1 = Interrupt enable 0 = Interrupt disable
6:5	Reserved				These bits must be read and left unchanged when performing a write.
4	Fiber Energy Detect Interrupt Enable	R/W	0x0	Retain	This bit only has effect when auto-media detect is enabled or mode is 0000, 0110 or 1110. 1 = Interrupt enable 0 = Interrupt disable
3:0	Reserved			1180	These bits must be read and left unchanged when performing a write.

^{1.} Interrupts should only be enabled during normal operation (not in test modes, power down, etc.).

Table 88: Interrupt Status Register Page 0, Register 19

Page 0, Register 19					
Bits	Field	Mode	HW Rst	SW Rst	Description
15	Auto-Negotia- tion Error	RO, LH	0	0 **	An error is said to occur if MASTER/SLAVE does not resolve, parallel detect fault, no common HCD, or link does not come up after negotiation is completed. 1 = Auto-Negotiation 0 = No Auto-Negotiation
14	Speed Changed	RO,LH	0x0	0x0	1 = Speed changed 0 = Speed not changed
13	Duplex Changed	RO,LH	0x0	0x0	1 = Duplex changed 0 = Duplex not changed
12	Page Received	RO,LH	0x0	0x0	1 = Page received 0 = Page not received
11	Auto- Negotiation Completed	RO,LH	0x0	0x0	1 = Auto-Negotiation completed 0 = Auto-Negotiation not completed
10	Link Status Changed	RO,LH	0x0	0x0	1 = Link status changed 0 = Link status not changed
9	Symbol Error	RO,LH	0x0	0x0	1 = Symbol error 0 = No symbol error
8	False Carrier	RO,LH	0x0	0x0	Does not apply for 1000Mbs. 1 = False carrier 0 = No false carrier
7	FIFO Over/ Underflow	RO,LH	0x0	0x0	1 = Over/Underflow Error 0 = No FIFO Error
6	MDI Crossover Changed	RO,LH	0x0	0x0	1 = Crossover changed 0 = Crossover not changed
5	Downshift Inter- rupt	RO,LH	0x0	0x0	1 = Downshift detected 0 = No down shift
4	Energy Detect Changed	RO,LH	0x0	0x0	1 = Bit 17.4 (Sleep state status) changed0 = Bit 17.4 (Sleep state status) did not change
3	Reserved			26	This bit must be read and left unchanged when performing a write.
2	DTE power detection sta- tus changed interrupt	RO,LH	0x0	0x0	1 = DTE power detection status changed 0 = No DTE power detection status change detected



Table 88: Interrupt Status Register (Continued)
Page 0, Register 19

Bits	Field	Mode	HW Rst	SW Rst	Description
1	Polarity Changed	RO,LH	0x0	0x0	1 = Polarity Changed 0 = Polarity not changed
0	Jabber	RO,LH	0x0	0x0	1 = Jabber 0 = No jabber

Table 89: Interrupt Status Register Page 1, Register 19

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Reserved	97 J			This bit must be read and left unchanged when performing a write.
14	Speed Changed	RO,LH	0x0	0x0	1 = Speed changed 0 = Speed not changed
13	Duplex Changed	RO,LH	0x0	0x0	1 = Duplex changed 0 = Duplex not changed
12	Page Received	RO,LH	0x0	0x0	1 = Page received 0 = Page not received
11 00	Auto-Negotia- tion Completed	RO,LH	0x0	0x0	1 = Auto-Negotiation completed 0 = Auto-Negotiation not completed
10	Link Status Changed	RO,LH	0x0	0x0	1 = Link status changed 0 = Link status not changed
9	Symbol Error	RO,LH	0x0	0x0	1 = Symbol error 0 = No symbol error
8	False Carrier	RO,LH	0x0	0x0	1 = False carrier 0 = No false carrier
7	FIFO Over/ Underflow	RO,LH	0x0	0x0	1 = Over/Underflow Error 0 = No FIFO Error
6:5	Reserved				These bits must be read and left unchanged when performing a write.
4	Fiber Energy Detect Changed	RO	0x0	0x0	Fiber Energy Detect changed has effect only when mode is 0000, 0110 or 1110. 1 = Fiber Energy Detect state changed 0 = No Fiber Energy Detect state change detected
3:0	Reserved			11/2	These bits must be read and left unchanged when performing a write.

Table 90: Extended PHY Specific Control Register Page Any, Register 20

Page Ally, Register 20				<u> </u>	<u> </u>
Bits	Field	Mode	HW Rst	SW Rst	Description
15	Block Carrier Extension Bit	R/W	0x0	0x0	1 = Enable Block Carrier Extension 0 = Disable Block Carrier Extension Refer to the White Paper "TRR Byte Stuffing and MACs" for details. In GMII mode, Register 20.15 is the register bit used to block carrier extension.
14	Line Loopback	R/W	0x0	0x0	1 = Enable Line Loopback 0 = Normal Operation
13	Reserved	* IIP	,		This bit must be read and left unchanged when performing a write.
12	Disable Link Pulses	R/W	0x0	0x0	1 = Disable Link Pulse 0 = Enable Link Pulse
11:9	Downshift counter	R/W	0x6	Update	Changes to these bits are disruptive to the normal operation; therefore, any changes to these registers must be followed by software reset to take effect. 1x, 2x,8x is the number of times the PHY attempts to establish Gigabit link before the PHY downshifts to the next highest speed. $000 = 1x 100 = 5x$ $001 = 2x 101 = 6x$ $010 = 3x 110 = 7x$ $011 = 4x 111 = 8x$ Note: Bit 9 is set to 0 when mode is one of these: 0010, 0011, 0111, 1000, 1001, 1100 or 1101.
8	Downshift Enable	R/W	0x0	Update	Changes to these bits are disruptive to the normal operation; therefore, any changes to these registers must be followed by software reset to take effect. This bit is set to 0 when mode is one of these: 0010, 0011, 0111, 1000, 1001, 1100 or 1101. 0 = Disable downshift. 1 = Enable downshift.
7	RGMII Receive Timing Control	R/W	0x0	Update	Changes to this bit are disruptive to the normal operation; hence, any change to this register must be followed by software reset to take effect. 1 = Add delay to RX_CLK for RXD Outputs. See"RGMII/RTBI Delay Timing for different RGMII/RTBI Modes" on page 218.



Table 90: Extended PHY Specific Control Register (Continued)
Page Any, Register 20

Bits	Field	Mode	HW Rst	SW Rst	Description
6:4	Default MAC interface speed (Bits 5:4 also determine the speed of operation in GMII/RGMII to SGMII mode when SGMII Auto-Negotiation is disabled.)	R/W	0x6	Update	Changes to these bits are disruptive to the normal operation; therefore, any changes to these registers must be followed by software reset to take effect. MAC Interface Speed during Link down while Auto-Negotiation is enabled. Bit Speed TX_CLK speed TX_CLK speed -link down - 1000BASE-T link 000 = 10 Mbps 2.5 MHz 0 MHz 001 = 100 Mbps 25 MHz 0 MHz 100 = 10 Mbps 0 MHz 0 MHz 100 = 10 Mbps 2.5 MHz 2.5 MHz 101 = 100 Mbps 25 MHz 2.5 MHz 101 = 100 Mbps 25 MHz 25 MHz 110 = 1000 Mbps 25 MHz 25 MHz 111 = 1000 Mbps 25 MHz 25 MHz Note: Bit 5 is set to 1 when mode is one of these: 0010, 0011, 0111, 1000, 1001, 1100 or 1101.
3	Reserved				This bit must be read and left unchanged when performing a write.
2	DTE detect enable	R/W	See descr	Update	1 = Enable DTE detection 0 = Disable DTE detection Upon hardware reset this bit defaults as follows: DIS_DTE Bit 20.2 0 1 1 0
50	RGMII Transmit Timing Control	R/W	0x0	Update	Changes to this bit are disruptive to the normal operation; hence, any change to this register must be followed by software reset to take effect. 1 = Add delay to GTX_CLK for TXD Outputs. See"RGMII/RTBI Delay Timing for different RGMII/RTBI Modes" on page 218.
0	Transmitter Disable	R/W	0x0	Retain	1 = Transmitter Enable 0 = Transmitter Disable

Table 91: Receive Error Counter Register Page Any, Register 21

Bits	Field	Mode	HW Rst	SW Rst	Description
15:0	Receive Error Count	RO, LH	0x0000	Retain	Counter will peg at 0xFFFF and will not roll over. Both False carrier and symbol errors are reported. The following modes of operation have the receive errors reported from Fiber media. 0011,0111,0110 and 1110. Copper media receive errors are reported in the remaining modes of operation.



Table 92: Extended Address
Page Any, Register 22

Bits	Field	Mode	HW Rst	SW K	Description
15:8	Reserved			10 P	These bits must be read and left unchanged when performing a write.
7:0	Page select for registers 0 to 28	R/W	0x00	Retain	Register bits 22.7:0 are used for fiber/copper register identity selection. 0x00 = Selects copper banks of registers 0, 1, 4, 5, 6, 7, 8, 17, 18, 19. 0x01 = Selects fiber banks of registers 0, 1, 4, 5, 6, 7, 8, 17, 18, 19. At the same time register 22.7:0 also selects the VCT™ pair for results to be read from register 28. 0x03 = MDI pair 3 0x02 = MDI pair 2 0x01 = MDI pair 1 0x00 = MDI pair 0 See Table 93 for details. Reg22[7:0] = 01 when Reg27[3:0] is either 0110, 1110, 0011 or 0111 and Reg22[7:0] = 00 when Reg27[3:0] is either 1001, 1101, 1011, 1111 and reg27[15] = 1. When modes is either 0000, 0010, 0100, 1000, 1010, or 1100 and Reg27[15] = 0 and Reg27[9] = 0 then Reg22[7:0] will be 0x00 or 0x01 depends on if the phy is resolved to fiber or copper. If Reg27[15] or Reg27[9] = 1, writing 0x01 to Reg22[7:0] for Fiber registers banks accesses and writing 00 to Reg22[7:0] for Copper registers banks accesses.

Table 93: Register 22[7:0] values for page 0 and 1 of Registers 0, 1, 4, 5, 6, 7, 8, 17, 19

MODE[3:0]	DIS_FC (reg27.15)	Default Bits 22.7:0 No Link	Default Bits 22.7:0 Link Up	Registers Bank Accesses Copper=page 0 Fiber=page1	Disable/ Enable Automatic Medium Register Selection (Reg27.9)	Updates 22.7:0	
0000 - SGMII with Clock with SGMII Auto-Neg to Copper	х	"00000000"	"00000000"	Copper/SGMII	х	N/A	יו
0100 - SGMII without Clock with SGMII Auto-Neg to Copper	х	"00000000"	"00000000"	Copper/SGMII	х	N/A	<u></u>
1000 - GBIC	х	"00000000"	"00000000"	Copper/fiber	х	N/A	- [
1100 - 1000BASE-X without Auto-Neg to Copper	х	"00000000"	"00000000"	Copper/fiber	х	N/A	-
1001 - RTBI to Copper	1	"00000000"	"00000000"	Copper Only	х	N/A	1.
1101 - TBI to Copper	1	"00000000"	"00000000"	Copper Only	х	N/A	-
0110 - RGMII to SGMII	х	"00000000"	"00000000"	Fiber Only	х	N/A	
1110 - GMII to SGMII	х	"00000000"	"00000000"	Fiber Only	х	N/A	
0011 - RGMII to Fiber	х	"00000000"	"00000000"	Fiber Only	X	N/A	
0111 - GMII to Fiber	х	"00000000"	"00000000"	Fiber Only	x	N/A	٦.
1011 - RGMII to Copper	1	"00000000"	"00000000"	Copper Only	X	N/A	-
1011 - RGMII with Auto-Selection(Resolved to Copper)	0	"00000000"	"00000000"	Copper/fiber	0-0-0	Yes	'
1011 - RGMII with Auto-Selection(Resolved to Fiber)	0	"00000000"	"00000001"	Copper/fiber	3 1	No	-
1111 - GMII to Copper	1	"00000000"	"00000000"	Copper Only	Х	N/A	_
1111 - GMII with Auto-Selection(Resolved to Copper)	0	"00000000"	"00000000"	Copper/fiber	0	Yes	1
1111 - GMII with Auto-Selection(Resolved to Fiber)	0	"00000000"	"0000001"	Copper/fiber	1	No	į

When mode is 0x01, 0x11, or x110, only fiber registers can be accessed. A write to Register 22 bits[7:0] will not change the pointer to Copper register banks. Similarly, a read from Register 22 bits[7:0] = 0x00 has no indication that copper registers are accessible.

When mode is 1x01 or 1x11 with DIS_FC = 0, both copper or fiber registers are accessible. Register 22 bits[7:0] = 0x00 when the MAC is resolved to Copper and 0x01 when the MAC is resolved to fiber. Register 22 bits[7:0] can be programmed to select copper or fiber register banks. If Disable/Enable Automatic Medium Register Selection bit (Register27.9) = 0, it means that the Register 22 bits[7:0] pointer must be updated which media is to be used. Register 22 bits[7:0] can still be written to to change the pointer to access the other bank.



Table 94: Global Status Register Page Any, Register 23

Bits	Field	Mode	HW SW Rst Rst	Description
23.15:1	Reserved		OCK	These bits must be read and left unchanged when performing a write.
23.0	Port 0 Interrupt	RO	0 0	1 = Interrupt on Port 0 = No Interrupt on Port Bit will stay high until active interrupts bits cleared on a read of register 19 of the corresponding port.

Table 95: LED Control Register Page Any, Register 24

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Disable LED	R/W	0x0	Retain	1 = Disable 0 = Enable
14:12	Pulse stretch duration	R/W	0x4	Retain	000 = No pulse stretching 001 = 21 ms to 42ms 010 = 42 ms to 84ms 011 = 84 ms to 170ms 100 = 170 ms to 340ms 101 = 340 ms to 670ms 110 = 670 ms to 1.3s 111 = 1.3s to 2.7s
11	Force Interrupt	R/W	0x0	Retain	1 = Force INTn pin to assert 0 = Normal operation
10:8	Blink Rate	R/W	0x1	Retain	000 = 42 ms 001 = 84 ms 010 = 170 ms 011 = 340 ms 100 = 670 ms 101 to 111 = Reserved
7	LED Duplex Control	R/W	0x0	Retain	See Bit 2
6	LED_TX Control (LSB)	R/W	0x0	Retain	bit 0,6 See section 2.22.2.3 for more details 00 = Transmit activity - solid on 01 = Transmit or receive activity - solid on 10 = Link and no activity - solid on. Transmit or receive activity - blink 11 = Transmit or receive activity - blink

Doc. No. MV-S100649-00, Rev. G

Table 95: LED Control Register (Continued)
Page Any, Register 24

Bits	Field	Mode	HW Rst	SW Rst	Description
5:3	LED_LINK Control	R/W	0x0	Retain	000 = Direct LED mode 011 = Master/Slave LED mode 001, 010, 100, 111, all other values = See Section 2.22.2.2 "Combined Link LED Modes" on page 109
2	LED_ DUPLEX Con- trol	R/W	0x0	Retain	Bit 7,2 - LED DUPLEX Behavior 00 Low = Full-duplex, High = Half-duplex, Blink = Collision 01 Low = Full-duplex, High = Half-duplex 10 Low = Fiber Link Up, High = Fiber Link Down 11 Reserved
1	LED_RX Control	R/W	0x0	Retain	See section 2.22.2.3 for more information. 1 = Receive activity/Link 0 = Receive activity
0	LED_TX control (MSB)	R/W	0x0	Retain	See bit 6

Table 96: Manual LED Override Register Page Any, Register 25

Bits	Field	Mode	HW	sw	Description
0	2		Rst	Rst	
15:14	SGMII Auto- Negotiation Timer	R/W	0x0	Retain	00 = 1.6 to 2.0 ms 01 = 0.50 to 0.60 us 10 = 0.98 to 1.2 us 11 = 2.1 to 2.3 us
13:12	Reserved				These bits must be read and left unchanged when performing a write.
11:10	LED_ DUPLEX	R/W	0x0	Retain	LED "Off" means LED pin output equals high. LED "On" means LED pin output equals low. 00 = Normal 01 = Blink 10 = LED Off 11 = LED On
9:8	LED_ LINK10	R/W	0x0	Retain	LED "Off" means LED pin output equals high. LED "On" means LED pin output equals low. 00 = Normal 01 = Blink 10 = LED Off 11 = LED On



Table 96: Manual LED Override Register (Continued)
Page Any, Register 25

Bits	Field	Mode	HW Rst	SW Rst	Description
7:6	LED_ LINK100	R/W	0x0	Retain	LED "Off" means LED pin output equals high. LED "On" means LED pin output equals low. 00 = Normal 01 = Blink 10 = LED Off 11 = LED On
5:4	LED_ LINK1000	R/W	0x0	Retain	LED "Off" means LED pin output equals high. LED "On" means LED pin output equals low. 00 = Normal 01 = Blink 10 = LED Off 11 = LED On
3:2	LED_RX	R/W	0x0	Retain	LED "Off" means LED pin output equals high. LED "On" means LED pin output equals low. 00 = Normal 01 = Blink 10 = LED Off 11 = LED On
1:0	LED_TX	R/W	0x0	Retain	LED "Off" means LED pin output equals high. LED "On" means LED pin output equals low. 00 = Normal 01 = Blink 10 = LED Off 11 = LED On

Table 97: Extended PHY Specific Control 2 Register Page Any, Register 26

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Reserved				This bit must be read and left unchanged when performing a write.
14	FCT PLL loop Bandwidth con- trol	R/W	0x0	Retain	1 = PLL bandwidth 2.2 Mhz 0 = PLL bandwidth 1.1 Mhz
13	FCT transmit- ter pre-empha- sis Control	R/W	0x0	Retain	1 = High pre-emphasis mode 0 = Low pre-emphasis mode
12	Reserved	R/W	0x0	Retain	Reserved

Extended PHY Specific Control 2 Register (Continued) Table 97: Page Any, Register 26

r age Arry, Register 20					
Bits	Field	Mode	HW Rst	SW Rst	Description
11:10	Autoselect pre- ferred media	R/W	0x0	Retain	00 = No Preference for Media 01 = Preferred Fiber Medium 10 = Preferred Copper Medium 11 = Reserved
9:8	SERDES pattern generation	R/W	0x0	Retain	When the fiber interface is enabled reg26[9:8] will control the pattern transmitted by the SERDES. Fixed square wave pattern can be generated so jitter can be measured. 0x = normal operation 10 = Generate K28.7 symbols (alternating five 0s and five 1s) 11 = generate D21.5 symbols (alternating 0s and 1s)
7	Enable External Fiber Signal Detect Input	R/W	See Descr	Update	Changes to this bit are disruptive to the normal operation; hence, any changes to these registers must be followed by a software reset to take effect. 1 = Use external hardware pins for signal detect 0 = Force signal detect to be good
6	Fiber Input Impedance	R/W	See Descr	Update	Changes to this bit are disruptive to the normal operation; hence, any changes to these registers must be followed by software reset to take effect. Upon hardware reset this bit defaults as follows: 75/50 OHM bit 26.6 0 0 1 1 1 1 = 75 ohm 0 = 50 ohm
5	Fiber Output Impedance	R/W	See Descr	Update	Changes to this bit are disruptive to the normal operation; hence, any changes to these registers must be followed by software reset to take effect. Upon hardware reset this bit defaults as follows: 75/50 OHM Bit 26.5 0 1 1 = 75 ohm 0 = 50 ohm



Table 97: Extended PHY Specific Control 2 Register (Continued)
Page Any, Register 26

	ı				A V Da
Bits	Field	Mode	HW Rst	SW Rst	Description
4	Fiber Mode Clock Enable	R/W	See Descr	Update	Changes to this bit are disruptive to the normal operation; therefore, any changes to these registers must be followed by a software reset to take effect. Upon hardware reset this bit defaults as follows: HWCFG_MODE[3:0] Bit 26.4 0000 1 0110 1 1110 1 all other configurations 0 1 = Power up TC± drivers to use as output clock 0 = Power down TC± drivers and use TC± as differential signal detect pins To enable fiber mode clock by writing this bit to 0, chip needs to be in one of the following modes: 0010,0011,0111,01110,1110,xx00
3	Reserved	KIN			This bit must be read and left unchanged when performing a write.
2:0	Fiber Output Amplitude (100 ohm differential load) Fiber Output Amplitude (150 ohm differential load)	R/W R/W	010 010	Retain Retain	0.50V - 1.20V = Differential voltage peak-to-peak measured with 100 ohm differential load. 000 = 0.50V 001 = 0.60V 010 = 0.70V 011 = 0.80V 100 = 0.90V 101 = 1.00V 110 = 1.10V 111 = 1.20V 0.62V - 1.32V = Differential voltage peak-to-peak measured with 150 ohm differential load. 000 = 0.62V 001 = 0.72V 010 = 0.82V 011 = 0.92V 100 = 1.02V 101 = 1.12V 110 = 1.22V 111 = 1.32V

Table 98: Extended PHY Specific Status Register Page Any, Register 27

	i age Airy, Register 27				
Bits	Field	Mode	HW Rst	SW Rst	Description
15	Fiber/Copper Auto Selection Disable	R/W	See Descr	Update	Changes to this bit are disruptive to the normal operation; hence, any changes to these registers must be followed by software reset to take effect. Upon hardware reset this bit defaults as follows: DIS_FC Bit 27.15 0 0 1 1 1 = Disable fiber/copper auto-selection 0 = Enable fiber/copper auto-selection
14	Reserved	* 18			This bit must be read and left unchanged when performing a write.
13	Fiber/Copper resolution	RO	0x0	Retain	Register 27.13 indicates the resolution of the Fiber/Copper Auto Detection. This bit is valid only when link is up. 1 = Fiber link 0 = Copper link
12	Serial Interface Auto- Negotiation bypass enable	R/W	See Descr	Update	Changes to this bit are disruptive to the normal operation; hence, any changes to these registers must be followed by software reset to take effect. The default value for Register 12 =1 for the following modes: 0111 = GMII to fiber 0011 = RGMII to fiber 1000 = GBIC mode
11	Serial Interface Auto- Negotiation bypass status	RO	0x0	Retain	For SGMII mode, if the bypass logic brings up the serial interface link, copper Auto-Negotiation will restart and advertise only gigabit speed. If this bit is 1, then bit 17_1.11 will be 0. 1 = Serial interface link came up because bypass mode timer timed out and fiber Auto-Negotiation was bypassed. 0 = Serial interface link came up because regular fiber Auto-Negotiation completed.
10	Interrupt Polarity	R/W	See Descr	Update	Changes to this bit are disruptive to the normal operation; hence, any changes to these registers must be followed by software reset to take effect. Default takes the value of INT_POL. 1 = INT active low 0 = INT active high
9	Disable/Enable Automatic Medium Regis- ter Selection	R/W	0x0	Retain	1 = Disable automatic medium register selection 0 = Enable automatic medium register selection



Table 98: Extended PHY Specific Status Register (Continued)
Page Any, Register 27

Bits	Field	Mode	HW	sw	Description
8:5	DTE detect sta- tus drop hyster- esis	R/W	0x4	Retain	0000: report immediately 0001: report 5s after DTE power status drop 1111: report 75s after DTE power status drop
4	DTE power sta- tus	RO	0x0	Retain	1 = Link partner needs DTE power 0 = Link partner does not need DTE power
3:0	HWCFG_MODE	R/W	See Descr	Update	Changes to these bits are disruptive to the normal operation; hence, any changes to these registers must be followed by software reset to take effect. Upon hardware reset Register 27.3:0 defaults to the value in HWCFG_MODE[3:0]. 0000 = SGMII with Clock with SGMII Auto-Neg to copper 0100 = SGMII without Clock with SGMII Auto-Neg to copper 1000 = 1000BASE-X without Clock with 1000BASE-X Auto-Neg to copper (GBIC) 1100 = 1000BASE-X without Clock without 1000BASE-X X Auto-Neg to copper 0001 = Reserved 0101 = Reserved 1001 = RTBI to Copper 1001 = RGMII to Copper 1101 = TBI to copper 0110 = RGMII to SGMII 1010 = RGMII to SGMII 1011 = GMII to Fiber 1011 = RGMII to Fiber 1011 = RGMII to Fiber 1011 = RGMII to copper

Table 99: MDI[0] Virtual Cable Tester™ Status Register, Page 0 Page 0, Register 28

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Run VCT™ Test	R/W, SC	0x0	Retain	1 = Run VCT test 0 = VCT test completed

Table 99: MDI[0] Virtual Cable Tester™ Status Register, Page 0 (Continued) Page 0, Register 28

Bits	Field	Mode	HW Rst	SW Rst	Description
14:13	Status	RO	0x0	Retain	MDI[0] ± VCT™ test result 00 = Valid test, normal cable (no short or open in cable) 01 = Valid test, short in cable (Impedance < 33 ohms) 10 = Valid test, open in cable (Impedance greater than 330 ohms) 11 = Test Fail
12:8	Amplitude	RO 80/8	0x00	Retain	Amplitude of reflection on pair MDI[0]±.These amplitude bits range from 0x07 to 0x1F. 0x1F = Maximum positive amplitude (+1) 0x10 = Zero amplitude 0x00 = Maximum negative amplitude (-1)
7:0	Distance	RO	0x00	Retain	Approximate distance (± 1m) to the open/short location on Pair MDI[0]±, measured at nominal conditions (room temperature and typical VDDs). Refer to the "VCT™ How to Use TDR Results" application note for distance to fault details.

Table 100: MDI[1] Virtual Cable Tester™ Status Register, Page 1
Page 1, Register 28

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Disable waiting period	R/W	0x0	Retain	1 = Start VCT without waiting to bring link down 0 = Wait for link down before starting VCT test
14:13	Status	RO	0x0	Retain	MDI[1] ± VCT test result 00 = Valid test, normal cable (no short or open in cable) 01 = Valid test, short in cable (Impedance < 33 ohms) 10 = Valid test, open in cable (Impedence greater than 330 ohms) 11 = Test Fail
12:8	Amplitude	RO	0x00	Retain	Amplitude of reflection on pair MDI[1]±.These amplitude bits range from 0x07 to 0x1F. 0x1F = Maximum positive amplitude (+1) 0x10 = Zero amplitude 0x00 = Maximum negative amplitude (-1)
7:0	Distance	RO	0x00	Retain	Approximate distance (± 1m) to the open/short location on Pair MDI[1]±, measured at nominal conditions (room temperature and typical VDDs). Refer to the "VCT How to Use TDR Results" application note for distance to fault details.



Table 101: MDI[2] Virtual Cable Tester™ Status Register, Page 2 Page 2, Register 28

88E1111

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Reserved			NO P	This bit must be read and left unchanged when performing a write.
14:13	Status	RO	0x0	Retain	 MDI[2] ± VCT™ test result 00 = Valid test, normal cable (no short or open in cable) 01 = Valid test, short in cable (Impedance < 33 ohms) 10 = Valid test, open in cable (Impedance greater than 330 ohms) 11 = Test Fail
12:8	Amplitude	RO *	0x00	Retain	Amplitude of reflection on pair MDI[2]±.These amplitude bits range from 0x07 to 0x1F. 0x1F = Maximum positive amplitude (+1) 0x10 = Zero amplitude 0x00 = Maximum negative amplitude (-1)
7:0	Distance	RO	0x00	Retain	Approximate distance (± 1m) to the open/short location on Pair MDI[2]±, measured at nominal conditions (room temperature and typical VDDs). Refer to the "VCT How to Use TDR Results" application note for distance to fault details.

Table 102: MDI[3] Virtual Cable Tester™ Status Register, Page 3
Page 3, Register 28

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Reserved				This bit must be read and left unchanged when performing a write.
14:13	Status	RO	0x0	Retain	MDI[3] ± VCT test result 00 = Valid test, normal cable (no short or open in cable) 01 = Valid test, short in cable (Impedance < 33 ohms) 10 = Valid test, open in cable (Impedance greater than 330 ohms) 11 = Test Fail
12:8	Amplitude	RO	0x00	Retain	Amplitude of reflection on pair MDI[3]±.These amplitude bits range from 0x07 to 0x1F. 0x1F = Maximum positive amplitude (+1) 0x10 = Zero amplitude 0x00 = Maximum negative amplitude (-1)

Table 102: MDI[3] Virtual Cable Tester™ Status Register, Page 3 Page 3, Register 28

Bits	Field	Mode	HW Rst	SW Rst	Description
7:0	Distance	RO	0x00	Retain	Approximate distance (± 1m) to the open/short location on Pair MDI[3]±, measured at nominal conditions (room temperature and typical VDDs). Refer to the "VCT How to Use TDR Results" application note for distance to fault details.



MARVELL CONFIDENTIAL

Note

Page 0-3 reg 28{14:0] are valid after the completion of VCT™ (Page 0, bit 28.15 is 0).

Table 103: 1000 BASE-T Pair Skew Register, Page 4
Page 4, Register 28

Bits	Field	Mode	HW Rst	SW Rst	Description
15:12	Pair 7,8 (MDI[3]±)	RO	0x0	0x0	Skew = Bit value x 8 ns. Value is correct to within ± 8ns.
11:8	Pair 4,5 (MDI[2]±)	RO	0x0	0x0	Skew = Bit value x 8 ns. Value is correct to within ± 8ns.
7:4	Pair 3,6 (MDI[1]±)	RO	0x0	0x0	Skew = Bit value x 8 ns. Value is correct to within ± 8ns.
3:0	Pair 1,2 (MDI[0]±)	RO	0x0	0x0	Skew = Bit value x 8 ns. Value is correct to within ± 8ns. The contents of 28_4.15:0 are valid only if Register 28_5.6 = 1



Table 104: 1000 BASE-T Pair Swap and Polarity, Page 5
Page 5, Register 28

Bits	Field	Mode	HW Rst	SW Rst	Description
15:7	Reserved			NO P	These bits must be read and left unchanged when performing a write.
6	Register 28_4 and 28_5 are valid	RO	0x0	0x0	1= Valid 0 = Invalid
5	C, D Crossover	RO	0x0	0x0	1 = Channel C received on MDI[2]± Channel D received on MDI[3]± 0 = Channel D received on MDI[2]± Channel C received on MDI[3]±
4	A, B Crossover	RO	0x0	0x0	1 = Channel A received on MDI[0]± Channel B received on MDI[1]± 0 = Channel B received on MDI[0]± Channel A received on MDI[1]±
3	Pair 7,8 (MDI[3]±) Polarity	RO	0x0	0x0	1 = Negative 0 = Positive
2	Pair 4,5 (MDI[2]±) Polarity	RO	0x0	0x0	1 = Negative 0 = Positive
1 405	Pair 3,6 (MDI[1]±) Polarity	RO	0x0	0x0	1 = Negative 0 = Positive
0	Pair 1,2 (MDI[0]±) Polarity	RO	0x0	0x0	1 = Negative 0 = Positive The contents of 28_5.15:0 are valid only if Register 28_5.6 = 1

Table 105: Extended Address
Page Any, Register 29

Bits	Field	Mode	HW Rst	SW Rst	Description
15:5	Reserved			C P	These bits must be read and left unchanged when performing a write.
4:0	Page select	R/W	0x00	Retain	00000 = No register 30 page access or Page 0 of register 30 00011 = Select Page 3 of register 30 00111 = Select Page 7 of register 30 01100 = Select Page 12 of register 30 10000 = Select Page 16 of register 30 10010 = Select Page 18 or register 30

Table 106: Calibration Override Page 3, Register 30

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Restart Calibra- tion	R/W, SC	0x0	Retain	Calibration will start once bit 15 is set to 1. 0 = Normal 1 = Restart
14	Calibration Complete	RO	0x0	Retain	Calibration is done once bit 14 becomes 1. 0 = Not done 1 = Done
13	Reserved				This bit must be read and left unchanged when performing a write.
12:8	PMOS Value	R/W	See Descr	Retain	00000 = All fingers off 11111 = All fingers on Register reflects on the calibrated value after hardware reset.
7	Reserved				This bit must be read and left unchanged when performing a write.
6	LATCH	R/W, SC	0x0	Retain	1 = Latch in new value Once LATCH is set to 1 the new calibration value is written into the I/O pad. The automatic calibrated value is lost.
5	PMOS/NMOS Select	R/W	0x0	Retain	1 = PMOS 0 = NMOS If select set to 1 the PMOS value is written into when LATCH is set to 1. If select set to 0 the NMOS value is written into when LATCH is set to 0.



Table 106: Calibration Override (Continued) Page 3, Register 30

Bits	Field	Mode	HW Rst	SW Rst	Description
4:0	NMOS value	R/W	See Descr	Retain	00000 = All fingers off 11111 = All fingers on Register reflects on the calibrated value after hardware reset.

Table 107: Force Gigabit Mode Page 7, Register 30

Bits	Field	Mode	HW Rst	SW Rst	Description
15:4	Reserved	S			These bits must be read and left unchanged when performing a write.
3	Force Gigabit Mode	R/W	0	Retain	The Force Gigabit Mode bit is used for the Gigabit stub loopback mode. See Section 2.14.3.2 "Enabling 1000 Mbps Stub Loopback" on page 94 for details. 1 = Forced Gigabit 0 = Not forced
2:0	Reserved				These bits must be read and left unchanged when performing a write.

Table 108: Transmitter Type Page 11, Register 30

Bits	Field	Mode	HW Rst	SW Rst	Description
15	Transmitter Type	R/W	0	Retain	1 = Class A 0 = Class B
14:0	Reserved				These bits must be read and left unchanged when performing a write.

Table 109: CRC checker result Page 12, Register 30

Bits	Field	Mode	HW Rst	SW Rst	Description
15:8	Frame count	RO	0x00	Retain	Frame count is stored in these bits. 00000000 = No frame counted 11111111 = Maximum number of frames counted The counter does not clear on a read command. To clear the CRC error counter, disable the crc_checker (Register 30_16.15 = 0).
7:0	CRC error count	RO	0x00	Retain	Error counter is stored in these bits. 00000000 = No frame counted 11111111 = Maximum number of frame counted The counter does not clear on a read command. To clear the CRC error counter, disable the crc_checker (Register 30_16.15 = 0).

Table 110: Test Enable Control Page 16, Register 30

Bits	Field	Mode	HW Rst	SW Rst	Description
15:2	Reserved				These bits must be read and left unchanged when performing a write.
1	Enable Gigabit Stub Loopback	R/W	0x0	Retain	1 = Enable Gigabit Stub loopback 0 = Normal operation
0	Enable CRC checker	R/W	0x0	Retain	1 = Enable CRC checker 0 = Disable CRC checker, clear frame counter and CRC error counter (Register 30_1215:0 = 0x0000)



Table 111: Miscellaneous Control Page 18, Register 30

88E1111

Bits	Field	Mode	HW Rst	SW Rst	Description
15:12	Reserved	RW	0x8	Retain	These bits must be read and left unchanged when performing a write.
11:9	Calibration PMOS Target Impedance	RW	0x1	Retain	000 = 80 ohm 001 = 69 ohm 100 = 49 ohm 101 = 44 ohm 110 = 41 ohm 111 = 38 ohm
8:6	Calibration NMOS Target Impedance	RW	0x1	Retain	000 = 80 ohm 001 = 69 ohm 100 = 49 ohm 101 = 44 ohm 110 = 41 ohm 111 = 38 ohm
5:2	Packet Generator	RW	0x00	Retain	Bit 5: 1 = Packet generation enable, 0 = Disable Bit 4: 0 = Random, 1 = 0x5a (packet pattern select) Bit 3: 0 = 64 byte, 1 = 1518 byte (packet length select) Bit 2: 1 = Generate error packet, 0 = No error
1	Reserved	RW	0x00	Retain	These bits must be read and left unchanged when performing a write.
0	Turn off NEXT Canceller	RW	0x0	Retain	0 = Enable NEXT 1 = Disable NEXT

Table 112: Reserved Registers Page Any, Register 31

Bits	Field	Mode	HW Rst	SW Rst	Description
15:0	Reserved				These bits must be read and left unchanged when performing a write.

Section 4. Electrical Specifications

4.1 Absolute Maximum Ratings

Stresses above those listed in Absolute Maximum Ratings may cause permanent device failure. Functionality at or above these limits is not implied. Exposure to absolute maximum ratings for extended periods may affect device reliability.

Symbol	Parameter	Min	Тур	Max	Units
A _{VDD}	Power Supply Voltage on VDDA with respect to VSS	-0.5		2.75	V
D _{VDD}	Power Supply Voltage on DVDD with respect to VSS	-0.5		1.32	V
V_{DDO}	Power Supply Voltage on VDDO with respect to VSS	-0.5		2.75	V
V _{PIN}	Voltage applied to any input pin	-0.5		3.6	V
T _{STORAGE}	Storage temperature	-55		+125 ¹	°C

 ^{1. 125 °}C is only used as bake temperature for not more than 24 hours. Long term storage (e.g weeks or longer) should be kept at 85 °C or lower.

February 10, 2006, Preliminary



4.2 Recommended Operating Conditions

Symbol	Parameter	Condition	Min	Тур	Max	Units
A _{VDD}	AVDD supply ¹	For AVDD	2.37	2.5	2.63	V
D_{VDD}	DVDD supply	For DVDD	0.95	1.0 ²	1.32	V
V_{DDO}	VDDO supply	For VDDO, VDDOH, VDDOX	2.37	2.5	2.63	V
RSET	Internal bias reference	Resistor connected to V _{SS}		5000 ± 1% Tolerance		Ω
T _A	Ambient operating	Commercial Parts	0		70 ³	°C
	temperature	Industrial Parts ⁴	-40		85	°C
T _J	Maximum junction temperature				125 ²	°C

Although VDDOH, VDDOX, and VDDO can operate over a wide range, only the voltage ranges specified are tested and guaranteed.

^{2.} Instead of 1.0V, 1.2V can be used.

^{3.} The important parameter is maximum junction temperature. As long as the maximum junction temperature is not exceeded, the device can be operated at any ambient temperature. Refer to White Paper on "TJ Thermal Calculations" for more information.

^{4.} Industrial part numbers have an "I" following the commercial part numbers. See Section 6.1 "Ordering Part Numbers and Pack age Markings" on page 249.

4.3 Package Thermal Information

4.3.1 Thermal Conditions for 117-Pin TFBGA Package

Symbol	Parameter	Condition	Min	Тур	Max	Units
θ_{JA}	Thermal resistance - junction to	JEDEC 3 in. x 4.5 in. 4-layer PCB with no air flow		38.30		°C/W
	ambient of the 88E1111 device 117-Pin TFBGA package $\theta_{JA} = (T_J - T_A)/P$ $P = Total Power Dissipation$ Thermal characteristic parameter ¹ - junction to top center of the 88E1111 device 117-Pin TFBGA package $\psi_{JT} = (T_J - T_C)/P.$ $P = Total Power Dissipation$ Thermal resistance ¹ - junction to case of the 88E1111 device 117-Pin TFBGA package	JEDEC 3 in. x 4.5 in. 4-layer PCB with 1 meter/sec air flow		33.90		°C/W
		JEDEC 3 in. x 4.5 in. 4-layer PCB with 2 meter/sec air flow		32.00		°C/W
		JEDEC 3 in. x 4.5 in. 4-layer PCB with 3 meter/sec air flow		30.90		°C/W
ΨJT	parameter ¹ - junction to top center of the 88E1111 device 117-Pin TFBGA package $\psi_{JT} = (T_J - T_c)/P$.	JEDEC 3 in. x 4.5 in. 4-layer PCB with no air flow		0.27		°C/W
θ _{JC}	tion to case of the 88E1111	JEDEC with no air flow		10.10	277	°C/W
θ_{JB}	Thermal resistance ¹ - junction to board of the 88E1111 device 117-Pin TFBGA package	JEDEC with no air flow	O C	31.10		°C/W
	$\theta_{JB} = (T_J - T_B)/P_{bottom}$ $P_{bottom} = power dissipation$ from the bottom of the package to the PCB surface.	* Q100				

^{1.} Refer to white paper on TJ Thermal Calculations for more information

4.3.2 Thermal Conditions for 96-Pin BCC Package

	т.		1	1	1	
Symbol	Parameter	Condition	Min	Тур	Max	Units
θ_{JA}	Thermal resistance - junction to	JEDEC 3 in. x 4.5 in. 4-layer PCB with no air flow		25.00		°C/W
	ambient of the 88E1111 device 96-Pin BCC package	JEDEC 3 in. x 4.5 in. 4-layer PCB with 1 meter/sec air flow		23.60		°C/W
	$\theta_{JA} = (T_J - T_A)/P$ P = Total Power Dissipation	JEDEC 3 in. x 4.5 in. 4-layer PCB with 2 meter/sec air flow		20.90		°C/W
ΨЈΤ	Thermal characteristic parameter ¹ - junction to top center of the 88E1111 device 96-Pin BCC package $\psi_{JT} = (T_J - T_c)/P.$ P = Total Power Dissipation	JEDEC 3 in. x 4.5 in. 4-layer PCB with no air flow		1.3		°C/W
θ _{JC}	Thermal resistance 1 - junction to case of the 88E1111 device 96-Pin BCC package $\theta_{JC} = (T_J - T_C)/P_{Top} P_{Top} = Power Dissipation from the top of the package$	JEDEC with no air flow		20.50	200	°C/W
θ _{JB}	Thermal resistance ¹ - junction to board of the 88E1111 device 96-Pin BCC package	JEDEC with no air flow		9.60	C N	°C/W
O	$\theta_{\text{JB}} = (T_{\text{J}} - T_{\text{B}}) / P_{\text{bottom}}$ $P_{\text{bottom}} = \text{power dissipation}$ from the bottom of the package to the PCB surface.		_4		OP.	

^{1.} Refer to white paper on TJ Thermal Calculations for more information.

4.3.3 Thermal Conditions for 128-Pin PQFP Package

Symbol	Parameter	Condition	Min	Тур	Max	Units
θ_{JA}	Thermal resistance - junction to ambient of the	JEDEC 3 in. x 4.5 in. 4-layer PCB with no air flow		34.50		°C/W
	88E1111 device 128-Pin PQFP package	JEDEC 3 in. x 4.5 in. 4-layer PCB with 1 meter/sec air flow		31.50		°C/W
	$\theta_{JA} = (T_J - T_A)/P$ P = Total Power Dissipation	JEDEC 3 in. x 4.5 in. 4-layer PCB with 2 meter/sec air flow		30.20		°C/W
	N. S.	JEDEC 3 in. x 4.5 in. 4-layer PCB with 3 meter/sec air flow		29.50		°C/W
ΨJT	Thermal characteristic parameter - junction to top center of the device 128-Pin PQFP package	JEDEC 3 in. x 4.5 in. 4-layer PCB with no air flow		3.22		°C/W
θјс	Thermal resistance 1 - junction to case of the 88E1111 device 128-Pin PQFP package $\theta_{JC} = (T_{J} - T_{C})/P_{Top} \\ P_{Top} = Power Dissipation from the top of the package$	JEDEC with no air flow		17.40	0000 X	°C/W
θЈВ	Thermal resistance ¹ - junction to board of the 88E1111 device 128-Pin PQFP package $\theta_{JB} = (T_J - T_B)/P_{bottom} \\ P_{bottom} = power dissipation from the bottom of the package to the PCB surface.$	JEDEC with no air flow		26.60		°C/W

^{1.} Refer to white paper on TJ Thermal Calculations for more information.

4.4 DC Electrical Characteristics

4.4.1 Current Consumption AVDDH, AVDDL

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Pins	Condition	Min	Typ ¹	Max	Units
I _{AVDD}	2.5V Power to analog core	AV _{DDH} , AV _{DDL}	GMII/RGMII/TBI/RTBI over 1000BASE-T with traffic		160		mA
		Ö.S	SERDES/SGMII over 1000BASE-T with traffic		170		mA
		601	GMII/RGMII over 1000BASE-X with traffic		9		mA
		" A LAN.	RGMII/MII over 100BASE- TX with traffic		70		mA
	¹ 6		RGMII/MII over 10BASE-T with traffic		52		mA
	16.4		COMA		0		mA 🙀
	27.07	ř	Sleep (Energy Detect and Energy Detect+™)		17		mA
	83,1		Power Down		13		mA

^{1.} The values listed are typical values with six LEDs per port and Auto-Negotiation on.

4.4.2 Current Consumption VDDO, VDDOX, VDDOH

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Pins	Condition M	/lin	Typ ¹	Max	Units
I _{VDDO}	2.5V Power to outputs	$V_{DDO,}V_{DDOX,}$ V_{DDOH}	GMII/RGMII/TBI/RTBI over 1000BASE-T with traffic		37		mA
			SERDES/SGMII over 1000BASE-T with traffic	3	15		mA
			GMII/RGMII over 1000BASE-X with traffic	0	39		mA
			RGMII/MII over 100BASE- TX with traffic		10		mA
			RGMII/MII over 10BASE-T with traffic		8		mA
			COMA		0		mA
			Sleep (Energy Detect and Energy Detect+™)		19		mA
			Power Down		9		mA

^{1.} The values listed are typical values with six LEDs per port and Auto-Negotiation on.

Doc. No. MV-S100649-00, Rev. G

4.4.3 Current Consumption Center_Tap

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Pins	Condition	Min	Typ ¹	Max	Units
I _{CENTER} _ TAP	2.5V Power to center tap	External Mag- netics Center Tap Pin	GMII/RGMII/TBI/RTBI over 1000BASE-T with traffic (CLASS B Drivers used)		92.5		mA
		Ŏ	GMII/RGMII/TBI/RTBI over 1000BASE-T with traffic (CLASS A Drivers used)		184		mA
		SO TO	SERDES/SGMII over 1000BASE-T with traffic		95		mA
	4	6.06.71	RGMII/MII over 100BASE- TX with traffic		26		mA
	*	ZIP	RGMII/MII over 10BASE-T with traffic		75		mA
	,014		COMA		0		mA
	, ø19_K		Sleep (Energy Detect and Energy Detect+™)		0		mA .
	370		Power Down		0		mA

^{1.} The values listed are typical values with six LEDs per port and Auto-Negotiation on.

4.4.4 Current Consumption DVDD

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Pins	Condition	Min	Typ ¹	Max	Units
I _{DVDD}	1.0V Power to digital core	DV _{DD}	GMII/RGMII/TBI/RTBI over 1000BASE-T with traffic	47	250		mA
			SERDES/SGMII over 1000BASE-T with traffic		253		mA
			GMII/RGMII over 1000BASE-X with traffic		19		mA
			RGMII/MII over 100BASE- TX with traffic		29		mA
			RGMII/MII over 10BASE-T with traffic		9		mA
			COMA		8		mA
			Sleep (Energy Detect and Energy Detect+™)		8		mA
			Power Down		9		mA

^{1.} The values listed are typical values with six LEDs per port and Auto-Negotiation on.



4.5 DC Operating Conditions

88E1111

4.5.1 Digital Pins

4.5.1.1 VDDOH

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Pins ¹	Condition	Min	Тур	Max	Units
VIH_ VDDOH	Input high voltage VDDOH	All digital inputs on VDDOH	VDDOH = 2.5V	2.0		3.47	V
VIL_ VDDOH	Input low voltage VDDOH	All digital inputs on VDDOH	VDDOH = 2.5V	-0.3		0.8	V
VOH_ VDDOH	High level output voltage VDDOH	All digital outputs on VDDOH	IOH = -4 mA	VDDOH - 0.2V			V
VOL_ VDDOH	Low level out- put voltage VDDOH	All digital outputs on VDDOH except LED	IOL = 4 mA			0.2	VO.
VOL_LED	Low level out- put voltage LED	All digital LED outputs	IOL = 8 mA		4	0.2	V

^{1.} VDDOH supplies CONFIG[4:0], GCONFIG0, GCONFIG1, SEL_FREQ, XTAL1, XTAL2, LED_LINK10, LED_LINK100, LED_LINK1000, LED_DUPLEX, LED_RX, LED_TX. Although VDDOH requires 2.5V, these digital input pins are 3.3V tolerant.

Doc. No. MV-S100649-00, Rev. G

4.5.1.2 VDDOX

MARVELL CONFIDENTIAL

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

	T.	T	- X - X - X - X - X - X - X - X - X - X		1		ı
Symbol	Parameter	Pins ¹	Condition	Min	Тур	Max	Units
VIH_	Input high	All digital inputs	VDDOX = 2.5V	2.0		3.47	V
VDDOX voltage VDDOX	on VDDOX	VDDOX = 1.5V	1.05		VDDOX + 0.6V	V	
VIL_	Input low	All digital inputs	VDDOX = 2.5V	-0.3		0.8	V
VDDOX	VDDOX on VDDOX	OU ADDOX	VDDOX = 1.5V	-0.3		0.45	V
VOH_ VDDOX	High level output	All digital outputs on VDDOX	IOH = -4 mA VDDOX = 2.5V	VDDOX - 0.2V			V
	voltage VDDOX		IOH = -2 mA VDDOX = 1.5V	VDDOX - 0.2V			V
VOL_ VDDOX	Low level out-	All digital outputs on VDDOX	IOL = 4 mA VDDOX = 2.5V			0.4	V 10.
	voltage VDDOX		IOL = 2 mA VDDOX = 1.5V			0.2	V

^{1.} VDDOX supplies RESET, COMA, MDC, MDIO, CLK125, INT, TDI, TMS, TCK, TRSTn, TDO. Although VDDOX requires 2.5V, these digital input pins are 3.3V tolerant.



88E1111

4.5.1.3 VDDO

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Pins ¹	Condition	Min	Тур	Max	Units	
VIH_ VDDO	Input high voltage VDDO	All digital inputs on VDDO	VDDO = 2.5V	1.7 ²		3.47	V	
VIL_ VDDO	Input low voltage VDDO	All digital inputs on VDDO	VDDO = 2.5V	-0.3		0.8	V	
VOH_ VDDO	High level output voltage VDDO	All digital outputs on VDDO	IOH = -4 mA	VDDO - 0.2V			V	
VOL_ VDDO	Low level output voltage VDDO	All digital outputs on VDDO except LED	IOL = 4 mA			0.2	V	

^{1.} VDDO supplies GTX_CLK, TX_CLK, TX_EN, TX_ER, TXD[7:0], RX_CLK, RX_DV, RX_ER, RXD[7:0], CRS, and COL. The input pins that are listed are 3.3V tolerant.

4.5.1.4 MISC

MARVELL CONFIDENTIAL

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Pins	Condition	Min	Тур	Max	Units
IILK	Input leakage current	With internal pull-up resistor			O O	+10 ¹ -50	uA
		All others without resistor		0,05		±10	uA
CIN	Input capacitance	All pins		5		5	pF

^{1. &}quot;+" is current into pin, "-" is current out of pin.

The VIH values in this DC table are not to be confused with the VIH values in the AC table. See IEEE Clause 35 GMII interface description for details.

4.5.2 Internal Resistor Description

117-Pin TFBGA Pin #	96-Pin BCC Pin #	128-Pin PQFP Pin #	Pin Name	Resistor
L7	44	67	TDI	150 kohm Internal pull-up
L8	46	69	TMS	150 kohm Internal pull-up
L9	49	70	TCK	150 kohm Internal pull-up
M9	47	68	TRSTn	150 kohm Internal pull-up
Н8	56	77	SEL_FREQ	Internal pull-up
	4	670.	Others	none



4.6 IEEE DC Transceiver Parameters

IEEE tests are typically based on template and cannot simply be specified by a number. For an exact description of the template and the test conditions, refer to the IEEE specifications.

-- 10BASE-T IEEE 802.3 Clause 14

88E1111

-- 100BASE-TX ANSI X3.263-1995

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Pins	Condition	Min	Тур	Max	Units
V _{ODIFF}	Absolute peak differential	MDI[1:0]	10BASE-T no cable	2.2	2.5	2.8	V
	output voltage	MDI[1:0]	10BASE-T cable model	585 ¹			mV
		MDI[1:0]	100BASE-TX mode	0.950	1	1.050	V
	3	MDI[3:0]	1000BASE-T ²	0.67	0.75	0.82	V
	Overshoot ²	MDI[1:0]	100BASE-TX mode	0		5%	V
	Amplitude Symmetry (positive/ negative)	MDI[1:0]	100BASE-TX mode	0.98x		1.02x	V+/V-
V _{IDIFF}	Peak Differential Input Voltage	MDI[1:0]	10BASE-T mode	585 ³		70	mV S
"etge"	Signal Detect Assertion	MDI[1:0]	100BASE-TX mode	1000	460 ⁴		mV peak- peak
7	Signal Detect De-assertion	MDI[1:0]	100BASE-TX mode	200	360 ⁵		mV peak- peak

- 1. IEEE 802.3 Clause 14, Figure 14.9 shows the template for the "far end" wave form. This template allows as little as 495 mV peak differential voltage at the far end receiver.
- 2. IEEE 802.3ab Figure 40 -19 points A&B.
- 3. The input test is actually a template test; IEEE 802.3 Clause 14, Figure 14.17 shows the template for the receive wave form.
- 4. The ANSI TP-PMD specification requires that any received signal with peak-to-peak differential amplitude greater than 1000 mV should turn on signal detect (internal signal in 100BASE-TX mode). The 88E1111 device will accept signals typically with 460 mV peak-to-peak differential amplitude.
- 5. The ANSI TP-PMD specification requires that any received signal with peak-to-peak differential amplitude less than 200 mV should de-assert signal detect (internal signal in 100BASE-TX mode). The 88E1111 device will reject signals typically with peak-to-peak differential amplitude less than 360 mV.

Doc. No. MV-S100649-00, Rev. G

4.6.1 Serial and SGMII Interface


4.6.1.1 Transmitter DC Characteristics

Symbol	Parameter ¹	Min	Тур	Max	Units
V _{OH}	Output Voltage High			1600	mV
V _{OL} Output Voltage Low		800			mV
V _{RING}	Output Ringing			10	mV
V _{OD} ² Output Voltage Swing (differential, peak)		Programmable - see Table 97.			mV peak
V _{OS}	V _{OS} Output Offset Voltage		Variable - see 4.6.1.2 for details.		
R _O	Output Impedance (single-ended) (50 ohm termination)	40		60	ohm
	Output Impedance (single-ended) (75 ohm termination)	60		90	
Delta R _O	Mismatch in a pair			10	%
Delta V _{OD}	Change in V _{OD} between 0 and 1			25	mV
Delta V _{OS}	Change in V _{OS} between 0 and 1			25	mV
I _{S+} , I _{S-}	Output current on short to VSS			40	mA
I _{S+-}	Output current when S_OUT+ and S_OUT- are shorted			12	mA
I _{X+} , I _{X-}	Power off leakage current			10	mA

See Section 2.1.1.2 "Fiber Interface" on page 45 for details. Parameters are measured with outputs AC connected with 100 ohm differential load.

Figure 40: CML I/Os

MARVELL CONFIDENTIAL



Copyright © 2006 Marvell

^{2.} Output amplitude is programmable by writing to Register 26.2:0.



4.6.1.2 Common Mode Voltage (Voffset) Calculations

There are four different main configurations for the SGMII/Fiber interface connections. These are:

DC connection to an LVDS receiver

88E1111

- AC connection to an LVDS receiver
- DC connection to an CML receiver
- · AC connection to an CML receiver

If AC coupling or DC coupling to an LVDS receiver is used, the DC output levels are determined by the following:

- The output voltage swing is programmed by Register 26_2.2:0 (seeTable 97).
- Voffset (i.e., common mode voltage) = Internal bias Single-ended peak-peak voltage swing. See Figure 41 for details

If DC coupling is used with a CML receiver, then the DC levels will be determined by a combination of the MACs output structure, and the 88E1111 input structure shown in the CML Inputs diagram in Figure 42. Assuming the same MAC CML voltage levels and structure, the common mode output levels will be determined by:

Voffset (i.e., common mode voltage) = Internal bias - Single-ended peak-peak voltage swing/2. See Figure 42 for details.


CML Outputs Internal bias1 V = Internal bias - Vpeak AC doupling Cap. 50 ohm 50 ohm s_out V = Voffset s_out-(opposite of S_OUT+) sink 1. Internal bias is generated from the AVDDH supply and is typically 1.4V. Single-ended Voltage details Internal bias - Vpeak Vpeak V = Voffset (i.e., common mode voltage) = Internal bias - Vpeak-peak S OUT+ Vmin = Internal bias - 3 * Vpeak Vmin must be greater than 700 mV Internal bias - Vpeak S_OUT-


Figure 41: AC connections (CML or LVDS receiver) or DC connection LVDS receiver



Figure 42: DC connection to a CML receiver

88E1111






Symbol	Parameter	Min	Тур	Max	Units
V _I	Input DC Voltage range S_IN+ or S_IN-	750		1650	mV
V _{IDTH} ¹	Input Differential Threshold S_IN+ - S_IN- , SD+ - SD-	50			mV (peak differential)
V _{HYST} ¹	Input Differential Hysteresis	25			mV
R _{IN}	Receiver 100 ohm Differential Input Impedance	80		120	ohm
	Receiver 150 ohm Differential Input Impedance	120		180	ohm

^{1.} Receiver is at high level when V_{S_IN+} - V_{S_IN} is greater than V_{IDTH}(min) and is at low level when V_{S_IN+} - V_{S_IN} is less than - V_{IDTH}(min). A minimum hysteresis of V_{HYST} is present between -V_{IDTH} and +V_{IDTH} as shown in the figure. When the fiber link is down, an offset is applied to prevent false signal detect due to noise. When the fiber link is up, the offset circuit is disabled.

Figure 43: Input Differential Hysteresis





4.7 AC Timing Reference Values

Symbol	Parameter	Pins	Min	Тур	Max	Units			
V _{IH_GMII} (Min.)	GMII input high voltage reference	TXD[7:0], TX_EN, TX_ER, GTX_CLK	1.9 ¹			V			
V _{IL_GMII} (Max.)	GMII input low voltage reference	TXD[7:0], TX_EN, TX_ER, GTX_CLK,			0.7	V			
V _{OH_GMII} (Min.)	GMII output high voltage reference	RXD[7:0], RX_DV, RX_ER, RX_CLK, TX_CLK, CRS, COL	1.9			V			
V _{OL_GMII} (Max.)	GMII output low voltage reference	RXD[7:0], RX_DV, RX_ER, RX_CLK, TX_CLK, CRS, COL			0.7	V 1000			
V _{IH_TBI} (Min.)	TBI input high voltage reference	TXD[9:0]	2.0		, C 1	V			
V _{IL_TBI} (Max.)	TBI input low voltage reference	TXD[9:0]			0.8	V			
V_{I_TBI}	TBI input clock threshold	GTX_CLK		1.4	8	V			
V _{OH_TBI} (Min.)	TBI output high voltage reference	RXD[9:0]	2.0	ORIGIN		V			
V _{OL_TBI} (Max.)	TBI output low voltage reference	RXD[9:0]	*		0.8	V			
V _{O_TBI}	TBI output clock threshold	RCLK0, RCLK1	2,0	1.4		V			

^{1.} The VIH values in this AC table are not to be confused with the VIH values in the DC table. See IEEE Clause 35 GMII interface description for details.


4.8 AC Electrical Specifications

4.8.1 Reset Timing

(Over Full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{PU_RESET}	Valid power to RESETn de-asserted	OF	10			ms
T _{SU_XTAL1}	Number of valid XTAL1 cycles prior to RESETn de-asserted	8	10			clks
T _{RESET}	Minimum reset pulse width during normal operation		10			ms
T _{RST_RW}	Delay after deasserting reset before register Read/ write available.		5			ms

Figure 44: Reset Timing





4.8.2 XTAL1 Input Clock Timing¹

88E1111


(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{P_XTAL1}	XTAL1 Period	25 MHz	40 -50 ppm	40	40 +50 ppm	ns
		125 MHz	8 -50 ppm	8	8 +50 ppm	ns
T _{H_XTAL1}	XTAL1 High time	25 MHz	14	20	26	ns
_	, o'	125 MHz	2.8	4	5.2	ns
T _{L_XTAL1}	XTAL1 Low time	25 MHz	14	20	26	ns
_	0,00	125 MHz	2.8	4	5.2	ns
T _{R_XTAL1}	TAL1 XTAL1 Rise	V _{IL} (max) to V _{IH} (min) - 25 MHz	-	3.0	-	ns
CHZYIO!		V _{IL} (max) to V _{IH} (min) - 125 MHz		0.6		ns
T _{F_XTAL1}	XTAL1 Fall	V _{IH} (min) to V _{IL} (max) - 25 MHz	-	3.0	-	ns
COUNTY		V _{IH} (min) to V _{IL} (max) - 125 MHz		0.6	70	ns
T _{J_XTAL1}	XTAL1 total jitter ²	25 MHz	-	-	200	ps ³
o _L		125 MHz			40	ps ³

^{1.} If the crystal option is used, ensure that the frequency is 25 MHz ± 50 ppm. Capacitors must be chosen carefully - see application note supplied by the crystal vendor.

Figure 45: Clock Timing

MARVELL CONFIDENTIAL



Doc. No. MV-S100649-00, Rev. G

PLL generated clocks are not recommended as input to XTAL1 since they can have excessive jitter. Zero delay buffers are also not recommended for the same reason.


^{3.} Broadband peak-peak = 200 ps, Broadband rms = 3 ps, 12 kHz to 20 MHz rms = 1 ps.

4.8.3 125CLK Output Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{P_125CLK}	125CLK Period	0,0	8 -50 ppm	8	8 +50 ppm	ns
T _{H_125CLK}	125CLK High time	201	3.5	4	4.4	ns
T _{L_125CLK}	125CLK Low time	2	3.5	4	4.4	ns
T _{R_125CLK}	125CLK Rise	V _{IL} (max) to V _{IH} (min)	-	1	-	ns
T _{F_125CLK}	125CLK Fall	V _{IH} (min) to V _{IL} (max)	-	1	-	ns
T _{J_125CLK}	125CLK Total Jitter		-	-	80	ps (peak- peak)
T _{P_CD}	125CLK power up to stable clock delay				38	μs

Figure 46: Clock Timing





4.9 GMII Interface Timing

88E1111

4.9.1 GMII Transmit Timing


(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{SU_GMII_} GTX_CLK	GMII Setup Time	CHILD P.	2.0			ns
T _{HD_GMII_} GTX_CLK	GMII Hold Time		0			ns
T _{H_GMII_} GTX_CLK	GTX_CLK High		2.5 ¹			ns
T _{L_GMII_} GTX_CLK	GTX_CLK Low		2.5 ¹			ns
T _{P_GMII_} GTX_CLK	GTX_CLK Period		7.5 ¹	8.0	8.5	ns
F _{GMII} _ GTX_CLK	GTX_CLK Frequency ²		125 ¹ -100 ppm		125 +100 ppm	MHz
T _{R_GMII_} GTX_CLK	GTX_CLK Rise Time				1.0	ns
T _{F_GMII_} GTX_CLK	GTX_CLK Fall Time				1.0	ns

^{1.} GTX_CLK toggle rate is "don't care" if link is down, or if not in 1000BASE-T mode in any clock cycle period.

2. Long Term Average Frequency

Figure 47: GMII Transmit Timing



Doc. No. MV-S100649-00, Rev. G


4.9.2 GMII Receive Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{SU_GMII_} RX_CLK	GMII output to clock	O THE	2.5			ns
T _{HD_GMII_} RX_CLK	GMII clock to output	TO,	0.5			ns
T _{H_GMII_} RX_CLK	RX_CLK High		2.5 ¹		5.5	ns
T _{L_GMII_} RX_CLK	RX_CLK Low		2.5 ¹		5.5	ns
T _{P_GMII_} RX_CLK	RX_CLK Period		7.5 ¹	8.0		ns
T _{R_GMII_} RX_CLK	RX_CLK Rise Time				1.0	ns
T _{F_GMII_} RX_CLK	RX_CLK Fall Time				1.0	ns
T _{RSLEW} _ GMII_ RX_CLK	RX_CLK Rising Slew Rate		0.62			V/ns
T _{FSLEW} GMII_ RX_CLK	RX_CLK Falling Slew Rate		0.62		Ze Z	V/ns

- RX_CLK numbers not guaranteed during transition between 10/100/1000BASE-T operation.
 Instantaneous change during internal VIH_GMII (Min.) and VIL_GMII (Max.)

Figure 48: GMII Receive Timing





4.10 MII Interface Timing

4.10.1 100 Mbps MII Transmit Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)


Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{SU_MII_} TX_CLK	MII Setup Time	Cit 20	10			ns
T _{HD_MII_} TX_CLK	MII Hold Time		0			ns
T _{H_MII_} TX_CLK	TX_CLK High		14		26	ns
T _{L_MII_} TX_CLK	TX_CLK Low		14		26	ns
T _{P_MII_} TX_CLK	TX_CLK Period			40		ns

4.10.2 10 Mbps MII Transmit Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symb	ol P	arameter	Condition	Min	Тур	Max	Units
T _{SU_MII}	M	II Setup Time		10		70	ns
T _{HD_MII}	_ M	II Hold Time		0		.010 A	ns
T _{H_MII_} TX_CLK	T	X_CLK High		140		260	ns
T _{L_MII_}		X_CLK Low		140	0,0	260	ns
T _{P_MII_} TX_CLK	T	X_CLK Period			400		ns

Doc. No. MV-S100649-00, Rev. G





4.10.3 100 Mbps MII Receive Timing

88E1111

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)


Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{SU_MII_} RX_CLK	MII Output to Clock	01/4	10			ns
T _{HD_MII_} RX_CLK	MII Clock to Output	CT TO	10			ns
T _{H_MII_} RX_CLK	RX_CLK High		14		26	ns
T _{L_MII_} RX_CLK	RX_CLK Low		14		26	ns
T _{P_MII_} RX_CLK	RX_CLK Period			40		ns

4.10.4 10 Mbps MII Receive Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{SU_MII_} RX_CLK	MII Output to Clock		10			ns
T _{HD_MII_} RX_CLK	MII Clock to Output		10		70	ns
T _{H_MII_} RX_CLK	RX_CLK High		140		260	ns
T _{L_MII_} RX_CLK	RX_CLK Low		140	25	260	ns
T _{P_MII_} RX_CLK	RX_CLK Period			400		ns

Figure 50: 10/100 Mbps Receive Timing



Doc. No. MV-S100649-00, Rev. G


4.11 TBI Interface Timing

4.11.1 TBI Transmit Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{SU_TBI_} GTX_CLK	TBI Setup Time		2.0			ns
T _{HD_TBI_} GTX_CLK	TBI Hold Time	-	1.0			ns
T _{H_ TBI_} GTX_CLK	GTX_CLK High		3.2		4.8	ns
T _{L_TBI_} GTX_CLK	GTX_CLK Low		3.2		4.8	ns
T _{P_TBI_} GTX_CLK	GTX_CLK Period		8.0 -100ppm	8.0	8.0 +100ppm	ns
T _{R_TBI_} GTX_CLK	GTX_CLK Rise Time				2.4	ns
T _{F_TBI_} GTX_CLK	GTX_CLK Fall Time				2.4	ns

Figure 51: TBI Transmit Timing






4.11.2 TBI Receive Timing

88E1111

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{SU_TBI_} RCLK	TBI Output to RCLK	O CAN	2.5			ns
T _{HD_TBI} _ RCLK	TBI RCLK to Output	CT DY	1.5			ns
T _{H_TBI} _ RCLK	RCLK High		7.0	8.0	9.0	ns
T _{L_TBI} _ RCLK	RCLK Low		7.0	8.0	9.0	ns
T _{P_TBI} _ RCLK	RCLK Period			16.0		ns
T _{DIFF_TBI} _ RCLK	RCLK0/RCLK1 Offset		7.5	8.0	8.5	ns
T _{R_TBI} _ RCLK	RCLK Rise Time				2.0	ns
T _{F_TBI} _ RCLK	RCLK Fall Time				2.0	ns

Figure 52: TBI Receive Timing



4.12 RGMII/RTBI Interface Timing


4.12.1 RGMII AC Characteristics

(For other timing modes see Section 4.12.2 "RGMII/RTBI Delay Timing for different RGMII/RTBI Modes" on page 218.)

	. (1 N				
Symbol	Parameter	Min	Тур	Max	Units
TskewT	Data to Clock output Skew (at transmitter)	-500	0	500	ps
TskewR	Data to Clock input Skew (at receiver)	1.0	-	2.8	ns
T _{CYCLE}	Clock Cycle Duration	7.2	8.0	8.8	ns
T _{CYCLE} HIGH1000	High Time for 1000BASE-T ¹		4.0	4.4	ns
T _{CYCLE_HIGH100}	High Time for 100BASE-T ¹	16	20	24	ns
T _{CYCLE_HIGH10}	High Time for 10BASE-T ¹	160	200	240	ns
T _{RISE} /T _{FALL}	Rise/Fall Time (20-80%)			0.75	ns

Duty cycle may be stretched/shrunk during speed changes or while transitioning to a received packet's clock domain as long as minimum duty cycle is not violated and stretching occurs for no more than three TCYCLE of the lowest speed transitioned between.

Figure 53: RGMII/RTBI Multiplexing and Timing





4.12.2 RGMII/RTBI Delay Timing for different RGMII/RTBI Modes


4.12.2.1 PHY Input - GTX_CLK Delay when Register 20.1 = 0

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Min	Тур	Max	Units
t _{setup}	Register 20.1 = 0	1.0			ns
t _{hold}	C.L.O.	0.8			ns

Figure 54: GTX_CLK Delay Timing - Register 20.1 = 0

88E1111



4.12.2.2 PHY Input - GTX_CLK Delay when Register 20.1 = 1

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Min	Тур	Max	Units
t _{setup}	Register 20.1 = 1 (add delay)	-0.9		11 O	ns
t _{hold}		2.7			ns

Figure 55: GTX_CLK Delay Timing - Register 20.1 = 1 (add delay)


Doc. No. MV-S100649-00, Rev. G

4.12.2.3 PHY Output - RX_CLK Delay

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Min	Тур	Max	Units
t _{skew}	Register 20.7 = 0	- 0.5		0.5	ns

Figure 56: RGMII RX_CLK Delay Timing - Register 20.7 = 0




4.12.2.4 PHY Output - RX_CLK Delay

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Min	Тур	Max	Units
t _{setup}	Register 20.7 = 1 (add delay)	1.2		00,0	ns
t _{hold}		1.2			ns

Figure 57: RGMII RX_CLK Delay Timing - Register 20.7 = 1 (add delay)





4.13 Serial and SGMII Interface Timing

4.13.1 Serial Interface and SGMII Transmitter AC Characteristics

Symbol	Parameter	Min	Тур	Max	Units
CLOCK	Clock signal duty cycle @ 625 MHz	48		52	%
T _{FALL}	VOD Fall time (20% - 80%)	100		200	ps
T _{RISE}	VOD Rise time (20% - 80%)	100		200	ps
T _{SKEW1} 1	Skew between two members of a differential pair			20	ps
T _{CLOCK2Q} ²	Clock to data relationship from either edges of the clock to valid data	250		550	ps


^{1.} Skew measured at 50% of the transition.

4.13.2 Serial Interface and SGMII Receiver AC Characteristics

Symbol	Parameter	Min	Тур	Max	Units
T _{SOUTPUT} ¹	SERDES output to S_CLK	360	400	440	ps

^{1.} Measured at 50% of the transition.

Figure 58: Serial Interface Rise and Fall Times



Doc. No. MV-S100649-00, Rev. G

^{2.} Skew measured at 0V differential.

4.14 Latency Timing

4.14.1 GMII to 1000BASE-T Transmit Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_TXEN_} CRS_1000	1000BASE-T TX_EN Asserted to CRS Asserted	2,50			16	ns
T _{AS_TXEN_} COL_1000	1000BASE-T TX_EN Asserted to COL Asserted	*			16	ns
T _{AS_TXEN_} MDI_1000	1000BASE-T TX_EN Asserted to MDI SSD1		76 ¹		84	ns
T _{DA_TXEN_} CRS_1000	1000BASE-T TX_EN De-asserted to CRS De-asserted				16	ns
T _{DA_TXEN_} COL_1000	1000BASE-T TX_EN De-asserted to COL De-asserted				16	ns
T _{DA_TXEN_} MDI_1000	1000BASE-T TX_EN De- asserted to MDI CSReset, CSExtend, CSExtend_Err		76 ^{1,2}		84	ns

^{1.} Assumes register 16.15:14 is set to 00, which is the minimum latency. Each increase in setting adds 8 ns of latency.

4.14.2 MII to 100BASE-TX Transmit Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_TXEN_} CRS_100	100BASE-TX TX_EN Asserted to CRS Asserted			NO HO	24	ns
T _{AS_TXEN_} COL_100	100BASE-TX TX_EN Asserted to COL Asserted		* 64	X	24	ns
T _{AS_TXEN_} MDI_100	100BASE-TX TX_EN Asserted to /J/		64		72	ns
T _{DA_TXEN_} CRS_100	100BASE-TX TX_EN De-asserted to CRS De-asserted	(6)			24	ns
T _{DA_TXEN_} COL_100	100BASE-TX TX_EN De-asserted to COL De-asserted	93,77)		24	ns
T _{DA_TXEN_} MDI_100	100BASE-TX TX_EN De-asserted to /T/	118 JV	64		72	ns

^{2.} Minimum and maximum values on end of packet assume zero frequency drift between the transmitted signal on MDI and GTX_CLK in GMII or TBI modes, or the received signal on S_IN± in serial interface mode. The worst case variation will be outside these limits, if there is a frequency difference.




4.14.3 MII to 10BASE-T Transmit Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_TXEN_} CRS_10	10BASE-T TX_EN Asserted to CRS Asserted		2.		200	ns
T _{AS_TXEN_} COL_10	10BASE-T TX_EN Asserted to COL Asserted	"TOLEN			200	ns
T _{AS_TXEN_} MDI _10	10BASE-T TX_EN Asserted to Preamble		200		300	ns
T _{DA_TXEN_} CRS_10	10BASE-T TX_EN De-asserted to CRS De-asserted				200	ns
T _{DA_TXEN_} COL_10	10BASE-T TX_EN De-asserted to COL De-asserted				200	ns
T _{DA_TXEN_} MDI_10	10BASE-T TX_EN De-asserted to ETD		200		300	ns

Figure 59: GMII/MII to 10/100/1000BASE-T Transmit Latency Timing



4.14.4 1000BASE-T to GMII Receive Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_MDI_} CRS_1000	1000BASE-T MDI start of Packet to CRS Asserted	OL TH	156 ¹		188	ns
T _{AS_MDI_} COL_1000	1000BASE-T MDI start of Packet to COL Asserted	40 ,	156 ^{<u>1</u>}		188	ns
T _{AS_MDI_} RXDV_1000	1000BASE-T MDI start of Packet to RX_DV Asserted		176 ¹		208	ns
T _{DA_MDI_} CRS_1000	1000BASE-T MDI CSRe- set to CRS De-asserted		172 ¹		204	ns
T _{DA_MDI_} COL_1000	1000BASE-T MDI CSReset to COL De-asserted		172 ¹		204	ns
T _{DA_MDI_} RXDV_1000	1000BASE-T MDI CSReset, CSExtend, CSExtend_Err to RX_DV De-asserted		176 ¹		208	ns

^{1.} In 1000BASE-T, the signals on the 4 MDI pairs arrive at different times because of the skew introduced by the cable. All timing on MDI±[3:0] is referenced from the latest arriving signal.

4.14.5 100BASE-TX to MII Receive Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_MDI_} CRS_100	100BASE-TX MDI start of Packet to CRS Asserted		152		184	ns
T _{AS_MDI_} COL_100	100BASE-TX MDI start of Packet to COL Asserted		152	o O	184	ns
T _{AS_MDI_} RXDV_100	100BASE-TX MDI start of Packet to RX_DV Asserted		216		248	ns
T _{DA_MDI_} CRS_100	100BASE-TX MDI /T/ to CRS De-asserted		192		224	ns
T _{DA_MDI_} COL_100	100BASE-TX MDI /T/ to COL De-asserted	4	192		224	ns
T _{DA_MDI_} RXDV_100	100BASE-TX MDI /T/ to RX_DV De-asserted		216		248	ns




4.14.6 10BASE-T to MII Receive Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_MDI_} CRS_10	10BASE-T MDI start of Packet to CRS Asserted	10 KV	800		1000	ns
T _{AS_MDI_} COL_10	10BASE-T MDI start of Packet to COL Asserted	CHADA	400		600	ns
T _{AS_MDI_} RXDV_10	10BASE-T MDI start of Packet to RX_DV Asserted			1400 ¹		ns
T _{DA_MDI_} CRS_10	10BASE-T MDI ETD to CRS De-asserted			1300 ¹		ns
T _{DA_MDI_} COL_10	10BASE-T MDI ETD to COL De-asserted			1300 ¹		ns
T _{DA_MDI_} RXDV_10	10BASE-T MDI ETD to RX_DV De-asserted			1300 ¹		ns

Actual values depend on number of bits in preamble and number of dribble bits, since nibbles on MII are aligned to start of frame delimiter and dribble bits are truncated.

Figure 60: 10/100/1000BASE-T to GMII/MII Receive Latency Timing



Doc. No. MV-S100649-00, Rev. G


4.14.7 GMII to 1000BASE-X Transmit Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_TXEN_} CRS _SERTX	1000BASE-T TX_EN Asserted to CRS Asserted	HOLE WAY			16	ns
T _{AS_TXEN_} COL _SERTX	1000BASE-T TX_EN Asserted to COL Asserted				16	ns
T _{AS_TXEN_S} ERTX	1000BASE-X TX_EN Asserted to S_OUT± Start of Packet /S/		90 ¹		106	ns
T _{DA_TXEN_} CRS _SERTX	1000BASE-T TX_EN De-asserted to CRS De-asserted				16	ns
T _{DA_TXEN_} COL _SERTX	1000BASE-T TX_EN De-asserted to COL De-asserted				16	ns
T _{DA_TXEN_} SERTX	1000BASE-X TX_EN De- asserted to S_OUT± /T/		90 ^{1,2}		106	ns

^{1.} Assumes Register 16.13:12 is set to 00, which is the minimum latency. Each increase in setting adds 8 ns of latency.

Figure 61: GMII to 1000BASE-X Transmit Latency Timing



Minimum and maximum values on end of packet assume zero frequency drift between the transmitted signal on S_OUT± and GTX_CLK, which is based on XTAL1. The worst case variation will be outside these limits, if there is a frequency difference.




4.14.8 1000BASE-X to GMII Receive Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS} _ SERRX_ CRS	S_IN± Start of Packet /S/ to CRS Asserted	CHO CIPH	76		84	ns
T _{AS} _ SERRX_ COL	S_IN± Start of Packet /S/ to COL Asserted	Will Company	84		92	ns
T _{AS} _ SERRX_ RXDV	S_IN ± Start of Packet /S/ to RX_DV Asserted	SE.	100 ¹		108	ns
T _{DA} _ SERRX_ CRS	S_IN± /T/ to CRS De- asserted		100		108	ns
T _{DA} _ SERRX_ COL	S_IN± /T/ to COL De- asserted		84		92	ns
T _{DA} _ SERRX_ RXDV	S_IN± /T/ to RX_DV De-asserted		100 ^{1,2}		108	ns

- Assumes Register 16.15:14 is set to 00, which is the minimum latency. Each increase in setting adds 8 ns of latency.
 Minimum and maximum values on end of packet assume zero frequency drift between the received signal on S_IN± and RX_CLK, which is derived from XTAL1. The worst case variation will be outside these limits, if there is a frequency difference.

Figure 62: 1000BASE-X to GMII Receive Latency Timing



4.14.9 RGMII to 1000BASE-T Transmit Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_TXC_} MDI_1000	1000BASE-T TX_CTL Asserted to MDI SSD1	OL THE	76 ¹		84	ns
T _{DA_TXC} MDI_1000	1000BASE-T TX_CTL De- asserted to MDI CSReset, CSExtend, CSExtend_Err	CHILDY CHILDY	76 ^{1,2}		84	ns

^{1.} Assumes Register 16.15:14 is set to 00, which is the minimum latency. Each increase in setting adds 8 ns of latency.

4.14.10 RGMII to 100BASE-TX Transmit Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_TXC} MDI_100	100BASE-TX TX_CTL Asserted to /J/		84		92	ns
T _{DA_TXC} MDI_100	100BASE-TX TX_CTL De-asserted to /T/		84		92	ns


4.14.11 RGMII to 10BASE-T Transmit Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_TXC} MDI _10	10BASE-T TX_CTL Asserted to Preamble		200	Wille	300	ns
T _{DA_TXC} MDI_10	10BASE-T TX_CTL De-asserted to ETD		200		300	ns

Minimum and maximum values on end of packet assume zero frequency drift between the transmitted signal on MDI and GTX_CLK. The worst case variation will be outside these limits, if there is a frequency difference.

Figure 63: RGMII/MII to 10/100/1000BASE-T Transmit Latency Timing



4.14.12 1000BASE-T to RGMII Receive Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_MDI_} RXC_1000	1000BASE-T MDI start of Packet to RX_CTL Asserted	1027	176 ¹		208	ns
T _{DA_MDI_} RXC_1000	1000BASE-T MDI CSReset, CSExtend, CSExtend_Err to RX_CTL De-asserted	STANKE PER	176 ¹		208	ns

4.14.13 100BASE-TX to RGMII Receive Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_MDI_} RXC_100	100BASE-TX MDI start of Packet to RX_CTL Asserted		200		232	ns
T _{DA_MDI_} RXC_100	100BASE-TX MDI /T/ to RX_CTL De-asserted		200		232	ns


4.14.14 10BASE-T to RGMII Receive Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

						1
Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_MDI_} RXC_10	10BASE-T MDI start of Packet to RX_CTL Asserted			14001		ns
T _{DA_MDI_} RXC_10	10BASE-T MDI ETD to RX_CTL De-asserted			14001		ns

Actual values depend on number of bits in preamble and number of dribble bits, since nibbles on MII are aligned to start of frame delimiter and dribble bits are truncated.

Figure 64: 10/100/1000BASE-T to RGMII Receive Latency Timing



Copyright © 2006 Marvell

256xg0euupqdu92f-elp5025j * Prophet Electronic Technology Ltd. * UNDER NDA# 12104893




88E1111

4.14.15 RGMII to 1000BASE-X Transmit Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_TXC} SERTX	1000BASE-X TX_CTL Asserted to S_OUT± Start of Packet /S/		90 ¹		106	ns
T _{DA_TXC} SERTX	1000BASE-X TX_CTL Deasserted to S_OUT± /T/	I CHOLDER	90 ^{1,2}		106	ns

Figure 65: RGMII to 1000BASE-X Transmit Latency Timing



^{1.} Assumes Register 16.13:12 is set to 00, which is the minimum latency. Each increase in setting adds 8 ns of latency.

2. Minimum and maximum values on end of packet assume zero frequency drift between the transmitted signal on S_OUT± and GTX_CLK, which is based on XTAL1. The worst case variation will be outside these limits, if there is a frequency difference.


4.14.16 1000BASE-X to RGMII Receive Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS} _ SERRX_ RXC	S_IN± Start of Packet /S/ to RX_CTL Asserted	10,70	100 ¹		108	ns
T _{DA} _ SERRX_ RXC	S_IN± /T/ to RX_CTL De-asserted	CHO! PAR	100 ^{1,2}		108	ns

- 1. Assumes Register 16.15:14 is set to 00, which is the minimum latency. Each increase in setting adds 8 ns of latency.
- Minimum and maximum values on end of packet assume zero frequency drift between the received signal on S_IN± and RX_CLK, which is derived from XTAL1. The worst case variation will be outside these limits, if there is a frequency difference.

Figure 66: 1000BASE-X to RGMII Receive Latency Timing



February 10, 2006, Preliminary




4.14.17 TBI to 1000BASE-T Transmit Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_TBITX} MDI	TBI Start of Packet to MDI SSD1	ic k	100 ¹		108	ns
T _{DA_TBITX} MDI	TBI /T/ to MDI CSReset, CSExtend, CSExtend_Err	CHADI	100 ^{1,2}		108	ns

- 1. Assumes register 16.15:14 is set to 00, which is the minimum latency. Each increase in setting adds 8 ns of latency.
- 2. Minimum and maximum values on end of packet assume zero frequency drift between the transmitted signal on MDI and GTX_CLK in GMII or TBI modes, or the received signal on S_IN± in serial interface mode. The worst case variation will be outside these limits, if there is a frequency difference.

Figure 67: TBI to 100BASE-T Transmit Latency Timing



4.14.18 1000BASE-T to TBI Receive Latency Timing


(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_MDI_} TBIRX	MDI Start of Packet /S/ to TBI Start of Packet	OL THE	228 ^{1,2}		276	ns
T _{DA_MDI_} TBIRX	MDI CSReset, CSExtend, CSExtend_Err to TBI /T/	AD,	228 ^{1,2,3}		276	ns

^{1.} In 1000BASE-T, the signals on the 4 MDI pairs arrive at different times because of the skew introduced by the cable. All timing on MDI ±[3:0] is referenced from the latest arriving signal.

2. Assumes Register 16.15:14 is set to 00, which is the minimum latency. Each increase in setting adds 8 ns of latency.

Figure 68: 1000BASE-T to TBI Receive Latency Timing



February 10, 2006, Preliminary

Minimum and maximum values on end of packet assume zero frequency drift between the transmitted signal on MDI and the internally generated reference clock. The worst case variation will be outside these limits if there is a frequency difference.


4.14.19 RTBI to 1000BASE-T Transmit Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS} _ RTBITX_MDI	RTBI Start of Packet to MDI SSD1		100 ¹		108	ns
T _{DA} _ RTBITX_MDI	RTBI /T/ to MDI CSReset, CSExtend, CSExtend_Err	OF A	100 ^{1,2}		108	ns

- 1. Assumes Register 16.15:14 is set to 00, which is the minimum latency. Each increase in setting adds 8 ns of latency.
- Minimum and maximum values on end of packet assume zero frequency drift between the transmitted signal on MDI and GTX_CLK. The worst case variation will be outside these limits, if there is a frequency difference.

Figure 69: RTBI to 1000BASE-T Transmit Latency Timing




(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_MDI_} RTBIRX	MDI Start of Packet /S/ to RTBI Start of Packet	10,70	228 ^{1,2}		276	ns
T _{DA_MDI_} RTBIRX	MDI CSReset, CSExtend, CSExtend_Err to RTBI /T/	,0T/A	228 ^{1,2,3}		276	ns

- 1. In 1000BASE-T, the signals on the 4 MDI pairs arrive at different times because of the skew introduced by the cable. All timing on MDI ±[3:0] is referenced from the latest arriving signal.
- 2. Assumes Register 16.13:12 is set to 00, which is the minimum latency. Each increase in setting adds 8 ns of latency.
- 3. Minimum and maximum values on end of packet assume zero frequency drift between the received signal on MDI and RCLK1/ RCLK0, which are derived from XTAL1. The worst case variation will be outside these limits if there is a frequency difference.

Figure 70: 1000BASE-T to RTBI Receive Latency Timing



February 10, 2006, Preliminary


4.14.21 SGMII to 10/100/1000BASE-T Transmit Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_SERT} X_MDI_ 1000	S_IN± Start of Packet /S/ to MDI SSD1		124 ¹		148	ns
T _{DA_SERT} X_MDI_ 1000	S_IN± /T/ to MDI CSReset, CSExtend, CSExtend_Err	STO DE	124 ^{1,2}		148	ns
T _{AS_SERT} X_MDI_1 00	S_IN± Start of Packet /S/ to MDI /J/		250 ¹		310	ns
T _{DA_SERT} X_MDI_100	S_IN± /T/ to MDI /T/	2	250 ^{1,2}		310	ns
T _{AS_SERT} X_MDI_1 0	S_IN± Start of Packet /S/ to MDI Preamble		1200 ¹		2000	ns
T _{DA_SERT} X_MDI_10	S_IN± /T/ to MDI ETD		1200 ^{1,2}		2000	ns

^{1.} Assumes Register 16.15:14 is set to 00, which is the minimum latency. Each increase in setting adds 8 ns of latency in 1000 Mbps 40 ns in 100 Mbps, and 400 ns in 10 Mbps.

Figure 71: SGMII to 10/100/1000BASE-T Transmit Latency Timing



Minimum and maximum values on end of packet assume zero frequency drift between the transmitted signal on MDI and the
received signal on S_IN±. The worst case variation will be outside these limits, if there is a frequency difference.


4.14.22 10/100/1000BASE-T to SGMII Receive Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_MDI_} SERRX_ 1000	MDI SSD1 to S_OUT± Start of Packet	No. No.	248 ^{1,2}		296	ns
T _{DA_MDI_} SERRX_ 1000	MDI CSReset, CSExtend, CSExtend_Err to S_OUT± /T/	ST DAY	248 ^{1,2,3}		296	ns
T _{AS_MDI_} SERRX_ 100	MDI /J/ to S_OUT± Start of Packet		370 ²		434	ns
T _{DA_MDI_} SERRX_ 100	MDI /T/ to S_OUT±/T/		370 ^{2,3}		434	ns
T _{AS_MDI_} SERRX_ 10	MDI Preamble to S_OUT± Start of Packet			2700 ^{2,4}		ns
T _{DA_MDI_} SERRX_ 10	MDI ETD to S_OUT± /T/			2700 ^{2,3,4}		ns

- 1. In 1000BASE-T the signals on the 4 MDI pairs arrive at different times because of the skew introduced by the cable. All timing on MDI±[3:0] is referenced from the latest arriving signal.
- Assumes Register 16.13:12 is set to 00, which is the minimum latency. Each increase in setting adds 8 ns of latency 1000 Mbps, 40 ns in 100 Mbps, and 400 ns in 10 Mbps.
- 3. Minimum and maximum values on end of packet assume zero frequency drift between the received signal on MDI and S_OUT±, which is based on XTAL1. The worst case variation will be outside these limits if there is a frequency difference.
- Actual values depend on number of bits in preamble and number of dribble bits, since nibbles on MII are aligned to start of frame delimiter and dribble bits are truncated.

Figure 72: 10/100/1000BASE-T to SGMII Receive Latency Timing



4.14.23 1000BASE-X to 1000BASE-T Transmit Latency Timing


(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

88E1111

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_SERTX_MDI} _1000	S_IN ± Start of Packet /S/ to MDI SSD1	OC TH	124 ¹		148	ns
T _{DA_SERTX_MD} I_1000	S_IN ± /T/ to MDI CSReset, CSExtend, CSExtend_Err		124 ^{1,2}		148	ns

- 1. Assumes Register 16.15:14 is set to 00, which is the minimum latency. Each increase in setting adds 8 ns of latency.
- 2. Minimum and maximum values on end of packet assume zero frequency drift between the transmitted signal on MDI and the received signal on S_IN±. The worst case variation will be outside these limits, if there is a frequency difference.

Figure 73: 1000BASE-X to 1000BASE-T Transmit Latency Timing




4.14.24 1000BASE-T to 1000BASE-X Receive Latency Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{AS_MDI_} SERRX_10 00	MDI SSD1 to S_OUT ± Start of Packet	NO OF	248 ^{1,2}		296	ns
T _{DA_MDI_} SERRX_10 00	MDI CSReset, CSExtend, CSExtend_Err to S_OUT ± /T/	8 2	248 ^{1,2,3}		296	ns

- In 1000BASE-T the signals on the 4 MDI pairs arrive at different times because of the skew introduced by the cable. All timing on MDI±[3:0] is referenced from the latest arriving signal.
- 2. Assumes Register 16.13:12 is set to 00, which is the minimum latency. Each increase in setting adds 8 ns of latency.
- Minimum and maximum values on end of packet assume zero frequency drift between the received signal on MDI and S_OUT±, which is based on XTAL1. The worst case variation will be outside these limits if there is a frequency difference.

Figure 74: 1000BASE-T to 1000BASE-X Receive Latency Timing



MARVELL CONFIDENTIAL

Page 239




4.15 Serial Management Interface, Two-Wire Serial Interface, and JTAG Timing

4.15.1 Serial Management Interface Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{DLY} MDIO	MDC to MDIO (Output) Delay Time	00 2	0		20	ns
T _{SU_MDIO}	MDIO (Input) to MDC Setup Time		10			ns
T _{HD_MDIO}	MDIO (Input) to MDC Hold Time		10			ns
T _{P_MDC}	MDC Period		120			ns
T _{H_MDC}	MDC High		30			ns
T _{L_MDC}	MDC Low		30			ns

Figure 75: Serial Management Interface Timing




4.15.2 Two-Wire Serial Interface (TWSI) Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units	
FTWSI_	SCL Clock Frequency	100 kHz	(C)		100	kHz	
SCL		400 kHz	6		400		
TTWSI_N	Noise Suppression Time at	100 kHz			80	ns	
S	SCL, SDA Inputs	400 kHz			80		
TTWSI_R	SDA Rise time	100 kHz			1000	ns	
		400 kHz			300	=	
TTWSI_F	SDA Fall Time	100 kHz			300	ns	
		400 kHz			300	=	
TTWSI_	Clock High Period	100 kHz	4000			ns	
HIGH	(06.2)	400 kHz	600				
TTWSI_	Clock Low Period	100 kHz	4700			ns	
LOW		400 kHz	1300			-	
TTWSI_		100 kHz	4700			ns	
SU:STA	(for a Repeated Start Condition)	400 kHz	600			1,0	
TTWSI_	Start Condition Hold Time	100 kHz	4000			ns	
HD:STA	SV C	400 kHz	600			9,	
TTWSI_	Stop Condition Setup Time	100 kHz	4000		20	ns	
SU:STO	<u>V</u>	400 kHz	600		30	% *	
TTWSI_	Data in Setup Time	100 kHz	250		YOU	ns	
SU:DAT		400 kHz	100		O N		
TTWSI_	Data in Hold Time	100 kHz	300	,(, Ch	ns	
HD:DAT		400 kHz	300		0,		
TTWSI_	Bus Free Time	100 kHz	4700	47.0-	•	ns	
BUF		400 kHz	1300	800			
TTWSI_	SCL Low to SDA Data Out	100 kHz	40		200	ns	
DLY	Valid	400 kHz	40		200		
	1				1		

Figure 76: Two-Wire Serial Interface Timing



Copyright © 2006 Marvell

MARVELL CONFIDENTIAL

CONFIDENTIAL

Doc. No. MV-S100649-00, Rev. G




4.15.3 JTAG Timing

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)

Symbol	Parameter	Condition	Min	Тур	Max	Units
T _{P_TCK}	TCK Period	NO. N.	40			ns
T _{H_TCK}	TCK High	(O, P.)	12			ns
T _{L_TCK}	TCK Low	(C) (E)	12			ns
T _{SU_TDI}	TDI, TMS to TCK Setup Time		10			ns
T _{HD_TDI}	TDI, TMS to TCK Hold Time		10			ns
T _{DLY_TDO}	TCK to TDO Delay		0		15	ns

Figure 77: JTAG Timing



4.16 IEEE AC Transceiver Parameters

IEEE tests are typically based on templates and cannot simply be specified by number. For an exact description of the templates and the test conditions, refer to the IEEE specifications:

- -10BASE-T IEEE 802.3 Clause 14-2000
- -100BASE-TX ANSI X3.263-1995
- -1000BASE-T IEEE 802.3ab Clause 40 Section 40.6.1.2 Figure 40-26 shows the template waveforms for transmitter electrical specifications.

(Over full range of values listed in the Recommended Operating Conditions unless otherwise specified)


Symbol	Parameter	Pins	Condition	Min	Тур	Max	Units
T _{RISE}	Rise time	MDI[1:0]	100BASE-TX	3.0	4.0	5.0	ns
T _{FALL}	Fall Time	MDI[1:0]	100BASE-TX	3.0	4.0	5.0	ns
T _{RISE} / T _{FALL} Symmetry	(0)(1)	MDI[1:0]	100BASE-TX	0		0.5	ns
DCD	Duty Cycle Distortion	MDI[1:0]	100BASE-TX	0		0.5 ¹	ns, peak- peak
Transmit Jitter	,	MDI[1:0]	100BASE-TX	0		1.4	ns, peak- peak


1. ANSI X3.263-1995 Figure 9-3





Section 5. Package Mechanical Dimensions

5.1 117-pin TFBGA Package









(All dimensions in mm.)

Doc. No. MV-S100649-00, Rev. G

Table 113: 117-Pin TFBGA Package Dimensions


	Dimensio	ns in mm		
Symbol	MIN	NOM	MAX	
Α	il a		1.54	
A1	0.40	0.50	0.60	
A2	0.84	0.89	0.94	
С	0.32	0.36	0.40	
D	9.90	10.00	10.10	
E	13.90	14.00	14.10	
D1	-	8.00		
*E1	1	12.00		
e		1.00		
6 6	0.50	0.60	0.70	
aaa		0.20		
bbb		0.25		
ccc	0.35			
ddd	0.15			
MD/ME		·		


NOTE:

- 1. CONTROLLING DIMENSION: MILLIMETER.
- 2. PRIMARY DATUM C AND SEATING PLANE ARE DEFINED BY THE SPHERICAL CROWNS OF THE SOLDER BALLS.
- 3. DIMENSION b IS MEASURED AT THE MAXIMUM SOLDER BALL DIAMETER, PARALLEL TO PRIMARY DATUM C.




5.2 96-pin BCC Package - Top View






Doc. No. MV-S100649-00, Rev. G


5.3 96-Pin BCC Package - Bottom View





5.4 128-Pin PQFP Package





Section 6. Order Information

6.1 Ordering Part Numbers and Package Markings

Figure 78 shows the ordering part numbering scheme for the 88E1111 devices. Contact Marvell® FAEs or sales representatives for complete ordering information.

Figure 78: Sample Part Number




Table 114: 88E1111 Part Order Options - RoHS 6/6 Compliant Package

Package Type	Part Order Number
88E1111 117-pin TFBGA - Commercial	88E1111-XX-BAB1C000
88E1111 117-pin TFBGA - Industrial	88E1111-XX-BAB11000
88E1111 96-pin BCC - Commercial	88E1111-XX-CAA1C000
88E1111 96-pin BCC - Industrial	88E1111-XX-CAA1I000
88E1111 128-pin PQFP - Commercial	88E1111-XX-RCJ1C000

Table 115: 88E1111 Part Order Options - Non Lead-free Package

Package Type	Part Order Number
88E1111 117-pin TFBGA - Commercial	88E1111-XX-BAB-C000
88E1111 117-pin TFBGA - Industrial	88E1111-XX-BAB-I000
88E1111 96-pin BCC - Commercial	88E1111-XX-CAA-C000
88E1111 96-pin BCC - Industrial	88E1111-XX-CAA-I000
88E1111 128-pin PQFP - Commercial	88E1111-XX-RCJ-C000

Copyright © 2006 Marvell

MARVELL CONFIDENTIAL


Doc. No. MV-S100649-00, Rev. G



6.1.1 RoHS 6/6 Compliant Marking Examples

Figure 79 is an example of the package marking and pin 1 location for the 88E1111 117-pin TFBGA commercial RoHS 6/6 compliant package.

Figure 79: 88E1111 117-pin TFBGA Commercial RoHS 6/6 Compliant Package Marking and Pin 1 Location




Note: The above example is not drawn to scale. Location of markings is approximate.

Figure 80 is an example of the package marking and pin 1 location for the 88E1111 117-pin TFBGA industrial RoHS 6/6 compliant package.

Figure 80: 88E1111 117-pin TFBGA Industrial RoHS 6/6 Compliant Package Marking and Pin 1

Location




Note: The above example is not drawn to scale. Location of markings is approximate.

Doc. No. MV-S100649-00, Rev. G

Figure 81 is an example of the package marking and pin 1 location for the 88E1111 96-pin BCC Commercial RoHS 6/6 compliant package.


Figure 81: 88E1111 96-pin BCC Commercial RoHS 6/6 Compliant Package Marking and Pin 1
Location



Note: The above example is not drawn to scale. Location of markings is approximate.

Figure 82 is an example of the package marking and pin 1 location for the 88E1111 96-pin BCC Industrial RoHS 6/6 compliant package.


Figure 82: 88E1111 96-pin BCC Industrial RoHS 6/6 Compliant Package Marking and Pin 1 Location



Note: The above example is not drawn to scale. Location of markings is approximate.

Figure 83 is an example of the package marking and pin 1 location for the 88E1111 128-pin PQFP Commercial RoHS 6/6 compliant package.

Figure 83: 88E1111 128-pin PQFP Commercial RoHS 6/6 Compliant Package Marking and Pin 1




Note: The above example is not drawn to scale. Location of markings is approximate.

6.1.2 Non Lead-free Marking Examples

Figure 84 is an example of the package marking and pin 1 location for the 88E1111 117-pin TFBGA commercial non lead-free package.


Figure 84: 88E1111 117-pin TFBGA Commercial Non Lead-free Package Marking and Pin 1



Note: The above example is not drawn to scale. Location of markings is approximate.

Figure 85 is an example of the package marking and pin 1 location for the 88E1111 117-pin TFBGA Industrial non lead-free package.

Figure 85: 88E1111 117-pin TFBGA Industrial Non Lead-free Package Marking and Pin 1 Location




Note: The above example is not drawn to scale. Location of markings is approximate.

Copyright © 2006 Marvell



Figure 86 is an example of the package marking and pin 1 location for the 88E1111 96-pin BCC Commercial non lead-free package.


Figure 86: 88E1111 96-pin BCC Commercial Non Lead-free Package Marking and Pin 1 Location



Note: The above example is not drawn to scale. Location of markings is approximate.

Figure 87 is an example of the package marking and pin 1 location for the 88E1111 96-pin BCC Industrial non lead-free package.


Figure 87: 88E1111 96-pin BCC Industrial Non Lead-free Package Marking and Pin 1 Location



Note: The above example is not drawn to scale. Location of markings is approximate.

Figure 88 is an example of the package marking and pin 1 location for the 88E1111 128-pin PQFP Commercial non lead-free package.

Figure 88: 88E1111 128-pin PQFP Commercial Non Lead-free Package Marking and Pin 1 Loca-



Note: The above example is not drawn to scale. Location of markings is approximate.



MOVING FORWARD

FASTER®

Marvell Semiconductor, Inc.

5488 Marvell Lane Santa Clara, CA 95054, USA

Tel: 1.408.222.2500 Fax: 1.408.752.9028 www.marvell.com

MARVELL CONFIDENTIA

Worldwide Corporate Offices

Marvell Semiconductor, Inc.

5488 Marvell Lane Santa Clara CA 95054 USA Tel: 1.408.222.2500

Marvell Asia Pte. Ltd.

151 Lorong Chuan, #02-05 New Tech Park, Singapore 556741 Tel: 65 6756 1600 Fax: 65.6756.7600

Marvell Japan K.K.

Shinjuku Center Bldg. 44F 1-25-1, Nishi-Shinjuku, Shinjuku-ku Tokyo 163-0644, Japan Tel: 81.(0).3.5324.0355 Fax: 81.(0).3.5324.0354

Marvell Semiconductor Israel, Ltd.

6 Hamada Street Mordot HaCarmel Industrial Park Yokneam 20692, Israel Tel: 972.(0).4.909.1500 Fax: 972.(0).4.909.1501

Marvell Semiconductor Korea, Ltd.

Rm. 603, Trade Center 159-2 Samsung-Dong, Kangnam-Ku Seoul 135-731, Korea Tel: 82.(0).2.551-6070/6079 Fax: 82.(0).2.551.6080

Radlan Computer Communications, Ltd. Atidim Technological Park, Bldg. #4

Tel Aviv 61131, Israel Tel: 972.(0).3.645.8555 Fax: 972.(0).3.645.8544

Worldwide Sales Offices

Western US

Marvell

5488 Marvell Lane Santa Clara, CA 95054, USA Tel: 1.408.222.2500 Fax: 1.408.752.9028 Sales Fax: 1.408.752.9029

Central US

Marvell

9600 North MoPac Drive, Suite #215 Austin, TX 78759, USA Tel: 1.512.343.0593 Fax: 1.512.340.9970

Eastern US/Canada

Marvell

Parlee Office Park 1 Meeting House Road, Suite 1 Chelmsford, MA 01824, USA Tel: 1.978.250.0588 Fax: 1.978.250.0589

Europe

Marvell

5 Marchmont Gate Boundary Way Hemel Hempstead Hertfordshire, HP2 7BF United Kingdom Tel: 44.(0).1442.211668 Fax: 44.(0).1442.211543

Israel

Marvell

6 Hamada Street Mordot HaCarmel Industrial Par Yokneam 20692, Israel Tel: 972.(0).4.909.1500 Fax: 972.(0).4.909.1501

China

Marvell

5J1, 1800 Zhongshan West Road Shanghai, PRC 200233 Tel: 86.21.6440.1350 Fax: 86.21.6440.0799

Marvell

Rm. 1102/1103, Jintian Fudi Mansion #9 An Ning Zhuang West Rd. Qing He, Haidian District Beijing, PRC 100085 Tel: 86.10.8274.3831 Fax: 86.10.8274.3830

Japan

Marvell

Shinjuku Center Bldg. 44F 1-25-1, Nishi-Shinjuku, Shinjuku-ku Tokyo 163-0644, Japan Tel: 81.(0).3.5324.0355 Fax: 81.(0).3.5324.0354

Taiwan

Marvell

2FI., No.1, Alley 20, Lane 407, Sec. 2 Ti-Ding Blvd., Nei Hu District Taipei, Taiwan, 114, R.O.C Tel: 886.(0).2.8177.7071 Fax: 886.(0).2.8752.5707

Marvell

Rm. 603, Trade Center 159-2 Samsung-Dong, Kangnam-Ku Seoul 135-731, Korea Tel: 82.(0).2.551-6070/6079 Fax: 82.(0).2.551.6080

