# CanFestival3. Version 3.0 The CANOpen stack manual

# **Table of contents**

1 - Introduction	2
1.1) The CanFestival project	
1.2) What is CANopen	
2 - CanFestival Features	
2.1) Tools	
2.2) Standard conformance	
3 - How to start	
3.1) Host requirements	
3.2) How to get CanFestival	
4 - Understanding Canfestival	
4.1) CanFestival Project tree layout	
4.2) Implement CanFestival in your application	
4.3) CanFestival CAN interfaces	
4.4) CanFestival events scheduling	
5 - Linux Target	
5.1) Linux Compilation and installation	
5.2) Normal Linux node	
5.3) Real-Time Linux node.	
5.4) CAN devices	
6 - Windows Targets	
6.1) Object Dictionary Editor GUI installation	
6.2) CYGWIN	
6.3) Visual Studio C++	12
7 - Motorola HCS12	
7.1) Running a HCS12 node	
8 - Example and test program:	
8.1) TestMasterSlave :	
8.2) gene SYNC HCS12 :	14
9 - Developing a new node	
9.1) Using Dictionary Editor GUI	15
9.2) Generating the object Dictionary	
10 - FAQ	
10.1) General	
10.2) LINUX	23
10.3) HCS12	23
11 - Documentation resources	
12 - About the project	
12.1) Contributors	
12.2) Getting support	
12.3) Contributing	
12 4) License	30

#### 1 - Introduction

This document describe the CANOpen layer.CanFestival is an OpenSource (LGPL) CANOpen framework.

## 1.1) The CanFestival project

This project, initiated by Edouard TISSERANT in 2001, as grown thanks to Francis DUPIN and other contributors.

Today, CanFestival focuses on providing an ANSI-C platform independent CANOpen stack that can be implemented as master or slave nodes on PCs, Real-time IPCs, and Microcontrollers.

CanFestival is a project supported by Lolitech.

#### 1.2) What is CANopen

CANopen is a CAN based high level protocol. It defines some protocols to :

- Configure a CAN network.
- Transmit data to a specific node or in broadcast.
- Administrate the network. For example detecting a not responding node.

The documentation can be found in the Can in automation website:

#### http://www.can-cia.de/canopen

The most important document about CANopen is the normative CiA Draft Standard 301, version 4.02. You can now download with no cost the specification in Can in automation website.

To continue reading this document, let us assume that you have read some papers introducing CANopen.

#### 2 - CanFestival Features

#### 2.1) Tools

The CANopen library is coming with some tools:

- Object Dictionary editor GUI. WxPython Model-View-Controler based GUI, that help a lot in generating object dictionary source code for each node.
- A configure script, that let you chose compile time options such as target CPU/HOST, CAN and TIMER drivers.

This script have not been generated with autoconf, it have been made keeping microcontroller target in mind.

### 2.2) Standard conformance

#### a)Multi-Platform

- Library source code is C-ANSI.
- Driver and examples coding conventions merely depend on target specific contributor/compiler.
- Unix compatible interfaces and examples should compile and run on any Unix system (tested on GNU/Linux and GNU/FreeBSD).

#### b)CanOpen conformance

- Should conform to DS301. V.4.02 13 february 2002.
- Master and Slave functionality implemented.
- Sending SYNC implemented.
- 1 SDO server per node. (update: more than one possible. To be more tested)
- Unlimited SDO client.
- SDO transmission mode: normal, expedited download and upload.
- Unlimited PDO receive.
- Unlimited PDO transmit.
- Object Data type implemented: 8, 16, 32 bits values, and fixed length strings.
- Slave state full implemented.
- NMT to change slave's state implemented.
- PDO transmission mode: on request, every reception of 0 to n SYNC, on event.
- NMT Heartbeat implemented: A node can be either heartbeat producer or receiver.
- NMT NodeGuard implemented : Not fully implemented.
- TIME (time Stamp): Not implemented.
- EMCY (emergency objects) : Not implemented.

#### 3 - How to start

## 3.1) Host requirements

What you need on your development workstation.

## 3.1.1) Object Dictionary Editor GUI

- Python, with
  - wxPyhon modules installed (at least version 2.6.3).
  - Gnosis xml tools. (Optional can also be installed locally to the project automatically will the help of a Makefile. Please see 9.1) <u>Using Dictionary Editor</u> <u>GUI</u>)

#### 3.1.2) Linux and Unix-likes

- Linux, FreeBSD, Cygwin or any Unix environment with GNU toolchain.
- The GNU C compiler (gcc) or any other ANSI-C compiler for your target platform.
- Xpdf, and the official 301\_v04000201.pdf file in order to get GUI context sensitive help. Download the ds301 at <a href="http://www.can-cia.org/downloads/ciaspecifications/?1390">http://www.can-cia.org/downloads/ciaspecifications/?1390</a>.
- GNU Make
- Bash and sed

#### 3.1.3) Windows (for native win32 target)

- Visual Studio Express 2005 or worst.
- Microsoft platform SDK (requires Genuine Advantage)
- Cygwin (for configuration only)

## 3.2) How to get CanFestival

Please always use CVS, this is the best way to get the most reactive support from the developer community:

cvs -d:pserver:anonymous@lolitech.dyndns.org:/canfestival login (type return, without entering a password)

Then, enter:

cvs -z3 -d:pserver:anonymous@lolitech.dyndns.org:/canfestival co -P CanFestival-3

# 4 - Understanding Carfestival

### 4.1) CanFestival Project tree layout

Simplified directory structure.

./src /include

./drivers

./drivers/unix
./drivers/win32

./drivers/timers xeno

./drivers/timers\_unix

./drivers/can peak linux

./drivers/can peak win32

./drivers/can uvccm win32

./drivers/can virtual

./drivers/hcs12

./examples

./examples/TestMasterSlave

./examples/gene SYNC HCS12

./examples/win32test

./objdictgen

./objdictgen/config

./objdictgen/examples

./doc

ANSI-C source of CANOpen stack Exportables Header files Interfaces to specific platforms/HW

Linux and Cygwin OS interface

Native Win32 OS interface

Xenomai timers/threads (Linux only)

Posix timers/threads (Linux, Cygwin)

PeakSystem CAN library interface

PeakSystem PCAN-Light interface

Acacetus's RS232 "CAN-uVCCM" interface

Fake CAN network (Linux, Cygwin)

HCS12 full target interface

Examples

2 nodes, NMT SYNC SDO PDO, win32+unix Just send periodic SYNC on HCS12

Ask some DS301 infos to a node (win32)

Object Dictionary editor GUI


Pre-defined OD profiles

Some examples/test OD

Project and CanOpen doc

## 4.2) Implement CanFestival in your application

# Implementation overview




# 4.3) CanFestival CAN interfaces


Because most CAN controllers and drivers implement FIFOs, CanFestival consider sending message as a non bloking operation.

In order to prevent reentrent calls to the stack, messages reception is implemented differently on  $\mu C$  and OS.:

- μC must provide interuption masking for timer and can receive IT



 OS must provide a receive thread, a timer thread and a mutex. CAN reception is a bloking operation.




## 4.4) CanFestival events scheduling

A CanOpen node must be able to take delayed actions.

As exemples, periodic sync emission, heartbeat production or SDO timeout need to set some alarms that will be called later and do the job.


 $\mu$ C generaly do not have enough free timers to handle all the CanOpen needs directly. Moreover, CanFestival internal data may be corrupt by reentrant calls.

CanFestival implement a micro-scheduler (timer.c). It uses only one timer to mimic many timers. It manage an alarm table, and call alarms at desired time.



Scheduler can handle short clock value ranges limitation found on some  $\mu$ C. As an example, value range for a 16bit clock counter with 4 $\mu$ s tick is crossed within 0.26 seconds... Long alarms must be segmented.

Chronogram illustrate a long alarm (A) and a short periodic alarm (B), with a A value > clock range > B value. Values t0...t8 are successive setTimer call parameter values. t1 illustrates an intermediate call to TimeDispatch, caused by a delay longer than clock range. Because of long alarm segmentation, at the end of t1, TimeDispatch call will not trig any alarm callback.



# 5 - Linux Target

Linux target is default configure target.

## 5.1) Linux Compilation and installation

Call ./configure -help to see all available compile time options.

After invoking ./configure with your platform specific switches, just type make.

```
./configure [options]
make
make install
```

#### 5.2) Normal Linux node

Configure switch:

```
--timers=unix
```

To do a CANopen node running on PC-Linux, you need:

- A working linux distribution
- One or more Peak system PC CAN interface and the last Peak Linux driver installed.

#### 5.3) Real-Time Linux node

Configure switch:

```
--timers=xeno
```

To do a CANopen node running on PC-Linux, you need:

- A working linux distribution patched with XENOMAI 2.1 or greater.
- One or more Peak system PC CAN interface and the last Peak Real Time Linux driver installed.

## 5.4) CAN devices

Curently supported CAN devices and corresponding configure switch:

# 5.4.1)Peak systems

Configure switch:

```
--can=peak linux
```

PeakSystems CAN interface is automatically chosen as default CAN interface if libpcan is present in the system.

Please download driver at  $\underline{\text{http://www.peak-system.com/linux}}$  and follow instructions in order to install driver on your system.

#### 5.4.2)LinCan

Configure switch:

```
--can=LinCan
```

# 5.4.3) Virtual CAN interfaces (for test/debug)

Configure switch:

#### --can=virtual

Virtual CAN interface use Unix pipes to emulate a virtual CAN network. Each message issued from a node is repeat to all other nodes. Currently only works with nodes running in the same process, and does not support work with Xenomai.

# 6 - Windows Targets

CanFestival can be compiled and run on Windows platform. It is possible to use both Cygwin and win32 native runtime environment.

## 6.1) Object Dictionary Editor GUI installation.

Please refer to 8.2.1) Using Dictionary Editor GUI

#### 6.2) CYGWIN

## 6.2.1) Requirements

Cygwin have to be installed with those packages:

- gcc
- unzip
- wget
- make

Currently, the only supported CAN devices are PeakSystems ones, with PcanLight driver and library.

Please download driver at <a href="http://www.peak-system.com/themen/download\_gb.html">http://www.peak-system.com/themen/download\_gb.html</a> and follow instructions in order to install driver on your system.

Install Cygwin as required, and the driver for your Peak CAN device.

Open a Cygwin terminal, and follow those instructions:

## 6.2.2) Cygwin configuration and compilation

#### a)A single node with PcanLight and Peak CAN-USB adapter

Download the PCAN-Light Zip file for your HW (URL from download page):

```
wget http://www.peak-system.com/files/usb.zip
```

Extract its content into your cygwin home (it will create a "Disk" directory):

```
unzip usb.zip
```

Configure CanFestival3 providing path to the desired PcanLight implementation:

```
cd CanFestival-3
export PCAN_INCLUDE=~/Disk/PCAN-Light/Api/
export PCAN_HEADER=Pcan_usb.h
export PCAN_LIB=~/Disk/PCAN-Light/Lib/Visual\ C++/Pcan_usb.lib
./configure --can=peak_win32
make
```

In order to test, you have to use another CanFestival node, connect with a CAN cable.

Then, on the other node:

```
./TestMasterSlave -1 my_driver.so -S none -M 500K
```

You should now see messages exchanged between master and slave node.

#### b)Two nodes with PcanLight and Peak dual PCMCIA-CAN adapter

Download the PCAN-Light Zip file for your HW (URL from download page):

```
wget http://www.peak-system.com/files/pccard.zip
```

Extract its content into your cygwin home (it will create a "Disk" directory):

```
unzip pccard.zip
```

The configure CanFestival3 providing path to the desired PcanLight implementation:

```
export PCAN_INCLUDE=~/Disk/PCAN-Light/Api/
export PCAN_HEADER=Pcan_pcc.h
export PCAN_LIB=~/Disk/PCAN-Light/Lib/Visual\ C++/Pcan_pcc.lib
export PCAN2_HEADER=Pcan_2pcc.
export PCAN2_LIB=~/Disk/PCAN-Light/Lib/Visual\ C++/Pcan_2pcc.lib
```

In order to test, just connect together both CAN ports of the PCMCIA card. Dont forget 120ohms terminator.

You should now see messages exchanged between master and slave node.

#### 6.3) Visual Studio C++

## 6.3.1) Requirements

Minimal Cygwin installation is required at configuration time in order to create specific header files (config.h and cancfg.h). Once this files created, cygwin is not necessary any more.

Project and solution files have been created and tested with Visual Studio Express 2005. Be sure to have installed Microsoft Platform SDK, as recommended at the end of Visual Studio installation.

# 6.3.2) Configuration with cygwin

Follow instructions given at <u>4.2.2)Cygwin configuration and compilation</u>, but do neither call make nor do tests, just do configuration steps. This will create headers files accordingly to your configuration parameters, and the desired CAN hardware.

# 6.3.3) Compilation with Visual Studio

You can either load independents "\*.vcproj" project files along your own projects in your own solution or load the provided "CanFestival-3.vc8.sln" solution files directly.

Build CanFestival-3 project first.

### a)PcanLight and the can\_peak\_win32 project.

Chosen Pcan\_xxx.lib and eventually Pcan\_2xxx.lib files must be added to can\_peak\_win32 project before build of the DLL.

# 6.3.4)Testing

Copy eventually needed dlls (ie : Pcan\_Nxxx.lib) into Release or Debug directory, and run the test program:

```
TestMasterSlave.exe -1 can peak win32.dll
```

#### 7 - Motorola HCS12

The examples have been tested on a MC9S12DG255 mounted on a Elektronikladen HCS12 T-board.

Beware that there are a few differences in the MSCAN module of the 68HC12 and HCS12 microcontroller. For a HC12, you must adapt the driver that we provide for the HCS12.

For the difference MSCAN HC12/HCS12, see the Motorola application note AN2011/D.

Configure switch:

```
--target=hcs12
```

To do a CANopen node running on a microncontroller Motorola MC9S12DP256, you need :

- The compiler GNU gcc for HC11, HC12, HCS12 : m6811-elf.
  Download the **release 3.1** at : <a href="http://m68hc11.serveftp.org/m68hc11">http://m68hc11</a>.serveftp.org/m68hc11 pkg rpm.php
- A board with this chip. We are using the T-board from Electronikladden.
- At least about 40 kBytes of program memory.
- A tool to flash the memory. (We are using the hight cost Lauterbach debugger).

## 7.1) Running a HCS12 node

#### 7.1.1) Compiling Canfestival:

```
./configure -target=hcs12
```

### 7.1.2) Compiling and building an example

Enter in the folder of an HCS12 example,

make all

# 7.1.3) Flashing the memory:

Use your prefered loader! If you are using a debugger Lauterbach, you can load the bash file: trace32 flash programmer.cmm. It loads directly the elf file.

# 7.1.4)Connecting to a serial RS232 console:

Connect the portS(TxD0) of the HCS12 to a console configured at 19200 bauds 8N1, via a Max232 chip to adapt the electricals levels. On Linux, you can use minicom. Connecting to a console is usefull to read the messages, but not required.

## 7.1.5) Connecting to the CAN network:

Connect the port CANO (pin PMO, PM1) to the network via a CAN controller. On our board, the CAN controler is a PCA82C250 chip.

# 7.1.6) starting the node:

Press the reset of your HCS12 board.

## 8 - Example and test program:

The "examples" directory contains some test program you can use as example for your own developments.

#### 8.1) TestMasterSlave:

```
*****************
  TestMasterSlave
  A simple example for PC. It does implement 2 CanOpen
  nodes in the same process. A master and a slave. Both
  communicate together, exchanging periodically NMT, SYNC,
  SDO and PDO.
  Usage:
   ./TestMasterSlave [OPTIONS]
   OPTIONS:
    -1 : Can library ["libcanfestival can virtual.so"]
    Slave:
    -s : bus name ["0"]
    -S: 1M,500K,250K,125K,100K,50K,20K,10K,none(disable)
   Master:
    -m : bus name ["1"]
    -M: 1M,500K,250K,125K,100K,50K,20K,10K,none(disable)
*****************
```

## 8.2) gene\_SYNC\_HCS12 :

This is a simple CanOpen node that only send cyclic SYNC message. It demonstrate implementation on HCS12 based board.

# 9 - Developing a new node

Using provided examples as a base for your new node is generally a good idea. You can also use the provided \*.od files as a base for your node object dictionary.

Creating a new CanOpen node implies to define the Object Dictionary of this node. For that, developer have to provide a C file. This C file contains the definition of all dictionary entries, and some kind of index table that helps the stack to access some entries directly.

## 9.1) Using Dictionary Editor GUI

The Object Dictionary Editor is a WxPython based GUI that is used to create the C file needed to create a new CanOpen node.

## 9.1.1)Installation and usage on Linux

You first have to download and install Gnosis XML modules. This is automated by a Makefile rule.

```
cd objdictgen
make
```

Now start the editor.

```
python objdictedit.py [od files...]
```

## 9.1.2)Installation and usage on Windows

Install Python (at least version 2.4) and wxPython (at least version 2.6.3.2).

Cygwin users can install Gnosis XML utils the same as Linux use. Just call make.

```
cd objdictgen make
```


Others will have to download and intall Gnosis XML by hand:

```
Gnosis Utils:
   http://freshmeat.net/projects/gnosisxml/
   http://www.gnosis.cx/download/Gnosis_Utils.More/Gnosis_Utils-
1.2.1.win32-py24.exe
   Get latest version.
```

Download CanFestival archive and uncompress it. Use windows file explorer to go into CanFestival3\objdicgten, and double-click on objdictedit.py.


# 9.1.3) About


The Object Dictionary editor GUI is a python application that use the Model-View-Controller design pattern. It depends on WxPython to display view on any supported platform.



#### 9.1.4) Main view


Top list let you choose dictionary section, bottom left list is the selected index in that dictionary, and bottom right list are edited sub-indexes.






#### 9.1.5) New node

Edit your node name, ID and type. Choose your inherited specific profile.



# 9.1.6) Node info

Edit your node name, ID and type.




#### 9.1.7) Profile editor

Chose the used profile to edit.




Pick up optional chosen profile entries.




# 9.1.8) User types

Use User Types to implement value boundaries, and string lentgth




## 9.1.9) Mapped variable

Add your own specific dictionary entries and associated mapped variables.




#### 9.1.10) Integrated help

Using F1 key, you can get context sensitive help.



In order to do that, official  $301\_v04000201.pdf$  file must be placed into doc/ directory, and xpdf must be present on your system.

F2 key open HTML CanFestival help.




## 9.2) Generating the object Dictionary

Once object dictionary has been edited and saved, you have to generate object dictionary C code for your CanFestival node.

## 9.2.1) With GUI

Menu entry "File/Build Dictionary".



Choose C file to create or overwrite. Header file will be also created with the same prefix as C file.

# 9.2.2) With command line

Usage of objdictgen.py:
python objdictgen.py XMLFilePath CfilePath

#### 10 - FAQ

#### 10.1) General

#### 10.1.1) Does the code compiles on Windows?

Yes, some user got success wompiling with Visual Studio C++.

Because CANopen layer is coded with C, put a compilation option /TC or /TP if you plant to mix C++ files. See the MSDN documentation about that.

## 10.1.2) How to fit the library to an other microcontrôler?

First, be sure that you have at least 40K bytes of program memory, and about 2k of RAM.

You have to create target specific interface to HW resources. Take model on bundled interfaces provided in drivers/ and create your own interface. You also have to update Makefile.in files for target specific cflags and options. Chose –targer= configure switch to compile your specific interface.

You are welcome to contribute-back your own interfaces! Other Canfestival users will use it and provide feedback, tests and enhancements.

## 10.1.3) Is CanFestival3 conform to DS301 v.4.02?

Thanks to Philippe Foureys (IUT of Valence), a slave node have been tested with the National Instrument CanOpen Conformance Test. It passed the test with success.

Some very small unconformity have been found in very unusual situations, for example in the SDO code response to wrong messages.

#### 10.2) LINUX

# 10.2.1) How to use a Peaksystem CAN board?

Just install peak driver and then compile and install Canfestival. Peak driver is detected at compile time.

# 10.2.2) How to use an unsupported CAN board?

You have to install the specific driver on your system, with necessary libs and headers.

Use can\_peak.c/h or can\_virtual.c/h as an example, and adapt it to your driver API.

Execute configure script and choose --can=mydriver

# 10.3) HCS12

# 10.3.1)Which board are you using?

A T-board from elektronikladen with a MC9S12DP256 or MC9S12DG256.

# 10.3.2) Does the code compile with an other compiler than GNU gcc?

It is known to work with Metrowerks CodeWarrior. Here are some tips from Philippe Foureys. :

#### a)Interrupt functions

#### i)Code for GCC:

```
// prototype
void __attribute__((interrupt))timer3Hdl(void):
// function
void __attribute__((interrupt))timer3Hdl(void){...}

ii)Code for CodeWarrior
// protoype
```

```
// protoype
void interrupt timer3Hdl(void);
// function
pragma CODE_SEG__NEAR_SEG_NON_BANKED
void interrupt timer3Hdl(void)
{...}
pragma CODE SEG DEFAULT
```

#### b)Interrupt lock, unlock

#### i)Code for GCC

```
void unlock (void)
{
   __asm__ _volatile__("cli");
}
void lock (void)
{
   unsigned short mask;
   __asm__ _volatile__("tpa\n\tsei":"=d"(mask));
}
```

#### ii)Code for CodeWarrior

```
void unlock (void)
{
    _asm("cli");
}
void lock (void)
{
    unsigned short mask;
    _asm
    {
     tpa:tsei:"=d"(mask);
    }
}
```

#### c)Initialize function

#### i)Code for GCC

```
void initCanHCS12 (void)
   //Init the HCS12 microcontroler for CanOpen
   initHCS12();
   // Init the HCS12 CAN driver
   const canBusInit bi0 = {
    0, /* no low power
                                         */
         /* no time stamp
                                          * /
     Ο,
         /* enable MSCAN
                                          */
    1,
         /* clock source : oscillator (In fact, it is not used) */
         /* no loop back
                                         */
         /* no listen only
    0,
    0, /* no low pass filter for wk up */
  CAN Baudrates [CAN BAUDRATE 250K],
      0x00, /* Filter on 16 bits.
                  See Motorola Block Guide V02.14 fig 4-3 */
      0x00, 0xFF, /* filter 0 hight accept all msg
                                                      * /
      0x00, 0xFF, /* filter 0 low accept all msg
                                                       * /
      0x00, 0xFF, /* filter 1 hight filter all of msg */
      0x00, 0xFF, /* filter 1 low filter all of msg */
      0x00, 0xFF, /* filter 2 hight filter most of msg */
      0x00, 0xFF, /* filter 2 low filter most of msg */
      0x00, 0xFF, /* filter 3 hight filter most of msg */
      0x00, 0xFF, /* filter 3 low filter most of msg */
     }
   };
```

#### ii)Code for CodeWarrior

```
void initCanHCS12 (void)
   //Init the HCS12 microcontroler for CanOpen
  initHCS12();
   // Init the HCS12 CAN driver
  const canBusInit bi0 = {
         /* no low power
                                          */
    0,
         /* no time stamp
                                          */
    Ο,
         /* enable MSCAN
                                          */
         /* clock source : oscillator (In fact, it is not used) */
         /* no loop back
                                       */
    Ο,
         /* no listen only
                                          */
    Ο,
    Ο,
         /* no low pass filter for wk up */
     1, /* clksrc */
     3, /* brp
                 */
     0, /* sjw
                  */
     0, /* samp */
     1, /* tseg2 */
     12,/* tseg1 */
    },
               /* Filter on 16 bits.
      0x00,
                 See Motorola Block Guide V02.14 fig 4-3 */
      0x00, 0xFF, /* filter 0 hight accept all msg
      0x00, 0xFF, /* filter 0 low accept all msg
                                                      * /
      0x00, 0xFF, /* filter 1 hight filter all of msg */
      0x00, 0xFF, /* filter 1 low filter all of msg */
      0x00, 0xFF, /* filter 2 hight filter most of msg */
      0x00, 0xFF, /* filter 2 low filter most of msg */
      0x00, 0xFF, /* filter 3 hight filter most of msg */
      0x00, 0xFF, /* filter 3 low filter most of msg */
    }
   };
```

## 10.3.3) Who to use warnings and errors messages?

#### a)Warnings messages

DEBUG_W AR_CONS OLE _ON	DEBUG _CAN	PrintMsg- WarTo- Console	Printing long message on console	message on console.	Sending number and value in a PDO., only if the node is a slave, in operational state.
DEF	DEF	1		yes	
DEF	DEF	0	yes		
DEF	UNDEF	1			
DEF	UNDEF	0			
UNDEF	X	X			

#### b)Errors messages

DEBUG_E RR_CONS OLE _ON	DEBUG _CAN	PDO _ERROR	PrintMsg- ErrTo- Console	Printing long message on console		Sending number and value in a PDO., only if the node is a slave, in operational state.
DEF	DEF	X	1		yes	yes
DEF	DEF	X	0	yes		yes
DEF	UNDEF	X	1			yes
DEF	UNDEF	X	0			yes
UNDEF	X	DEF	X			yes
UNDEF	X	UNDEF	X			

# 10.3.4) Does the code works in banked memory?

No. Today it seems that the port of gcc is bogged for using the banked memory. So, unfortunately, we are limited to  $48\ \text{Kbytes}$  of memory code.

## 10.3.5) What GCC version are you using?

We are using the stable RPM release 2.2:

- GNU Gcc 3.0.4. Build 20030501
- Newlib 1.10.0 Build 20030421
- GNU Binutils 2.12.1 Build 20030427

## 11 - Documentation resources

#### a)CIA: Can in Automation

Many documentation on CANopen.

http://www.can-cia.de

## b)Resources and training in CANopen

http://www.esacademy.com

#### c)Elektronikladen HCS12 T-board

http://www.elektronikladen.de/en hcs12tb.html

#### d)Gnu gcc compiler for HC12

http://m68hc11.serveftp.org/m68hc11\_port.php

#### e)Motorola documentation on HC12

 $\underline{http://www.freescale.com/webapp/sps/site/prod\_summary.jsp?code=MC9S12DP256}$ 

#### f)Lauterbach debugger for HC12

http://www.lauterbach.com

#### g)Python language

http://www.python.org

# 12 - About the project

#### 12.1) Contributors



Unité mixte de recherche INRETS-LCPC

sur les Interractions Véhicule-Infrastructure-Conducteur

14, route de la minière

78000 Versailles

**FRANCE** 

Tel: +33 1 40 43 29 01

http://www.inrets.fr/ur/livic

**Contributors:** Francis DUPIN

Camille BOSSARD
Laurent ROMIEUX



LOLITECH

204, rue du Haut du Pin

88470 Saint-Michel sur Meurthe

**FRANCE** 

Tel: +33 3 29 52 95 67

http://www.lolitech.fr

**Contributors:** Edouard TISSERANT (Original author)

Laurent BESSARD

Many thanks to the other contributors for their great work:

Raphael ZULLIGER

David DUMINY (sté A6R)

Zakaria BELAMRI

# 12.2) Getting support

Send your feedback and bug reports to <u>canfestival-devel@lists.sourceforge.net</u>.

For commercial support, training and specific integration and developments, please ask LOLITECH (see contributors).

## 12.3) Contributing

You are free to contribute your specific interfaces back to the project. This way, you can hope to get support from CanFestival users community.

Please send your patch to canfestival-devel@lists.sourceforge.net.

Feel free to create some new predefined DS-4xx profiles (\*.prf) in objdictgen/config, as much as possible respectful to the official specifications.

#### 12.4) License

All the project is licensed with LGPL. This mean you can link CanFestival with any code without being obliged to publish it.

```
#This file is part of CanFestival, a library implementing CanOpen Stack.

# #Copyright (C): Edouard TISSERANT, Francis DUPIN and Laurent BESSARD

# #See COPYING file for copyrights details.

# #This library is free software; you can redistribute it and/or

#modify it under the terms of the GNU Lesser General Public

#License as published by the Free Software Foundation; either

#version 2.1 of the License, or (at your option) any later version.

# #This library is distributed in the hope that it will be useful,

#but WITHOUT ANY WARRANTY; without even the implied warranty of

#MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU

#Lesser General Public License for more details.

# #You should have received a copy of the GNU Lesser General Public

#License along with this library; if not, write to the Free Software

#Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA
```