KEEP BESIDE YOUR PHONE

Dial guide

Lift the handset or press Speaker, dial a number, then end the call when finished.

Four phones, two independent lines each

PHONE 1	PHONE 2	PHONE 3	PHONE 4
201 / 202	203 / 204	205 / 206	207 / 208

DIAL	SERVICE	WHAT TO EXPECT
600	**Echo test**	Hear your voice returned to you.
601	**Test tone**	Check that audio plays.
620	**Ring all phones**	Calls each phone's primary line; DND phones are skipped.
630	**Home Assistant**	Russian voice assistant using Silero Baya.
640	**Manual tone test**	Finite test tone; not the timer/alarm ringer.
701	**Matryoshka Radio London**	Russian and international music
702	**Echo online**	Russian speech; current Echo service
703	**RADIO BOB! Live**	Rock
704	**RADIO BOB! Metal**	Metal
705	**RADIO BOB! Gothic**	Gothic rock
706	**SomaFM PopTron**	Electropop and indie dance rock
707	**Radyo Viva**	Turkish music

Radio needs an Internet connection. Calls are limited to 2 hours; hang up to stop immediately. Echo online is the current online service, not the former Moscow FM broadcast.

CONTROL FROM HOME ASSISTANT

Calls, alarms & messages

Updated alerts require the matching gateway and Home Assistant integration.

Set an alarm for selected days

Choose the local time and weekdays, then enable the alarm. It keeps ringing until you answer or reject it on the phone, press Stop alert, or disable Alarm enabled. There is no auto-answer or audio after answering.

Start or stop a timer

Set the duration and press Start timer. At zero, the phone rings until you answer, reject it or press Stop alert. Cancel timer cancels the countdown and stops its active alert. Busy, offline or DND phones can miss alerts; recovery does not replay them.

Call controls

Choose the line and allowed destination, then use Dial. HA Answer handles normal ringing calls, not timer/alarm alerts. Hang up ends the selected active call. Speaker toggles a physical key; HA cannot reliably report the hardware speaker or handset state.

Do Not Disturb and auto-answer

DND blocks local calls routed through the PBX and gateway calls. It is separate from the phone's native DND icon. Optional auto-answer is off by default and applies only to normal calls. Timers and alarms always require manual dismissal.

Send text, photos or still sprites

Send a text page or an approved local PNG/JPEG image through the integration. Pictures fit the 298 x 156 Services pane. Press Exit on the phone to return. These are local screen notifications, not mobile SMS/MMS; animation and video are not supported.

External calls and free SIP accounts

801-803 are reserved for optional provider tests and work only after both the account and its call route are verified. Free SIP-to-SIP calling does not mean free calls to ordinary telephone numbers. Google Voice has no supported free direct Asterisk trunk. Use another working service for emergency calls.

New alerts: deployment and live acceptance pending. If the screen is dark, press Display (two overlapping rectangles). Voice assistance: dial 630. Setup and validation: github.com/4alvit/cisco-home-telephony