KEEP BESIDE YOUR PHONE

Dial guide

Lift the handset or press Speaker, dial a number, then end the call when finished.

Four phones, two independent lines each

PHONE 1	PHONE 2	PHONE 3	PHONE 4
201 / 202	203 / 204	205 / 206	207 / 208

DIAL	SERVICE	WHAT TO EXPECT
600	**Echo test**	Hear your voice returned to you.
601	**Test tone**	Check that audio plays.
620	**Ring all phones**	Calls each phone's primary line; DND phones are skipped.
630	**Home Assistant**	Russian voice assistant using Silero Baya.
640	**Alarm sound**	Short alarm tone; the call ends automatically.
701	**Matryoshka Radio London**	Russian and international music
702	**Echo online**	Russian speech; current Echo service
703	**RADIO BOB! Live**	Rock
704	**RADIO BOB! Metal**	Metal
705	**RADIO BOB! Gothic**	Gothic rock
706	**SomaFM PopTron**	Electropop and indie dance rock
707	**Radyo Viva**	Turkish music

Radio needs an Internet connection. Calls are limited to 2 hours; hang up to stop immediately. Echo online is the current online service, not the former Moscow FM broadcast.

CONTROL FROM HOME ASSISTANT

Calls, alarms & messages

Use the Cisco Phone Control device for the phone you want to operate.

Set an alarm for selected days

Choose an alarm time, enable the desired weekdays, and enable the alarm. Times follow Home Assistant's configured local time zone. The selected phone rings; answer to hear the short alarm sound.

Start a timer

Set the timer duration and press Start timer. Use Cancel timer to stop it. A timer is one-shot. DND, an offline phone, or a busy phone can prevent delivery; missed alerts are not replayed after recovery.

Call controls

Choose the line and allowed destination, then use Dial. Answer acts on a currently ringing call. Hang up ends the selected active call. Speaker is an explicit button toggle; Home Assistant cannot reliably report the physical speaker or handset state.

Do Not Disturb and auto-answer

DND blocks local calls routed through the PBX and gateway alerts. It is separate from the phone's native DND icon. Auto-answer is optional and off by default. When enabled it answers incoming calls; the phone's selected audio path may be speaker or headset.

Send text, photos or still sprites

Send a text page or an approved local PNG/JPEG image through the integration. Pictures fit the 298 x 156 Services pane. Press Exit on the phone to return. These are local screen notifications, not mobile SMS/MMS; animation and video are not supported.

External calls and free SIP accounts

801-803 are reserved for optional provider tests and work only after account setup. Free SIP-to-SIP calling does not mean free calls to ordinary telephone numbers. Google Voice has no supported free direct Asterisk trunk. Use another working service for emergency calls.

If the screen is dark: press the Display button (two overlapping rectangles). For voice assistance: dial 630 and speak after the prompt. Full setup, capabilities and validation: github.com/4alvit/cisco-home-telephony