


# Analog Inputs


# 3.5mm\_Mono\_Switched 47k A0 Start\_CV







# Digital Ins/Outs










# **Buttons/Switches**









#### SD Card




#### **Pots**




# Audio




### Headers




		JB1		
AUDIO_OUT2	t_02×	05_P	2.54mm_TH	DO Bank_But_
AUDIO_OUT1	3		4	D1 Bank_But_
AUDIO_IN2	5		6	* D15 End_Out
AUDIO_IN1	7		8	* D13 Play_Trig
Rev_But_B D3	9		10	D2 Rev_Trig








# **POWER**











# 4ms Sampler Kit

