

# **Advanced Audio Coding Encoder Library**

MPEG-2 and MPEG-4 AAC Low-Complexity,

MPEG-4 High-Efficiency AAC v2

MPEG-4 Enhanced Low Delay AAC

encoder

Fraunhofer Institut fuer Integrierte Schaltungen IIS, Fraunhofer Institute for Integrated Circuits IIS http://www.iis.fraunhofer.de/amm

#### Disclaimer

Information in this document is subject to change without notice. Companies, names, and data used in examples herein are fictitious unless otherwise noted. Product and corporate names may be trademarks or registered trademarks of other companies. They are used for explanation only, with no intent to infringe. All rights reserved. No part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from the publisher.

# **Contents**

1	Intro	oduction	1
	1.1	Scope	1
	1.2	Encoder Basics	1
2	Libr	ary Usage	3
	2.1	API Files	3
	2.2	Calling Sequence	3
	2.3	Encoder Instance Allocation	4
	2.4	Input/Output Arguments	5
		2.4.1 Provide Buffer Descriptors	5
		2.4.2 Provide Input/Output Argument Lists	6
	2.5	Feed Input Buffer	6
	2.6	Output Bitstream Data	$\epsilon$
	2.7	Meta Data Configuration	7
	2.8	Encoder Reconfiguration	7
	2.9	Encoder Parametrization	7
		2.9.1 Mandatory Encoder Parameters	8
		2.9.2 Channel Mode Configuration	8
		2.9.3 Audio Quality Considerations	8
		2.9.4 ELD Auto Configuration Mode	8
	2.10	Audio Channel Configuration	9
	2.11	Supported Bitrates	10
	2.12	Recommended Sampling Rate and Bitrate Combinations	11
		2.12.1 AAC-LC, HE-AAC, HE-AACv2 in Dualrate SBR mode	11
		2.12.2 AAC-LD, AAC-ELD, AAC-ELD with SBR in Dualrate SBR mode	11
		2.12.3 AAC-ELD with SBR in Downsampled SBR mode	12
3	Enco	oder Behaviour	13
	2.1	D 1 114	1.0

ii CONTENTS

	3.2	Frame	Sizes & Bit Reservoir	13
		3.2.1	Estimating Average Frame Sizes	14
	3.3	Encode	er Tools	14
4	Clea	s Index		15
4	4.1		List	15
	4.1	Class I	2181	13
5	File	Index		17
	5.1	File Li	st	17
6	Clas	s Docui	mentation	19
	6.1		NC_BufDesc Struct Reference	19
		6.1.1	Detailed Description	19
		6.1.2	Member Data Documentation	19
			6.1.2.1 bufElSizes	19
			6.1.2.2 bufferIdentifiers	19
			6.1.2.3 bufs	19
			6.1.2.4 bufSizes	20
			6.1.2.5 numBufs	20
	6.2	AACE	NC_InArgs Struct Reference	20
		6.2.1	Detailed Description	20
		6.2.2	Member Data Documentation	20
			6.2.2.1 numAncBytes	20
			6.2.2.2 numInSamples	20
	6.3	AACE	NC_InfoStruct Struct Reference	20
		6.3.1	Detailed Description	21
		6.3.2	Member Data Documentation	21
			6.3.2.1 confBuf	21
			6.3.2.2 confSize	21
			6.3.2.3 encoderDelay	21
			6.3.2.4 frameLength	21
			6.3.2.5 inBufFillLevel	21
			6.3.2.6 inputChannels	21
			6.3.2.7 maxAncBytes	21
			6.3.2.8 maxOutBufBytes	22
	6.4		NC_MetaData Struct Reference	22
		6.4.1	Detailed Description	22
		6.4.2	Member Data Documentation	22

CONTENTS

			6.4.2.1	centerMixLevel	22
			6.4.2.2	comp_profile	22
			6.4.2.3	comp_TargetRefLevel	22
			6.4.2.4	dolbySurroundMode	23
			6.4.2.5	drc_profile	23
			6.4.2.6	drc_TargetRefLevel	23
			6.4.2.7	ETSI_DmxLvl_present	23
			6.4.2.8	PCE_mixdown_idx_present	23
			6.4.2.9	prog_ref_level	23
			6.4.2.10	prog_ref_level_present	23
			6.4.2.11	surroundMixLevel	23
	6.5	AACE	NC_OutA	rgs Struct Reference	23
		6.5.1	Detailed	Description	24
		6.5.2	Member	Data Documentation	24
			6.5.2.1	numAncBytes	24
			6.5.2.2	numInSamples	24
			6.5.2.3	numOutBytes	24
7	File	Docum	entation		25
	7.1	aacenc	_lib.h File	Reference	25
	7.1	aacenc		Reference	25 28
	7.1		Detailed		
	7.1	7.1.1	Detailed	Description	28
	7.1	7.1.1	Detailed Typedef 7.1.2.1	Description	28 28
	7.1	7.1.1 7.1.2	Detailed Typedef 7.1.2.1	Description	28 28 28
	7.1	7.1.1 7.1.2	Detailed Typedef 7.1.2.1 Enumera	Description	28 28 28 28
	7.1	7.1.1 7.1.2	Detailed Typedef 7.1.2.1 Enumera 7.1.3.1	Description	28 28 28 28 28
	7.1	7.1.1 7.1.2	Detailed Typedef 7.1.2.1 Enumera 7.1.3.1 7.1.3.2	Description  Documentation  HANDLE_AACENCODER  ACENC_BufferIdentifier  AACENC_CTRLFLAGS	28 28 28 28 28 28
	7.1	7.1.1 7.1.2	Detailed Typedef 7.1.2.1 Enumera 7.1.3.1 7.1.3.2 7.1.3.3	Description  Documentation  HANDLE_AACENCODER  tion Type Documentation  AACENC_BufferIdentifier  AACENC_CTRLFLAGS  AACENC_ERROR	28 28 28 28 28 28
	7.1	7.1.1 7.1.2	Detailed Typedef 7.1.2.1 Enumera 7.1.3.1 7.1.3.2 7.1.3.3 7.1.3.4 7.1.3.5	Description  Documentation  HANDLE_AACENCODER  ACTION Type Documentation  AACENC_BufferIdentifier  AACENC_CTRLFLAGS  AACENC_ERROR  AACENC_METADATA_DRC_PROFILE	28 28 28 28 28 28 28 29
	7.1	7.1.1 7.1.2 7.1.3	Detailed Typedef 7.1.2.1 Enumera 7.1.3.1 7.1.3.2 7.1.3.3 7.1.3.4 7.1.3.5	Description  Documentation  HANDLE_AACENCODER  Ation Type Documentation  AACENC_BufferIdentifier  AACENC_CTRLFLAGS  AACENC_ERROR  AACENC_ERROR  AACENC_METADATA_DRC_PROFILE  AACENC_PARAM	28 28 28 28 28 28 28 29 29
	7.1	7.1.1 7.1.2 7.1.3	Detailed Typedef 7.1.2.1 Enumera 7.1.3.1 7.1.3.2 7.1.3.3 7.1.3.4 7.1.3.5 Function	Description  Documentation  HANDLE_AACENCODER  ACENC_BufferIdentifier  AACENC_CTRLFLAGS  AACENC_ERROR  AACENC_METADATA_DRC_PROFILE  AACENC_PARAM  Documentation	28 28 28 28 28 28 29 29
	7.1	7.1.1 7.1.2 7.1.3	Detailed Typedef 7.1.2.1 Enumera 7.1.3.1 7.1.3.2 7.1.3.3 7.1.3.4 7.1.3.5 Function 7.1.4.1	Description  Documentation  HANDLE_AACENCODER  Ition Type Documentation  AACENC_BufferIdentifier  AACENC_CTRLFLAGS  AACENC_ERROR  AACENC_ERROR  AACENC_METADATA_DRC_PROFILE  AACENC_PARAM  Documentation  aacEncClose	28 28 28 28 28 28 29 29 32
	7.1	7.1.1 7.1.2 7.1.3	Detailed Typedef 7.1.2.1 Enumera 7.1.3.1 7.1.3.2 7.1.3.3 7.1.3.4 7.1.3.5 Function 7.1.4.1 7.1.4.2	Description  Documentation  HANDLE_AACENCODER  Ition Type Documentation  AACENC_BufferIdentifier  AACENC_CTRLFLAGS  AACENC_ERROR  AACENC_METADATA_DRC_PROFILE  AACENC_PARAM  Documentation  aacEncClose  aacEncClose	28 28 28 28 28 28 29 29 32 32 33
	7.1	7.1.1 7.1.2 7.1.3	Detailed Typedef 7.1.2.1 Enumera 7.1.3.1 7.1.3.2 7.1.3.3 7.1.3.4 7.1.3.5 Function 7.1.4.1 7.1.4.2 7.1.4.3	Description  Documentation  HANDLE_AACENCODER  Ation Type Documentation  AACENC_BufferIdentifier  AACENC_CTRLFLAGS  AACENC_ERROR  AACENC_METADATA_DRC_PROFILE  AACENC_PARAM  Documentation  aacEncClose  aacEncClose  aacEncGetLibInfo	28 28 28 28 28 28 29 29 32 32 33 34
	7.1	7.1.1 7.1.2 7.1.3	Detailed Typedef 7.1.2.1 Enumera 7.1.3.1 7.1.3.2 7.1.3.3 7.1.3.4 7.1.3.5 Function 7.1.4.1 7.1.4.2 7.1.4.3 7.1.4.4	Description  Documentation  HANDLE_AACENCODER  Ation Type Documentation  AACENC_BufferIdentifier  AACENC_CTRLFLAGS  AACENC_ERROR  AACENC_METADATA_DRC_PROFILE  AACENC_PARAM  Documentation  aacEncClose  aacEncClose  aacEncGetLibInfo  aacEncInfo	28 28 28 28 28 29 32 32 33 34 34
	7.1	7.1.1 7.1.2 7.1.3	Detailed Typedef 7.1.2.1 Enumera 7.1.3.1 7.1.3.2 7.1.3.3 7.1.3.4 7.1.3.5 Function 7.1.4.1 7.1.4.2 7.1.4.3 7.1.4.4 7.1.4.5	Description  Documentation  HANDLE_AACENCODER  ACTION Type Documentation  AACENC_BufferIdentifier  AACENC_CTRLFLAGS  AACENC_ERROR  AACENC_METADATA_DRC_PROFILE  AACENC_PARAM  Documentation  aacEncClose  aacEncClose  aacEncGetLibInfo  aacEncInfo  aacEncoder_GetParam	28 28 28 28 28 29 29 32 32 33 34 34

## **Chapter 1**

## Introduction

### 1.1 Scope

This document describes the high-level interface and usage of the ISO/MPEG-2/4 AAC Encoder library developed by the Fraunhofer Institute for Integrated Circuits (IIS).

The library implements encoding on the basis of the MPEG-2 and MPEG-4 AAC Low-Complexity standard, and depending on the library's configuration, MPEG-4 High-Efficiency AAC v2 and/or AAC-ELD standard.

All references to SBR (Spectral Band Replication) are only applicable to HE-AAC or AAC-ELD versions of the library. All references to PS (Parametric Stereo) are only applicable to HE-AAC v2 versions of the library.

#### 1.2 Encoder Basics

This document can only give a rough overview about the ISO/MPEG-2 and ISO/MPEG-4 AAC audio coding standard. To understand all the terms in this document, you are encouraged to read the following documents.

- ISO/IEC 13818-7 (MPEG-2 AAC), which defines the syntax of MPEG-2 AAC audio bitstreams.
- ISO/IEC 14496-3 (MPEG-4 AAC, subparts 1 and 4), which defines the syntax of MPEG-4 AAC audio bitstreams.
- Lutzky, Schuller, Gayer, Krämer, Wabnik, "A guideline to audio codec delay", 116th AES Convention, May 8, 2004

MPEG Advanced Audio Coding is based on a time-to-frequency mapping of the signal. The signal is partitioned into overlapping portions and transformed into frequency domain. The spectral components are then quantized and coded.

An MPEG-2 or MPEG-4 AAC audio bitstream is composed of frames. Contrary to MPEG-1/2 Layer-3 (mp3), the length of individual frames is not restricted to a fixed number of bytes, but can take on any length between 1 and 768 bytes.

2 Introduction

## **Chapter 2**

# **Library Usage**

#### 2.1 API Files

All API header files are located in the folder /include of the release package. All header files are provided for usage in C/C++ programs. The AAC encoder library API functions are located at <a href="mailto:acceeding-nc-lib.h">accenc\_lib.h</a>.

In binary releases the encoder core resides in statically linkable libraries called for example libAA-Cenc.a/libFDK.a (LINUX) or FDK\_fastaaclib.lib (MS Visual C++) for the plain AAC-LC core encoder and libSBRenc.a (LINUX) or FDK\_sbrEncLib.lib (MS Visual C++) for the SBR (Spectral Band Replication) and PS (Parametric Stereo) modules.

## 2.2 Calling Sequence

For encoding of ISO/MPEG-2/4 AAC bitstreams the following sequence is mandatory. Input read and output write functions as well as the corresponding open and close functions are left out, since they may be implemented differently according to the user's specific requirements. The example implementation in main.cpp uses file-based input/output.

1. Call aacEncOpen() to allocate encoder instance with required configuration.

2. Call aacEncoder\_SetParam() for each parameter to be set. AOT, samplingrate, channelMode, bitrate and transport type are mandatory.

```
ErrorStatus = aacEncoder_SetParam(hAacEncoder, parameter, value);
```

3. Call aacEncEncode() with NULL parameters to initialize encoder instance with present parameter set.

```
ErrorStatus = aacEncEncode(hAacEncoder, NULL, NULL, NULL);
```

4. Call aacEncInfo() to retrieve a configuration data block to be transmitted out of band. This is required when using RFC3640 or RFC3016 like transport.

```
AACENC_InfoStruct encInfo;
ErrorStatus = aacEncInfo(hAacEncoder, &encInfo);
```

4 Library Usage

5. Encode input audio data in loop.

```
do
```

Feed input buffer with new audio data and provide input/output arguments to aacEncEncode().

```
ErrorStatus = aacEncEncode(hAacEncoder,
                           &inBufDesc,
                           &outBufDesc,
                           &inargs,
                          &outargs);
```

Write output data to file or audio device.

```
} while (ErrorStatus==AACENC_OK);
```

6. Call aacEncClose() and destroy encoder instance.

```
aacEncClose(&hAacEncoder);
```

#### 2.3 **Encoder Instance Allocation**

The assignment of the aacEncOpen() function is very flexible and can be used in the following way.

• If the amount of memory consumption is not an issue, the encoder instance can be allocated for the maximum number of possible audio channels (for example 6 or 8) with the full functional range supported by the library. This is the default open procedure for the AAC encoder if memory consumption does not need to be minimized.

```
aacEncOpen(&hAacEncoder,0,0)
```

• If the required MPEG-4 AOTs do not call for the full functional range of the library, encoder modules can be allocated selectively.

```
AAC | SBR | PS | MD | FLAGS | value
- | - | X | (0x01 | |0x10) | 0x11
X | - | X | (0x01|0x02 | |0x10) | 0x13
Χ
  | X | X | X | (0x01|0x02|0x04|0x10) | 0x17
- AAC: Allocate AAC Core Encoder module.
```

- SBR: Allocate Spectral Band Replication module.
- PS: Allocate Parametric Stereo module.
- MD: Allocate Meta Data module within AAC encoder.

```
aacEncOpen(&hAacEncoder,value,0)
```

- Specifying the maximum number of channels to be supported in the encoder instance can be done as follows.
  - For example allocate an encoder instance which supports 2 channels for all supported AOTs. The library itself may be capable of encoding up to 6 or 8 channels but in this example only 2 channel encoding is required and thus only buffers for 2 channels are allocated to save data memory.

```
aacEncOpen(&hAacEncoder, 0, 2)
```

 Additionally the maximum number of supported channels in the SBR module can be denoted separately.

In this example the encoder instance provides a maximum of 6 channels out of which up to 2 channels support SBR. This encoder instance can produce for example 5.1 channel AAC-LC streams or stereo HE-AAC (v2) streams. HE-AAC 5.1 multi channel is not possible since only 2 out of 6 channels support SBR, which saves data memory.

```
aacEncOpen(&hAacEncoder, 0, 6|(2<<8))
```

### 2.4 Input/Output Arguments

#### 2.4.1 Provide Buffer Descriptors

In the present encoder API, the input and output buffers are described with buffer descriptors. This mechanism allows a flexible handling of input and output buffers without impact to the actual encoding call. Optional buffers are necessary e.g. for ancillary data, meta data input or additional output buffers describing superframing data in DAB+ or DRM+.

At least one input buffer for audio input data and one output buffer for bitstream data must be allocated. The input buffer size can be a user defined multiple of the number of input channels. PCM input data will be copied from the user defined PCM buffer to an internal input buffer and so input data can be less than one AAC audio frame. The output buffer size should be 6144 bits per channel excluding the LFE channel. If the output data does not fit into the provided buffer, an AACENC\_ERROR will be returned by aacEncEncode().

```
static INT_PCM inputBuffer[8*2048];
static UCHAR ancillaryBuffer[50];
static AACENC_MetaData metaDataSetup;
static UCHAR outputBuffer[8192];
```

All input and output buffer must be clustered in input and output buffer arrays.

#### Allocate buffer descriptors

```
AACENC_BufDesc inBufDesc = {0};
AACENC_BufDesc outBufDesc = {0};
```

#### Initialize input buffer descriptor

6 Library Usage

Initialize output buffer descriptor

#### 2.4.2 Provide Input/Output Argument Lists

The input and output arguments of an aacEncEncode() call are described in argument structures.

```
AACENC_InArgs inargs = {0};
AACENC_OutArgs outargs = {0};
```

### 2.5 Feed Input Buffer

The input buffer should be handled as a modulo buffer. New audio data in the form of pulse-code-modulated samples (PCM) must be read from external and be fed to the input buffer depending on its fill level. The required sample bitrate (represented by the data type INT\_PCM which is 16, 24 or 32 bits wide) is fixed and depends on library configuration (usually 16 bit).

After the encoder's internal buffer is fed with incoming audio samples, and <a href="mailto:aceEncode">aceEnceDecode</a>() processed the new input data, update/move remaining samples in input buffer, simulating a modulo buffer:

## 2.6 Output Bitstream Data

If any AAC bitstream data is available, write it to output file or device. This can be done once the following condition is true:

```
if (outargs.numOutBytes>0) {
} /* (outBytes>0) */
```

If you use file I/O then for example call mpegFileWrite\_Write() from the library libMpegFileWrite

```
mpegFileWrite_Write(hMpegFile, outputBuffer, outargs.numOutBytes)
;
```

### 2.7 Meta Data Configuration

If the present library is configured with Metadata support, it is possible to insert meta data side info into the generated audio bitstream while encoding.

To work with meta data the encoder instance has to be allocated with meta data support. The meta data mode must be be configured with the AACENC\_METADATA\_MODE parameter and aacEncoder\_SetParam() function.

```
aacEncoder_SetParam(hAacEncoder, AACENC_METADATA_MODE, 0-2);
```

This configuration indicates how to embed meta data into bitstrem. Either no insertion, MPEG or ETSI style. The meta data itself must be specified within the meta data setup structure AACENC\_MetaData.

Changing one of the AACENC\_MetaData setup parameters can be achieved from outside the library within IN\_METADATA\_SETUP input buffer. There is no need to supply meta data setup structure every frame. If there is no new meta setup data available, the encoder uses the previous setup or the default configuration in initial state.

In general the audio compressor and limiter within the encoder library can be configured with the AACENC\_METADATA\_DRC\_PROFILE parameter AACENC\_MetaData::drc\_profile and and AACENC\_MetaData::comp\_profile.

## 2.8 Encoder Reconfiguration

The encoder library allows reconfiguration of the encoder instance with new settings continuously between encoding frames. Each parameter to be changed must be set with a single aacEncoder\_SetParam() call. The internal status of each parameter can be retrieved with an aacEncoder\_GetParam() call.

There is no stand-alone reconfiguration function available. When parameters were modified from outside the library, an internal control mechanism triggers the necessary reconfiguration process which will be applied at the beginning of the following <a href="mailto:aacEncencode">aacEncencode</a>() call. This state can be observed from external via the AACENC\_INIT\_STATUS and <a href="mailto:aacEncode">aacEncode</a>() function. The reconfiguration process can also be applied immediately when all parameters of an <a href="mailto:aacEncode">aacEncencode</a>() call are NULL with a valid encoder handle.

The internal reconfiguration process can be controlled from extern with the following access.

```
aacEncoder_SetParam(hAacEncoder, AACENC_CONTROL_STATE, AACENC_CTRLFLAGS);
```

#### 2.9 Encoder Parametrization

All parameteres listed in AACENC\_PARAM can be modified within an encoder instance.

8 Library Usage

#### 2.9.1 Mandatory Encoder Parameters

The following parameters must be specified when the encoder instance is initialized.

```
aacEncoder_SetParam(hAacEncoder, AACENC_AOT, value);
aacEncoder_SetParam(hAacEncoder, AACENC_BITRATE, value);
aacEncoder_SetParam(hAacEncoder, AACENC_SAMPLERATE, value);
aacEncoder_SetParam(hAacEncoder, AACENC_CHANNELMODE, value);
```

Beyond that is an internal auto mode which preinitizializes the AACENC\_BITRATE parameter if the parameter was not set from extern. The bitrate depends on the number of effective channels and sampling rate and is determined as follows.

```
AAC-LC (AOT_AAC_LC): 1.5 bits per sample
HE-AAC (AOT_SBR): 0.625 bits per sample (dualrate sbr)
HE-AAC (AOT_SBR): 1.125 bits per sample (downsampled sbr)
HE-AAC v2 (AOT_PS): 0.5 bits per sample
```

#### 2.9.2 Channel Mode Configuration

The input audio data is described with the AACENC\_CHANNELMODE parameter in the aacEncoder\_SetParam() call. It is not possible to use the encoder instance with a 'number of input channels' argument. Instead, the channelMode must be set as follows.

```
aacEncoder_SetParam(hAacEncoder, AACENC_CHANNELMODE, value);
```

The parameter is specified in CHANNEL\_MODE and can be mapped from the number of input channels in the following way.

#### 2.9.3 Audio Quality Considerations

The default encoder configuration is suggested to be used. Encoder tools such as TNS and PNS are activated by default and are internally controlled (see Encoder Tools).

There is an additional quality parameter called AACENC\_AFTERBURNER. In the default configuration this quality switch is deactivated because it would cause a workload increase which might be significant. If workload is not an issue in the application we recommended to activate this feature.

```
aacEncoder_SetParam(hAacEncoder, AACENC_AFTERBURNER, 1);
```

#### 2.9.4 ELD Auto Configuration Mode

For ELD configuration a so called auto configurator is available which configures SBR and the SBR ratio by itself. The configurator is used when the encoder parameter AACENC\_SBR\_MODE and AACENC\_-SBR\_RATIO are not set explicitly.

Based on sampling rate and chosen bitrate per channel a reasonable SBR configuration will be used.

Sampling Rate	   Channel Bitrate	I I SBR I	SBR Ratio
1 2			
	min - 27999		-
	28000 - max +		
	min - 39999		
	40000 - max		
	min - 27999		
	28000 - 55999	on	downsampled SBR
	56000 - max +		
	min - 63999		
	64000 - max		
	+   min - 63999		
-	64000 - max	off	

## 2.10 Audio Channel Configuration

The MPEG standard refers often to the so-called Channel Configuration. This Channel Configuration is used for a fixed Channel Mapping. The configurations 1-7 are predefined in MPEG standard and used for implicit signalling within the encoded bitstream. For user defined Configurations the Channel Configuration is set to 0 and the Channel Mapping must be explecitly described with an appropriate Program Config Element. The present Encoder implementation does not allow the user to configure this Channel Configuration from extern. The Encoder implementation supports fixed Channel Modes which are mapped to Channel Configuration as follow.

ChannelMode	ChCfg	 	front	El		   side_El +	   +-	back_El	   	lfe_El
MODE_1 MODE_2 MODE_1_2 MODE_1_2_1 MODE_1_2_2 MODE_1_2_2 MODE_1_2_2_1 MODE_1_2_2_1	1   2   3   4   5   6	 	SCE CPE SCE, SCE, SCE, SCE,	CPE CPE CPE	CPE	           	i	SCE CPE CPE CPE	.	LFE LFE
MODE_7_1_REAR_SURROUND MODE_7_1_FRONT_CENTER	0   0		SCE,		CPE	+   	+-   	CPE, CPE	+-	LFE LFE

- SCE: Single Channel Element.
- CPE: Channel Pair.
- SCE: Low Frequency Element.

Moreover, the Table describes all fixed Channel Elements for each Channel Mode which are assigned to a speaker arrangement. The arrangement includes front, side, back and lfe Audio Channel Elements.

This mapping of Audio Channel Elements is defined in MPEG standard for Channel Config 1-7. The Channel assignment for MODE\_1\_1, MODE\_2\_2 and MODE\_2\_1 is used from the ARIB standard. All other configurations are defined as suggested in MPEG.

In case of Channel Config 0 or writing matrix mixdown coefficients, the encoder enables the writing of Program Config Element itself as described in encPCE. The configuration used in Program Config Element refers to the denoted Table.

Beside the Channel Element assignment the Channel Modes are resposible for audio input data channel mapping. The Channel Mapping of the audio data depends on the selected AACENC\_CHANNELORDER

10 Library Usage

which can be MPEG or WAV like order.

Following Table describes the complete channel mapping for both Channel Order configurations.

ChannelMode	MPEG-Channelorder   WAV-Channelorder	
	+++++++++++	++
MODE_1		
MODE_2		
MODE_1_2		
MODE_1_2_1	0   1   2   3           2   0   1   3	
MODE_1_2_2	0   1   2   3   4         2   0   1   3   4	
MODE_1_2_2_1	0   1   2   3   4   5       2   0   1   4   5	3
MODE_1_2_2_2_1	0   1   2   3   4   5   6   7   2   6   7   0   1	4   5   3
	++++++++++	++
MODE_7_1_REAR_SURROUND	0   1   2   3   4   5   6   7   2   0   1   6   7	4   5   3
MODE_7_1_FRONT_CENTER	0   1   2   3   4   5   6   7   2   6   7   0   1	4   5   3

The denoted mapping is important for correct audio channel assignment when using MPEG or WAV ordering. The incoming audio channels are distributed MPEG like starting at the front channels and ending at the back channels. The distribution is used as described in Table concering Channel Config and fix channel elements. Please see the following example for clarification.

## 2.11 Supported Bitrates

The FDK AAC Encoder provides a wide range of supported bitrates. The minimum and maximum allowed bitrate depends on the Audio Object Type. For AAC-LC the minimum bitrate is the bitrate that is required to write the most basic and minimal valid bitstream. It consists of the bitstream format header information and other static/mandatory information within the AAC payload. The maximum AAC framesize allowed by the MPEG-4 standard determines the maximum allowed bitrate for AAC-LC. For HE-AAC and HE-AAC v2 a library internal look-up table is used.

A good working point in terms of audio quality, sampling rate and bitrate, is at 1 to 1.5 bits/audio sample for AAC-LC, 0.625 bits/audio sample for dualrate HE-AAC, 1.125 bits/audio sample for downsampled HE-AAC and 0.5 bits/audio sample for HE-AAC v2. For example for one channel with a sampling frequency of 48 kHz, the range from 48 kbit/s to 72 kbit/s achieves reasonable audio quality for AAC-LC.

For HE-AAC and HE-AAC v2 the lowest possible audio input sampling frequency is 16 kHz because then the AAC-LC core encoder operates in dual rate mode at its lowest possible sampling frequency, which is 8 kHz. HE-AAC v2 requires stereo input audio data.

Please note that in HE-AAC or HE-AAC v2 mode the encoder supports much higher bitrates than are appropriate for HE-AAC or HE-AAC v2. For example, at a bitrate of more than 64 kbit/s for a stereo audio signal at 44.1 kHz it usually makes sense to use AAC-LC, which will produce better audio quality at that bitrate than HE-AAC or HE-AAC v2.

## 2.12 Recommended Sampling Rate and Bitrate Combinations

The following table provides an overview of recommended encoder configuration parameters which we determined by virtue of numerous listening tests.

### 2.12.1 AAC-LC, HE-AAC, HE-AACv2 in Dualrate SBR mode.

Audio Object Type	Bit Rate Range	Supported	Preferred	No. of
	[bit/s]	Sampling Rates	Sampl.	Chan.
	I	[kHz]	Rate	l
		1	[kHz]	
AAC LC + SBR + PS	+   8000 - 11999	22.05, 24.00	24.00	1 2
AAC LC + SBR + PS	1 12000 - 17999	32.00	32.00	I 2
AAC LC + SBR + PS	18000 - 39999	32.00, 44.10, 48.00	44.10	2
AAC LC + SBR + PS	40000 - 56000	32.00, 44.10, 48.00	48.00	2
AAC LC + SBR	+   8000 - 11999	+   22.05, 24.00	24.00	+   1
AAC LC + SBR	1 12000 - 17999	32.00	32.00	 I 1
AAC LC + SBR	18000 - 39999	32.00, 44.10, 48.00	44.10	I 1
AAC LC + SBR	1 40000 - 56000	32.00, 44.10, 48.00	48.00	1
AAC LC + SBR	16000 - 27999	32.00, 44.10, 48.00	32.00	. 2
AAC LC + SBR	28000 - 63999	32.00, 44.10, 48.00	44.10	. 2
AAC LC + SBR	64000 - 128000	32.00, 44.10, 48.00	48.00	2
AAC LC + SBR	+   64000 - 69999	+   32.00, 44.10, 48.00	32.00	5, 5.1
AAC LC + SBR	70000 - 159999	32.00, 44.10, 48.00		5, 5.1
AAC LC + SBR	160000 - 245999	32.00, 44.10, 48.00	48.00	5
AAC LC + SBR	160000 - 265999	32.00, 44.10, 48.00	48.00	5.1
AAC LC	+   8000 - 15999	+   11.025, 12.00, 16.00	12.00	+ I 1
AAC LC	16000 - 23999	16.00	16.00	1
AAC LC	24000 - 31999	16.00, 22.05, 24.00	24.00	1
AAC LC	32000 - 55999	32.00	32.00	1
AAC LC	56000 - 160000	32.00, 44.10, 48.00	44.10	1
AAC LC	160001 - 288000	48.00	48.00	1
AAC LC	+   16000 - 23999	+   11.025, 12.00, 16.00	12.00	2
AAC LC	24000 - 31999	16.00	16.00	. 2
AAC LC	32000 - 39999	16.00, 22.05, 24.00	22.05	2
AAC LC	40000 - 95999	32.00	32.00	2
AAC LC	96000 - 111999	32.00, 44.10, 48.00	32.00	2
AAC LC	112000 - 320001	32.00, 44.10, 48.00	44.10	2
AAC LC	320002 - 576000	48.00	48.00	2
AAC LC	+   160000 - 239999	32.00	32.00	5, 5.1
AAC LC	240000 - 279999	32.00, 44.10, 48.00	32.00	5, 5.1
AAC LC	280000 - 800000	32.00, 44.10, 48.00	44.10	5, 5.1
AAC LC		32.00, 44.10, 48.00	1 44.10	, D, D.I

## 2.12.2 AAC-LD, AAC-ELD, AAC-ELD with SBR in Dualrate SBR mode.

Audio Object Type	 	Bit Rate Range [bit/s]	Supported Sampling Rates [kHz]	İ	-		No. of Chan.
ELD + SBR ELD + SBR ELD + SBR	-+-         -+-	18000 - 24999 25000 - 31999 32000 - 64000	 32.00 - 44.10 32.00 - 48.00 32.00 - 48.00	-+       	32.00 32.00 48.00	        -+	1 1 1

12 Library Usage

ELD + SBR ELD + SBR	32000 - 51999   52000 - 128000	32.00 - 48.00 32.00 - 48.00	44.10     48.00	2 2
ELD + SBR	72000 - 160000	44.10 - 48.00	48.00	3
ELD + SBR	96000 - 212000	44.10 - 48.00	48.00	4
ELD + SBR	120000 - 246000	44.10 - 48.00	48.00	5
ELD + SBR	120000 - 266000	44.10 - 48.00	48.00	5.1
LD, ELD LD, ELD LD, ELD LD, ELD LD, ELD LD, ELD	16000 - 19999   20000 - 39999   40000 - 49999   50000 - 61999   62000 - 84999   85000 - 192000	16.00 - 24.00 16.00 - 32.00 22.05 - 32.00 24.00 - 44.10 32.00 - 48.00 44.10 - 48.00	16.00   24.00   32.00   32.00   44.10   48.00	1 1 1 1 1 1
LD, ELD LD, ELD LD, ELD LD, ELD	64000 - 75999   76000 - 97999   98000 - 135999   136000 - 384000		32.00   32.00   44.10   48.00	2 2 2 2
LD, ELD LD, ELD LD, ELD	96000 - 113999   114000 - 146999   147000 - 203999   204000 - 576000	24.00 - 32.00 24.00 - 44.10 32.00 - 48.00 44.10 - 48.00	32.00   32.00   44.10   48.00	3 3 3 3
LD, ELD LD, ELD LD, ELD LD, ELD	128000 - 151999   152000 - 195999   196000 - 271999   272000 - 768000	24.00 - 32.00 24.00 - 44.10 32.00 - 48.00 44.10 - 48.00	32.00   32.00   44.10   48.00	4 4 4 4
LD, ELD LD, ELD LD, ELD	160000 - 189999   190000 - 244999   245000 - 339999   340000 - 960000	24.00 - 32.00 24.00 - 44.10 32.00 - 48.00 44.10 - 48.00	32.00   32.00   32.00   44.10   48.00	5 5 5

## 2.12.3 AAC-ELD with SBR in Downsampled SBR mode.

Audio Object Type		Bit Rate Range		Supported	-	Preferred		No. of
		[bit/s]		Sampling Rates		Sampl.		Chan.
				[kHz]	- 1	Rate		
						[kHz]		
	-+-		-+-		-+		-+	
ELD + SBR		18000 - 24999		16.00 - 22.05		22.05		1
(downsampled SBR)		25000 - 35999		22.05 - 32.00		24.00		1
		36000 - 64000		32.00 - 48.00	-	32.00		1

## **Chapter 3**

## **Encoder Behaviour**

#### 3.1 Bandwidth

The FDK AAC encoder usually does not use the full frequency range of the input signal, but restricts the bandwidth according to certain library-internal settings. They can be changed in the table "band-WidthTable" in the file bandwidth.cpp (if available).

The encoder API provides the AACENC\_BANDWIDTH parameter to adjust the bandwidth explicitly.

```
aacEncoder_SetParam(hAacEncoder, AACENC_BANDWIDTH, value);
```

However it is not recommended to change these settings, because they are based on numerious listening tests and careful tweaks to ensure the best overall encoding quality.

Theoretically a signal of for example 48 kHz can contain frequencies up to 24 kHz, but to use this full range in an audio encoder usually does not make sense. Usually the encoder has a very limited amount of bits to spend (typically 128 kbit/s for stereo 48 kHz content) and to allow full range bandwidth would waste a lot of these bits for frequencies the human ear is hardly able to perceive anyway, if at all. Hence it is wise to use the available bits for the really important frequency range and just skip the rest. At lower bitrates (e. g. <= 80 kbit/s for stereo 48 kHz content) the encoder will choose an even smaller bandwidth, because an encoded signal with smaller bandwidth and hence less artifacts sounds better than a signal with higher bandwidth but then more coding artefacts across all frequencies. These artefacts would occur if small bitrates and high bandwidths are chosen because the available bits are just not enough to encode all frequencies well.

Unfortunately some people evaluate encoding quality based on possible bandwidth as well, but it is a two-sided sword considering the trade-off described above.

Another aspect is workload consumption. The higher the allowed bandwidth, the more frequency lines have to be processed, which in turn increases the workload.

#### 3.2 Frame Sizes & Bit Reservoir

For AAC there is a difference between constant bit rate and constant frame length due to the so-called bit reservoir technique, which allows the encoder to use less bits in an AAC frame for those audio signal sections which are easy to encode, and then spend them at a later point in time for more complex audio sections. The extent to which this "bit exchange" is done is limited to allow for reliable and relatively low delay real time streaming. Over a longer period in time the bitrate will be constant in the AAC constant bitrate mode, e.g. for ISDN transmission. This means that in AAC each bitstream frame will in general

14 Encoder Behaviour

have a different length in bytes but over time it will reach the target bitrate. One could also make an MPEG compliant AAC encoder which always produces constant length packages for each AAC frame, but the audio quality would be considerably worse since the bit reservoir technique would have to be switched off completely. A higher bit rate would have to be used to get the same audio quality as with an enabled bit reservoir.

The maximum AAC frame length, regardless of the available bit reservoir, is defined as 6144 bits per channel.

For mp3 by the way, the same bit reservoir technique exists, but there each bit stream frame has a constant length for a given bit rate (ignoring the padding byte). In mp3 there is a so-called "back pointer" which tells the decoder which bits belong to the current mp3 frame - and in general some or many bits have been transmitted in an earlier mp3 frame. Basically this leads to the same "bit exchange between mp3 frames" as in AAC but with virtually constant length frames.

This variable frame length at "constant bit rate" is not something special in this Fraunhofer IIS AAC encoder. AAC has been designed in that way.

#### 3.2.1 Estimating Average Frame Sizes

A HE-AAC v1 or v2 audio frame contains 2048 PCM samples per channel (there is also one mode with 1920 samples per channel but this is only for special purposes such as DAB+ digital radio).

The number of HE-AAC frames N FRAMES per second at 44.1 kHz is:

$$N FRAMES = 44100/2048 = 21.5332$$

At a bit rate of 8 kbps the average number of bits per frame  $N\_BITS\_PER\_FRAME$  is:

$$N \ BITS \ PER \ FRAME = 8000/21.5332 = 371.52$$

which is about 46.44 bytes per encoded frame.

At a bit rate of 32 kbps, which is quite high for single channel HE-AAC v1, it is:

$$N_BITS_PER_FRAME = 32000/21.5332 = 1486$$

which is about 185.76 bytes per encoded frame.

These bits/frame figures are average figures where each AAC frame generally has a different size in bytes. To calculate the same for AAC-LC just use 1024 instead of 2048 PCM samples per frame and channel. For AAC-LD/ELD it is either 480 or 512 PCM samples per frame and channel.

#### 3.3 Encoder Tools

The AAC encoder supports TNS, PNS, MS, Intensity and activates these tools depending on the audio signal and the encoder configuration (i.e. bitrate or AOT). It is not required to configure these tools manually.

PNS improves encoding quality only for certain bitrates. Therefore it makes sense to activate PNS only for these bitrates and save the processing power required for PNS (about 10 % of the encoder) when using other bitrates. This is done automatically inside the encoder library. PNS is disabled inside the encoder library if an MPEG-2 AOT is choosen since PNS is an MPEG-4 AAC feature.

If SBR is activated, the encoder automatically deactivates PNS internally. If TNS is disabled but PNS is allowed, the encoder deactivates PNS calculation internally.

# **Chapter 4**

# **Class Index**

## 4.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

AACENC_BufDesc																						19
AACENC_InArgs .	,																					20
AACENC_InfoStruct	,																					20
AACENC_MetaData	,																					22
AACENC_OutArgs .																						23

16 Class Index

# **Chapter 5**

# **File Index**

5	1	-	Fί	ما	T	ist
. 7			n I	16	•	/151

Here is a list of all files with brief descriptions:	
aacenc_lib.h (FDK AAC Encoder library interface header file )	25

18 File Index

## Chapter 6

## **Class Documentation**

## 6.1 AACENC\_BufDesc Struct Reference

#include <aacenc\_lib.h>

#### **Public Attributes**

- INT numBufs
- void \*\* bufs
- INT \* bufferIdentifiers
- INT \* bufSizes
- INT \* bufElSizes

#### **6.1.1 Detailed Description**

Describes the input and output buffers for an aacEncEncode() call.

#### **6.1.2** Member Data Documentation

#### 6.1.2.1 INT\* AACENC\_BufDesc::bufElSizes

Size of each buffer element in bytes.

#### 6.1.2.2 INT\* AACENC\_BufDesc::bufferIdentifiers

Identifier of each buffer element. See AACENC\_BufferIdentifier.

#### 6.1.2.3 void\*\* AACENC\_BufDesc::bufs

Pointer to vector containing buffer addresses.

20 Class Documentation

#### 6.1.2.4 INT\* AACENC\_BufDesc::bufSizes

Size of each buffer in 8-bit bytes.

#### 6.1.2.5 INT AACENC\_BufDesc::numBufs

Number of buffers.

The documentation for this struct was generated from the following file:

• aacenc\_lib.h

## 6.2 AACENC\_InArgs Struct Reference

#include <aacenc\_lib.h>

#### **Public Attributes**

- INT numInSamples
- INT numAncBytes

#### **6.2.1** Detailed Description

Defines the input arguments for an aacEncEncode() call.

#### **6.2.2** Member Data Documentation

#### 6.2.2.1 INT AACENC\_InArgs::numAncBytes

Number of ancillary data bytes to be encoded.

#### 6.2.2.2 INT AACENC\_InArgs::numInSamples

Number of valid input audio samples (multiple of input channels).

The documentation for this struct was generated from the following file:

• aacenc\_lib.h

## 6.3 AACENC\_InfoStruct Struct Reference

#include <aacenc\_lib.h>

#### **Public Attributes**

- UINT maxOutBufBytes
- UINT maxAncBytes
- UINT inBufFillLevel
- UINT inputChannels
- UINT frameLength
- UINT encoderDelay
- UCHAR confBuf [64]
- UINT confSize

#### **6.3.1** Detailed Description

Provides some info about the encoder configuration.

#### **6.3.2** Member Data Documentation

#### 6.3.2.1 UCHAR AACENC\_InfoStruct::confBuf[64]

Configuration buffer in binary format as an AudioSpecificConfig or StreamMuxConfig according to the selected transport type.

#### 6.3.2.2 UINT AACENC\_InfoStruct::confSize

Number of valid bytes in confBuf.

#### 6.3.2.3 UINT AACENC\_InfoStruct::encoderDelay

Codec delay in PCM samples/channel. Depends on framelength and AOT. Does not include framing delay for filling up encoder PCM input buffer.

#### 6.3.2.4 UINT AACENC\_InfoStruct::frameLength

Amount of input audio samples consumed each frame per channel, depending on audio object type configuration.

#### 6.3.2.5 UINT AACENC\_InfoStruct::inBufFillLevel

Internal input buffer fill level in samples per channel. This parameter will automatically be cleared if samplingrate or channel(Mode/Order) changes.

#### 6.3.2.6 UINT AACENC\_InfoStruct::inputChannels

Number of input channels expected in encoding process.

#### 6.3.2.7 UINT AACENC\_InfoStruct::maxAncBytes

Maximum number of ancillary data bytes which can be inserted into bitstream within one frame.

22 Class Documentation

#### 6.3.2.8 UINT AACENC\_InfoStruct::maxOutBufBytes

Maximum number of encoder bitstream bytes within one frame. Size depends on maximum number of supported channels in encoder instance. For superframing (as used for example in DAB+), size has to be a multiple accordingly.

The documentation for this struct was generated from the following file:

· aacenc\_lib.h

#### 6.4 AACENC MetaData Struct Reference

#include <aacenc\_lib.h>

#### **Public Attributes**

- AACENC\_METADATA\_DRC\_PROFILE drc\_profile
- AACENC\_METADATA\_DRC\_PROFILE comp\_profile
- INT drc\_TargetRefLevel
- INT comp\_TargetRefLevel
- INT prog\_ref\_level\_present
- INT prog\_ref\_level
- UCHAR PCE\_mixdown\_idx\_present
- UCHAR ETSI\_DmxLvl\_present
- SCHAR centerMixLevel
- SCHAR surroundMixLevel
- UCHAR dolbySurroundMode

#### 6.4.1 Detailed Description

Meta Data setup structure.

#### **6.4.2** Member Data Documentation

#### 6.4.2.1 SCHAR AACENC\_MetaData::centerMixLevel

Center downmix level (0...7, according to table)

#### 6.4.2.2 AACENC\_METADATA\_DRC\_PROFILE AACENC\_MetaData::comp\_profile

ETSI heavy compression profile. See AACENC\_METADATA\_DRC\_PROFILE.

#### 6.4.2.3 INT AACENC\_MetaData::comp\_TargetRefLevel

Adjust limiter to avoid overload. Scaled with 16 bit.  $x*2^{16}$ .

#### 6.4.2.4 UCHAR AACENC\_MetaData::dolbySurroundMode

Indication for Dolby Surround Encoding Mode.

- 0: Dolby Surround mode not indicated
- 1: 2-ch audio part is not Dolby surround encoded
- 2: 2-ch audio part is Dolby surround encoded

#### 6.4.2.5 AACENC\_METADATA\_DRC\_PROFILE AACENC\_MetaData::drc\_profile

MPEG DRC compression profile. See AACENC\_METADATA\_DRC\_PROFILE.

#### 6.4.2.6 INT AACENC\_MetaData::drc\_TargetRefLevel

Used to define expected level to: Scaled with 16 bit.  $x*2^{16}$ .

#### 6.4.2.7 UCHAR AACENC\_MetaData::ETSI\_DmxLvl\_present

Flag, if dmx-lvl should be written in ETSI-ancData

#### 6.4.2.8 UCHAR AACENC\_MetaData::PCE\_mixdown\_idx\_present

Flag, if dmx-idx should be written in programme config element

#### 6.4.2.9 INT AACENC\_MetaData::prog\_ref\_level

Programme Reference Level = Dialogue Level: -31.75dB .. 0 dB; stepsize: 0.25dB Scaled with 16 bit.  $x*2^{16}$ .

#### 6.4.2.10 INT AACENC\_MetaData::prog\_ref\_level\_present

Flag, if prog\_ref\_level is present

#### 6.4.2.11 SCHAR AACENC\_MetaData::surroundMixLevel

Surround downmix level (0...7, according to table)

The documentation for this struct was generated from the following file:

• aacenc\_lib.h

## 6.5 AACENC\_OutArgs Struct Reference

#include <aacenc\_lib.h>

24 Class Documentation

#### **Public Attributes**

- INT numOutBytes
- INT numInSamples
- INT numAncBytes

#### 6.5.1 Detailed Description

Defines the output arguments for an aacEncEncode() call.

#### **6.5.2** Member Data Documentation

#### 6.5.2.1 INT AACENC\_OutArgs::numAncBytes

Number of ancillary data bytes consumed by the encoder.

#### 6.5.2.2 INT AACENC\_OutArgs::numInSamples

Number of input audio samples consumed by the encoder.

#### 6.5.2.3 INT AACENC\_OutArgs::numOutBytes

Number of valid bitstream bytes generated during aacEncEncode().

The documentation for this struct was generated from the following file:

• aacenc\_lib.h

## **Chapter 7**


## **File Documentation**

## 7.1 aacenc\_lib.h File Reference

FDK AAC Encoder library interface header file.

```
#include "machine_type.h"
#include "FDK_audio.h"
```

Include dependency graph for aacenc\_lib.h:



#### Classes

- struct AACENC\_InfoStruct
- struct AACENC\_BufDesc
- struct AACENC\_InArgs
- struct AACENC\_OutArgs
- struct AACENC\_MetaData

#### **Typedefs**

• typedef struct AACENCODER \* HANDLE\_AACENCODER

26 File Documentation

#### **Enumerations**

```
enum AACENC_ERROR {
 AACENC_OK = 0x0000,
 AACENC_INVALID_HANDLE = 0x0020,
 AACENC\_MEMORY\_ERROR = 0x0021,
 AACENC_UNSUPPORTED_PARAMETER = 0x0022,
 AACENC_INVALID_CONFIG = 0x0023,
 AACENC_INIT_ERROR = 0x0040,
 AACENC_INIT_AAC_ERROR = 0x0041,
 AACENC_INIT_SBR_ERROR = 0x0042,
 AACENC_INIT_TP_ERROR = 0x0043,
 AACENC_INIT_META_ERROR = 0x0044,
 AACENC\_ENCODE\_ERROR = 0x0060,
 AACENC\_ENCODE\_EOF = 0x0080 }
• enum AACENC_BufferIdentifier {
 IN\_AUDIO\_DATA = 0,
 IN\_ANCILLRY\_DATA = 1,
 IN_METADATA_SETUP = 2,
 OUT BITSTREAM DATA = 3,
 OUT AU SIZES = 4 }
enum AACENC_METADATA_DRC_PROFILE {
 AACENC\_METADATA\_DRC\_NONE = 0,
 AACENC_METADATA_DRC_FILMSTANDARD = 1,
 AACENC\_METADATA\_DRC\_FILMLIGHT = 2,
 AACENC_METADATA_DRC_MUSICSTANDARD = 3,
 AACENC_METADATA_DRC_MUSICLIGHT = 4,
 AACENC METADATA DRC SPEECH = 5 }
• enum AACENC_CTRLFLAGS {
 AACENC_INIT_NONE = 0x0000,
 AACENC_INIT_CONFIG = 0x0001,
 AACENC_INIT_STATES = 0x0002,
 AACENC_INIT_TRANSPORT = 0x1000,
 AACENC_RESET_INBUFFER = 0x2000,
 AACENC_INIT_ALL = 0xFFFF }
enum AACENC_PARAM {
 AACENC AOT = 0x0100,
 AACENC_BITRATE = 0x0101,
 AACENC_BITRATEMODE = 0x0102,
 AACENC SAMPLERATE = 0x0103,
 AACENC\_SBR\_MODE = 0x0104,
 AACENC_GRANULE_LENGTH = 0x0105,
```

```
AACENC_CHANNELMODE = 0x0106,

AACENC_CHANNELORDER = 0x0107,

AACENC_SBR_RATIO = 0x0108,

AACENC_AFTERBURNER = 0x0200,

AACENC_BANDWIDTH = 0x0203,

AACENC_TRANSMUX = 0x0300,

AACENC_HEADER_PERIOD = 0x0301,

AACENC_SIGNALING_MODE = 0x0302,

AACENC_TPSUBFRAMES = 0x0303,

AACENC_PROTECTION = 0x0306,

AACENC_ANCILLARY_BITRATE = 0x0500,

AACENC_METADATA_MODE = 0x0600,

AACENC_CONTROL_STATE = 0xFF00,

AACENC_NONE = 0xFFFF }

AAC encoder setting parameters.
```

#### **Functions**

 AACENC\_ERROR aacEncOpen (HANDLE\_AACENCODER \*phAacEncoder, const UINT enc-Modules, const UINT maxChannels)

Open an instance of the encoder.

\*inargs, AACENC\_OutArgs \*outargs)

Close the encoder instance.

- AACENC\_ERROR aacEncClose (HANDLE\_AACENCODER \*phAacEncoder)
- AACENC\_ERROR aacEncEncode (const HANDLE\_AACENCODER hAacEncoder, const AACENC\_BufDesc \*inBufDesc, const AACENC\_BufDesc \*outBufDesc, const AACENC\_InArgs

Encode audio data.

AACENC\_ERROR aacEncInfo (const HANDLE\_AACENCODER hAacEncoder, AACENC\_InfoStruct \*pInfo)

Acquire info about present encoder instance.

 AACENC\_ERROR aacEncoder\_SetParam (const HANDLE\_AACENCODER hAacEncoder, const AACENC\_PARAM param, const UINT value)

Set one single AAC encoder parameter.

 UINT aacEncoder\_GetParam (const HANDLE\_AACENCODER hAacEncoder, const AACENC\_-PARAM param)

Get one single AAC encoder parameter.

• AACENC\_ERROR aacEncGetLibInfo (LIB\_INFO \*info)

Get information about encoder library build.

28 File Documentation

#### 7.1.1 Detailed Description

FDK AAC Encoder library interface header file.

#### 7.1.2 Typedef Documentation

#### 7.1.2.1 typedef struct AACENCODER\* HANDLE\_AACENCODER

AAC encoder handle.

#### **7.1.3** Enumeration Type Documentation

#### 7.1.3.1 enum AACENC\_BufferIdentifier

AAC encoder buffer descriptors identifier. This identifier are used within buffer descriptors AACENC\_-BufDesc::bufferIdentifiers.

#### **Enumerator:**

IN\_AUDIO\_DATA Audio input buffer, interleaved INT\_PCM samples.

*IN\_ANCILLRY\_DATA* Ancillary data to be embedded into bitstream.

IN\_METADATA\_SETUP Setup structure for embedding meta data.

OUT\_BITSTREAM\_DATA Buffer holds bitstream output data.

**OUT\_AU\_SIZES** Buffer contains sizes of each access unit. This information is necessary for superframing.

#### 7.1.3.2 enum AACENC\_CTRLFLAGS

AAC encoder control flags.

In interaction with the AACENC\_CONTROL\_STATE parameter it is possible to get information about the internal initialization process. It is also possible to overwrite the internal state from extern when necessary.

#### **Enumerator:**

AACENC\_INIT\_NONE Do not trigger initialization.

AACENC\_INIT\_CONFIG Initialize all encoder modules configuration.

AACENC\_INIT\_STATES Reset all encoder modules history buffer.

AACENC\_INIT\_TRANSPORT Initialize transport lib with new parameters.

AACENC\_RESET\_INBUFFER Reset fill level of internal input buffer.

AACENC INIT ALL Initialize all.

#### 7.1.3.3 enum AACENC\_ERROR

AAC encoder error codes.

#### **Enumerator:**

AACENC\_OK No error happened. All fine.

AACENC\_INVALID\_HANDLE Handle passed to function call was invalid.

AACENC\_MEMORY\_ERROR Memory allocation failed.

AACENC UNSUPPORTED PARAMETER Parameter not available.

AACENC\_INVALID\_CONFIG Configuration not provided.

AACENC INIT ERROR General initialization error.

AACENC\_INIT\_AAC\_ERROR AAC library initialization error.

AACENC\_INIT\_SBR\_ERROR SBR library initialization error.

AACENC\_INIT\_TP\_ERROR Transport library initialization error.

AACENC\_INIT\_META\_ERROR Meta data library initialization error.

AACENC\_ENCODE\_ERROR The encoding process was interrupted by an unexpected error.

AACENC\_ENCODE\_EOF End of file reached.

#### 7.1.3.4 enum AACENC\_METADATA\_DRC\_PROFILE

Meta Data Compression Profiles.

#### **Enumerator:**

AACENC\_METADATA\_DRC\_NONE None.

AACENC\_METADATA\_DRC\_FILMSTANDARD Film standard.

AACENC\_METADATA\_DRC\_FILMLIGHT Film light.

AACENC\_METADATA\_DRC\_MUSICSTANDARD Music standard.

AACENC\_METADATA\_DRC\_MUSICLIGHT Music light.

AACENC\_METADATA\_DRC\_SPEECH Speech.

#### 7.1.3.5 enum AACENC\_PARAM

AAC encoder setting parameters.

Use aacEncoder\_SetParam() function to configure, or use aacEncoder\_GetParam() function to read the internal status of the following parameters.

#### **Enumerator:**

AACENC\_AOT Audio object type. See AUDIO\_OBJECT\_TYPE in FDK\_audio.h.

- 2: MPEG-4 AAC Low Complexity.
- 5: MPEG-4 AAC Low Complexity with Spectral Band Replication (HE-AAC).
- 29: MPEG-4 AAC Low Complexity with Spectral Band Replication and Parametric Stereo (HE-AAC v2). This configuration can be used only with stereo input audio data.
- 23: MPEG-4 AAC Low-Delay.
- 39: MPEG-4 AAC Enhanced Low-Delay. Since there is no AUDIO\_OBJECT\_TYPE for ELD in combination with SBR defined, enable SBR explicitly by AACENC\_SBR\_MODE parameter.
- 129: MPEG-2 AAC Low Complexity.
- 132: MPEG-2 AAC Low Complexity with Spectral Band Replication (HE-AAC).
- 156: MPEG-2 AAC Low Complexity with Spectral Band Replication and Parametric Stereo (HE-AAC v2). This configuration can be used only with stereo input audio data.

30 File Documentation

**AACENC\_BITRATE** Total encoder bitrate. This parameter is mandatory and interacts with AACENC BITRATEMODE.

- CBR: Bitrate in bits/second. See Supported Bitrates for details.
- **AACENC\_BITRATEMODE** Bitrate mode. Configuration can be different kind of bitrate configurations:
  - 0: Constant bitrate, use bitrate according to AACENC\_BITRATE. (default) Within none LD/ELD AUDIO\_OBJECT\_TYPE, the CBR mode makes use of full allowed bitreservoir. In contrast, at Low-Delay AUDIO\_OBJECT\_TYPE the bitreservoir is kept very small.
  - 8: LD/ELD full bitreservoir for packet based transmission.
- **AACENC\_SAMPLERATE** Audio input data sampling rate. Encoder supports following sampling rates: 8000, 11025, 12000, 16000, 22050, 24000, 32000, 44100, 48000, 64000, 88200, 96000
- **AACENC\_SBR\_MODE** Configure SBR independently of the chosen Audio Object Type AUDIO\_-OBJECT\_TYPE. This parameter is for ELD audio object type only.
  - -1: Use ELD SBR auto configurator (default).
  - 0: Disable Spectral Band Replication.
  - 1: Enable Spectral Band Replication.
- AACENC\_GRANULE\_LENGTH Core encoder (AAC) audio frame length in samples:
  - 1024: Default configuration.
  - 512: Default LD/ELD configuration.
  - 480: Optional length in LD/ELD configuration.
- AACENC\_CHANNELMODE Set explicit channel mode. Channel mode must match with number of input channels.
  - 1-7 and 33,34: MPEG channel modes supported, see CHANNEL\_MODE in FDK\_audio.h.
- AACENC\_CHANNELORDER Input audio data channel ordering scheme:
  - 0: MPEG channel ordering (e. g. 5.1: C, L, R, SL, SR, LFE). (default)
  - 1: WAVE file format channel ordering (e. g. 5.1: L, R, C, LFE, SL, SR).
- AACENC\_SBR\_RATIO Controls activation of downsampled SBR. With downsampled SBR, the delay will be shorter. On the other hand, for achieving the same quality level, downsampled SBR needs more bits than dual-rate SBR. With downsampled SBR, the AAC encoder will work at the same sampling rate as the SBR encoder (single rate). Downsampled SBR is supported for AAC-ELD and HE-AACv1.
  - 1: Downsampled SBR (default for ELD).
  - 2: Dual-rate SBR (default for HE-AAC).
- AACENC\_AFTERBURNER This parameter controls the use of the afterburner feature. The afterburner is a type of analysis by synthesis algorithm which increases the audio quality but also the required processing power. It is recommended to always activate this if additional memory consumption and processing power consumption is not a problem. If increased MHz and memory consumption are an issue then the MHz and memory cost of this optional module need to be evaluated against the improvement in audio quality on a case by case basis.
  - 0: Disable afterburner (default).
  - 1: Enable afterburner.
- AACENC\_BANDWIDTH Core encoder audio bandwidth:
  - 0: Determine bandwidth internally (default, see chapter Bandwidth).
  - 1 to fs/2: Frequency bandwidth in Hertz. (Experts only, better do not touch this value to avoid degraded audio quality)

AACENC\_TRANSMUX Transport type to be used. See TRANSPORT\_TYPE in FDK\_audio.h. Following types can be configured in encoder library:

- 0: raw access units
- 1: ADIF bitstream format
- 2: ADTS bitstream format
- 6: Audio Mux Elements (LATM) with muxConfigPresent = 1
- 7: Audio Mux Elements (LATM) with muxConfigPresent = 0, out of band StreamMuxConfig
- 10: Audio Sync Stream (LOAS)

**AACENC\_HEADER\_PERIOD** Frame count period for sending in-band configuration buffers within LATM/LOAS transport layer. Additionally this parameter configures the PCE repetition period in raw\_data\_block(). See encPCE.

- 0xFF: auto-mode default 10 for TT\_MP4\_ADTS, TT\_MP4\_LOAS and TT\_MP4\_LATM\_-MCP1, otherwise 0.
- n: Frame count period.

#### AACENC\_SIGNALING\_MODE Signaling mode of the extension AOT:

- 0: Implicit backward compatible signaling (default for non-MPEG-4 based AOT's and for the transport formats ADIF and ADTS)
  - A stream that uses implicit signaling can be decoded by every AAC decoder, even AAC-LC-only decoders
  - An AAC-LC-only decoder will only decode the low-frequency part of the stream, resulting in a band-limited output
  - This method works with all transport formats
  - This method does not work with downsampled SBR
- 1: Explicit backward compatible signaling
  - A stream that uses explicit backward compatible signaling can be decoded by every AAC decoder, even AAC-LC-only decoders
  - An AAC-LC-only decoder will only decode the low-frequency part of the stream, resulting in a band-limited output
  - A decoder not capable of decoding PS will only decode the AAC-LC+SBR part. If the stream contained PS, the result will be a a decoded mono downmix
  - This method does not work with ADIF or ADTS. For LOAS/LATM, it only works with AudioMuxVersion==1
  - This method does work with downsampled SBR
- 2: Explicit hierarchical signaling (default for MPEG-4 based AOT's and for all transport formats excluding ADIF and ADTS)
  - A stream that uses explicit hierarchical signaling can be decoded only by HE-AAC decoders
  - An AAC-LC-only decoder will not decode a stream that uses explicit hierarchical signaling
  - A decoder not capable of decoding PS will not decode the stream at all if it contained PS
  - This method does not work with ADIF or ADTS. It works with LOAS/LATM and the MPEG-4 File format
  - This method does work with downsampled SBR

For making sure that the listener always experiences the best audio quality, explicit hierarchical signaling should be used. This makes sure that only a full HE-AAC-capable decoder will decode those streams. The audio is played at full bandwidth. For best backwards compatibility, it is

File Documentation

recommended to encode with implicit SBR signaling. A decoder capable of AAC-LC only will then only decode the AAC part, which means the decoded audio will sound band-limited.

For MPEG-2 transport types (ADTS,ADIF), only implicit signaling is possible.

For LOAS and LATM, explicit backwards compatible signaling only works together with AudioMuxVersion==1. The reason is that, for explicit backwards compatible signaling, additional information will be appended to the ASC. A decoder that is only capable of decoding AAC-LC will skip this part. Nevertheless, for jumping to the end of the ASC, it needs to know the ASC length. Transmitting the length of the ASC is a feature of AudioMuxVersion==1, it is not possible to transmit the length of the ASC with AudioMuxVersion==0, therefore an AAC-LC-only decoder will not be able to parse a LOAS/LATM stream that was being encoded with AudioMuxVersion==0.

For downsampled SBR, explicit signaling is mandatory. The reason for this is that the extension sampling frequency (which is in case of SBR the sampling frequency of the SBR part) can only be signaled in explicit mode.

For AAC-ELD, the SBR information is transmitted in the ELDSpecific Config, which is part of the AudioSpecificConfig. Therefore, the settings here will have no effect on AAC-ELD.

**AACENC\_TPSUBFRAMES** Number of sub frames in a transport frame for LOAS/LATM or ADTS (default 1).

- ADTS: Maximum number of sub frames restricted to 4.
- LOAS/LATM: Maximum number of sub frames restricted to 2.

#### AACENC\_PROTECTION Configure protection in transsort layer:

- 0: No protection. (default)
- 1: CRC active for ADTS bitstream format.

#### AACENC\_ANCILLARY\_BITRATE Constant ancillary data bitrate in bits/second.

- 0: Either no ancillary data or insert exact number of bytes, denoted via input parameter, numAncBytes in AACENC\_InArgs.
- else: Insert ancillary data with specified bitrate.

#### AACENC METADATA MODE Configure Meta Data. See AACENC MetaData for further details:

- 0: Do not embed any metadata.
- 1: Embed MPEG defined metadata only.
- 2: Embed all metadata.

**AACENC\_CONTROL\_STATE** There is an automatic process which internally reconfigures the encoder instance when a configuration parameter changed or an error occured. This parameter allows overwriting or getting the control status of this process. See AACENC\_CTRLFLAGS.

AACENC\_NONE -----

#### 7.1.4 Function Documentation

#### 7.1.4.1 AACENC\_ERROR aacEncClose ( HANDLE\_AACENCODER \* phAacEncoder )

Close the encoder instance.

Deallocate encoder instance and free whole memory.

#### **Parameters**

*phAacEncoder* Pointer to the encoder handle to be deallocated.

#### Returns

- AACENC\_OK, on success.
- AACENC INVALID HANDLE, on failure.

# 7.1.4.2 AACENC\_ERROR aacEncEncode ( const HANDLE\_AACENCODER hAacEncoder, const AACENC\_BufDesc \* inBufDesc, const AACENC\_BufDesc \* outBufDesc, const AACENC\_InArgs \* inargs, AACENC\_OutArgs \* outargs )

Encode audio data.

This function is mainly for encoding audio data. In addition the function can be used for an encoder (re)configuration process.

- PCM input data will be retrieved from external input buffer until the fill level allows encoding a single frame. This functionality allows an external buffer with reduced size in comparison to the AAC or HE-AAC audio frame length.
- If the value of the input samples argument is zero, just internal reinitialization will be applied if it is requested.
- At the end of a file the flushing process can be triggerd via setting the value of the input samples argument to -1. The encoder delay lines are fully flushed when the encoder returns no valid bitstream data AACENC\_OutArgs::numOutBytes. Furthermore the end of file is signaled by the return value AACENC\_ENCODE\_EOF.
- If an error occured in the previous frame or any of the encoder parameters changed, an internal reinitialization process will be applied before encoding the incoming audio samples.
- The function can also be used for an independent reconfiguration process without encoding. The first parameter has to be a valid encoder handle and all other parameters can be set to NULL.
- If the size of the external bitbuffer in outBufDesc is not sufficient for writing the whole bitstream, an internal error will be the return value and a reconfiguration will be triggered.

#### **Parameters**

hAacEncoder A valid AAC encoder handle.

inBufDesc Input buffer descriptor, see AACENC\_BufDesc:

- At least one input buffer with audio data is expected.
- Optionally a second input buffer with ancillary data can be fed.

outBufDesc Output buffer descriptor, see AACENC\_BufDesc:

• Provide one output buffer for the encoded bitstream.

inargs Input arguments, see AACENC\_InArgs.outargs Output arguments, AACENC\_OutArgs.

#### Returns

- AACENC\_OK, on success.
- AACENC\_INVALID\_HANDLE, AACENC\_ENCODE\_ERROR, on failure in encoding process.
- AACENC\_INVALID\_CONFIG, AACENC\_INIT\_ERROR, AACENC\_INIT\_AAC\_ERROR, AACENC\_INIT\_SBR\_ERROR, AACENC\_INIT\_TP\_ERROR, AACENC\_INIT\_META\_ERROR, on failure in encoder initialization.
- AACENC\_ENCODE\_EOF, when flushing fully concluded.

34 File Documentation

#### 7.1.4.3 AACENC\_ERROR aacEncGetLibInfo ( LIB\_INFO \* info )

Get information about encoder library build.

Fill a given LIB\_INFO structure with library version information.

#### **Parameters**

info Pointer to an allocated LIB INFO struct.

#### Returns

- AACENC OK, on success.
- AACENC\_INVALID\_HANDLE, AACENC\_INIT\_ERROR, on failure.

# 7.1.4.4 AACENC\_ERROR aacEncInfo ( const HANDLE\_AACENCODER hAacEncoder, AACENC\_InfoStruct \* pInfo )

Acquire info about present encoder instance.

This function retrieves information of the encoder configuration. In addition to informative internal states, a configuration data block of the current encoder settings will be returned. The format is either Audio Specific Config in case of Raw Packets transport format or StreamMuxConfig in case of LOAS/LATM transport format. The configuration data block is binary coded as specified in ISO/IEC 14496-3 (MPEG-4 audio), to be used directly for MPEG-4 File Format or RFC3016 or RFC3640 applications.

#### **Parameters**

hAacEncoder A valid AAC encoder handle.pInfo Pointer to AACENC\_InfoStruct. Filled on return.

#### **Returns**

- AACENC\_OK, on succes.
- AACENC\_INIT\_ERROR, on failure.

# 7.1.4.5 UINT aacEncoder\_GetParam ( const HANDLE\_AACENCODER hAacEncoder, const AACENC\_PARAM param )

Get one single AAC encoder parameter.

This function is the complement to aacEncoder\_SetParam(). After encoder reinitialization with user defined settings, the internal status can be obtained of each parameter, specified with AACENC\_PARAM.

#### **Parameters**

hAacEncoder A valid AAC encoder handle.param Parameter to be returned. See AACENC PARAM.

#### Returns

Internal configuration value of specifed parameter AACENC\_PARAM.

# 7.1.4.6 AACENC\_ERROR aacEncoder\_SetParam ( const HANDLE\_AACENCODER hAacEncoder, const AACENC\_PARAM param, const UINT value )

Set one single AAC encoder parameter.

This function allows configuration of all encoder parameters specified in AACENC\_PARAM. Each parameter must be set with a separate function call. An internal validation of the configuration value range will be done and an internal reconfiguration will be signaled. The actual configuration adoption is part of the subsequent aacEncEncode() call.

#### **Parameters**

hAacEncoder A valid AAC encoder handle.param Parameter to be set. See AACENC\_PARAM.value Parameter value. See parameter description in AACENC\_PARAM.

#### Returns

- AACENC\_OK, on success.
- AACENC\_INVALID\_HANDLE, AACENC\_UNSUPPORTED\_PARAMETER, AACENC\_INVALID\_CONFIG, on failure.

# 7.1.4.7 AACENC\_ERROR aacEncOpen ( HANDLE\_AACENCODER \* phAacEncoder, const UINT encModules, const UINT maxChannels )

Open an instance of the encoder.

Allocate memory for an encoder instance with a functional range denoted by the function parameters. Preinitialize encoder instance with default configuration.

#### **Parameters**

phAacEncoder A pointer to an encoder handle. Initialized on return.

encModules Specify encoder modules to be supported in this encoder instance:

- 0x0: Allocate memory for all available encoder modules.
- else: Select memory allocation regarding encoder modules. Following flags are possible and can be combined.
  - 0x01: AAC module.
  - 0x02: SBR module.
  - 0x04: PS module.
  - 0x10: Metadata module.
  - example: (0x01|0x02|0x04|0x10) allocates all modules and is equivalent to default configuration denoted by 0x0.

maxChannels Number of channels to be allocated. This parameter can be used in different ways:

- 0: Allocate maximum number of AAC and SBR channels as supported by the library.
- nChannels: Use same maximum number of channels for allocating memory in AAC and SBR module.
- nChannels | (nSbrCh<<8): Number of SBR channels can be different to AAC channels to save data memory.

#### Returns

• AACENC\_OK, on succes.

File Documentation

• AACENC\_INVALID\_HANDLE, AACENC\_MEMORY\_ERROR, AACENC\_INVALID\_-CONFIG, on failure.

# **Index**

AACENC_AFTERBURNER	aacenc_lib.h, 28
aacenc_lib.h, 30	AACENC_INVALID_CONFIG
AACENC_ANCILLARY_BITRATE	aacenc_lib.h, 29
aacenc_lib.h, 32	AACENC_INVALID_HANDLE
AACENC_AOT	aacenc_lib.h, 28
aacenc_lib.h, 29	aacenc_lib.h
AACENC_BANDWIDTH	AACENC_AFTERBURNER, 30
aacenc_lib.h, 30	AACENC_ANCILLARY_BITRATE, 32
AACENC_BITRATE	AACENC_AOT, 29
aacenc_lib.h, 30	AACENC_BANDWIDTH, 30
AACENC BITRATEMODE	AACENC_BITRATE, 30
aacenc_lib.h, 30	AACENC_BITRATEMODE, 30
AACENC_CHANNELMODE	AACENC_CHANNELMODE, 30
aacenc_lib.h, 30	AACENC_CHANNELORDER, 30
AACENC_CHANNELORDER	AACENC_CONTROL_STATE, 32
aacenc_lib.h, 30	AACENC_ENCODE_EOF, 29
AACENC_CONTROL_STATE	AACENC_ENCODE_ERROR, 29
aacenc_lib.h, 32	AACENC_GRANULE_LENGTH, 30
AACENC_ENCODE_EOF	AACENC_HEADER_PERIOD, 31
aacenc_lib.h, 29	AACENC_INIT_AAC_ERROR, 29
AACENC_ENCODE_ERROR	AACENC_INIT_ALL, 28
aacenc_lib.h, 29	AACENC_INIT_CONFIG, 28
AACENC_GRANULE_LENGTH	AACENC_INIT_ERROR, 29
aacenc_lib.h, 30	AACENC_INIT_META_ERROR, 29
AACENC_HEADER_PERIOD	AACENC_INIT_NONE, 28
aacenc_lib.h, 31	AACENC_INIT_SBR_ERROR, 29
AACENC_INIT_AAC_ERROR	AACENC_INIT_STATES, 28
aacenc_lib.h, 29	AACENC_INIT_TP_ERROR, 29
AACENC_INIT_ALL	AACENC_INIT_TRANSPORT, 28
aacenc_lib.h, 28	AACENC_INVALID_CONFIG, 29
AACENC_INIT_CONFIG	AACENC_INVALID_HANDLE, 28
aacenc_lib.h, 28	AACENC_MEMORY_ERROR, 29
AACENC_INIT_ERROR	AACENC_METADATA_DRC_FILMLIGHT
aacenc_lib.h, 29	29
AACENC_INIT_META_ERROR	AACENC METADATA DRC -
aacenc_lib.h, 29	FILMSTANDARD, 29
AACENC_INIT_NONE	AACENC_METADATA_DRC
aacenc_lib.h, 28	MUSICLIGHT, 29
AACENC_INIT_SBR_ERROR	AACENC_METADATA_DRC
aacenc_lib.h, 29	MUSICSTANDARD, 29
AACENC_INIT_STATES	AACENC_METADATA_DRC_NONE, 29
aacenc_lib.h, 28	AACENC_METADATA_DRC_SPEECH, 29
AACENC_INIT_TP_ERROR	AACENC_METADATA_MODE, 32
aacenc_lib.h, 29	AACENC_NONE, 32
AACENC INIT TRANSPORT	AACENC OK 28

38 INDEX

AACENC PROTECTION, 32	AACENC_BufDesc, 19
AACENC_RESET_INBUFFER, 28	bufElSizes, 19
AACENC_SAMPLERATE, 30	bufferIdentifiers, 19
AACENC_SBR_MODE, 30	bufs, 19
AACENC_SBR_RATIO, 30	bufSizes, 19
AACENC_SIGNALING_MODE, 31	numBufs, 20
AACENC_TPSUBFRAMES, 32	AACENC_BufferIdentifier
AACENC_TRANSMUX, 30	aacenc_lib.h, 28
AACENC_UNSUPPORTED_PARAMETER,	AACENC_CTRLFLAGS
29	aacenc_lib.h, 28
IN_ANCILLRY_DATA, 28	AACENC_ERROR
IN_AUDIO_DATA, 28	aacenc_lib.h, 28
IN_METADATA_SETUP, 28	AACENC_InArgs, 20
OUT_AU_SIZES, 28	numAncBytes, 20
OUT_BITSTREAM_DATA, 28	numInSamples, 20
AACENC_MEMORY_ERROR	AACENC_InfoStruct, 20
aacenc_lib.h, 29	confBuf, 21
AACENC_METADATA_DRC_FILMLIGHT	confSize, 21
aacenc lib.h, 29	encoderDelay, 21
AACENC_METADATA_DRC_FILMSTANDARD	frameLength, 21
	inBufFillLevel, 21
aacenc_lib.h, 29	
AACENC_METADATA_DRC_MUSICLIGHT	inputChannels, 21
aacenc_lib.h, 29	maxAncBytes, 21
AACENC_METADATA_DRC	maxOutBufBytes, 21
MUSICSTANDARD	aacenc_lib.h, 25
aacenc_lib.h, 29	AACENC_BufferIdentifier, 28
AACENC_METADATA_DRC_NONE	AACENC_CTRLFLAGS, 28
aacenc_lib.h, 29	AACENC_ERROR, 28
AACENC_METADATA_DRC_SPEECH	AACENC_METADATA_DRC_PROFILE, 29
aacenc_lib.h, 29	AACENC_PARAM, 29
AACENC_METADATA_MODE	aacEncClose, 32
aacenc_lib.h, 32	aacEncEncode, 33
AACENC_NONE	aacEncGetLibInfo, 33
aacenc_lib.h, 32	aacEncInfo, 34
AACENC_OK	aacEncoder_GetParam, 34
aacenc_lib.h, 28	aacEncoder_SetParam, 34
AACENC_PROTECTION	aacEncOpen, 35
aacenc_lib.h, 32	HANDLE_AACENCODER, 28
AACENC_RESET_INBUFFER	AACENC_MetaData, 22
aacenc_lib.h, 28	centerMixLevel, 22
AACENC_SAMPLERATE	comp_profile, 22
aacenc_lib.h, 30	comp_TargetRefLevel, 22
AACENC_SBR_MODE	dolbySurroundMode, 22
aacenc_lib.h, 30	drc_profile, 23
AACENC_SBR_RATIO	drc_TargetRefLevel, 23
aacenc_lib.h, 30	ETSI_DmxLvl_present, 23
AACENC_SIGNALING_MODE	PCE_mixdown_idx_present, 23
aacenc lib.h, 31	prog ref level, 23
<del>-</del> '	1 2
AACENC_TPSUBFRAMES	prog_ref_level_present, 23
aacenc_lib.h, 32	surroundMixLevel, 23
AACENC_TRANSMUX	AACENC_METADATA_DRC_PROFILE
aacenc_lib.h, 30	aacenc_lib.h, 29
AACENC_UNSUPPORTED_PARAMETER	A A CENIC Out A new 22
aacenc_lib.h, 29	AACENC_OutArgs, 23 numAncBytes, 24

INDEX 39

numInSamples, 24	aacenc_lib.h, 28
numOutBytes, 24	
AACENC_PARAM	IN_ANCILLRY_DATA
aacenc_lib.h, 29	aacenc_lib.h, 28
aacEncClose	IN_AUDIO_DATA
aacenc_lib.h, 32	aacenc_lib.h, 28
aacEncEncode	IN_METADATA_SETUP
aacenc_lib.h, 33	aacenc_lib.h, 28
aacEncGetLibInfo	inBufFillLevel
aacenc_lib.h, 33	AACENC_InfoStruct, 21
aacEncInfo	inputChannels
aacenc_lib.h, 34	AACENC_InfoStruct, 21
aacEncoder_GetParam	711 1021 (0 <u>_</u> 11110811404, <b>2</b> 1
	maxAncBytes
aacenc_lib.h, 34	AACENC_InfoStruct, 21
aacEncoder_SetParam	maxOutBufBytes
aacenc_lib.h, 34	AACENC_InfoStruct, 21
aacEncOpen	7 in iobi (o_imobilact, 21
aacenc_lib.h, 35	numAncBytes
1 CDIC:	AACENC_InArgs, 20
bufElSizes	AACENC_OutArgs, 24
AACENC_BufDesc, 19	numBufs
bufferIdentifiers	AACENC_BufDesc, 20
AACENC_BufDesc, 19	numInSamples
bufs	AACENC_InArgs, 20
AACENC_BufDesc, 19	
bufSizes	AACENC_OutArgs, 24
AACENC_BufDesc, 19	numOutBytes
	AACENC_OutArgs, 24
centerMixLevel	OUT ALL CITES
AACENC_MetaData, 22	OUT_AU_SIZES
comp_profile	aacenc_lib.h, 28
AACENC_MetaData, 22	OUT_BITSTREAM_DATA
comp_TargetRefLevel	aacenc_lib.h, 28
AACENC_MetaData, 22	DCE will be will assessed
confBuf	PCE_mixdown_idx_present
AACENC_InfoStruct, 21	AACENC_MetaData, 23
confSize	prog_ref_level
AACENC_InfoStruct, 21	AACENC_MetaData, 23
	prog_ref_level_present
dolbySurroundMode	AACENC_MetaData, 23
AACENC_MetaData, 22	200
drc_profile	surroundMixLevel
AACENC_MetaData, 23	AACENC_MetaData, 23
drc_TargetRefLevel	
AACENC_MetaData, 23	
THEELITE INCLUDING 25	
encoderDelay	
AACENC_InfoStruct, 21	
ETSI_DmxLvl_present	
AACENC_MetaData, 23	
MACLINC_INICIADAIA, 23	
frameLength	
AACENC_InfoStruct, 21	
MCLINC_IIIIOOUUCI, 21	
HANDLE AACENCODER	