



FOC_Controller




C:\Users\Administrator\Desktop\Simulink\FOC_Controller.slx

FOC_Controller/CurrentControl




C:\Users\Administrator\Desktop\Simulink\FOC_Controller.slx

FOC_Controller/CurrentControl/DQ_Current_Control




C:\Users\Administrator\Desktop\Simulink\FOC_Controller.slx

FOC_Controller/SpeedControl



C:\Users\Administrator\Desktop\Simulink\FOC_Controller.slx

FOC_Controller/PositionControl



FOC_Controller/ModeRegul

