
CpE 690: Introduction to VLSI Design

Lecture 6 CMOS Fabrication and Layout


Bryan Ackland
Department of Electrical and Computer Engineering
Stevens Institute of Technology
Hoboken, NJ 07030

Adapted from Lecture Notes, David Mahoney Harris CMOS VLSI Design




CMOS Wafers

- CMOS transistors are fabricated on silicon wafer
 - mechanical support
 - electrical ground plane
 - epitaxial layer: "single crystal" substrate (< 0.2 defects/cm²)



CMOS Fabrication

- Lithography process similar to printing press
 - glass masks and UV light
- On each step, different materials are deposited or etched according to one of these masks
- As process line width shrinks:
 - smaller transistors & wires
 - faster transistors
 - lower power transistors




Wikipedia

 Easiest to understand by viewing both top and crosssection of wafer in a simplified manufacturing process


CMOS Fabrication

- Typically use p-type substrate for nMOS transistors
- Requires n-well for body of pMOS transistors




Well and Substrate Taps

- Substrate must be tied to GND and n-well to VDD
- Metal to lightly-doped semiconductor forms poor connection called Shottky Diode
- Use heavily doped well & substrate contacts / taps / ties



Inverter Layout


- Transistors and wires are defined by masks
- Cross-section taken along dashed line




Detailed Mask Views

• 6 masks

- n-well
- polysilicon
- n+ diffusion
- p+ diffusion
- contact
- metal






Fabrication Steps

- Start with blank wafer
- Build inverter from the bottom up
- First step will be to form the n-well:
- Cover wafer with protective layer of SiO₂ (oxide)
- Remove layer where n-well should be built
- Implant or diffuse n dopants into exposed wafer
- Strip off SiO₂

p substrate

Oxidation


- Grow SiO₂ on top of Si wafer
- 900 1200 °C with H₂O or O₂ in oxidation furnace



SiO₂


Photoresist

- Spin on photoresist
- Photoresist is a light-sensitive organic polymer
- Softens where exposed to UV light
- Expose photoresist through n-well mask




Lithography

- Strip off exposed photoresist with developer
 - organic solvent
- Leaves exposed SiO₂ in pattern determined by n-well mask
- How do we make 65 nm patterns with UV-light where $\lambda = 193 \ nm$?




Wet Lithography



Wavelength reduced by refractive index of water


Optical Proximity Correction



- Mask pattern is modified to compensate for diffraction effects
- CAD tools have software to generate these patterns
 - typically based on library of pre-computed shapes

Etch

- Etch oxide with hydrofluoric acid (HF)
- Seeps through skin and eats bone; nasty stuff!!!
- Only attacks oxide where resist has been exposed




Strip Photoresist

Strip off remaining photoresist


食人鱼

- Use mixture of acids called piranha etch
 - mixture of H₂SO₄ and H₂O₂
- Necessary so resist doesn't melt in next step



Form n-well

- n-well is formed by counter-doping with arsenic (donor impurity) using diffusion or ion implantation
- Diffusion
 - Place wafer in furnace with arsine
 - AsH₃ lethal at a few ppm really nasty stuff!
 - Heat until As atoms diffuse into exposed Si
- Ion Implanatation
 - Blast wafer with beam of As ions
 - Ions blocked by SiO₂, only enter exposed Si




Strip Oxide

- Strip off the remaining oxide using HF
- Back to bare wafer with n-well
- Subsequent masks involve similar series of steps


n well p substrate

Gate Oxide and Polysilicon

- Deposit very thin layer of gate oxide
 - 40 Å (~13 atomic layers) at 180nm node
 - 20 Å (6-7 atomic layers) at 130nm node
 - 12 Å (4-5 atomic layers) at 65nm node
- Chemical Vapor Deposition (CVD) of silicon layer
 - Place wafer in furnace with Silane gas (SiH₄) pyrophoric
 - Forms many small crystals called polysilicon
 - Heavily doped to be good conductor



Polysilicon Structure



silicon


silicon

19

silicon


Polysilicon

Use same lithography process to pattern polysilicon




N+ Diffusion / Implantation

- Grow another layer of SiO₂
- Will use oxide and masking to expose where n+ dopants should be diffused or implanted
- N-diffusion forms nMOS source/drain, and n-well contact




Self-Aligned Process

- Pattern oxide and form n+ regions
- Self-aligned process where gate blocks diffusion
- Polysilicon is better than metal for self-aligned gates because it doesn't melt during later processing





N+ Diffusion (cont.)


- Historically dopants were diffused
- Usually ion implantation today
- But these n+ regions are still called diffusion



Ion Implantation








- The dominant doping method
- Excellent control of dose (ions/cm²)
- Good control of implant depth with ion energy (KeV to MeV)
- Repairing crystal damage and dopant activation requires annealing, which can cause dopant diffusion and loss of depth control.


N+ Diffusion (cont.)

Strip off oxide to complete patterning step




P+ Diffusion / Implant

- Similar set of steps form p+ diffusion regions for pMOS source and drain and substrate contact
- Boron atoms are implanted in the unmasked silicon




Contacts

- Now we need to wire together the devices
- Cover chip with thick field oxide
- Etch oxide where contact cuts are needed




Tungsten Plugs

- A layer of tungsten is grown over surface
- Etched away to leave only contact holes filled with tungsten
- Tungsten conforms better (than Al) to geometry of small holes




Metallization – Metal 1

- Sputter on aluminum over whole wafer
 - Patterned and plasma etched to remove excess metal, leaving wires
 - Aluminum (metal 1) wires connect (via plugs) to source/drain regions
 - M1 also connects to poly (not shown in this example)




More Tungsten Plugs

- Suppose we want to connect our first layer metal (M1) to a higher metal routing layer (M2)
- Grow another layer of SiO₂ as an insulating dielectric
- Etch VIA holes (VIA1) to connect M2 to M1
- Fill with Tungsten




Second Layer of Metallization – M2

- Pattern and plasma etch second layer of metal (M2)
- M2 connects to M1 through VIA1
- If there is a third layer of metallization, M2 connects to M3 through VIA2 (not shown)
- M2 cannot connect (directly) to poly or diffusion




Contacts & Vias

	Diffusion	Poly Gate	Poly Wire	Metal1	Metal2
Diffusion	√	×	×	contact	×
Poly Gate	×	√	√	×	×
Poly Wire	×	√	✓	contact	×
Metal1	contact	×	contact	√	VIA1
Metal2	×	×	×	VIA1	✓



Higher Metallization Layers

- Need at least 3-4 layers of metal to support dense custom (hand-drawn) layout.
- Automatic place & route tools rely on multiple metal layers to create dense designs with good power & clock distribution and minimum parasitics.
- Modern processes have 5-10 layers of metal
 - upper layers often Cu (rather than Al_)
 - each layer requires via and a metal pattern mask




cross-section showing 11 metallization layers (Courtesy IBM)

Mask vs. Layout


- Chips are built with set of masks
- Layout designers job is to define patterns for each mask
- Layout is specified using a number of "layers"
 - Layout layers are mapped to mask levels
- Some layers correspond directly to specific masks
 - e.g. poly, metal1, contact
- Other layers might be combined to create a mask
 - e.g. $(diff_{layout} AND nplus_{layout}) \Rightarrow NDIFF_{mask}$
 - $(diff_{layout} AND pplus_{layout}) \Rightarrow PDIFF_{mask}$
- Other layers may be added to assist CAD tools
 - e.g. designating ndiff wire as diffusion resistor

Mask to Layout



Process Limitations and Design Rules


- Would like to make objects (transistors, wires etc.) as small as possible
 - to increase speed, decrease cost & power
- Object size and spacing is limited by precision of photolithography & manufacturing process




- Need "Design Rules" to constrain layout engineer
 - ensure design is manufacturable

Layout & Design Rules

 Design Rules set minimum size and spacing for each layer to give acceptable yield (e.g. M1 min width = 230nm)




 Design Rules also specify spacing between objects on different layers (e.g. min distance of contact from gate = 200nm)



- Design Rules typically expressed in μm or nm.
- Each CMOS process typically characterized by feature size f = minimum distance between source and drain
- Set by minimum width of polysilicon (e.g. 180nm)
- Feature size improves 30% every 3 years or so

λ based Design Rules


- We can simplify design by adopting a conservative set of rules normalized to minimum feature size f
- Express rules in terms of $\lambda = f/2$
 - e.g. for 180nm process, $\lambda = 90$ nm
- For example MOSIS SCMOS rules:




 Layout can be scaled to new process by simply changing value of λ

Simplified Design Rules: Conductors

A simpler (more conservative) set to get you started:




Contact Design Rules



Contact Spacing Rule (for all 3 types)

Via Design Rules




Via Spacing Rule

41

Simplified Design Rules (cont.)

Creating NMOS devices:




• This produces minimum size device: $W = 4\lambda$, $L=2\lambda$

Simplified Design Rules (cont.)


PMOS device created in same way:


- PMOS device often wider to match drive strength of NMOS: (W = 8λ, L = 2λ)
- PMOS device surrounded by nwell (at least 6 λ)
- NMOS device must be separated from nwell by at least 6λ



Gate Layout


- Layout can be very time consuming
 - can waste a lot of time trying to squeeze last micron out
- Layout more efficient if we design gates to fit together nicely
- Build a library of standard cells






Standard Cell Design Methodology

- VDD and GND run horizontally & should abut
 - standard height cell
- nMOS horizontally at bottom and pMOS at top
- Polysilicon runs vertically to connect transistor gates
- All gates include well and substrate contacts
- Adjacent gates should satisfy design rules
 - extend VDD and GND rails by 2λ
- Layout can be built on 8λ x 8λ grid with metal1 wiring tracks between nMOS and pMOS devices.




Wiring tracks

- A wiring track is the space required for a wire
- 4 λ width, 4 λ spacing from neighbor = 8 λ pitch
- Transistors also consume one wiring track




Well Spacing


- Wells must surround transistors by 6 λ
- Implies 12 λ between opposite transistor flavors
- Leaves room for one wire track



Building Gates: Transistors in Series


 Transistors can be placed in series by simply overlaying their common source/drain region







Building Gates: Transistors in Parallel

 Transistors can be placed in parallel by using a combination of source/drain overlap and metal interconnect





Example: NAND3




Try to find placement of transistors that maximizes use of common vertical polysilicon and common source/drain overlap

Estimate area by counting wiring tracks

Area of this Nand3 is: $40\lambda \times 32\lambda = 1280 \lambda^2$


Stick Diagrams


- Stick diagrams help plan layout quickly
- Need not be to scale
- As drawn in textbook (Weste & Harris)



Stick Diagrams

• Or with color pencils or markers:






Example: O3AI


Sketch a stick diagram for O3AI and estimate area.

$$Y = \overline{(A + B + C) \cdot D}$$


Example: XOR gate

•
$$Y = A xor B = A.\overline{B} + \overline{A}.B = \overline{A.B + \overline{A}.\overline{B}}$$






XOR gate layout with M1




XOR gate layout with M1 & M2



Transistor Sizing

- In most layouts, transistors are not all of same size
 - pMOS has about ½ drive of same size nMOS
 - series/parallel combinations lead to different drive strength
- Transistor dimensions specified as Width / Length
- Minimum size is $4\lambda / 2\lambda$, sometimes called 1 unit
 - e.g. in f = 0.5 μ m process, this is 1.0 μ m wide, 0.5 μ m long



Impact of Sizing on Layout

- Adding sized transistors complicates simple 8λ x 8λ grid
- Still useful for draft layout and approximate area calculations
- When estimating area, add (w-1).4λ in height to accommodate a transistor of width w.
- Add extra contacts when possible
 - Improved contact resistance
 - Improves yield
 - Many designers will use two-contact transistor as "minimum width" device

