

▼Request from GROUND prior to Taxi and APVD by TWR prior to TAKEOFF

- 1. Used for RWY 03 departures regardless of active runway to expedite the departure movement.
- ATC may initiate to apply Simultaneous Opposite Direction Operations (SODO) when filed on FYTTR TWO or DREAM THREE and arrivals are landing RWY21.
- 3. ATC/aircrew may initiate to provide quick turn out to FYTTR TWO when departing RWY 03.
- 4. Prodcedure is VFR to IFR. During VFR portion aircrews are responsible for terrain clearance. CLASS B VFR separation services will be provided as appropriate.

FYTTR TWO:

- 1. Remain below 3000' MSL until north of Race Track and turned westbound
- 2. Turn left within 4NM of Nellis direct FLEX.
- 3. Fly north of FLEX at or below 4000'MSL and then heading 270°.
- 4. Intercept the LSV 15DME arc at or below 8000' MSL and arc south.
- Intercept the LSV R-270/15 at or above 10.000' MSL and track outbound.
 Aircrews are VFR until intercepting the LSV R-270 at or above 10.200' MSL.

DREAM THREE:

- 1. Remain below 3000' MSL until north of Race Track
- 2. Fly north of FLEX at or below 4000 MSL and then heading 320°.
- 3. Intercept the LSV R-349 (Ch 116) and comply with DREAM THREE restrictions. Aircrews are VFR until crossing the LSV R-349/20 at or above 10.200' MSL
- 4. If unable to comply with restrictions, maintain VFR and advise approach.
- All FLEX Turnouts to the DREAM THREE will comply with RWY 21 DREAM THREE (intercept LAS R-349) outbound) regardless of active rundway.

FLEX TURNOUT 03 DEPARTURE AND TRANSITIONS