
OpenCellular Battery Rework

- We are swapping the current PHR-3 connector on the battery with the 455-2745-ND connector.
- Place the 455-2745-ND connector such that small window faces upwards. Place the battery such that the cables are away from the table, and the orientation of the cables are top to bottom: Black, Yellow and Red.



3. This arrangement of the cables corresponds to how they will be attached to the 455-2745-ND connector.



- 4. Solder the cables to the connector such that top to bottom: Black, Yellow and Red.
- 5. Use electrical tape on each of wires after soldering it.
- 6. Use electrical tape to secure all the wires after. See soldered cable sent to Sanmina via Suresh for example.

Test

- 1. Use a Voltmeter to test the pins corresponding to the Black wire and Red wire.
- 2. The reading should show something around the 11V area.